


SHARP SERVICE MANUAL

CODE: 00ZARC260MA2E



(AR-C260, AR-C260M)

DIGITAL FULL COLOR COPIER/PRINTER/ MULTIFUNCTIONAL SYSTEM

AR-C260
MODEL AR-C260M

CONTENTS

| | |
|--|------|
| [1] OUTLINE | 1-1 |
| [2] CONFIGURATION | 2-1 |
| [3] SPECIFICATIONS | 3-1 |
| [4] CONSUMABLE PARTS | 4-1 |
| [5] UNPACKING AND INSTALLATION | 5-1 |
| [6] EXTERNAL VIEW AND INTERNAL STRUCTURE | 6-1 |
| [7] DESCRIPTIONS OF EACH SECTION | 7-1 |
| [8] SETTING AND ADJUSTMENTS | 8-1 |
| [9] SIMULATION | 9-1 |
| [10] MAINTENANCE LIST | 10-1 |
| [11] TROUBLESHOOTING | 11-1 |
| [12] ROM VERSION UP | 12-1 |
| [13] ELECTRIC DIAGRAM | 13-1 |
| [14] OTHERS | 14-1 |

Parts marked with “ \triangle ” are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used
for after sales service only.
The contents are subject to change without notice.

CONTENTS

| | | |
|--|-------|--|
| [1] OUTLINE | | |
| 1. Product features | 1-1 | |
| 2. Newly employed technology | 1-1 | |
| [2] CONFIGURATION | | |
| 1. Product Line and options | 2-1 | |
| A. Line of machines | 2-1 | |
| B. Line of options | 2-1 | |
| C. Combination of options | 2-2 | |
| 2. Block diagram | 2-2 | |
| [3] SPECIFICATIONS | | |
| 1. Basic specifications | 3-1 | |
| A. Base engine | 3-1 | |
| B. Paper feed unit | 3-2 | |
| C. Paper exit unit | 3-2 | |
| D. Scanner section | 3-2 | |
| 2. Functional specifications | 3-3 | |
| A. Specifications of copy functions | 3-3 | |
| 3. Environment conditions | 3-5 | |
| A. Operating environment conditions | 3-5 | |
| B. Storage environment conditions | 3-5 | |
| C. Transit environment conditions | 3-6 | |
| D. Standard temperature and humidity | 3-6 | |
| [4] CONSUMABLE PARTS | | |
| 1. Supply system table | 4-1 | |
| 2. Consumables (kit, unit) | 4-2 | |
| 3. Photoconductor, developer, toner | 4-3 | |
| [5] UNPACKING AND INSTALLATION | | |
| 1. Installing (use) conditions | 5-1 | |
| 2. Transit and delivery | 5-2 | |
| 3. Unpacking | 5-2 | |
| 4. Lock release | 5-3 | |
| 5. Fusing heat roller pressing (F/R) | 5-4 | |
| 6. Black drum cartridge insertion | 5-5 | |
| 7. Paper exit tray installation | 5-5 | |
| 8. Toner cartridges installation | 5-5 | |
| 9. AC cord connection | 5-6 | |
| 10. Machine power ON | 5-6 | |
| 11. Specifications setup | 5-6 | |
| 12. Image quality check | 5-6 | |
| 13. Function and operation check | 5-6 | |
| 14. Setup and adjustment data recording | 5-7 | |
| 15. Necessary works before moving the machine | 5-7 | |
| [6] EXTERNAL VIEW AND INTERNAL STRUCTURE | | |
| 1. Name and function of each section | 6-1 | |
| A. External view | 6-1 | |
| B. Internal structure | 6-2 | |
| C. Operation panel | 6-3 | |
| D. Job status display | 6-4 | |
| E. Cross section | 6-5 | |
| F. Motors, clutches, solenoids, fans | 6-7 | |
| G. Sensors, switches and heaters | 6-8 | |
| H. PWB 1 | 6-9 | |
| H. PWB 2 | 6-10 | |
| [7] DESCRIPTIONS OF EACH SECTION | | |
| 1. Fusing section | 7-1 | |
| A. Operational descriptions | 7-1 | |
| B. Disassembly/Assembly/Maintenance | 7-3 | |
| 2. Transfer section | 7-7 | |
| A. Operational descriptions | 7-7 | |
| B. Disassembly/assembly/maintenance | 7-10 | |
| 3. Process (image forming) section | 7-15 | |
| A. Operational descriptions | 7-15 | |
| B. Disassembly/assembly/maintenance | 7-19 | |
| 4. Optical section (Scanner section) | 7-22 | |
| A. Operational descriptions | 7-22 | |
| B. Disassembly/assembly/maintenance | 7-25 | |
| 5. Paper feed, paper transport, and paper exit sections | 7-27 | |
| A. Operational descriptions | 7-27 | |
| B. Disassembly/assembly/maintenance | 7-33 | |
| 6. Operation panel | 7-40 | |
| A. Operational descriptions | 7-40 | |
| B. Disassembly/assembly/maintenance | 7-41 | |
| 7. External fitting | 7-42 | |
| A. Disassembly | 7-42 | |
| 8. Others | 7-44 | |
| A. Disassembly/assembly/maintenance | 7-44 | |
| [8] SETTING AND ADJUSTMENTS | | |
| [ADJ 1] High voltage adjustment | 8-2 | |
| [ADJ 2] Image density sensor adjustment | 8-4 | |
| [ADJ 3] Image focus, image skew adjustment (LED (writing) unit) | 8-6 | |
| [ADJ 4] Image registration adjustment | 8-9 | |
| [ADJ 5] Image position/print area adjustment (Print engine section) | 8-15 | |
| [ADJ 6] Copy image distortion adjustment | 8-16 | |
| [ADJ 7] Copy image focus (main scanning direction copy magnification ratio) adjustment (CCD unit position adjustment) | 8-19 | |
| [ADJ 8] Sub scanning direction copy magnification ratio adjustment | 8-20 | |
| [ADJ 9] Main scanning direction copy image position adjustment (Scanner (reading) section) | 8-20 | |
| [ADJ 10] Copy image position/image loss/void area adjustment | 8-21 | |
| [ADJ 11] Copy color balance/density adjustment | 8-22 | |
| [ADJ 12] Fusing pressure adjustment | 8-36 | |
| [ADJ 13] Fusing paper guide position adjustment | 8-36 | |
| [ADJ 14] Document size sensor adjustment | 8-37 | |
| [ADJ 15] Manual paper feed tray paper size sensor adjustment | 8-37 | |
| [ADJ 16] Touch panel coordinates setting | 8-38 | |
| [ADJ 17] Power voltage adjustment | 8-38 | |
| [ADJ 18] FAX/scanner mode image loss adjustment | 8-38 | |
| [9] SIMULATION | | |
| 1. Outline and purpose | 9-1 | |
| 2. Code-type simulation | 9-1 | |
| A. Operating procedures and operations | 9-1 | |
| B. Simulation list | 9-3 | |
| C. Details | 9-13 | |
| [10] MAINTENANCE LIST | | |
| 1. Maintenance system table | 10-1 | |
| 2. List | 10-2 | |
| A. Drum peripheral section | 10-2 | |
| B. Developing section | 10-2 | |
| C. Transfer section | 10-3 | |
| D. Fusing section | 10-4 | |
| E. Optical section (Scanner section) | 10-5 | |
| F. Paper feed section, transport section | 10-6 | |
| G. LED | 10-6 | |
| H. Filters, drive section, others | 10-7 | |
| [11] TROUBLESHOOTING | | |
| 1. Outline | 11-1 | |
| 2. Functions and purposes | 11-1 | |
| 3. Kinds of self diagnostic messages | 11-1 | |
| 4. Self diagnostic operation | 11-1 | |
| A. Self diagnostic operation and work flow | 11-1 | |
| 5. List | 11-2 | |
| 6. Details | 11-3 | |
| [12] ROM VERSION UP | | |
| 1. Outline | 12-1 | |
| A. Target ROM for version up | 12-1 | |
| B. When version up of ROM is required | 12-1 | |
| C. Flash ROM version up method | 12-2 | |
| 2. Precautions | 12-4 | |
| A. Relationship between each ROM and version up | 12-4 | |
| 3. Necessary items for version up (copy) of Flash ROM | 12-5 | |
| 4. Flash ROM version up procedure | 12-6 | |
| A. By using a computer and the ICU PWB, the program data of Flash ROM is written from the computer to the Flash ROM of the ICU PWB | 12-6 | |
| B. Method using two Flash ROM sockets on the ICU MAIN PWB to copy between Flash ROM's | 12-9 | |
| [13] ELECTRIC DIAGRAM | | |
| 1. Block diagram | 13-1 | |
| 2. AC power line diagram | 13-5 | |
| 3. DC power line diagram | 13-7 | |
| 4. ACTUAL WIRING CHART | 13-8 | |
| 5. Signal list | 13-26 | |
| [14] OTHERS | | |
| 1. Key operator program | 14-1 | |
| A. Classification of set items | 14-1 | |
| 2. Special tools | 14-2 | |

[1] OUTLINE

1. Product features

| No. | Feature | Content | Employed technology |
|-----|--|--|---|
| 1 | Compact, lightweight, A3 tandem engine | AR-C260: 670 x 676 x 709 mm (26.4 x 26.6 x 27.9 inch), about 67kg (about 148 lbs.) (Include OC) AR-C260M: 670 x 676 x 709mm (26.4 x 26.6 x 27.9 inch), about 69kg (about 152 lbs.) (Include OC) | Mono-component wax-free toner, LED printhead |
| | High speed output | Color: 26PPM B/W: 33PPM (A4) / 32PPM (LT) | |
| 2 | High-speed, first color copy | Color: 8.0sec (A4/LT, without pre-scan, side paper exit) B/W: 7.0sec | LED printhead |
| 3 | Automatic recognition of document kind | The document kind is automatically recognized from the document components by pre-scanning. (Photo, Print, Text, Photo/Text, and Print/Text are supported.) | Sharp's unique technology of automatic recognition of document kind, image process technology |
| 4 | Manual paper feed capacity | 300 sheets/64g (17 lbs.) | Development of a large capacity manual feed tray |
| | Heavy paper support | 64 to 300g/m ² (17 to 80 lbs.) | Oil-less fusing unit, paper feed/paper transport technology |
| | Heavy paper duplex feed support | 64 to 200g/m ² (17 to 53 lbs.) | |
| 5 | Improved user maintenance | Paper jam process: 2 positions of open/close (sides) | Paper jam control technology |
| | | Toner supply: Cartridge replacement | Mono-component wax-free toner |
| 6 | Improved service maintenance | Developing section: Mono-component development eliminates the need for developer replacement. | Mono-component wax-free toner |
| | | Drum section: Cartridge replacement | Designed for easy maintenance |
| | | Fusing section: Simplified structure by wax-free. The unit can be disassembled simply by releasing the lock with the knob. | Mono-component wax-free toner. Designed for easy maintenance |
| | | Transfer section: One-touch extraction. Designed for easy belt replacement. | Designed for easy maintenance |
| | | Color resist automatic adjustment: Visual judgment by paper exit is automatically performed. | Process control technology, which allows user adjustment. |


2. Newly employed technology

| | Item | Content | Remark |
|---|---------------------------------|---|---|
| 1 | LED printhead employed | <ul style="list-style-type: none"> • Employment of the 4bit LED provides 16-gradation expressions for each of YMCK. • Free from mechanical noises which are produced from the unit such as an LSU. Printing is started immediately without waiting for stabilization of the polygon motor speed. • Lower power consumption than an LSU | Resolution: 600dpi (Total dots: 7,424 dots) |
| 2 | Oil-less fusing system employed | <ul style="list-style-type: none"> • Development of a new wax-free toner • The wax-free fusing system provides a simplified structure and improved paper feed capability. • Notes and remarks can be put on a copy image similar to normal page. | |







[2] CONFIGURATION

1. Product Line and options

A. Line of machines

| Model name | Composition |
|---|----------------------------|
| AR-C260/260M | Copier model/Printer model |
|  <p>AR-C260/260M</p> | |

B. Line of options

| | | |
|---|---|---|
|  |  |  |
| AR-RF3/Reversing automatic document feeder | AR-D18/Paper feed module (3-stage paper feed desk) AR-D17/Paper feed module (1-stage paper feed desk) (Outside Japan only) | AR-RB1/Duplex pass + Reverse unit (Requires (AR-D19).) |
|  |  |  |
| AR-D19/Duplex module + Paper feed module (2-stage) (Requires (AR-RB1).) | AR-F13/Saddle stitch finisher (Requires (AR-RB1).) | AR-P16/Printer controller (for AR-C260) |

Line of other options

| | Model | Name | Necessary option | Support model |
|-------------------|-------------|--|-------------------------------|---------------|
| Paper exit system | AR-PN1A | Punch unit (2-hole) | AR-F13/Saddle stitch finisher | |
| | AR-PN1BA | Punch unit (3-hole) (Outside Japan only) | | |
| | AR-SC2 | Staple cartridge | | |
| Printer system | AR-NC5J | Print server card (NIC) | AR-P16/Printer controller | AR-C260 |
| | AR-HD4 | HDD | | |
| | AR-NS2 | Network scanner expansion kit | | |
| | AR-U11, U15 | Sharp desk license kit | | |
| Other | AR-VR4 | Original cover (Except Asia only) | | |
| | AR-TE3 | Paper exit tray (Except Asia only) | | |

C. Combination of options

| | Option name | Necessary option | Installing condition | Remark |
|-------------------|---------------------|--------------------------------|--|---|
| Paper feed system | AR-D17 | 1-stage paper feed desk | — | Cannot use the 3-stage paper feed desk. |
| | AR-D18 | 3-stage paper feed desk | — | Cannot use the 1-stage paper feed desk. |
| | AR-D19 | 2-stage duplex paper feed desk | Reverse bypass module (AR-RB1) | — |
| | AR-RB1 | Reverse bypass module | Desk (AR-D19 only) | — |
| | AR-LC5 | Large capacity tray | Desk (Either of AR-D17/D18/D19) | — |
| Paper exit system | AR-F13 | Saddle finisher | Desk (AR-D19) and Reverse bypass module (AR-RB1) | Cannot use the sorter. |
| | AR-PN1A AR-PN1BA | Punch unit | Saddle finisher (AR-F13) | — |
| | AR-S11 | Sorter | Desk (AR-D19) and Reverse bypass module (AR-RB1) | Cannot use the saddle finisher. |
| Electrical system | AR-NC5J | NIC | Printer controller (AR-P16) | — |
| | AR-HD4 | HDD 3.5 inch (40GB) | Printer controller (AR-P16) | — |
| | | 128MB expansion memory | — | — |
| | | 256MB expansion memory | — | — |
| | AR-NS2 | Network scanner expansion kit | Printer controller (AR-P16) | The MFP model has the printer controller installed. |


• Expansion memory

| Manufacture | Capacity | DIMM model number |
|------------------------|----------|-------------------|
| Kingston Technology | 128MB | KVR133X64C3/128 |
| | 256MB | KVR 1 33X64C3-256 |
| Simple Technology | 128MB | RB 168S64-128A |
| | 256MB | RB 168S64-256A |
| Viking Compnehts | 128MB | VIK6642CL2 |
| | 256MB | VIK2642CL2 |
| Memory Card Technology | 128MB | DM1665VS65804X-7G |

The following combinations are also inhibited.

- OC cover and Duplex automatic document feeder
- Paper feed module (1-stage desk)/Paper feed module (3-stage desk)/Reverse bypass module + Paper feed module (2-stage) (Only one of them can be installed.)

2. Block diagram



[3] SPECIFICATIONS

1. Basic specifications

A. Base engine

(1) Type

| | |
|------|----------|
| Type | Desk-top |
|------|----------|

(2) Engine speed

| Paper size | Color | | B/W | |
|----------------|---|--------|--|--------|
| | Print B/W 4bit mode (Image quality priority mode) | Copy | Print B/W 1bit mode only (Speed priority mode) | Copy |
| A4 | 26 ppm | 26 cpm | 33 ppm | 33 cpm |
| 8.5" x 11" | 26 ppm | 26 cpm | 32 ppm | 32 cpm |
| A5/8.5" x 5.5" | 26 ppm | 26 cpm | 33 ppm | 33 cpm |
| B5 | 26 ppm | 26 cpm | 33 ppm | 33 cpm |
| B4/8.5" x 14" | 15 ppm | 15 cpm | 17 ppm | 17 cpm |
| A3/11" x 17" | 13 ppm | 13 cpm | 15 ppm | 15 cpm |

(3) Engine composition

| | |
|---------------------|---|
| Photoconductor kind | OPC (Drum diameter: ϕ 30mm x 4) |
| Recording system | Electronic photo system (LED head system) |
| Developing system | Contact, non-magnetic 1-component development |
| Charging system | Saw teeth scorotron corona charging |
| Transfer system | Transfer belt structure direct transfer system |
| Cleaning system | Counter blade cleaning system |
| Fusing system | Pressure roller fusing system |
| Oil supply | Oil-less system |
| Waste toner process | Self collection of each toner cartridge Waste toner box collection for transfer belt |
| Shifter | Standard |

(4) Shifter

| | | | | |
|---|---|---|---------------|---|
| Type | Shifter | | | |
| Paper weight | 64 to 105g/m ² , 106 to 200g/m ² | | | |
| Paper size | Non offset mode (Simple load) 64 to 200g/m ² | A3W to A5, Postcard, 12" x 18" to 8.5" x 5.5" | | |
| | Offset mode 64 to 200g/m ² | A3 to A5 11" x 17" to 8.5" x 5.5" | | |
| Productivity | Non offset mode: Color 26 sheets, B/W 32 sheets (LT)/33 sheets (A4) Offset mode: Color/B/W 24 sheets | | | |
| Offset width | 30mm | | | |
| Alignment | | Extending | FR shift | Between jobs |
| | Non offset mode | Must not fall from the tray. | — | — |
| | Offset mode | Within 50mm | Within ± 10mm | 1 – 150 sheets: 10mm or more 151 sheets or more: 5mm or more |
| * When A4/Letter recommended paper is used. | | | | |

(5) Engine resolution

| | | |
|------------|--------------------------|--|
| Resolution | Writing: 600dpi x 600dpi | |
| Smoothing | None | |
| Gradation | Color | Writing: 1 pixel 16 gradations for each color * |
| | B/W | Writing: 1 pixel 2 gradations (1bit) 16 gradations (4bit) |

* Dither matrix allows printing in 1-pixel, 256-gradation (8bit).

(6) Warm-up

| | |
|-------------------|-------|
| Warm-up time | 99sec |
| Pre-heat function | Yes |

(7) Jam recovery time

| | | |
|--------------------------------------|-------------|------------------------------------|
| With the left cover open | About 60sec | 60sec left standard condition open |
| With the right and front covers open | About 8sec | |

(8) Image chip (Printable area)

| | |
|-----------|--|
| Full size | Total circumference 4mm \pm 2mm Only when A3 full image is outputted, 6mm or less in total. CHP1 mode: 10mm or less at lead/rear edges |
|-----------|--|

(9) Power source

| | |
|------------|-------------|
| Voltage | 100V / 120V |
| Frequency | 50/60Hz |
| Power cord | Inlet type |

(10) Power consumption

| | |
|-------------------------------|--------------|
| Max. power consumption | 1450W |
| Stand-by (average) | 180W |
| Low power mode | 90Wh |
| Sleep mode | 15Wh or less |
| Energy consumption efficiency | 257Wh/h |

(11) Noise/Ozone

| | | | |
|-------|-----------|-------|------------------------------|
| Noise | Operating | B/W | 68dB or less |
| | | Color | 63dB or less |
| | Stand-by | | 55dB or less |
| | Sleep | | 40dB or less |
| Ozone | | | 0.02g/m ³ or less |

(12) External dimensions

| | Copier (without desk) | Copier (with 3-stage desk) |
|-------------------------|--|---|
| Floor to Glass surface | 670 x 676 x 655mm (26.4 x 26.6 x 25.8 inch) | 670 x 676 x 1049mm (26.4 x 26.6 x 41.3 inch) |
| Floor to OC top surface | 670 x 676 x 709mm (26.4 x 26.6 x 27.9 inch) | 670 x 676 x 1104mm (26.4 x 26.6 x 43.5 inch) |

(13) Weight

| Toner cartridge | Copier (without desk) | Copier (with 3-stage desk) |
|-----------------|--------------------------------|-----------------------------------|
| Not installed | About 85kg (About 187 lbs.) | About 114.5kg (About 252 lbs.) |
| Installed | About 95kg (About 209 lbs.) | About 124.5kg (About 274 lbs.) |

(14) Machine occupying dimensions

| | |
|---|-----------------------------------|
| Machine occupying dimensions (Machine only, with the trays full open) | 994 x 676mm (39.1 x 26.6 inch) |
|---|-----------------------------------|

B. Paper feed unit

(1) Machine paper feed tray

| | |
|---|---|
| Paper feed system | 1-stage tray |
| Paper feed size | AB series: A3, B4, A4, A4R, B5, B5R, A5, Special paper Inch series: 11" x 17", 8.5" x 14", 8.5" x 13", 8.5" x 11", 8.5" x 11"R, 8.5" x 5.5", A4, EXTRA |
| Paper feed capacity | 550 sheets (64g/m ² (17 lbs.) paper) 500 sheets (80g/m ² (21 lbs.) paper, recommended paper for color) |
| Weight of paper suitable for paper feed | 64 to 105g/m ² (17 to 28 lbs) |
| Paper kind | Normal paper (including recommended paper for color), recycled paper, printed paper, punched paper, color paper, letter head |
| Paper size detection | Slide lever detection |
| Paper size selection | Use selection (Special paper size is inputted from the operation panel.) |
| Heater | Yes (Japan Only) |
| Remaining quantity detection | Yes (0, 25%, 50%, 75%, Full, 5 steps) |
| Initial size when shipping | A3 (11" x 17") |
| Tray attach/detach | Possible |
| Universal support | Universal tray (free size) |

(2) Manual feed tray (Bypass tray)

| | |
|------------------------|---|
| Transport reference | Center reference |
| Paper feed capacity | 250 sheets (80g/m ²), 300 sheets (64g/m ²), 100 sheets (Postcard) |
| Paper size | A3W to A6R (Postcard) |
| Paper weight | 64 to 300g/m ² / 17 to 80lbs specified paper for color |
| Paper kind | Normal paper (including recommended paper for color), OHP1, OHP2, heavy paper 1 (106 to 200g/m ² (28 to 53 lbs.)), heavy paper 2 (201 to 300g/m ² (54 to 80 lbs.)), envelope |
| Paper size detection | Inch series: 12" x 18", 11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R, 7.25" x 10.5"R, 8.5" x 5.5", A3, B4, A4, B5, A6R AB series: A3W, A3, B4, A4, A4R, B5, A5, A6R, 11" x 17", 8.5" x 14", 8.5" x 11", 7.25" x 10.5"R |
| Manual feed size setup | Yes (Ignoring automatic setup) Selected with key operation. |

Detection of 8.5 x 14 can be changed to detection of 8.5 x 13 (216 x 330) with the simulation.

C. Paper exit unit

(1) Face down paper exit tray (Top section)

| | |
|---------------------------------|--|
| Paper exit position/system | Machine top face down paper exit |
| Paper exit capacity | 500 sheets (A4/LT recommended paper for color) |
| Paper size | A6R (Postcard), 8.5 x 5.5 to A3W |
| Paper weight | 64 to 200g/m ² (17 to 53 lbs.) |
| Paper kind | Normal paper (including recommended paper for color), heavy paper 1 (106 to 200g/m ² (28 to 53 lbs.)) |
| Remaining quantity detection | No |
| Discharged paper full detection | Yes |

(2) Face up paper exit tray (sides)

| | |
|---------------------------------|---|
| Paper exit position/system | Machine side face up paper exit |
| Paper exit capacity | 250 sheets (A4/LT recommended paper for color) |
| Paper size | All sizes which are fed |
| Paper weight | 64 to 300g/m ² (17 to 80 lbs.) |
| Paper kind | All sizes which are fed (except for OHP sheets) |
| Remaining quantity detection | No |
| Discharged paper full detection | Yes |

(3) Face down paper exit tray (side) (With the reverse unit installed)

| | |
|---------------------------------|---|
| Paper exit position/system | Machine side face down paper exit |
| Paper exit capacity | 250 sheets (A4/LT recommended paper for color) |
| Paper size | AB series: A3W, A3, B4, A4, A4R, B5, B5R, A5 Inch series: 12" x 18", 11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R, 7.25" x 10.5"R, 8.5" x 5.5", A3, B4, A4, B5 |
| Paper weight | 64 to 200g/m ² (17 to 53 lbs.) |
| Paper kind | Normal paper (including recommended paper for color) |
| Remaining quantity detection | No |
| Discharged paper full detection | Yes |

(4) Face up paper exit tray (side) (With the reverse unit installed)

| | |
|---------------------------------|---|
| Paper exit position/system | Machine side face up paper exit |
| Paper exit capacity | 250 sheets (A4/LT recommended paper for color) |
| Paper size | A3W to A5R (Postcard) |
| Paper weight | 64 to 300g/m ² (17 to 80 lbs.) |
| Paper kind | Normal paper (including recommended paper for color), OHP, heavy paper (106 to 300g/m ² (28 to 80 lbs.)), all other paper which is supported by the machine. |
| Remaining quantity detection | No |
| Discharged paper full detection | Yes |

D. Scanner section

(1) Resolution, gradation

| | |
|-----------------------|---|
| Scan resolution (dpi) | 600 x 600dpi |
| Scan speed | Color 160pm / B/W 190pm: A4/LT size |
| Scan gradation | 256 gradations for each color 2 gradations for scanner B/W mode only |
| Exposure lamp | Xenon lamp without electrode tube |
| Output gradation | 8bit for each color 1bit for Scanner B/W mode only |

(2) Document table

| | | |
|-----------------------------|---------------------------|--|
| Scan range | (A3/WT full image scan) | |
| Document reference position | Center reference | |
| Detection | Yes | |
| Detection size | Automatic detection | |
| | Inch series | <INCH-1: Default> 11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5" |
| | | <INCH-2> 11" x 17", 8.5" x 13", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5" |
| | AB series | <AB-1: Default> A3, B4, A4, A4R, B5, B5R, A5 |
| | | <AB-2> A3, 8.5" x 13" (216 x 330), A4, A4R, B5, B5R, A5 |
| | Manual doc size selection | Yes |

2. Functional specifications

A. Specifications of copy functions

(1) Copy speed (Continuous copy speed)

| Color / B/W | | Color | | | | B/W | | | |
|--|---------------------|--------------------------------|-----------------|---------------|--------------------|-----------------------------------|-----------------|---------------|--------------------|
| Print/Copy | | Print | Copy | | | Print | Copy | | |
| Paper size | Magnification ratio | B/W 4bit (Image priority mode) | Reduction (25%) | Normal (100%) | Enlargement (400%) | B/W 1bit (Speed priority mode) *3 | Reduction (25%) | Normal (100%) | Enlargement (400%) |
| A3W (12" x 18") | | 7 ppm | 7 cpm | 7 cpm | 7 cpm | 7 ppm | 7 cpm | 7 cpm | 7 cpm |
| A3 (11" x 17"), 8K | | 13 ppm | 13 cpm | 13 cpm | 13 cpm | 15 ppm | 15 cpm | 15 cpm | 15 cpm |
| B4 (8.5" x 14" / 8.5" x 13") | | 15 ppm | 15 cpm | 15 cpm | 15 cpm | 17 ppm | 17 cpm | 17 cpm | 17 cpm |
| A4 | | 26 ppm | 26 cpm | 26 cpm | 26 cpm | 33 ppm | 33 cpm | 33 cpm | 33 cpm |
| 8.5" x 11" | | 26 ppm | 26 cpm | 26 cpm | 26 cpm | 32 ppm | 32 cpm | 32 cpm | 32 cpm |
| A4R (8.5" x 11"R) | | 19 ppm | 19 cpm | 19 cpm | 19 cpm | 22 ppm | 22 cpm | 22 cpm | 22 cpm |
| B5, 16K | | 26 ppm | 26 cpm | 26 cpm | 26 cpm | 33 ppm | 33 cpm | 33 cpm | 33 cpm |
| B5R (7.25" x 10.5"R), 16KR | | 19 ppm | 19 cpm | 19 cpm | 19 cpm | 22 ppm | 22 cpm | 22 cpm | 22 cpm |
| A5 (8.5" x 5.5") | | 26 ppm | 26 cpm | 26 cpm | 26 cpm | 33 ppm | 33 cpm | 33 cpm | 33 cpm |
| A6R (Postcard) | | 6 ppm | 6 cpm | 6 cpm | 6 cpm | 6 ppm | 6 cpm | 6 cpm | 6 cpm |
| A6R (Normal paper) | | 13 ppm | 13 cpm | 13 cpm | 13 cpm | 15 ppm | 15 cpm | 15 cpm | 15 cpm |
| OHP (Speed *2), A4 (LT) | | 26 ppm | 26 cpm | 26 cpm | 26 cpm | 26 ppm | 26 cpm | 26 cpm | 26 cpm |
| OHP (Image quality), A4 (LT) | | 13 ppm | 13 cpm | 13 cpm | 13 cpm | 13 ppm | 13 cpm | 13 cpm | 13 cpm |
| Heavy paper 1 (106 to 200g/m ²), A4 (LT) or less | | 13 ppm | 13 cpm | 13 cpm | 13 cpm | 13 ppm | 13 cpm | 13 cpm | 13 cpm |
| Heavy paper 2 (201 to 300g/m ²), A4 (LT) or less | | 13 ppm | 13 cpm | 13 cpm | 13 cpm | 13 ppm | 13 cpm | 13 cpm | 13 cpm |
| Envelope *1 (All kinds) | | 7 ppm | 7 cpm | 7 cpm | 7 cpm | 7 ppm | 7 cpm | 7 cpm | 7 cpm |
| Size specified, EXTRA | | 7 ppm | 7 cpm | 7 cpm | 7 cpm | 7 ppm | 7 cpm | 7 cpm | 7 cpm |
| Size not specified, EXTRA | | 7 ppm | 7 cpm | 7 cpm | 7 cpm | 7 ppm | 7 cpm | 7 cpm | 7 cpm |

* ppm: page per minute when printing two or more pages of a same document.

cpm: copy per minute in 1-scan multi copy mode

* 1: Envelope kind: COM10, Monarch, DL, C5, Long No.3, Western type No. 2, Western type No. 4

* 2: Max. speed

* 3: Same as color print in the image quality priority mode (B/W 4bit)

(2) First copy time

| Platen/ RADF | Pre- scan | Paper exit position | Rotation copy | B/W | Color |
|-----------------|--------------|------------------------|------------------|---------------------------|---------------------------|
| Platen | No | Side face up | No | Within 7.0sec (A4/LT) | Within 8.0sec (A4/LT) |
| | | | Yes | Within 8.9sec (A4) | Within 10.7sec (A4) |
| | | Machine face down | No | Within 8.8sec (A4/LT) | Within 10.2sec (A4/LT) |
| | | | Yes | Within 10.7sec (A4/LT) | Within 12.6sec (A4/LT) |
| | Yes | Side face up | No | — | Within 10.9sec (A4/LT) |
| | | | Yes | — | Within 14.3sec (A4) |
| | | Machine face down | No | — | Within 12.9sec (A4/LT) |
| | | | Yes | — | Within 16.3sec (A4/LT) |
| RADF | No | Side face up | No | 8.0sec | 9.5sec |
| | | | Yes | Within 10.4sec (A4) | Within 12.3sec (A4) |
| | | Machine face down | No | 9.8sec | 11.7sec |
| | | | Yes | Within 12.1sec (A4/LT) | Within 14.0sec (A4/LT) |
| | Yes | Side face up | No | — | 12.2sec |
| | | | Yes | — | Within 15.7sec (A4) |
| | | Machine face down | No | — | 14.4sec |
| | | | Yes | — | Within 17.6sec (A4/LT) |

* When the RADF is used, the data are those without APS.

(3) Job speed

| Controller | | 128MB+256MB ICU: 256MB | |
|----------------|---|---------------------------|--------|
| B/W / Color | | B/W | Color |
| Copy method | 10 x 1 set S to S (A4) (Letter) | 19 cpm | 16 cpm |
| | 10 x 5 sets S to D (A4) (Letter) | 33 cpm 32 cpm | 26 cpm |
| | 5 x 5 sets D to D (A4) (Letter) | 33 cpm 32 cpm | 26 cpm |

Copy conditions: Document size A4 (8.5" x 11"), transfer belt position:
B/W position, excluding pre-scan

Note: The above are speeds of copying a single document excluding
the pre-rotation and after-rotation of the process and paper cycle
time.

(4) Continuous copy

| | |
|-------------------|------------|
| Multi max. number | 999 sheets |
|-------------------|------------|

(5) Resolution

| | |
|--------------------|--------------|
| Scan resolution | 600 x 600dpi |
| Writing resolution | 600 x 600dpi |

(6) Copy magnification ratio

| | |
|--|--|
| Copy magnification ratio | AB series: 25%, 50%, 70%, 81%, 86%, 100%, 115%, 122%, 141%, 200%, 400% Inch series: 25%, 50%, 64%, 77%, 95%, 100%, 121%, 129%, 200%, 400% |
| Custom magnification ratio registration | AB series/Inch series: 4 keys (2E/2R) |
| Zoom | 25%, 45 to 400% (1% increment) |
| Independent zoom | Yes (25, 45 to 400%) |

(7) Density, copy image process

| | | |
|-------------------|------------------------|--|
| Exposure mode | Color (Hexadecimal) | Auto: Auto, Pre-scan allowed |
| | B/W (Binary) | Auto: Text Auto: AE, Pre-scan inhibited |
| Color enhancement | | Yes (Valid for Text, Text/Print, Text/Photo, Print, Photo, Map) |
| Manual steps | | 9 steps |
| Smoothing process | | No |
| Toner save mode | | Yes (for B/W) |

(8) Copy functions

| | | |
|----------------------|-----------------------------------|--|
| Functions | APS | Yes |
| | AMS | Yes |
| | ACS (Auto Color Selection) | No |
| | Paper type select | Yes |
| | Free size input | Document: Yes Paper: Yes (Manual feed cassette) |
| | Auto tray switching | Yes |
| | Rotation copy | Yes (A4/8.5 x 11/B5/16K paper size only) |
| | Rotation sort | No |
| | Electronic sort (E-RDH) | Yes (B/W only) |
| | Copy reservation | No |
| | Program call/registration | Yes (Max. 9 items) |
| | Proof copy | No |
| | Pre-heat | Yes (Conditions are set by the key operation.) |
| | Auto power shut off | Yes (Conditions are set by the key operation.) |
| | Department management | Yes (200 departments) |
| | Key operator program | Yes |
| | Communication support (RIC) | Yes (Requires Connector or Installing port.) |
| | Process control | Yes |
| | Card counter support | Option (Japan only) |
| | Con vendor support | Yes (A connector must be installed inside the machine.) |
| Special functions | Binding margin | Yes |
| | Edge erase/Center erase | Yes |
| | 1 set 2 copy | Yes |
| | Cover paper | Yes (Color, one sheet only) |
| | OHP insert paper | Yes (White paper insertion only) |
| | Insert paper insertion (Index) | No |
| | Centering | Yes |
| | Multi shot (N in 1) | Yes (Ruled line ON/OFF allowed) |
| | Center binding | Option (B/W only) * Requires Duplex desk, Duplex pass/Inverter, Saddle finisher (in saddle stitch only). |
| | Duplex copy direction switch | Option * Requires Duplex desk, Duplex pass/Inverter. |
| | Negative/Positive conversion | No |
| | Photo repeat | Yes (2/4/8/12/16/24)10 is for visiting cards. |
| | RGB adjustment | Yes |
| | Color balance | Yes |

| | | |
|-------------------|-----------------------------|-----------------------------|
| Special functions | Color Gamma adjustment | Yes |
| | Brightness adjustment | Yes |
| | Contrast adjustment | No |
| | Sharpness adjustment | Yes |
| | Mirror image | Yes |
| | Single color | 6 colors (R, G, B, C, M, Y) |
| | Enlargement continuous copy | Yes |
| | Background erase | Yes |
| | A3 wide copy | Yes |
| | Auto color calibration | Yes |
| | Auto registration | Yes |

(9) Memory limitation matrix

| Copier specifications | | ICU PWB | Combination | Standard | Expansion 1 | Expansion 2 |
|-----------------------|--------|---------|--------------------------------|--------------|--------------|--------------|
| | | | Standard (Slot 1) | 256MB | 256MB | 256MB |
| | | | Expansion memory (Slot 2) | — | 128MB | 256MB |
| | | | Total memory capacity | 256MB | 384MB | 512MB |
| | | Mode | Document size | — | — | — |
| Copy | Single | Color | to A4 (8.5" x 11") | SOPM | SOPM | SOPM |
| | | | B4, A3 (8.5" x 14", 11" x 17") | SOPM | SOPM | SOPM |
| | | | A3W (12" x 18") | SOPM | SOPM | SOPM |
| | | B/W | to A4 (8.5" x 11") | 400 surfaces | 400 surfaces | 680 surfaces |
| | | | B4, A3 (8.5" x 14", 11" x 17") | 200 surfaces | 200 surfaces | 340 surfaces |
| | | | A3W (12" x 18") | 165 surfaces | 165 surfaces | 280 surfaces |
| | Duplex | Color | to A4 (8.5" x 11") | SOPM | SOPM | SOPM |
| | | | B4, A3 (8.5" x 14", 11" x 17") | No | SOPM | SOPM |
| | | | A3W (12" x 18") | — | — | — |
| | | B/W | to A4 (8.5" x 11") | 400 surfaces | 400 surfaces | 680 surfaces |
| | | | B4, A3 (8.5" x 14", 11" x 17") | 200 surfaces | 200 surfaces | 340 surfaces |
| | | | A3W (12" x 18") | — | — | — |


B/W (Electronic sort): Equivalent to "TEST SHEET B."

SOPM: Scan Once Print (Copy) Many

3. Environment conditions

A. Operating environment conditions



(1) Temperature and humidity





(2) Power voltage and frequency

| | |
|-----------------|-------------------------------|
| Power voltage | Specified voltage $\pm 10\%$ |
| Power frequency | Specified frequency $\pm 2\%$ |

B. Storage environment conditions



C. Transit environment conditions



D. Standard temperature and humidity

| | |
|-------------|-------------------------|
| Temperature | 20 to 25°C (68 to 77°F) |
| Humidity | 65 ±5% |

[4] CONSUMABLE PARTS

1. Supply system table

A. USA/Canada

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TBU | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TCU | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TMU | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TYU | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DU | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DR | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MK | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

B. Europe/Australia

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TBE | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TCE | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TME | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TYE | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DUE | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DM | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MKE | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

C. Central & South America

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TBA | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TCA | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TMA | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TYA | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DU | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DR | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MK | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

D. Philippine/Taiwan/SMEF

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TBP | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TCP | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TMP | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TYP | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DU | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DR | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MK | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

E. SOCC parts

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TB-C | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TC-C | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TM-C | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TY-C | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DU-C | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DR-C | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MK-C | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

F. SRH parts

| | Part name | Model name | Content | Life | Packing | Remark |
|---|-------------------------------|------------|--|------------------|---------|----------------------------|
| 1 | Toner (Black) | AR-C26TB-C | Toner cartridge (Black) x 1 | 16.7K (A4/LT 6%) | 10 | For A4/LT 5%, life is 20K. |
| 2 | Color toner (Cyan) | AR-C26TC-C | Toner cartridge (Cyan) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 3 | Color toner (Magenta) | AR-C26TM-C | Toner cartridge (Magenta) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 4 | Color toner (Yellow) | AR-C26TY-C | Toner cartridge (Yellow) x 1 | 5.5K (A4/LT 10%) | 10 | |
| 5 | Photoconductor drum cartridge | AR-C26DU-C | Drum cartridge (including OPC drum & unit parts) x 1 Color identification seal (Y/M/C/K) x 1 each | 50K | 10 | |
| 6 | Drum | AR-C26DR-C | OPC Drum x 1 | 50K | 10 | |
| 7 | Main charger kit | AR-C26MK-C | Charging unit x 1 Cleaning blade x 1 Toner reception seal x 1 | 50K | 10 | |

2. Consumables (kit, unit)


| | Part name | Model name | Content | Life |
|---|--------------------------------|---|---|---------|
| 1 | Upper heat roller kit | AR-C26UH | Upper heat roller x 1 Heat roller 60T gear x 1 Upper heat roller bearing x 2 Thermistor x 1 Upper heat roller stopper x 2 | 100K *1 |
| 2 | Lower heat roller kit | AR-C26LH | Lower heat roller x 1 Lower heat roller bearing x 2 Thermistor x 1 Lower heat roller stopper x 2 Fusing separation pawl lower x 2 | 100K *1 |
| 3 | Transfer belt kit | AR-C26TT | Transfer belt x 1 | 100K *1 |
| 4 | Transfer roller kit | AR-C26TX | Transfer roller x 4 | 100K |
| 5 | Transfer waste toner tank unit | AR-C26HB | Transfer waste toner tank unit x 1 | 100K |
| 6 | Filter kit | AR-C26FL | Ozone filter A x 1 Ozone filter B x 1 | 50K |
| 7 | Saddle staple cartridge | AR-SC2 | — | |
| 5 | Fusing unit | AR-C26FU (230V heater lamp) AR-C26FU1 (120V heater lamp) AR-C26FU2 (100V heater lamp) | Fusing unit for servicing (including upper/lower heater lamps) | *1 |
| 6 | Transfer belt unit | AR-C26TU | Transfer unit for servicing | 100K *1 |

*1: Replace at 100K or within 2 years

3. Photoconductor, developer, toner


A. Lot number identification and the term of validity

(1) Photoconductor

| | |
|---|--|
|  | <ul style="list-style-type: none">(1) Figure 2 for this model(2) Alphabet Indicates the model support code.(3) Figure Indicates the end digit of the production year.(4) Figure or X, Y, Z Indicates the production month. (X= October, Y= November, Z= December)(5) (6) Figure Indicates the production day.(7) Figure or X, Y, Z Indicates the packing month. (X= October, Y= November, Z= December)(8) (9) Figure Indicates the packing day.(10) Figure or alphabet Indicates the production division. |
|---|--|


The term of validity: 36 months from the production day (month).

(2) Photoconductor cartridge

| | |
|--|---|
|  | <ul style="list-style-type: none">(1) Figure Version No.(2) Figure The end digit of the year.(3) Alphabet Production code (B for SOCC)(4) Alphabet Destination code(5) (6) Figure Production day(7) Figure or X, Y, Z Indicates the production month. (X= October, Y= November, Z= December) |
|--|---|

The term of validity: 24 months from the production day (month).

(3) Toner cartridge

| | |
|---|---|
|  | <ul style="list-style-type: none">(1) Alphabet or figure Unit code(2) Alphabet Destination code(3) Alphabet Skating(4) Alphabet Production site code(5) Figure Serial number (5 digits)(6) Figure Production year, month, day (6 digits)(7) Alphabet Version No. (A ~ sequentially revised) |
|---|---|

The term of validity: 24 months from the production day (month).

[5] UNPACKING AND INSTALLATION

1. Installing (use) conditions

Before installing the machine, check that the following installing (use) conditions are satisfied.

If the installing (use) conditions are not satisfied, the machine may not display full performances, resulting in troubles. It may also cause safety problems. Therefore, be sure to arrange the installing (use) conditions before setting up the machine.

| No. | Content |
|-----|---|
| 1 | Bringing space |
| 2 | Installing space |
| 3 | Power source (Capacity, fluctuation, safety) |
| 4 | Floor strength |
| 5 | Direct rays of the sun, dust, temperature, humidity, gases, chemicals |

A. Bringing space


For installation of a large size machine, be sure to check that the door size is great enough before bringing in.

B. Installing space

The following space must be provided around the machine in order to assure machine performances and proper operations.

If any option is installed, provide the additional space for installing it.

Especially the space at the rear of the machine must be provided sufficiently. If not, the machine cannot exhibit functions against heat and dust, causing some troubles.



C. Power source

(Capacity, voltage, frequency, safety, plug)

If the power specifications are not satisfied, the machine cannot exhibit full performances and may cause safety trouble.

Strictly observe the following specifications.

(1) Power capacity

Check that the following power capacity is satisfied. If not, additionally provide a power source.

Current capacity

Japan: 20A or more

100V: 15A or more

200V: 10A or more

(2) Power voltage

Measure the voltage during copying to check that the voltage is in the range of the specified voltage $\pm 10\%$.

If the voltage is outside the specified range, use thicker lead wires to reduce impedance.

(An electrical work is required.)

Use of a step-up transformer is also available. In this case, the capacity must be great enough for the max. power consumption of the machine.

(3) Power frequency, waveform

The frequency must be within the range of the specified frequency $\pm 2\%$. If power waveform is deformed, a trouble may occur.

(4) Safety

Be sure to properly ground the machine.

(5) Power plug


Check the form of the power plug. If the shape does not match, do not use it.

D. Floor strength and level

This machine is considerably heavy and becomes heavier with an option installed.

The floor must be strong enough for assuring safety.

If not, color shift or image distortion may occur.




E. Direct rays of the sun, dust, temperature, humidity, gasses, chemicals, vibration

(1) Temperature and humidity

This machine is designed to perform properly under the specified temperature and humidity. If the temperature and humidity exceeds the specified range, the machine may not operate properly and or cause equipment failure.


Especially when the humidity is too high, paper absorbs humidity to cause a paper jam or dirty copy.



(Do not install the machine near a stove, a humidifier, or an air conditioner.)

Do not install the machine near a heater, a cooler, or a humidifier.

Dew may be formed inside the machine to cause a trouble. Use enough care for ventilation.




(2) Dust

If dust enters the machine, it may cause dirty copy and a paper jam, resulting in a shortened lifetime.



(3) Direct rays of the sun


If the machine is installed under the rays of the sun, the exterior of the machine may be discolored and abnormal copies may be produced.



(4) Gases and chemicals

Do not install the machine at a place where there are gases and chemicals. Especially be careful to avoid installation near a diazo-type copier, which produces ammonium gas.


Copy quality may be adversely affected and a trouble may be caused.



(5) Vibration

Avoid installation near a machine which produces vibrations.

If vibrations are applied to the copier machine, copy images may be deflected and a trouble may be caused.



2. Transit and delivery

| No. | Content | Method |
|-----|-------------------------------------|--|
| 1 | Implements, facility, and man power | Use a forklift. (If no forklift is available, manpower of four persons is required.) |
| 2 | Delivery | Transit must be made in packed condition. |

A. Implements, facility, and manpower

It is recommendable to use a forklift for bringing in the machine for safety.

If no forklift is available, man-power of four persons is required. The machine is considerably heavy, and requires safety precautions for delivery and installation.

Transit of the machine must be made in packed condition to the installing place.



B. Delivery

Remove the packing materials prior to installation in the office environment.

3. Unpacking


A. Unpacking procedure

- 1) Remove the PP band.
- 2) Remove the top case.
- 3) Remove the internal packing pads and the items packed together with the machine.
- 4) Remove the machine from the package.




Fixing tape and protection pads removal

- 1) Remove the fixing tape and protection pads from the machine.




Note: The document cover may be supplied as a standard part in some destinations, and may be an option in some other destinations.

- 2) Open the left door, and remove the transfer fixing pads.




Actuator installation

- 1) Remove the actuator fixed to the left door.




- 2) Install the actuator to the paper exit port of the left door.



4. Lock release


A. Scanner (2/3 mirror unit) lock release

- 1) Remove the scanner fixing screw, and remove the caution label.




B. Main body cassette lock release

- 1) Pull out the main body cassette.
- 2) Remove the rotation plate fixing pad and remove the caution label.




C. Transfer unit pressure release


- 1) Pull the knob and open the left door.





- 2) Loosen the roller knob (A), and remove the fusing unit (B).




- 3) Hold section A of the transfer unit and pull it out so that the both sides of the transfer unit can be held.
4) Hold sections B and remove the transfer unit.



- 5) Remove the transfer belt protect sheet.




- 6) Remove the screw and apply a tension to the transfer belt.




- 7) Install the transfer unit to the machine.

5. Fusing heat roller pressing (F/R)

- 1) Pull the knob and open the left door.




- 2) Turn the pressure release lever to press.




Note: If the machine is left for one month or more, the heat roller rubber may be deformed. In such a case, therefore, release the pressure.

6. Black drum cartridge insertion

- 1) Pull the knob and open the left door.
- 2) Open the front cover.




- 3) Insert the black drum cartridge, and fix it with a screw.



7. Paper exit tray installation


- 1) Install the paper exit tray to the left door.




Note: The paper exit tray may be supplied as a standard part in some destinations, and may be an option in some other destinations.

8. Toner cartridges installation

- 1) Shake the toner cartridge horizontally several times.




- 2) Remove the tape, and remove the protection pad.




- 3) Open the front cover.
- 4) Insert the toner cartridge.

* As shown below, fit the cartridge with the insertion port and push it in.




Note: Be sure to install the color cartridges to their proper positions. Avoid installation to a different color position.


[Color toner cartridge positions]



- 5) Insert the cartridge securely until it locks.



- 6) Return the cartridge lever to the original position.




- 7) Close the front cover.




9. AC cord connection

- 1) Insert the AC power plug into the connector at the rear of the machine, and connect the other end to the power outlet.



10. Machine power ON

- 1) Turn on the power switch on the left side of the machine.



11. Specifications setup

Used to set the specifications with SIM26 according to the customer's request.

| SIM No | | Content |
|--------|---|------------------------------|
| 26 | 6 | Used to set the destination. |

To customize the following items after completion of the destination setup, change the set values.

| SIM No | | Content |
|--------|--|---|
| 26 | 2 | Used to set the large capacity paper feed tray paper size. |
| | | Used to set the detection paper size and display when using 8.5 x 13 size paper and document. |
| | | Used to set the paper kind and the display form in the manual paper feed mode. |
| | 3 | Used to set the auditor specification mode. |
| | 5 | Used to set the count mode of the total counter and the maintenance counter. |
| | 18 | Used to set YES/NO of the toner save mode (Only in UK and Japan versions) For other destination versions, this setup is made by the user program. |
| | 52 | Used to set YES/NO of counting when non-print paper is passed through each counter. |
| | 53 | Used to set YES/NO of user calibration permission. |
| 65 | Used to set the limit number of sheets for stapling. | |

On completion of the installation of the AR-F13 finisher, please change the default output tray of the machine to the top tray of the finisher.

12. Image quality check

Check the following items related to image quality. For details of the adjustment and checking procedures, refer to the chapter of adjustments.

- 1) Image focus, image skew (Refer to ADJ 3.)
- 2) Image registration (Refer to ADJ 4.)
- 3) Image loss, void area (Refer to ADJ 10.)
- 4) Copy color balance, density (Refer to ADJ 11.)

Check that the above items are normal. If not, make the adjustment.

13. Function and operation check

Check that the following operations are normal.

| Check item | | Installation | |
|--|--------------------------------|---|---|
| Key input operation (Operation panel) | | | |
| Display (Operation panel) | | | |
| Paper feed operation | Manual paper feed | | |
| | Machine paper tray | | |
| | Desk unit paper feed tray | When the desk unit is installed. | |
| | Large capacity paper feed tray | When the large capacity paper feed tray is installed. | |
| Paper size detection operation | | | |
| Document size detection operation | Document table mode | | |
| | RADF mode | When the RADF is installed. | |
| RADF operation/ Duplex copy operation | S-S mode | When the RADF is installed. | |
| | D-S mode | When the RADF is installed. | |
| | S-D mode | When the RADF is installed. | When the desk unit with the duplex unit is installed. |
| | D-D mode | When the RADF is installed. | When the desk unit with the duplex unit is installed. |

| Check item | Installation | |
|-----------------------|---------------------------------|-------------------------------|
| Bookbinding operation | When the finisher is installed. | |
| Stapling operation | When the finisher is installed. | |
| Grouping operation | When the finisher is installed. | When the sorter is installed. |
| Sorting operation | When the finisher is installed. | When the sorter is installed. |

14. Setup and adjustment data recording

Print the various setup data and the adjustment data (list) with SIM22-6 and keep the data.

In case of a memory trouble, if the data are not kept, all the adjustments must be made again.

If the data are kept, the setup values and the adjustment values can be entered without adjustments, shortening the servicing time.


15. Necessary works before moving the machine

- 1) If the following options are installed, remove all of them from the machine.
 - Sorter
 - Finisher
 - Reverse unit
 - RADF unit
 - Desk unit
- 2) Remove the following consumable parts from the machine.
 - Paper
 - Toner cartridge
 - Photoconductor cartridge
- 3) Lock the following sections.
 - Scanner (Optical section)
 - Paper cassette lift plate

[6] EXTERNAL VIEW AND INTERNAL STRUCTURE


1. Name and function of each section

A. External view




| No. | Parts | | Model | Note |
|-----|-------------------------------------|--|-------|------|
| | Name | Function | | |
| 1 | Paper exit tray (Left tray) | Receives discharged paper. | | |
| 2 | Left side cover | Opened to process a paper jam in the fusing unit or the transfer unit. | | |
| 3 | Automatic duplex document feeder | Automatically feeds and transports sheet documents to be scanned. Supports duplex documents and scans the back surface as well as the front surface of a document. (Option) | | |
| 4 | Main switch | Turns on/off the power source. | | |
| 5 | Front cover | Opened to replace the toner cartridge. | | |
| 6 | Operation panel | Performs various functions with the operation keys and the touch panel. | | |
| 7 | Upper paper exit tray (Center tray) | Receives discharged paper. | | |
| 8 | Document cover | Presses a document. | | |
| 9 | Original stacker | Stacks documents. | | |
| 10 | Manual feed tray | Used for manual paper feed. | | |
| 11 | 3-stage paper feed desk | Provided with the 3-stage trays for paper feed. Each tray holds about 500 sheets of the recommended color paper (80g/m ² (21 lbs.)) or about 550 sheets of Sharp standard paper (64g/m ² (17 lbs.)). (Option) | | |
| 12 | 2-stage duplex paper feed desk | Provided with the 2-stage duplex paper feed trays. Each tray holds about 500 sheets of the recommended color paper (80g/m ² (21 lbs.)) or about 550 sheets of Sharp standard paper (64g/m ² (17 lbs.)). For duplex paper exit, the reverse bypass module (AR-RB1) (15) is required. (Option) | | |
| 13 | Tray | Holds about 500 sheets of the recommended color paper (80g/m ² (21 lbs.)) or about 550 sheets of Sharp standard paper (64g/m ² (17 lbs.)). | | |
| 14 | Left side cover open/close knob | Push up this knob to open the left cover. | | |
| 15 | Reverse bypass module | Reverses paper for automatic duplex paper exit. (Option) | | |

B. Internal structure



| No. | Parts | | Model | Note |
|-----|-----------------------------|--|-------|--|
| | Name | Function | | |
| 16 | Fusing section | Fuses transferred images on paper. | | Note: Since the fusing section is heated to a high temperature, be careful not to burn your hands when processing a paper jam. |
| 17 | Toner cartridges | Toner is in this cartridge. When toner is empty, replace the empty cartridge with a new one. | | |
| 18 | Right side cover | Opened to process a paper jam in the paper feed section. | | |
| 19 | Paper feed desk right cover | Opened to process a paper jam in a peripheral unit. | | |
| 20 | Cleaning lever | Use this level to clean the charger. Provided for each toner cartridge. | | |

C. Operation panel




| No. | Parts | | Model | Note |
|-----|---|--|-------|------|
| | Name | Function | | |
| 1 | Touch panel | Displays messages and keys. The display key can be directly touched to be operated. Provides selection of PRINTER/COPY/NETWORK SCANNER/FAX mode. | | |
| 2 | Mode select key/ Display lamp [PRINTER] key READY lamp DATA lamp [FAX/IMAGE SEND] key *1 Communication lamp Data lamp [COPY] key | Switches the display mode of the touch panel. [PRINTER] key: Set to the printer mode. • READY lamp: ON when reception of print data is allowed. • DATA lamp: On or flashing during printing or receiving print data. Switches the network scanner (when expanded)/ FAX mode (AR-C250F only). Switches to the copy mode. | | |
| 3 | [JOB STATUS] key | Displays the current job status. | | |
| 4 | [USER SETUP] key | Used to adjust contrast of the touch panel and set the key operator program. | | |
| 5 | 10-key pad | Used to input figures for various setups. | | |
| 6 | [*] key ([DEPT COUNT END] key) | Used in the copy function and the FAX function. | | |
| 7 | [#/P] key ([PROGRAM] key) | Used when dialing in the copy function and the FAX function. | | |
| 8 | [C] key (Clear key) | Used in the copy function and the FAX function. | | |
| 9 | B/W [START] key | Used during outputting B/W copy in the copy function, during scanning B/W images in the network scanner function, and during scanning a send document in the FAX function. | | |
| 10 | [CA] key ([ALL CANCEL] key) | Used in the copy function and the FAX function. | | |
| 11 | Color [START] key | Used during outputting a full-color or single-color copy in the copy function and during scanning color images in the network scanner function. | | |

*1: For the AR-C250S, [IMAGE SEND] key.

D. Job status display

The job status display is shown by pressing the [JOB STATUS] key on the operation panel.


The list of jobs which are reserved, being executed, or completed is displayed to allow checking the job contents or to delete (terminate) jobs.



* The above example shows the job list of reservation and execution.

| No. | Display of inside of touch panel | | Model | Note |
|-----|----------------------------------|--|-------|---|
| | Name | Function | | |
| 1 | Job list | Displays the list of reservation and execution. Touch the key (3), (4) or (5) to select the mode and display the job list. The icon in front of each job name indicates the job mode. <div> Copy mode Printer mode </div> <div> Network scanner mode </div> <div> FAX mode (Send job) FAX mode (Receive job) </div> When the job list of reservation and execution is displayed, each job on the list serves as a key. To terminate the output, touch the job key to select the job and press [HALT/DELETE] key (6) ([PRIORITY] key (7)). | | * Paper empty of status display If the status display is in paper empty, the specified size paper is exhausted. (Need to be supplied.) To print on another size paper already set, touch and select the job and touch the detail key (8) to change the size. |
| 2 | Mode select key | This key is displayed only in the job status display in the FAX mode, and is used to switch the job list display to the [RESERVATION/EXECUTION] job or the [COMPLETED] job. [RESERVATION/EXECUTION] job: Displays the list of reserved or executing jobs. [COMPLETED] job: Displays the list of completed jobs. | | |
| 3 | [PRINT] key | Displays the list of the output jobs in all the modes (printer, copy, and FAX). | | |
| 4 | [SCANNER] key | Displays only the jobs of the network scanner function. * When the network scanner function is optionally expanded. | | |
| 5 | Display select key | Switches the page of displayed job list. | | |
| 6 | [HALT/DELETE] key | Halts or deletes a job which is being executed or a reserved job. * Halt/delete during execution cannot be made. | | |
| 7 | [PRIORITY] key | This key is valid only in the job status display in the FAX mode. Touch and select the reserved FAX job to set the highest priority on the job. | | |
| 8 | [DETAIL] key | This key is displayed only on the job status display in the print mode. It is valid only for a print job from PC. The details of the selected job are displayed. Also used to change the specified output paper. | | |


E. Cross section



| No. | Parts | | Model | Note |
|-----|-------------------------|---|-------|------|
| | Name | Function | | |
| 1 | No. 3 mirror | Leads a document image to the CCD. | | |
| 2 | No. 2 mirror | Leads a document image to No. 3 mirror. | | |
| 3 | No. 1 mirror | Leads a document image to No. 2 mirror. | | |
| 4 | Scanner lamp | Radiates light on a document for the CCD to scan the document image. | | |
| 5 | Yellow toner cartridge | Attaches yellow toner to electrostatic latent images on the photoconductor. | | |
| 6 | Magenta toner cartridge | Attaches magenta toner to electrostatic latent images on the photoconductor. | | |
| 7 | Cyan toner cartridge | Attaches cyan toner to electrostatic latent images on the photoconductor. | | |
| 8 | Black toner cartridge | Attaches black toner to electrostatic latent images on the photoconductor. | | |
| 9 | Discharge lamp | Discharges the photoconductor. | | |
| 10 | Main charger unit | Charges the magenta photoconductor negatively. | | |
| 11 | LED unit | Converts the color component image signal sent from the ICU PWB into LED light, and radiate it to the OPC drum. | | |
| 12 | Doctor blade | Regulates the toner quantity on the developing roller. | | |
| 13 | Supply roller | Supplies toner to the developing roller. | | |
| 14 | Developing roller | Attaches toner to the photoconductor. | | |
| 15 | Cleaning blade | Cleans residual toner from the photoconductor. | | |
| 16 | OPC drum unit | Forms electro-static latent images. | | |
| 17 | CCD lens | Reduces document images (light) and projects it to the CCD. | | |
| 18 | CCD PWB | Reads document images (photo signals) and converts them into electrical signals. | | |
| 19 | Transfer roller (K) | Applies the transfer voltage to the transfer belt. | | |
| 20 | Transfer roller (C) | Applies the transfer voltage to the transfer belt. | | |
| 21 | Transfer roller (M) | Applies the transfer voltage to the transfer belt. | | |
| 22 | Transfer roller (Y) | Applies the transfer voltage to the transfer belt. | | |


| No. | Parts | | Model | Note |
|-----|------------------------------------|---|-------|---------------------------|
| | Name | Function | | |
| 23 | Transfer belt | Transfers toner images of the photoconductor onto paper. | | |
| 24 | Waste toner box (Transfer section) | Collects waste toner on the transfer belt. | | |
| 25 | Lift-up unit | Lifts the transfer belt. | | |
| 26 | Paper pickup roller (No. 1 tray) | Sends paper to the paper feed roller. | | |
| 27 | Idle roller | Applies a pressure to paper and the transport roller to provide transport power of the transport roller to paper. | | |
| 28 | Manual paper feed roller | Feed paper to the paper transport section. | | |
| 29 | Paper pickup roller | Sends paper to the paper feed roller. | | Manual paper feed section |
| 30 | Separation roller | Separates paper to prevent double feed. | | |
| 31 | Manual paper transport roller | Transports paper to the resist roller. | | |
| 32 | Upper resist roller | Transports paper to the transfer section. | | |
| 33 | Lower resist roller | Transports paper to the transfer section. | | |
| 34 | Idle roller | Prevents paper skew. | | |
| 35 | Paper transport roller 1 | Transports paper to the resist roller. | | |
| 36 | Paper feed roller (No. 1 tray) | Feed paper to the paper transport section. | | |
| 37 | Separation roller (No. 1 tray) | Separates paper to prevent double feed. | | |
| 38 | Idle roller | Applies a pressure to paper and the transport roller to provide transport power of the transport roller to paper. | | |
| 39 | Paper transport roller 2 | Transports paper to the transport roller 1. | | |
| 40 | Fusing unit | Fuses toner on paper. | | |
| 41 | Lower heat roller thermistor | Detects the temperature on the fuser roller surface. | | |
| 42 | Lower heat roller thermostat | Detects an abnormally high temperature and turns off the heater lamp. | | |
| 43 | Lower heat roller | Heats and presses toner on paper to fuse toner on paper. | | |
| 44 | Lower heater lamp | Heats the lower fuser roller. | | |
| 45 | Lower separation pawl | Mechanically separates paper which was not separated naturally from the lower heat roller. | | |
| 46 | Fusing transport roller | Transports paper after fusing. | | |
| 47 | Idle roller | Applies a pressure to paper and the transport roller to provide transport power of the transport roller to paper. | | |
| 48 | Gate | Switches the paper exit path. (face up, face down) | | |
| 49 | Upper heater lamp | Heats the heat roller. | | |
| 50 | Upper heat roller | Heats and presses toner on paper to fuse toner on paper. | | |
| 51 | OPC drum | Forms latent static electrostatic images with LED light. | | |
| 52 | Upper heat roller thermistor | Detects the temperature on the heat roller surface. | | |
| 53 | Upper heat roller thermostat | Detects an abnormally high temperature and turns off the heater lamp. | | |
| 54 | Idle roller | Applies a pressure to paper and the transport roller to provide transport power of the transport roller to paper. | | |
| 55 | Transfer belt cleaning blade | Cleans toner on the transfer belt. | | |
| 56 | Paper transport roller 3 | Transport paper to the paper exit roller. | | |
| 57 | Belt waste toner transport shaft | Transports waste toner on the transfer belt to the waste toner box. | | |
| 58 | Paper exit roller | Discharges paper to outside of the machine. | | |
| 59 | Idle roller | Applies a pressure to paper and the transport roller to provide transport power of the transport roller to paper. | | |

F. Motors, clutches, solenoids, fans



| No. | Parts | | Code, signal name | Type |
|-----|---------------------------------------|--|-------------------|--------------------------|
| | Name | Function | | |
| 1 | Exit select gate solenoid | Drives the exit path select gate. | GSS | Electromagnetic solenoid |
| 2 | Offset motor (Slide motor) | Drives the paper exit offset. | OSM | Stepping motor |
| 3 | Fusing drive motor | Drives the fusing unit. | FUSM | Stepping motor |
| 4 | Exhaust fan motor 1 | Exhaust and cools the fusing section. | VFMP | DC motor |
| 5 | Exhaust fan motor 2 | Exhaust and cools the fusing section. | VFMS | DC motor |
| 6 | Power unit cooling fan motor | Cools the power unit. | PSFM | DC motor |
| 7 | Drum motor (Y) | Drives the yellow photoconductor unit. | DM_Y | Stepping motor |
| 8 | Drum motor (M) | Drives the magenta photoconductor unit. | DM_M | Stepping motor |
| 9 | Drum motor (C) | Drives the cyan photoconductor unit. | DM_C | Stepping motor |
| 10 | Drum motor (K) | Drives the black photoconductor unit. | DM_K | Stepping motor |
| 11 | Printer controller cooling fan motor | Cools the printer controller. | | |
| 12 | PS motor | Drives and turns ON/OFF the resist roller. | PSM | Stepping motor |
| 13 | Process cooling fan motor | Exhaust and cools the process section. | PCFM | DC motor |
| 14 | Scanner motor | Drives the scanner unit. | SM | Stepping motor |
| 15 | PS front clutch | Transmits power of the paper feed motor to the manual paper feed unit. (Controls ON/OFF.) | MTRC | Electromagnetic clutch |
| 16 | Paper feed motor | Drives the paper feed section and the paper transport section. | PFM | DC servo motor |
| 17 | Paper feed clutch | Transmits power of the paper feed motor to each transport roller. (Controls ON/OFF.) | TRC | Electromagnetic clutch |
| 18 | Manual paper feed clutch | Controls ON/OFF of the manual paper feed roller. Presses the paper pickup roller to paper. | MPFC | Electromagnetic clutch |
| 19 | Paper feed drive clutch | Controls ON/OFF of the paper feed roller. | CPFC1 | Electromagnetic clutch |
| 20 | No. 1 cassette lift-up motor | Drives the lift plate. | LUM1 | Synchronous motor |
| 21 | Belt lift-up motor | Lifts the transfer belt unit. | BLUM | Stepping motor |
| 22 | Calibration plate open/close solenoid | Switches the image density sensor. | CALS | Electromagnetic solenoid |
| 23 | Transfer belt motor | Drives the transfer belt. | BTM | Stepping motor |


G. Sensors, switches and heaters



| No. | Parts | | Code, signal name | Type |
|-----|---|---|-------------------|-----------------------------------|
| | Name | Function | | |
| 1 | Dehumidifier heater | Dehumidifies the scanner section. | DH (Japan only) | |
| 2 | O/C open/close sensor | Detects open/close of the document cover. (A timing signal of document size detection is produced.) | OCSW | Photo sensor (Photo transmission) |
| 3 | Offset home position sensor | Detects the offset home position. | HPOS | Photo sensor (Photo transmission) |
| 4 | Paper exit tray full detection | Detects full of the face down paper exit tray. | TFD2 | Photo sensor (Photo transmission) |
| 5 | Mirror home position sensor | Detects the scanner home position. | MHPS | Photo sensor (Photo transmission) |
| 7 | Dehumidifier heater switch | Turns ON/OFF the dehumidifier heater installed in the scanner (reading) section and the paper feed section. | DHSW (Japan only) | — |
| 8 | Toner empty sensor (Y) | Detects toner empty (Y). | TES_Y | Photo sensor (Photo transmission) |
| 9 | Toner empty sensor (M) | Detects toner empty (M). | TES_M | Photo sensor (Photo transmission) |
| 10 | Toner empty sensor (C) | Detects toner empty (C). | TES_C | Photo sensor (Photo transmission) |
| 11 | Toner empty sensor (K) | Detects toner empty (K). | TES_K | Photo sensor (Photo transmission) |
| 12 | No. 1 paper transport sensor | Detects paper in front of the resist roller. | PPD1 | Photo sensor (Photo transmission) |
| 13 | Paper feed door open detection | Detects open/close of the paper feed door. | DSWR | Micro switch |
| 14 | Manual feed paper empty detection | Detects paper empty on the paper tray. | MPED | Photo sensor (Photo transmission) |
| 15 | Manual feed tray pulling out detection 2 | Detects the paper tray position. | MTOP2 | Contact switch |
| 16 | No. 1 cassette paper size detection 1 | Detects the paper size set by the paper size set blocks. | C1SS1 | Contact switch |
| 17 | No. 1 cassette paper size detection 2 | Detects the paper size set by the paper size set blocks. | C1SS2 | Contact switch |
| 18 | No. 1 cassette paper size detection 3 | Detects the paper size set by the paper size set blocks. | C1SS3 | Contact switch |
| 19 | No. 1 cassette paper size detection 4 | Detects the paper size set by the paper size set blocks. | C1SS4 | Contact switch |
| 20 | No. 1 cassette lift-up position detection 1 | Detects the lift plate position. (Detects the paper quantity.) | C1PD1 | Photo sensor (Photo transmission) |
| 21 | Manual feed paper length detection 2 | Detects the paper length. | MPLD2 | Photo sensor (Photo transmission) |
| 22 | Manual feed tray pulling out detection 1 | Detects the paper tray position. | MTOP1 | Contact switch |

| No. | Parts | | Code, signal name | Type |
|-----|--|--|-------------------|-----------------------------------|
| | Name | Function | | |
| 23 | Manual feed paper length detection 1 | Detects the paper length. | MPLD1 | Photo sensor (Photo transmission) |
| 24 | Humidity sensor | Detects the ambient humidity. | HUD | — |
| 25 | No. 1 cassette paper feed detection | Detects paper exit from No. 1 paper tray. | PDF1 | Photo sensor (Photo transmission) |
| 26 | Manual feed paper width detection | Detects the paper width. | MPWS | Volume (Variable resistor) |
| 27 | No. 1 cassette lift-up upper limit detection | Detects the upper limit position of paper. | LUD1 | Photo sensor (Photo transmission) |
| 28 | PS front sensor | Detects paper in front of PS. | PPD2 | Photo sensor (Photo transmission) |
| 29 | No. 1 cassette paper empty detection | Detects paper empty on the paper tray. | PED1 | Photo sensor (Photo transmission) |
| 30 | Dehumidifier heater | Dehumidifier heater for the main body cassette. (Japan only) | DH | — |
| 31 | Belt lift-up upper limit detection | Detects lift-up or lift-down of the transfer belt. | BLUD | Photo sensor (Photo transmission) |
| 32 | Belt waste toner full detection | Detects belt waste toner full. | BTNF | Contact switch |
| 33 | Color toner concentration (process control) sensor/Auto image Reg. | Detects the toner patch density (color toner) in image density correction operation. 2-sensors on PWB. | PCS_C | Photo sensor (Photo transmission) |
| 34 | Lower heat roller thermistor | Detects the temperature on the heat roller surface. | THSD | Thermistor |
| 35 | Lower heat roller thermostat | Detects an abnormally high temperature and turns off the heater lamp. | HLTS2 | Thermostat Thermal switch |
| 36 | Machine paper exit sensor 1 | Detects discharged paper. | POD1 | Photo sensor (Photo transmission) |
| 37 | Upper heat roller thermistor | Detects the temperature on the heat roller surface. | THSU | Thermistor |
| 38 | Upper heat roller thermostat | Detects an abnormally high temperature and turns off the heater lamp. | HLTS1 | Thermostat Thermal switch |
| 39 | Main switch | Turns ON/OFF the main power. | MSW | Seesaw switch |
| 40 | Front door open detection | Detects open/close of the front door. | DSWF | Micro switch |
| 41 | Paper exit door open detection | Detects open/close of the paper exit door. | DSWL | Micro switch |
| 42 | Face-up paper exit tray full detection | Detects full of the face-up paper exit tray. | TFD | Photo sensor (Photo transmission) |
| 43 | Machine paper exit sensor 2 | Detects discharged paper. | POD2 | Photo sensor (Photo transmission) |
| 44 | Black toner concentration sensor | Detects black patch density for toner concentration | PCS_B | — |


H. PWB 1



Front / right side / top view

| No. | Parts | | Code, signal name | Type |
|-----|--|--|-------------------|------|
| | Name | Function | | |
| 1 | CL inverter PWB | Drives the xenon lamp. | | |
| 2 | MFP PWB | Corrects images from the CCD and controls the operation panel. | | |
| 3 | Flash PWB (OP) | Includes the program to drive the OP PWB. | | |
| 4 | Flash PWB (MFP) | Includes the program to drive the MFP PWB. | | |
| 5 | Document detection LED PWB | Emits light for document size detection. | | |
| 6 | CCD PWB | Converts document images into electric signals. | | |
| 7 | Lift-up unit PWB tray | Detects the cassette size and interfaces the cassette lift-up motor signals. | | |
| 8 | Manual feed VR PWB | Outputs manual feed width signals. | | |
| 9 | Process control PWB (for black) | Outputs the black toner density on the transfer belt. | | |
| 10 | Process control PB (for color) | Outputs the color toner density on the transfer belt. | | |
| 11 | Document detection light receiving PWB | Outputs the document size detection signal. | | |
| 12 | Operation PWB | Outputs the key operation signal. | | |
| 13 | INV/LVDS PWB | Interfaces LCD from the MFPPWB and the touch panel signal, and drives the LCD backlight. | | |
| 14 | Temp sensor PWB | Temp/humidity sensor readings. | | |


H. PWB2



| No. | Parts | | Code, signal name | Type |
|-----|---------------------|---|-------------------|------|
| | Name | Function | | |
| 15 | Flash PWB (ICU) | Includes the program to drive the ICU PWB. | | |
| 16 | ICU PWB | Performs image process and controls LED. | | |
| 17 | PCU PWB | Controls the engine section. | | |
| 18 | Driver PWB | Controls the DC load power and drive the motor. | | |
| 19 | AC power PWB | Controls the power on the primary side. | | |
| 20 | LED DL PWBs | Discharges electric charges on the OPC drums. | | |
| 21 | Flash PWB (PCU) | Includes the program to drive the PCU PWB. | | |
| 22 | High voltage TC PWB | Produces the transfer voltage. | | |
| 23 | DC power PWB | Outputs the voltage on the secondary side, and controls the heater lamp. | | |
| 24 | High voltage MC PWB | Produces a high voltage for the main charger and the developing bias voltage. | | |

[7] DESCRIPTIONS OF EACH SECTION

1. Fusing section




A. Operational descriptions

(1) Outline


This section performs the following function and operation.

- 1) Toner attached to paper in the transport section is fused onto paper by heat and pressure of the heat roller.

(2) Electrical section



(3) Major parts/signals functions and operations




| No. | Name | Code, Signal name | Function |
|-----|------------------------------|----------------------------|--|
| 1 | Heat roller | — | Heats and presses toner to fuse it on paper. Silicon rubber rollers are used as the upper and the lower heat rollers. Teflon tube is wound around the upper heat roller. |
| 2 | Upper/lower separation pawls | — | Mechanically separate paper from the heat roller, which was not separated naturally. |
| 3 | Heater lamp | Upper: HL1, Lower: HL2 | Heats the heat rollers. |
| 4 | Thermistor | Upper: THSU, Lower: THSD | Detects the surface temperature of the heat roller. (Keeps the roller surface temperature at a constant level.) |
| 5 | Thermostat | Upper: HLTS1, Lower: HLTS2 | Cuts conduction of the heater lamp when an abnormally high temperature is detected. |
| 6 | Paper exit sensor | POD1 | Detects paper discharged from the fusing section. |
| RW | Control signal | FUSM_A, A', B, B' | Drives the fusing section. |
| RW | Control signal | FUCHin | Fusing unit installation detecting signal |
| RW | Control signal | DSWL | Left cabinet open/close detection signal |
| RW | Control signal | HLPR | Heater lamp power relay (in the DC power PWB) drive signal |

RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

(4) Operational descriptions

a. Fusing unit drive

To drive the fusing unit, drive power is transmitted from the drive motor (FUSM) through the connection gear to the upper heat roller gear. The drive motor (stepping motor) is driven by the motor drive IC in the driver PWB according to the control signal sent from the PCU.




b. Heater lamp drive

The surface temperature detected by the thermistor is sent to the PCU. When the temperature is lower than the specified level, the PCU sends the heater lamp lighting signal to the heater lamp drive circuit in the DC power PWB. The triac in the heater lamp drive circuit is turned on to apply AC power to the heater lamp, which turns on to heat the heat rollers. The thermostats are provided as a safety measure to prevent against an abnormally high temperature of the heat rollers. When the thermostat is opened, the power supply (AC neutral) to the heater lamp is cut off.

c. Fusing operation

Color toner of YMCK on paper is heated and pressed by the heat rollers to be fused on paper. At that time, color toner of YMCK is mixed to reproduce nearly actual colors of document images.



The upper and the lower heat rollers are provided to heat from above and below. This is because it is necessary to heat four layers of toner from above and below and right and left to fuse it on paper. The upper and lower heat rollers are of silicon rubber. This is because of the following reasons:

- 1) To provide a greater nip quantity and a higher heating capacity for paper.
- 2) The soft, flexible rollers press multi-layer toner without deformation to fuse on paper.
- 3) An even pressure is applied to an uneven surface of multi-layer toner.

d. Fusing temperature control

The temperature sensor is provided at the center of the upper and the lower heat rollers.

The temperature sensor at the center detects the heat roller temperature and controls the heater lamp to keep the fusing temperature at the specified level.

The fusing temperature is switched according to the machine condition and paper type selected.



| | Upper heat roller | | Lower heat roller |
|-----------------|-------------------|-------|-------------------|
| Ready state | 170°C | | 120°C |
| Power save mode | 143°C | | OFF |
| Print mode | Normal paper | 175°C | 140°C |
| | OHP sheet | 170°C | 155°C |
| | Heavy paper 1 | 175°C | 136°C |
| | Heavy paper 2 | 175°C | 145°C |
| | Envelope | 180°C | 145°C |

B. Disassembly/Assembly/Maintenance

(1) Fusing section maintenance target parts

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|----------------|-----|---------------------|--------------|-----|------|------|------|------|------|------|------|---|
| Fusing section | 1 | Upper heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Lower heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 3 | Heat roller gear | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 4 | Heat roller bearing | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 5 | Separation pawl | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Thermistor | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | — | Bearings | × | × | × | × | × | × | × | × | × | |
| | 7 | Gears | × | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 8 | Paper guides | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 9 | Paper exit roller | × | × | × | × | × | × | × | × | × | |
| | — | Fusing unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |




(2) Maintenance parts replacement procedure

a. Fusing unit removal

- 1) Open the left cabinet.




- 2) Loosen the roller knob (A) and remove the fusing unit (B).




b. Upper thermistor

- 1) Remove the fusing unit from the machine.
- 2) Remove the screw and the harness cover (A).
- 3) Remove the connector, the screw, and the harness, and remove the thermistor (B).




c. Lower thermistor

- 1) Remove the fusing unit from the machine.
- 2) Remove the screws, and remove the fusing front PG (A).
- 3) Remove the connector, the screw, and the harness, and remove the thermistor (B).




d. Upper heater lamp

- 1) Remove the fusing unit from the machine.
- 2) Remove the screw and remove the fusing front cover (A). Remove the harness cover (B).
- 3) Remove the connector, the screw, and the lamp holder (C), and remove the upper heater lamp.




e. Lower heater lamp

- 1) Remove the fusing unit from the machine.
- 2) Remove the screw, and remove the fusing front cover (A).
- 3) Remove the screw, and remove the fusing front PG (B).
- 4) Remove the connector, the screw, and the lamp holder (C), and remove the lower heater lamp.




f. Upper heat roller, bearing, gear


- 1) Remove the fusing unit from the machine.
- 2) Remove the lever (A), and release the roller pressure.
- 3) Remove the screw.




- 4) Open the upper fusing section.




- 5) Remove the heat roller upper unit (B).



* When assembling, put the flanges of the upper bearings outside of the frames F and R.




- 6) Remove the C-ring and the bearing, and remove the gear (A) and the heat roller (B).




g. Lower heat roller, bearing

- 1) Remove the fusing unit from the machine.
- 2) Remove the screw, and open the upper fusing section.
- 3) Remove the lower heat roller unit (B).




- 4) Remove the C-ring and the bearing (A), and remove the heat roller (B).



h. Paper guide


- 1) Remove the fusing unit from the machine.
- 2) Remove the screw, and remove the paper guide.



Note: Refer to the adjustment (ADJ13) when installing the paper guide.

i. Paper exit roller

- 1) Remove the fusing unit from the machine.
- 2) Open the upper fusing section.
- 3) Remove the E-ring (A), and shift the bearing (B).
- 4) Remove the paper exit roller unit (C).




- 5) Remove the E-ring, the gear, the pin, and the bearing.




j. Lower separation pawl


- 1) Remove the fusing unit from the machine.
- 2) Open the upper fusing section.
- 3) Remove the paper exit roller unit.
- 4) Lift the separation pawl and shift it to the right and lift it from the heat roller.



- 5) Remove the POD1 connector.
- 6) Remove the screw, and slide and remove the lower separation pawl mounting plate.




- 7) Rotate the separation pawl in direction A and remove it from the mounting plate. Remove the spring.



Note: When attaching the separation pawl, check that the separation pawl is in contact with the heat roller.

2. Transfer section




A. Operational descriptions

(1) Outline




This section functions and operates as follows:

- 1) A high, positive voltage is applied to the transfer roller to charge the transfer belt and paper on it positively, attracting negatively charged toner images on the OPC drum onto paper.

(2) Electrical and mechanical sections



(3) Major parts/signals functions and operations



| No. | Name | Code, signal name | Function |
|-----|-----------------------------------|---------------------------------|--|
| 1 | Transfer belt | — | Transfers toner images on the OPC drum onto paper. |
| 2 | Transfer roller | — | Applies a transfer voltage to the transfer belt. |
| 3 | Belt cleaning blade | — | Cleans and removes toner from the transfer belt. |
| 4 | Transfer discharge sheet | — | Discharges the transfer belt. |
| 5 | Transfer belt cleaning roller | — | Removes paper dust from the transfer belt. |
| 6 | Transfer belt drive roller | — | Drives the transfer belt. |
| 7 | Transfer belt follower roller | — | Transfer drive follower roller |
| 8 | Transfer belt cleaning brush | — | Cleans the back surface of the transfer belt. |
| 9 | Process control sensor | Monochrome: PCSK Color: PCSC | Detects the toner patch density in image density correction. |
| 10 | Transfer waste toner tank | — | Collects waste toner on the transfer belt. |
| RW | Belt motor | BTM | Drives the transfer belt. |
| RW | Calibration solenoid | CALS | Drives the shutter on the process control sensor. |
| RW | Waste toner full detection switch | BTNF | Detects waste toner full in the waste toner box. |
| RW | Belt lift-up motor | BLUM | Lifts up the transfer belt unit. |
| RW | Belt lift-up sensor | BLUD | Detects the position of the transfer belt unit. |
| RW | Control signal | TC (K, C, M, Y) | Each color transfer high voltage control signal |
| RW | Control signal | THV (K, C, M, Y) | Each color transfer high voltage |

RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

(4) Operational descriptions

a. Transfer belt drive


The transfer belt drive power is transmitted from the drive motor (BTM) to the transfer drive roller.

The motor (stepping motor) is driven by the drive signal sent from the PCU.

b. Applying a transfer high voltage to the transfer roller

According to the high voltage control signal from the PCU, the signal is converted into a transfer high voltage control signal with the HV (MC) PWB, and sent to the HV (TC) PWB.

According to each color transfer high voltage control signal, a high voltage is applied to each transfer roller from the transfer high voltage HV (TC) PWB through the connection spring to each transfer roller.



c. Process control sensor control

The process control shutter is provided on the process control sensor of monochrome (PCSK) and color (PCSC). When the shutter is open (in image density correction and automatic registration), the toner patch formed on the transfer belt is read by the process control sensor, and its information is sent to the PCU.


When the shutter is closed, the calibration sheet is read to perform calibration of the sensor itself.

The shutter operation is controlled by the calibration solenoid (CALS).

d. Belt waste toner full detection

Toner scraped by the belt cleaning blade is transported to the waste toner box by the belt waste toner transport shaft.

When the waste toner box is full, the rotation load of the waste toner transport shaft increases to turn on the waste toner full detection switch with the lever by the torque limiter function.



e. Transfer belt unit up and down


In color print, the transfer belt is in contact with four OPC drums. In black and white print, the transfer belt unit moves down so that only the black OPC drum is in contact with the transfer belt.

This up-and-down movement of the transfer belt is performed by the lift-up motor (BLUM), the lift-up cam, and the unit position sensor (BLUD).

When the left cabinet is opened for jam process, the rotating mechanism of the lift-up unit separates all four OPC drums from the transfer belt.


• Transfer belt position for color print

The four OPC drums are in contact with the transfer belt by rotation of the cam in the transfer lift-up unit.




• Transfer belt position for black print

Only the black OPC drum is in contact with the transfer belt by rotation of the cam in the transfer lift-up unit.



• Transfer belt position in jam process or replacement of the transfer belt

When the left cabinet is opened, the transfer lift-up unit moves down, and the transfer unit moves by 9mm accordingly.




B. Disassembly/assembly/maintenance



(1) Transfer section maintenance target parts

X: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position

| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|------------------|-----|-------------------------------|--------------|-----|------|------|------|------|------|------|------|---|
| Transfer section | 1 | Transfer belt | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Transfer roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 3 | Transfer belt cleaning blade | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 4 | Transfer discharge sheet | | × | ○ | × | ○ | × | ○ | × | ○ | |
| | 5 | Transfer belt cleaning roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Transfer drive roller | | × | × | × | × | × | × | × | × | |
| | 7 | Transfer follower roller | | × | × | × | × | × | × | × | × | |
| | 8 | Transfer discharge brush | | × | × | × | × | × | × | × | × | |
| | 9 | Sensors | | × | × | × | × | × | × | × | × | |
| | 10 | Waste toner tank unit | ▲ | × | ▲ | × | ▲ | × | ▲ | × | ▲ | When waste toner full is detected. |
| | 11 | Transfer belt unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |




TX belt clean blade seals.




(2) Maintenance parts replacement procedure

a. Transfer unit removal

- 1) Open the left cabinet, and remove the fusing unit. (Refer to the section of the fusing unit.)
- 2) Hold section A of the transfer unit and pull it in the arrow direction so that you can hold both sides of the unit.
- 3) Hold both sides B and remove the transfer unit from the machine.




Note: Be careful not to scratch the surface of the transfer belt.




b. Belt drive motor

- 1) Remove the transfer unit from the machine.
- 2) Remove the screw, and remove the belt cover gear.




- 3) Remove the connector, the screw, and the motor.




c. Process control sensor


- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.




- 3) Remove the spring from the hook section.
- 4) Remove the hook, and remove the process control shutter.




Cleaning: Clean the calibration sheet. (Wipe with soft, dry cloth.)



- 5) Remove the connector, and remove the process control sensor.




Cleaning: Clean the sensor surface.




d. PWB

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the spring from the hook section.
- 4) Remove the process control shutter.
- 5) Remove the connector (A).
- 6) Remove the connector (B) and the screw, and remove the PWB.




e. Waste toner tank unit

- 1) Remove the transfer unit from the machine.
- 2) Remove the connectors and the screws, and remove the belt drive unit.
- 3) Remove the waste toner tank unit.




Note for assembly:

Insert the notches A and B of the waste toner tank unit into the positions in the transfer frame indicated in the figure below.




f. Transfer belt

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the lower screw.



Note: If the upper screw is removed and folded, the electrode is deformed. Therefore, be sure to remove the lower screw.

- 4) Fold the transfer belt housing and remove the transfer belt.




Note for installation:

When installing the transfer belt, be sure to place the lot number section marked inside the transfer belt on the front side.

g. Transfer roller

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the transfer belt.
- 4) Disengage the pawl, and remove the bearing and the transfer roller.




Note for assembly:

There are two different transfer roller bearings: black and white. The black bearing is conductive, and must be attached to the electrode side (rear frame side).


h. Transfer drive roller

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the transfer belt.
- 4) Remove the E-ring and the bearing, and remove the transfer drive roller.




i. Transfer follower roller

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the transfer belt.
- 4) Remove the E-ring and the bearing, and remove the transfer follower roller.




j. Transfer cleaning blade

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the waste toner tank unit.
- 4) Remove the screw, and remove the transfer cleaning blade.




k. Transfer belt cleaning roller

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the waste toner tank unit.
- 4) Press the cleaning lever in the arrow direction A, extend the pawl in the arrow direction B, and pull up the cleaning level in the arrow direction C.
- 5) Remove the transfer belt cleaning roller.




I. Belt cleaning brush

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the transfer belt.
- 4) Remove the Belt cleaning brush.




m. Transfer discharge sheets.

- 1) Remove the transfer unit from the machine.
- 2) Remove the connector and the screw, and remove the belt drive unit.
- 3) Remove the transfer belt.
- 4) Remove the terminals.




- 5) Remove the transfer discharge sheets.




n. Transfer lift-up unit



- 1) Remove the screw, and remove the left cabinet of the machine.




- 2) Remove the connector.
- 3) Adjust the rail positions so that section A does not make contact with the acuride section when the transfer lift-up unit is lifted up.



- 4) Lift the transfer lift-up unit in the arrow direction B with section A as the fulcrum, and remove it.



3. Process (image forming) section




A. Operational descriptions

(1) Outline


This section functions and operates as follows:

1) In this section, the LED is lighted according to the data sent from the image process section to form electrostatic latent images on the OPC drums which are charged evenly by the main charger, and toner is attached to the electrostatic latent images.

(2) Electrical and mechanical sections



(3) Major parts/signals functions and operations



| No. | Name | Code, Signal name | Function |
|-----|-----------------------------|-------------------|---|
| 1 | OPC drum (YMCK) | — | Forms electrostatic latent images. |
| 2 | Main charger (YMCK) | MC | Charges the OPC drum surface negatively. |
| 3 | Discharge lens | — | Discharges the OPC drum surface. |
| 4 | Cleaning blade | — | Cleans the OPC drum surface to remove residual toner. |
| 5 | Toner reception seal | — | Seals to prevent against toner leakage. |
| 6 | Waste toner transport screw | — | Transports toner scraped by the cleaning blade to the waste toner box of the toner cartridge. |
| 7 | MC cleaner | — | Cleans the MC (charging plate). |
| 8 | LED unit | — | Converts image signals into LED light and radiates it onto the OPC drum. |
| 9 | Developing roller | — | Attaches toner to the OPC drum. (Do not touch the developing roller.) |
| 10 | DV CRUM (Y, M, C, K) | — | Memory for toner cartridge data (counter, etc.) |
| 11 | Waste toner box | — | Collects waste toner transported from the drum cartridge. |
| RW | Grid biks | GB | Controls the drum surface potential. |
| RW | Discharge lamp | DL | Radiates lights onto the discharge lens. |
| RW | Drum motor A, A', B, B' | DM A, A', B, B' | Drives the OPC drum. |
| RW | Toner empty sensor | TES | Detects the toner quantity in the toner cartridge. |

RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

(4) Operational descriptions

a. Drum cartridge and toner cartridge drive

The drive power for the drum cartridges are transmitted from the drive motor (DM) to the drum gears.

The toner cartridge is driven through the drum gear and the connection gear.

The motor (stepping motor) for black is driven by the drive signal sent directly from the PCU, and the motors color are driven by the drive signals sent from the PCU through the driver PWB.

b. LED (writing) unit

Four LED (writing) units are provided for each of Yellow, Magenta, Cyan, and Black.

Each LED (writing) unit converts YMCK dot image data outputted from the ICU PWB into LED light, and radiate the light onto the OPC drum, forming electrostatic latent images on the OPC drum.

Since the position of each LED unit of CMYK is shifted in the paper transport direction, the above operation depends on the relative position and differs in the operating timing.


• LED unit composition

| Item | | Content |
|----------------------|---------------------|-------------|
| Print width | | 314mm |
| Total number of dots | | 7424 dot |
| Resolution | | 600dpi |
| LED composition | Number of LED chips | 58 chip |
| | Number of dots | 128 dot |
| Lens | | Selfoc lens |

c. OPC drum section operations


The OPC drum surface is charged negatively by the main charger, and LED light of images are radiated onto the OPC drum surface by the LED (writing) unit to form electrostatic latent images.

1) The OPC drum surface is negatively charged by the main charger.



The screen grid is attached to the main charger unit. The OPC drum is charged at a voltage nearly same as the voltage applied to the screen grid.

2) LED light is radiated onto the OPC drum surface by the LED (writing) unit to form electrostatic latent images.




When LED light is radiated onto the OPC drum CGL, positive and negative charges are generated. Positive charges generated in the CGL are attracted and moved by negative charges of the OPC drum, and negative charges by positive charges of the aluminum layer of the OPC drum. Therefore, on the OPC drum surface and in the aluminum layer, positive and negative charges are neutralized, reducing the OPC drum surface potential.

Electric charges remain in the areas where LED light is not radiated onto the OPC drum.

As a result, electrostatic latent images are formed on the OPC drum surface.


Charges are disposed in direct proportion to the amount of light received.

3) Clean and remove residual toner from the OPC drum with the cleaning blade after transfer operations.



Removed residual toner is transported to the waste toner section of the toner cartridge by the waste toner transport screw.


4) The whole surface of the OPC drum is discharged.



By radiating discharge lamp light onto the discharge lens, light is radiated through the discharge lens to the OPC drum surface.


When discharge lamp light is radiated onto the OPC drum CGL, positive and negative charges are generated.

Positive charges generated in the CGL are attracted and moved by negative charges of the OPC drum, and negative charges by positive charges of the aluminum layer of the OPC drum. Therefore, on the OPC drum surface and in the aluminum layer, positive and negative charges are neutralized, reducing the OPC drum surface potential, preparing the drum surface for the new copy cycle.



d. Developing section (composed of four units of YMCK) operations

Electrostatic latent images generated on the OPC drum by the LED (writing) units are converted into visible images by toner.



Toner in the developing unit is agitated by the mixing roller.

By mixing operation, toner is negatively charged due to mechanical friction.

The developing bias voltage (negative) is applied to the developing roller.


The difference for the voltage potential between the toner and DV roller surface attracts the toner to the DV roller.

In the areas of the OPC drum, when the charge was detected, the voltage potential difference is greater than the DV roller. Therefore the toner is attracted from the DV roller to the drum.

In the unexposed areas of the drum, the potential on the DV roller created by the bias voltage and therefore the toner to not attracted to those areas of the drum.


Negatively charged toner is attracted and attached to the exposed area on the OPC drum surface where the negative potential was reduced by LED exposure.

On the other hand, in the areas on the OPC drum where exposure was not made, the positive potential is higher than the developing bias voltage, repelling toner.




<1> Remaining toner quantity detection

Rotation of the detection lever connected to the mixing roller is sensed by the sensor (TES) to detect the remaining toner quantity.



<2> Waste toner collection

Waste toner collected by the drum cleaning blade is transported to the waste toner box of the toner cartridge by the toner transport spring in the drum unit.




B. Disassembly/assembly/maintenance

(1) Process section maintenance target parts

X: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position

| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|--|-----|----------------------|---------------------------------------|-----|------|------|------|------|------|------|------|-------------------------|
| Drum module | 1 | Drum (Black/color) | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Charging unit | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 3 | Cleaner blade | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 4 | Toner reception seal | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 5 | Drum cartridge | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | When replacing the unit |
| Developing section (integrated with toner cartridge) | 6 | Toner cartridge | User replacement at every toner empty | | | | | | | | | |
| LED | 7 | LED lens | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |


Note: When replacing the OPC drum, execute SIM 25-1 for 2 minutes. (This simulation is executed in order to avoid generation of stripes on a half-tone print image.)




(2) Maintenance parts/major parts replacement

a. Drum unit removal

- 1) Open the front cabinet and left cabinet.



- 2) Turn the fixing screw in the arrow direction A to release it, and remove the drum unit in the arrow direction B.




Note: Be sure to open the left cabinet before releasing the fixing screw.

If the fixing screw is released before opening the left cabinet, the lock cannot be released.

In that case, push the drum unit to the rear frame side and release the lock, and remove the drum unit.


b. Drum removal

- 1) Remove the drum unit.
- 2) Remove the retaining clip from the drum shaft (A).
- 3) Slide the drum shaft in the arrow direction B.
- 4) Remove the drum in the arrow direction C.



c. Charging unit


- 1) Remove the drum unit.
- 2) Remove the screw and remove the cover (A).
- 3) Remove the MC unit from the MC cleaning shaft.
- 4) Remove the charging unit (C).



* When assembling, attach the drum, then attach the charging unit. (This is to prevent against dirt by starting powder applied to the drum.)


d. Cleaner blade

- 1) Remove the drum unit.
- 2) Remove the charging unit.
- 3) Remove (A).
- 4) Remove the screw, and remove the cleaner blade.



e. Toner reception seal


- 1) Remove the drum unit.
- 2) Remove the drum.
- 3) Remove the screw, and remove the toner reception seal.




Note: Do not deform the seal.

f. MC cleaner


- 1) Remove the drum unit.
- 2) Remove the screw, and remove cover (A).
- 3) Remove the MC unit.
- 4) Disengage the pawl, and remove the MC case in the arrow direction.



- 5) Remove the screen grid.




- 6) Disengage the pawl, and remove the MC cleaner.



g. Developing unit removal


- 1) Open the front cabinet and the left cabinet of the machine.
- 2) Lift the lever in the arrow direction A, and remove the developing unit in the arrow direction B.





h. LED unit removal

- 1) Remove the rear cabinet.
- 2) Remove the PCU PWB unit.
- 3) Remove the drum unit.
- 4) Remove the developing unit.


- 5) Remove the top cover, and disconnect the connector of the ICU.




- 6) Remove the screw (A) on the rear side, and remove the LED unit.




- 7) Remove the LED unit.
- 8) Remove the connector cover and the harness.



i. LED lens cleaning



4. Optical section (Scanner section)




A. Operational descriptions

(1) Outline


This section functions and operates as follows:

- 1) The copy lamp radiates light onto the document, and the reflected light is scanned by the three line (RGB) CCD element and then converted into image signals (analog).
- 2) The image signals (analog) are converted into 8bit digital signals by the A/D converter.
- 3) The image signals (digital) are sent to the image process section (ICU PWB).

(2) Electrical section and mechanical section



(3) Major parts and signals functions and operations



| No. | Name | Code, Signal name | Function |
|-----|-----------------------------------|-------------------|--|
| 1 | Scanner motor | SM | Drives the copy lamp unit and the mirror base unit. |
| 2 | Pulley belt | — | Transmits drive power of the scanner motor to the pulley. |
| 3 | Pulley | — | Drives the scanner drive wire. |
| 4 | Scanner drive wire | — | Transmits drive power of the scanner motor to the copy lamp unit and the mirror base unit. |
| 5 | Scanner unit home position sensor | MHPS | Detects the home position of the copy lamp unit. |
| 6 | Shading glass | — | Reference glass for shading correction |
| 7 | Copy lamp | CL | Radiates light onto documents. (Xenon lamp) |
| 8 | Reflector | — | Converges light from the copy lamp. |
| 9 | No. 2 mirror | — | Sends document images to No. 3 mirror. |
| 10 | No. 3 mirror | — | Sends document images to the lens. |
| 11 | Lens | — | Reduces document images (photo images) and projects them to the CCD. |
| 12 | CCD PWB | — | Receives the document image (photo signals) and converts them into electrical signals. |
| RW | Inverter PWB | LAMP | Drives the copy lamp (Xenon lamp). |
| RW | Scanner motor drive | SM A, A', R, B' | |
| RW | MHPS | MHPS | Scanner home position detect jam |

RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

(4) Operational descriptions

a. Optical section drive

The optical section drive power is transmitted from the drive motor (SM) through the belt, the drive pulley, and the wire to drive the copy lamp unit and the mirror base which are attached by the drive wires.

The drive motor (stepping motor) is controlled by the drive signal sent from the MFP PWB.

b. Copy lamp drive

The copy lamp is driven by the copy lamp drive voltage generated in the inverter PWB according to the control signal sent from the MFP PWB.

c. Image scan/color separation

The CCD element, appeared as one unit, but has three separate rows of CCD elements drive each for (RGB).

Light is radiated to a document by the copy lamp (Xenon lamp), and the brightness of the reflected light is received by the three line (RGB) CCD element and converted into (analog) image signals.

Each color component of RGB is separately extracted from the document image by the three lines (RGB) of the CCD elements.

The red CCD extracts the red components from the document image, the green CCD the green components, and the blue CCD the blue components. This operation is called Color Separation.


The CCD element, appeared as one unit, but has three separate rows of CCD elements drive each for (RGB).

Scanning of a document in the main scanning direction is performed by the CCD elements. Scanning of a document in the sub scanning direction is performed by shifting the scanner unit position with the scanner motor.

Document images are optically reduced by the lens and projected to the CCD elements.


The scanning resolution is 600dpi × 600dpi.

(Image data for one line)



d. Image signal A/D conversion

- 1) Each image signal (analog) of RGB is converted into 8bit digital signal by the A/D converter. Each color pixel has 8bit information (256 gradations).
- 2) Each 8bit digital image signal of RGB is sent to the image process section.





e. Zooming operation

Zooming in the sub scanning direction is performed by changing the scanning speed in the sub scanning direction.

Zooming in the main scanning direction is not performed optically but by the image process technology (software).

3 LINES CCD UNIT




B. Disassembly/assembly/maintenance

(1) Transfer section maintenance target parts

X: Check (Clean, replace, or adjust as necessary.) O: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|-----------------|-----|---------------------------------|--------------|-----|------|------|------|------|------|------|------|--------|
| Optical section | 1 | CCD, mirror, lens, reflector | | O | O | O | O | O | O | O | O | |
| | 2 | Table glass, sensors, OC | | O | O | O | O | O | O | O | O | |
| | 3 | Shading glass | | O | O | O | O | O | O | O | O | |
| | 4 | Rails | | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 5 | Drive wire, pulley, pulley belt | | X | X | X | X | X | X | X | X | |



(2) Major parts replacement


a. MFP PWB

- 1) Open the upper cabinet rear cover.
- 2) Remove the connector and the screw, and remove the scanner control PWB unit. Remove the screw and remove the scanner control PWB (A).




b. CCD unit

- 1) Remove the screw, the glass holder right (A), the glass holder left (B), and the table glass (C).




- 2) Remove the screw and the dark box cover (A). Remove the connector, the screw, and the CCD unit (B).




c. Lamp unit

- 1) Shift the lamp unit to the position shown below. Loosen the screw and remove the wire.




- 2) Rotate the lamp unit and lift it, and remove the harness holder and the harness. Remove the lamp unit.




d. Xenon lamp

- 1) Remove the lamp unit.
- 2) Remove the harness and the screw, and remove the Xenon lamp.




e. Scanner motor

- 1) Remove the upper cabinet rear unit.
- 2) Remove the connector, the screw, and the belt. Remove the motor.




f. MHPS

- 1) Remove the upper cabinet rear unit.
- 2) Remove the screw and remove the upper cabinet left. Remove the screw and the connector, and remove the MHPS.



5. Paper feed, paper transport, and paper exit sections



A. Operational descriptions

(1) Outline

This model is provided with a cassette paper feed tray and a manual paper feed tray as standard provision.


As an option, either the 3-stage paper feed cassette module (AR-D18) or the 2-stage duplex paper feed cassette module (AR-D19) can be installed.

The paper transport section transports paper from each paper feed port to the PS roller section.


Paper with images transferred on it in the transfer section is passed to the fusing section, and discharged to the face-up tray or the face-down tray.

(2) Electrical section and mechanical section

a. Cassette paper feed, paper transport, and paper exit sections




b. Manual paper feed section



(3) Major parts and signals functions and operations


a. Manual paper feed unit



| No. | Name | Code, Signal name | Function |
|-----|------------------------------|-------------------|---|
| RW | Paper detector | MPED | Detects paper empty/presence in the paper tray. |
| 1 | Paper size (width) adjuster | — | Adjusts the paper position. |
| 2 | Paper size (width) sensor | MPWS | Detects the paper width. |
| 3 | Paper size (length) detector | MPLD1 | Detects the paper length. |
| 4 | Paper size (length) detector | MPLD2 | Detects the paper length. |
| 5 | Tray position detector | MTOPI | Detects the paper tray position. |
| 6 | Tray position detector | MTOPI2 | Detects the paper tray position. |
| 7 | Paper pickup roller | — | Sends paper to the paper feed roller. |
| 8 | Manual paper feed roller | — | Feeds paper to the paper transport section. |
| 9 | Manual paper feed clutch | MPFC | Transmits the paper feed drive motor power to the manual paper feed roller. |
| 10 | Separation roller | — | Separates paper and transmits it to the paper feed unit. |
| RW | Manual transport clutch | — | Transmits the paper feed motor power to the manual paper feed unit. |
| RW | Paper feed motor | — | Drives the paper feed section and the manual paper feed unit. |


RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

b. Paper tray lift unit




| No. | Name | Code, Signal name | Function |
|-----|----------------------------------|-------------------|--|
| 1 | Paper tray lift unit | — | Drives the paper tray lift plate. |
| 2 | Paper size detection actuator | — | Transmits the status data (ãðìþ) of the paper size block to the paper size detector. |
| 3 | Paper tray lift unit control PWB | — | Controls the paper tray lift unit. |
| 4 | Lift motor | LUMx | Drives the lift plate. |
| 5 | Paper size detector (switch) | CxSSx | Detects the paper size set by the paper size set block. |
| 6 | Lift position sensor | CxPDx | Detects the lift plate position. |

c. Paper feed unit



| No. | Name | Code, Signal name | Function |
|-----|----------------------------|-------------------|---|
| 1 | Paper tray paper feed unit | — | Feeds paper from the paper tray to the transport section. |
| 2A | Paper empty detector | PEDx | Detects paper empty in the paper tray. |
| 2B | Paper upper limit detector | LUDx | Detects the paper upper limit position. (Keeps the friction between the paper pickup roller and paper at a constant level.) |
| 3 | Paper pickup roller | — | Feeds paper to the paper feed roller. |
| 4 | Paper feed clutch | CPFCx | Controls ON/OFF of the paper feed roller. |
| 5 | Paper feed roller | — | Feeds paper to the paper transport section. |
| 6 | Separation roller | — | Separates paper to prevent against double feed. |

d. Paper exit section



| No. | Name | Code, Signal name | Function |
|-----|---------------------------------|-------------------|---|
| 1 | Paper exit sensor | POD2 | Detects discharged paper. |
| 2 | Offset motor | OSM | Drives the paper exit offset. |
| 3 | Shifter home position sensor | HPOS | Detects the offset home position. |
| 4 | FD paper exit full sensor | TFD | Detects the face-down paper exit tray full. |
| 5 | Paper exit switch gate solenoid | GSS | Drives the face-up/down switch gate. |
| 6 | FU paper exit full sensor | | |

(4) Operational descriptions




a. Paper feed tray section operation

The paper pickup roller moves up and down to press paper and separates the top paper, which is fed to the paper feed roller.

The paper feed roller feeds paper to the paper transport section. The separation roller prevents against double feed.

Up and down movement of the pickup roller is driven by the pickup solenoid, and ON/OFF control of the pickup roller and the paper feed roller is performed by the paper feed clutch.

The lift position is detected by the paper upper limit detector to control the pressure between the top paper and the pickup roller.



The paper lift plate lifts paper to control the upper limit position of paper so that the pressure between the top paper and the pickups roller remains constant. Lifting is performed by the lift motor and the lift gear.

The paper feed tray is provided with the paper size detection block, and the status (âp) of this block is detected with the combination of ON/OFF of the four paper size detectors to recognize the paper size. Relationship between the paper size detector and the paper size

| Paper size detector | | | | Paper size | | |
|---------------------------|------|------|------|---|-----------|-------------|
| | | | | Destination | | |
| CSS4 | CSS3 | CSS2 | CSS1 | Japan | AB series | Inch series |
| ON | OFF | OFF | ON | A3 | A3 | 11 x 17 |
| OFF | OFF | ON | ON | B4 | B4 | 8.5 x 14 |
| ON | OFF | ON | OFF | A4R | A4R | 11 x 8.5R |
| OFF | ON | ON | OFF | A4 | A4 | 11 x 8.5 |
| OFF | ON | ON | ON | B5R | B5 | INVOICE |
| OFF | ON | OFF | ON | B5 | A5 | FOOLSCAP |
| ON | ON | ON | OFF | A5 | 11 x 8.5 | A4 |
| ON | ON | OFF | OFF | EXTRA | EXTRA | EXTRA |
| Patterns other than above | | | | Recognized that the paper tray is not inserted. | | |

EXTRA: Operates with the paper size set by the user program.

The lift position sensor detects the lift plate lower limit position. Then lift-up operation is started, and the rotation of the lift motor up to detection of the upper limit by the paper upper limit detector is used to calculate the paper remaining quantity.



b. Manual paper feed section operation

The paper pickup roller moves up and down to press paper and separates the top paper, which is fed to the paper feed roller.

The paper feed roller feeds paper to the paper transport section. The separation roller prevents against double feed.

The manual paper feed clutch controls ON/OFF of the pickup roller and the paper feed roller.

The manual transport roller transports paper to the resist roller.





The paper size is detected by the paper length detector and the paper width sensor.

A volume-type sensor is used as the paper width sensor. The resistance varies according to variation of the paper guide position to detect the paper width.

The tray position detector detects that the paper tray is set to the maximum length position or to the minimum length position.


When the paper tray is set to the maximum length position, the paper length detector is forcibly turned ON. This is to recognize it.



c. Paper transport section

This section transports paper from each paper feed section to the transfer section (resist roller) by two transport rollers.

The paper transport clutch controls ON/OFF of each transport roller.




d. Paper resist section

The resist roller controls the relative position of the transported paper and the transfer image.

The resist roller is driven by the resist roller motor.

The relative position of paper and the transfer image is determined by the ON timing of the resist roller motor.



e. Others

* The paper transport section is provided with two paper detectors, which perform the following functions:


- 1) Paper jam detection
- 2) Output of the reference signal for the operating timing of each load

B. Disassembly/assembly/maintenance

(1) Paper feed/transport sections maintenance target parts

X: Check (Clean, replace, or adjust as necessary.) O: Clean ▲: Replace Δ: Adjust ☆: Lubricate □: Shift position

| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|--------------------|-----|---|--------------|-----|------|------|------|------|------|------|------|---|
| Paper feed section | 1 | Paper feed rollers in the cassette section | O | O | X | O | X | O | X | O | X | Replace at the specified count at each paper feed port or within 2 years. |
| | 2 | Torque limiter | X | | X | | X | | X | | X | |
| | 3 | Paper feed rollers in the manual paper feed section | O | X | X | X | X | X | X | X | X | Replace at the specified count at each paper feed port or within 2 years. |
| | 4 | Torque limiter | X | X | X | X | X | X | X | X | X | |
| Transport section | 5 | Transport rollers | O | O | O | O | O | O | O | O | O | |
| | 6 | Transport paper guide | O | O | O | O | O | O | O | O | O | |




(2) Maintenance parts and major parts replacement


a. Cassette paper feed

<1> Pickup roller

- 1) Remove the cassette.




- 2) Disengage the pawl, and remove the pickup roller.



Note: Do not remove the transfer belt unit.


<2> Paper feed roller, torque limiter

- 1) Remove the cassette.
- 2) Disengage the pawl, and remove the paper feed roller.




<3> Paper separation roller, torque limiter

- 1) Remove the cassette.
- 2) Disengage the pawl, and remove the paper separation roller.




<4> Cassette paper feed unit

- 1) Open the front cabinet, and remove the drum unit.




- 2) Remove the developing unit.




- 3) Remove the front cabinet and the front frame cover.
- 4) Remove the multi manual paper feed unit.
- 5) Remove the connection right cabinet, the rear cabinet, and the rear right cabinet.
- 6) Remove the screw and the paper feed unit. Remove the connector.

* When assembling, fit the positioning pin A with section C.




<5> Paper feed drive motor

- 1) Remove the screw, the rear cabinet, the rear right cabinet, and the connection right cabinet B.
- 2) Remove the screw, and remove the paper feed drive motor.



<6> Paper feed drive unit


- 1) Remove the harness and the screw, and remove the paper feed drive unit.



b. Multi manual paper feed


<1> Pickup roller

- 1) Open the arm cover (A). Disengage the pawl, and remove the pickup roller (B).




<2> Paper feed roller

- 1) Open the arm cover (A), open the auxiliary PG (B), and remove the paper feed roller (C).




<3> Paper separation roller

- 1) Open the vertical transport guide.




- 2) Open the maintenance cover (A) from the bottom of the multi paper feed unit. Disengage the pawl and remove the paper feed separation roller (B).




<4> Multi manual paper feed unit

- 1) Remove the screw and the harness, and remove the multi paper feed unit.




<5> Paper feed clutch

- 1) Remove the screw and the cover (A). Remove the connector and the E-ring, and remove the paper feed clutch (B).



<6> Transport roller


- 1) Remove the bottom lid (A), remove the connector and the screw, and remove the cover (B).




* When assembling, fit the cover projection with the spring.

- 2) Remove the screw, and remove (A) and (B).


* When assembling, first attach (A), then attach (C) and (D).




- 3) Remove the screw and the E-ring, and remove the angle (A) and the gear.



- 4) Remove the screw, and remove (A) and the manual upper unit (B).




- 5) Remove the E-ring, the gear, and the bearing, and remove the transport roller.




c. Transport section

<1> Vertical transport unit

- 1) Remove the drum and the developing unit.
- 2) Remove the front cabinet.
- 3) Remove the front frame cover.
- 4) Remove the multi manual paper feed unit.
- 5) Remove the rear cabinet, the connection right cabinet, the rear right cabinet, the front right cabinet, and the right lower cabinet.
- 6) Open the vertical transport guide. Remove the screw and remove the vertical transport guide unit.




- 7) Remove the screw, and remove the vertical transport lower unit.




- 8) Remove the paper feed drive motor, and remove the connector on the rear side. Remove the screw, and shift the vertical transport unit to the left to remove.

* When assembling, engage the four bosses indicated with ○ in the figure below.




<2> Transport roller 2

- 1) Remove the vertical transport unit.
- 2) Remove the screw, and remove the paper guide (A).
- 3) Remove the resin ring, and remove the pulley (B) from the belt.
- 4) Remove the resin E-ring, slide the bearing (C), and remove the transport roller 2 unit (D).




- 5) Remove the E-ring and parts, and remove the transport rollers.




<3> Transport roller 1

- 1) Remove the vertical transport unit.
- 2) Remove the resin ring. Remove the pulley (A) from the belt.
- 3) Remove the resin E-ring, slide the bearing (B), and remove the transport roller 1 (C).




<4> PS unit

- 1) Remove the vertical transport unit.
 - 2) Remove the screw and the spring. Release the lock. Remove the belt and remove the PS unit.
- * When assembling, attach from the left with avoiding the plate in section A.




<5> Upper resist roller

- 1) Remove the vertical transport unit.
- 2) Remove the PS unit.
- 3) Remove the spring (A), and remove the upper resist roller (B).




<6> Lower resist roller

- 1) Remove the vertical transport unit.
- 2) Remove the PS unit.
- 3) Remove the upper resist roller.
- 4) Remove the parts and remove the lower resist roller.



<7> PS motor


- 1) Remove the rear cabinet, the connection right cabinet, and the rear right cabinet.
- 2) Remove the connector and the screw, and remove the process exhaust fan unit. Remove the connector and the screw, and remove the PS motor.




d. Paper exit section

<1> Slide drive motor

- 1) Open the left cabinet.
- 2) Remove the FD connection cabinet.
- 3) Remove the connector and the screw, and remove the motor unit.




- 4) Remove the connector and the screw, and remove the motor (A).




<2> FD paper exit unit

- 1) Remove the rear cabinet, the rear cabinet upper, the left cabinet, the rear left cabinet lid, the rear left cabinet, and the front cabinet upper.
 - 2) Remove the motor unit.
 - 3) Slide section (A) to the front side. Remove the screw, and disengage the pawl in section (B). Remove the FD paper exit unit (C) from the rear side and remove the connector.
- * When assembling, attach from the front side.
* When assembling, be careful not to damage the actuator (D).



<3> FD paper exit roller B


- 1) Remove the cabinet.
- 2) Remove the paper exit unit.
- 3) Remove the E-ring, the bearing, and the gear. Remove the FD paper exit roller.




<4> FD paper exit roller A

- 1) Remove the cabinet.
- 2) Remove the paper exit unit.

- 3) Remove the E-ring, (A), the screw, (B), (C), and the bearing. Remove the unit (D).




- 4) Remove the E-ring and the bearing, and remove the FD paper exit roller (A).




e. Gate solenoid unit

- 1) Open the left door, and remove the rear cabinet and the rear left cabinet.
- 2) Remove the driver PWB unit.
- 3) Remove the connector and the screw, and remove the gate solenoid unit.




f. Lift-up unit

- 1) Remove the rear cabinet and the rear right cabinet.
- 2) Remove the power PWB unit.
- 3) Remove the connector and the screw, and remove the lift-up unit.



6. Operation panel




A. Operational descriptions

(1) Outline

The operation panel unit is composed of the operation key PWB, the inverter/LVDS PWB, the LCD unit, and the operation keys, and is used to operate the machine and to set and display the machine status.

The operation key PWB is connected to the ORS light receiving PWB for detecting the document size. It receives light from the ORS light emitting PWB attached to the rear frame, detecting the document size.

(2) Electrical section and mechanical section



(3) major parts functions and operations


| No. | Name | Code, signal name | Function |
|-----|-------------------------|-------------------|---|
| RW | Operation key PWB | — | Detects a pressed key on the operation panel. |
| RW | Inverter/LVDS PWB | — | Drives the LCD and the backlight, and controls the touch panel. |
| RW | ORS light receiving PWB | — | Receives light from the ORS light emitting PWB to detect the document size. |
| RW | ORS light emitting PWB | — | Emits light for detecting the document size. |
| RW | OC switch | OCSW | Timing switch for detecting the document size |

RW: Abbreviation of Related Wiring, which means the said load is specified in the related figure of the mechanical and the electrical sections.

B. Disassembly/assembly/maintenance


a. ORS light emitting PWB

- 1) Remove the upper cabinet rear cover and the upper cabinet rear unit.
- 2) Remove the screw, and remove the document size sensor unit. Remove the screw and the document size sensor, and remove the ORS light emitting PWB.




b. OCSW

- 1) Remove the upper cabinet rear cover and the upper cabinet rear unit.
- 2) Remove the connector and the screw, and remove the OCSW.




c. ORS light receiving PWB

- 1) Remove the FD connection cabinet, the front cabinet upper, the FD paper exit port cabinet, and the operation panel plate.
- 2) Remove the connector and the screw, and remove the ORS light receiving PWB.




d. Operation key PWB

- 1) Remove the FD connection cabinet, the front cabinet upper, the FD paper exit port cabinet, and the operation panel plate.
- 2) Remove the screw, and remove A and B.
- 3) Remove the screw and the connector, and remove the operation unit.




- 4) Remove the screw and remove the operation key PWB.



e. Inverter/LVDS PWB

- 1) Remove the FD connection cabinet, the front cabinet upper, the FD paper exit port cabinet, and the operation panel plate.
- 2) Remove the connector and the screw, and remove the inverter/LVDS PWB.




7. External fitting

A. Disassembly


(1) Cabinet disassembly 1

- 1) Open the front cabinet.
- 2) Remove the front cabinet band. Pull out the slide pin (B), and remove the front cabinet (C).




(2) Cabinet disassembly 2

- 1) Remove the front cabinet.
- 2) Open the left cabinet. Remove the screw and remove the front frame cover.



(3) Cabinet disassembly 3


- 1) Remove the screw, and slide the paper exit tray cabinet right to the right to remove.



(4) Cabinet disassembly 4


- 1) Remove the screw, and remove the rear cabinet (A). Remove the screw, and remove the DC power CFM unit (B) and the connector. Remove the screw, and remove the ROM cover (C) and the rear connection cabinet (D).

* When assembling, insert the boss in section E into the hole in the frame.




(5) Cabinet disassembly 5

- 1) Remove the rear cabinet.
- 2) Remove the screw (A), and slide the front right cabinet (B) upward to remove. Remove the screw, and slide the connection right cabinet (C), the rear right cabinet (D), and the right lower cabinet (E) upward to remove.




(6) Cabinet disassembly 6

- 1) Remove the rear cabinet.
- 2) Remove the screw, and remove the FD connection cabinet (A) and the front cabinet upper (B). Remove the screw, and slide the rear left cabinet lid (C) and the rear left cabinet (D) upper to remove.




(7) Cabinet disassembly 7

- 1) Remove the screw, and remove the FD paper exit port cabinet (A) and the operation panel plate (B).



(8) Cabinet disassembly 8

- 1) Remove the screw, and remove the upper cabinet rear cover (A). Remove the connector and the screw, and remove the upper cabinet rear unit.




8. Others

A. Disassembly/assembly/maintenance

(1) Maintenance target parts

X: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|---------------|-----|------------------|--------------|-----|------|------|------|------|------|------|------|--------|
| Filters | 1 | Ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Sub ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| Drive section | 3 | Gears | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 4 | Belts | × | × | × | × | × | × | × | × | × | |
| Others | 5 | Sensors | × | | × | | × | | × | | × | |



(2) Maintenance parts and major parts replacement


a. Ozone filter

- 1) Remove the ozone filter cover, and remove the ozone filter.



b. Sub ozone filter


- 1) Remove the sub ozone filter cover, and remove the sub ozone filter.



c. PWB


<1> PCU PWB

- 1) Remove the rear cabinet.
- 2) Remove the connector and the screw, and remove the PCU PWB.




<2> High voltage MC power PWB

- 1) Remove the rear cabinet.
- 2) Remove the connector and the screw, and remove the PCU PWB unit.
- 3) Remove the connector and the screw, and remove the high voltage MC power PWB.




<3> Power PWB

- 1) Remove the rear cabinet and the DC power CFM unit.
- 2) Remove the connector and the screw, and remove the power PWB.




<4> Driver PWB

- 1) Remove the rear cabinet, the rear left cabinet lid, and the rear left cabinet.
- 2) Remove the screw and the connector, and remove the driver PWB.




<5> AC PWB

- 1) Remove the screw, the rear cabinet, the rear left cabinet lid, and the rear left cabinet.
- 2) Remove the screw and the harness, and remove the driver PWB unit.




- 3) Remove the harness and remove the AC PWB from the supporter.




<6> High voltage TC power PWB

- 1) Remove the rear cabinet, the DC power CFM unit, the rear left cabinet lid, and the rear left cabinet.
- 2) Remove the connector, the harness, and the screw. Remove the Power PWB unit.




- 3) Remove the connector and the screw, and remove the high voltage TC power PWB.




<7> ICU PWB

- 1) Remove the paper exit tray cabinet right.
- 2) Remove the screw, and remove the box cover. Remove the screw, and remove the ICU PWB.





<8> Drum drive unit

- 1) Remove the rear cabinet.
- 2) Remove the DC power CFM unit.
- 3) Remove the driver PWB unit.
- 4) Remove the PCU PWB unit.
- 5) Remove the screw and the connector, and remove the intake duct FAN.
- 6) Remove the screw and the intake duct.



- 7) Remove the high voltage MC PWB.
- 8) Remove the connector screw and the drum drive unit.



[8] SETTING AND ADJUSTMENTS

Each adjustment item in the adjustment item list is indicated with its JOB number.

Perform the adjustment procedures in the sequence of Job numbers from the smallest to the greatest.

However, there is no need to perform all the adjustment items. Perform only the necessary adjustments according to the need.

Unnecessary adjustments can be omitted. Even in this case, however, the sequence from the smallest to the greatest JOB number must be observed.

If the above precaution should be neglected, the adjustment would not complete normally or a trouble may occur.

| JOB No | ADJUSTMENT ITEM LIST | | | SIMULATION |
|--------|---|---------|--|-------------|
| ADJ 1 | High voltage adjustment | ADJ 1A | Main charger grid voltage adjustment | 8-2 |
| | | ADJ 1B | DV bias voltage adjustment | 8-1 |
| | | ADJ 1C | Transfer voltage adjustment | 8-6 |
| ADJ 2 | Image density sensor adjustment | ADJ 2A | Color image density sensor adjustment (adjustment by the adjustment jig) | 44-13 |
| | | ADJ 2B | Black image density sensor adjustment | 44-2 |
| | | ADJ 2C | Color image density sensor & black image density sensor adjustment (Simple adjustment) *1 | 44-36 |
| ADJ 3 | Image focus, image skew adjustment (LED (writing) unit) | | | 64-1/61-4 |
| ADJ 4 | Image registration adjustment | ADJ 4A | Image registration adjustment (Auto adjustment) | 50-22 |
| | | ADJ 4B | Image registration adjustment (Manual adjustment) | 50-20 |
| ADJ 5 | Image position/print area adjustment (Print engine section) | ADJ 5A | Main scanning direction image position adjustment (Print engine section) | 50-10 |
| | | ADJ 5B | Sub scanning direction image position/print area adjustment (Print engine section) | 50-5 |
| ADJ 6 | Copy image distortion adjustment | ADJ 6A | Scanner (reading) unit parallelism adjustment | |
| | | ADJ 6B | Copy image sub scanning direction distortion adjustment | |
| | | ADJ 6C | Copy image main scanning direction distortion adjustment | |
| | | ADJ 6D | Scan image distortion adjustment | |
| ADJ 7 | Copy image focus (main scanning direction copy magnification ratio) adjustment (CCD unit position adjustment) | | | 48-1 |
| ADJ 8 | Sub scanning direction copy magnification ratio adjustment | | | 48-1 |
| ADJ 9 | Main scanning direction copy image position adjustment (Scanner (reading) section) | | | 50-12 |
| ADJ 10 | Copy image position/image loss/void area adjustment | | | 50-1/50-2 |
| ADJ 11 | Copy color balance/density adjustment | ADJ 11A | CCD gamma adjustment (CCD calibration) (Normal document copy mode) | 63-3 (63-5) |
| | | ADJ 11B | Copy color balance adjustment (Auto adjustment) | 46-24 |
| | | ADJ 11C | Copy color balance adjustment (Manual adjustment) | 46-21 |
| | | ADJ 11D | Copy density adjustment in low-density area (Normally unnecessary to adjust.) | 46-1/2 |
| | | ADJ 11E | Copy color balance density adjustment (each copy mode) (Normally unnecessary to adjust.) | 46-10 to 16 |
| | | ADJ 11F | CCD gamma adjustment (CCD calibration) (Copy document copy mode) | 63-9 |
| | | ADJ 11G | Image edge section gamma/density adjustment (Black text and black line reproduction adjustment) (Normally unnecessary to adjust.) | 46-27 |
| | | ADJ 11H | Copy color balance adjustment (Single color Copy mode) (Normally unnecessary to adjust.) | 46-25 |
| | | ADJ 11I | Auto color balance adjustment by user (Copy color balance auto adjustment enable setting and adjustment) | 26-53 |
| | | ADJ 11J | Background process conditions setting in the color auto copy mode, image auto recognition conditions setting, text-on-dot recognition conditions setting | 46-33 |
| ADJ 12 | Fusing pressure adjustment | | | |
| ADJ 13 | Fusing paper guide position adjustment | | | |
| ADJ 14 | Document size sensor adjustment | ADJ 14A | Original size sensor detection point adjustment | 41-2 |
| | | ADJ 14B | Original size sensor sensitivity adjustment | 41-2 |
| ADJ 15 | Manual paper feed tray paper size sensor adjustment | | | 40-2 |
| ADJ 16 | Touch panel coordinates setting | | | 65-1 |
| ADJ 17 | Power voltage adjustment | ADJ 17A | 3.4 V power voltage adjustment | |
| | | ADJ 17B | 5.0 V power voltage adjustment | |
| ADJ 18 | FAX/scanner mode image loss adjustment | | | 50-27 |

*1: The simple adjustment does not use the adjustment jig. Its adjustment accuracy may be lower than that of the adjustment by using the adjustment jig under some machine conditions.

ADJ 1 High voltage adjustment


Since the output voltage cannot be checked directly due to the machine structure, the adjustment value of the simulation is set to the default (specified value) to perform the adjustment.

ADJ 1A Main charger grid voltage adjustment

This adjustment must be performed in the following cases:

- When the high voltage power PWB is replaced.
- When a U2 trouble occurs.
- When the PCU PWB is replaced.
- When the EEPROM of the PCU PWB is replaced.

- 1) Enter the SIM 8-2 mode.



SIM 8-2

- 2) Select the output mode to be adjusted with the color key and scroll key.
- 3) Enter the adjustment value (specified value), and press the [OK] key.

By entering the default value (specified value), the specified voltage is outputted.


| Color | Item | Operation mode | Adjustment value | | Main charger grid voltage | | | |
|-------|-----------------|--|------------------|---------------------------|-----------------------------------|-----------|---------|----------------|
| | | | Adjustment range | Specified value (Default) | Monitor voltage (Specified value) | Connector | Pin No. | Actual voltage |
| K | A: HIGH SPEED | High speed (140mm/s) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMONK | 1 | –620v |
| | B: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMONK | 1 | –620v |
| | C: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMONK | 1 | –590v |
| C | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 3 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 3 | –590v |
| M | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 7 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 7 | –590v |
| Y | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 11 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 11 | –590v |

Remark: When the default value is set, the specified voltage is outputted.


There is, therefore, no need to check the output voltage unless there is a doubt for any abnormality in the output voltage.

If there is a need to check that the normal voltage is outputted or to adjust by referring to the output voltage, use the method below.

- 1) Remove the rear cover of the machine.
- 2) Remove the image process fan motor and the duct.



- 3) Connect the high voltage adjustment harnesses (DHAI-3471FCZZ/ DHAI-3472FCZZ) with the connectors CNMON and CNMONK on the high voltage PWB.



- 4) Enter the SIM8-2 mode.
- 5) Select the output mode to be adjusted with the color key and the scroll key.
- 6) Check that the pin numbers of the connectors CNMON and CNMONK are properly assigned to the connector pin numbers of the high voltage adjustment harness.
- 7) Apply a digital multi-meter to the connector pins of the high voltage adjustment harness corresponding to the output mode to be adjusted.

- 8) Press the [EXECUTE] key.

The main charger grid voltage is outputted for 30sec.

If this operation is performed for a long time, the OPC drum and the developing roller may be damaged. Be careful to perform this operation in a short time.

It is advisable to install an unnecessary developing unit and unnecessary OPC drums to the machine for this adjustment.

- 9) Check the monitor voltage with the digital multi-meter.

If the monitor voltage is not in the above specified range, change the adjustment value and adjust again. If the specified voltage is not obtained even by changing the adjustment value, the following parts may be judged as defective.

High voltage PWB

PCU PWB

Developing unit

Photoconductor unit


High voltage circuit electrode

ADJ 1B DV bias voltage adjustment

This adjustment must be performed in the following cases:

- When the high voltage power PWB is replaced.
- When a U2 trouble occurs.
- When the PCU PWB is replaced.
- When the EEPROM of the PCU PWB is replaced.

- 1) Enter the SIM 8-1 mode.



SIM 8-1

- 2) Select the output mode to be adjusted with the color key and the scroll key.
- 3) Enter the adjustment value (specified value), and press the [OK] key.

By entering the default value (specified value), the specified voltage is outputted.


| Color | Item | Operation mode | Adjustment value | | Developing bias voltage | | | |
|-------|-----------------|--|------------------|---------------------------|----------------------------|--------|---------|----------------|
| | | | Adjustment range | Specified value (Default) | Monitor (High voltage PWB) | | Pin No. | Actual voltage |
| K | A: HIGH SPEED | High speed (140mm/s) (B & W) | 180 – 700 | 315 | 7.43 ± 0.1V | CNMONK | 3 | -315v |
| | B: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 315 | 7.43 ± 0.1V | CNMONK | 3 | -315v |
| | C: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 285 | 6.45 ± 0.1V | CNMONK | 3 | -285v |
| C | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 265 | 5.76 ± 0.1V | CNMON | 1 | -265v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 235 | 4.75 ± 0.1V | CNMON | 1 | -235v |
| M | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 265 | 5.76 ± 0.1V | CNMON | 5 | -265v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 235 | 4.75 ± 0.1V | CNMON | 5 | -235v |
| Y | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 240 | 4.75 ± 0.1V | CNMON | 9 | -240v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 210 | 3.78 ± 0.1V | CNMON | 9 | -210v |

Remark: When the default value is set, the specified voltage is outputted.


There is, therefore, no need to check the output voltage unless there is a doubt for any abnormality in the output voltage.

If there is a need to check that the normal voltage is outputted or to adjust by referring to the output voltage, use the method below.

- 1) Remove the rear cover of the machine.
- 2) Remove the image process fan motor and the duct.



- 3) Connect the high voltage adjustment harnesses (DHAi-3471FCZZ/ DHAi-3472FCZZ) with the connectors CNMON and CNMONK on the high voltage PWB.



- 4) Enter the SIM8-2 mode.
- 5) Select the output mode to be adjusted with the color key and the scroll key.
- 6) Check that the pin numbers of the connectors CNMON and CNMONK are properly assigned to the connector pin numbers of the high voltage adjustment harness.

7) Apply a digital multi-meter to the connector pins of the high voltage adjustment harness corresponding to the output mode to be adjusted.

8) Press the [EXECUTE] key.

The developing bias voltage is outputted for 30sec.

If this operation is performed for a long time, the OPC drum and the developing roller may be damaged. Be careful to perform this operation in a short time.

It is advisable to install an unnecessary developing unit and unnecessary OPC drums to the machine for this adjustment.

9) Check the monitor voltage with the digital multi-meter.

If the monitor voltage is not in the above specified range, change the adjustment value and adjust again. If the specified voltage is not obtained even by changing the adjustment value, the following parts may be judged as defective.

High voltage PWB

PCU PWB

Developing unit

Photoconductor unit


High voltage circuit electrode

ADJ 1C Transfer voltage adjustment

This adjustment must be performed in the following cases:

- When the high voltage power PWB is replaced.
- When a U2 trouble occurs.
- When the PCU PWB is replaced.
- When the EEPROM of the PCU PWB is replaced.

1) Enter the SIM 8-6 mode.



SIM 8-6

2) Select the mode to be adjusted with the color key and scroll key.

3) Enter the adjustment value (specified value), and press the [OK] key.

By entering the default value (specified value), the specified voltage is outputted.

| Item | | Print mode | | | Standard setting value (Default) | | | | Adjustment range | Output voltage (Kv) | | | |
|------|-----------------|------------|----------------------------|----------|----------------------------------|-----|-----|-----|------------------|---------------------|-----|-----|-----|
| | | | | | K | C | M | Y | | K | C | M | Y |
| A | PLAIN_SPX_CL | Color | Normal paper | 117mm/s | 173 | 159 | 132 | 132 | 51 - 255 | 2.4 | 2.4 | 2.4 | 2.4 |
| B | PLAIN_DPX_CL | Color | Normal paper(Duplex mode) | 117mm/s | 188 | 173 | 142 | 142 | | 2.7 | 2.7 | 2.7 | 2.7 |
| C | OHP1_CL | Color | Transparency film 1 | 117mm/s | 204 | 187 | 153 | 153 | | 3 | 3 | 3 | 3 |
| D | OHP2_CL | Color | Transparency film 2 | 58.5mm/s | 137 | 150 | 153 | 163 | | 1.7 | 2.2 | 3 | 3.3 |
| E | HEAVY_P1_SPX_CL | Color | Thick paper 1 | 58.5mm/s | 158 | 146 | 122 | 122 | | 2.1 | 2.1 | 2.1 | 2.1 |
| F | HEAVY_P1_DPX_CL | Color | Thick paper 1(Duplex mode) | 58.5mm/s | 188 | 173 | 142 | 142 | | 2.7 | 2.7 | 2.7 | 2.7 |
| G | HEAVY_P2_CL | Color | Thick paper 2 | 58.5mm/s | 173 | 159 | 132 | 132 | | 2.2 | 2.2 | 2.2 | 2.2 |
| H | ENV_CL | Color | Envelope | 117mm/s | 163 | 150 | 125 | 125 | | 2.2 | 2.2 | 2.2 | 2.2 |
| I | PLAIN_SPX_BW | B & W | Normal paper | 140mm/s | 168 | | | | | 2.3 | | | |
| J | PLAIN_DPX_BW | B & W | Normal paper(Duplex mode) | 140mm/s | 178 | | | | | 2.5 | | | |
| K | OHP1_BW | B & W | Transparency film 1 | 117mm/s | 204 | | | | | 3 | | | |
| L | OHP2_BW | B & W | Transparency film 2 | 58.5mm/s | 137 | | | | | 1.7 | | | |
| M | HEAVY_P1_SPX_BW | B & W | Thick paper 1 | 58.5mm/s | 147 | | | | | 1.9 | | | |
| N | HEAVY_P1_DPX_BW | B & W | Thick paper 1(Duplex mode) | 58.5mm/s | 178 | | | | | 2.5 | | | |
| O | HEAVY_P2_BW | B & W | Thick paper 2 | 58.5mm/s | 163 | | | | | 2.2 | | | |
| P | ENV_BW | B & W | Envelope | 140mm/s | 168 | | | | | 2.3 | | | |

| Color | Actual output variable range | Voltage change/Adjustment value (1) (Varying amount when the adjustment value is changed by 1) |
|-------|------------------------------|--|
| K | 0 to 4000V | About 19.6V |
| C | 0 to 4500V | About 22.1V |
| M | 0 to 6000V | About 29.4V |
| Y | 0 to 6000V | About 29.4V |

Press the [EXECUTE] key to output the transfer voltage.

ADJ 2 Image density sensor adjustment

The image density sensor sections are of uneven quality in parts and assembly. This causes variations in the absolute detection level between machines. This adjustment (calibration) is performed to correct the variations.

This adjustment is required in the following cases:

- When the image density sensor is replaced.
- When the transfer unit is replaced.
- When maintenance is performed.
- When U2 trouble occurs.
- When the PCU PWB is replaced.
- When the EEPROM on the PCU PWB is replaced.

The targets of the adjustment are the color image density sensor and the black image density sensor. There are following adjustment methods:

- Color image density sensor adjustment (adjustment by the adjustment jig) SIM44-13
- Black image density sensor adjustment SIM44-2
- Image density sensor adjustment (The color image density sensor and the black image density sensor are adjusted at the same time.) (Simple adjustment) SIM44-36

Normally the following adjustments are executed:

- ADJ 2A Color image density sensor adjustment (adjustment by the adjustment jig) (SIM44-13)
- ADJ 2B Black image density sensor adjustment (SIM44-2)

Note:

There are two methods to adjust the color image density sensor; one method uses the adjustment jig, and the other method does not use it. If there is no adjustment jig available, the simple adjustment (SIM44-36) can be made, which may, however, result in insufficient adjustment accuracy depending on the machine condition.

If toner, the OPC drum, and the transfer belt are not new ones or almost new ones, the simple adjustment is not recommended.

Even though the machine conditions are well, the adjustment by use of the adjustment jig gives a higher adjustment accuracy than the adjustment without the adjustment jig (simple adjustment).

Also note that SIM44-36 must not be executed unnecessarily after execution of the color image density sensor adjustment (adjustment by the adjustment jig) with SIM44-13.

If SIM 44-36 is executed, the contents of the color image density sensor adjustment (adjustment by the adjustment jig) with SIM44-13 are erased, and the adjustment result of SIM44-36 is saved.

When the color image density sensor is adjusted with SIM44-13 and the black image density sensor is adjusted with SIM 44-2, the adjustment with SIM44-36 is not required.




To adjust the black image density sensor, the adjustment jig is not required.

Before executing this adjustment, check the following items:


- Check that the color image density sensor is clean.
- Check that the image density sensor calibration plate is clean.
- Check that the transfer belt is free from scratches.

ADJ 2A Color image density sensor adjustment (adjustment by the adjustment jig)

- 1) Open the front cover of the machine.
- 2) Insert the color image density sensor adjustment jig (CPLTM6305FC01) into the long hole in the transfer unit frame, and close the left cabinet.



- 3) With the front cover of the machine open (with the cover open/close switch OFF), turn on the power.
- 4) The Machine enters Sim 44-13 mode.



SIM 44-13

- 5) Close the front cover of the machine.
- 6) Press the [EXECUTE] key.

The adjustment is performed automatically. When the adjustment is completed, the adjustment result is displayed and the the [EXECUTE] key display returns to the original state.

| | Display | Content | Min Value | Max Value | Default value |
|---|----------------|--|-----------|-----------|---------------|
| A | PCS_C CARB ADJ | Color image density sensor LED current adjustment target value | 1 | 255 | 108 |
| B | PCS_C DARK | Color image density sensor dark voltage level | 0 | 255 | 0 |
| C | PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |

- 7) Remove the color image density sensor adjustment jig.
- If the adjustment is not completed normally, "ERROR" is displayed. In that case, check the following sections for no abnormality. If there is any abnormality, repair the part and perform the adjustment again. In case of an error, the adjustment result is not revised.


- Image density sensor
- PCU PWB
- Transfer belt

Note:

The color image density sensor adjustment jig is available in the following two forms:


- The jig metal plate with the calibration sheet attached to it (CPLTM6305FC01)
- Calibration sheet (for replacement) (TLABZ4843FCZZ)

TLABZ4843FCZZ is the calibration sheet for replacement. When the calibration sheet attached to CPLTM6305FC01 is dried or scratched too much to be used, replace only the calibration sheet with a new one.



ADJ 2B Black image density sensor adjustment

- 1) Enter the SIM44-2 mode.



- 2) Press the [EXECUTE] key.

The adjustment is performed automatically. When the adjustment is completed, the adjustment result is displayed and the the [EXECUTE] key display returns to the original state.

| Display | Content | Min Value | Max Value | Default value |
|-----------------|---|-----------|-----------|---------------|
| A PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |
| B PCS K LED ADJ | Black image density sensor LED Current adjustment value | 1 | 255 | 51 |
| C PCS_K GAIN | Black image density sensor output gain (AMP) adjustment value | 0 | 15 | 0 |
| D PCS_K DARK | Black image density sensor dark voltage level | 0 | 255 | 0 |
| E PCS_K GRND | Black image density sensor transfer belt surface detection level | 0 | 255 | 0 |
| F BELTMAX | Transfer belt surface max. detection level (Black image sensor) | 0 | 255 | 0 |
| G BELTMIN | Transfer belt surface min. detection level (Black image sensor) | 0 | 255 | 0 |
| H BELTDIF | Difference between the max. value and the min. value of the transfer belt surface detection level (BELTMAX-BELTMIN) | 0 | 255 | 0 |

If the adjustment is not completed normally, "ERROR" is displayed.

In that case, check the following sections for no abnormality. If there is any abnormality, repair the part and perform the adjustment again.

In case of an error, the adjustment result is not revised.


- Image density sensor
- PCU PWB
- Transfer belt

ADJ 2C Color image density sensor & black image density sensor adjustment (Simple adjustment)

When the color image density sensor is adjusted with SIM44-13 and the black image density sensor is adjusted with SIM44-2, the adjustment with SIM44-36 is not required.

In addition, the color image density adjustment jig is not used.

- 1) Enter the SIM44-36 mode.



- 2) Press the [EXECUTE] key.

The adjustment is performed automatically. When the adjustment is completed, the adjustment result is displayed and the the [EXECUTE] key display returns to the original state.

| Display | Content | Min Value | Max Value | Default value |
|----------------|---|-----------|-----------|---------------|
| PCS_C CARB ADJ | Color image density sensor LED current adjustment target value | 1 | 255 | 108 |
| PCS_C DARK | Color image density sensor dark voltage level | 0 | 255 | 0 |
| PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |
| PCS K LED ADJ | Black image density sensor LED current adjustment value | 1 | 255 | 51 |
| PCS_K GAIN | Black image density sensor output gain (AMP) adjustment value | 0 | 15 | 0 |
| PCS_K DARK | Black image density sensor dark voltage level | 0 | 255 | 0 |
| PCS_K GRND | Black image density sensor transfer belt surface detection level | 0 | 255 | 0 |
| BELTMAX | Transfer belt surface max. detection level (Black image sensor) | 0 | 255 | 0 |
| BELTMIN | Transfer belt surface min. detection level (Black image sensor) | 0 | 255 | 0 |
| BELTDIF | Difference between the max. value and the min. value of the transfer belt surface detection level (BELTMAX-BELTMIN) | 0 | 255 | 0 |

If the adjustment is not completed normally, "ERROR" is displayed.

In case of an error, the adjustment result is not revised.

In that case, check the following sections for no abnormality. If there is any abnormality, repair the part and adjust again.

- Image density sensor
- PCU PWB
- Transfer belt

ADJ 3 Image focus, image skew adjustment (LED (writing) unit)


(1) LED print engine image focus adjustment (LED (writing) unit)

This adjustment must be performed in the following cases:

- When the scanner (writing) unit is replaced.
- When the scanner (writing) unit is removed from the machine.
- When the print image is shifted. (Especially conspicuous for text and line drawings) (The scanner (reading) unit is normal, but the print image focus of the print engine is not normal.)
- When there is uneven density in the main scanning direction.
- When the color balance adjustment does not result in proper color matching.
- When in installation or when the installing site is changed. (Necessary depending on the case)

- 1) Execute the process correction forcibly. (SIM44-6)
This simulation is used to correct the print density of the adjustment pattern.

- 2) Enter the SIM 61-4 mode.




SIM 61-4

- 3) Set the items A, B and C according to the table below.


| | Parameter | Set value |
|---|---------------|-----------|
| A | PRINT PATTERN | 2 |
| B | DENSITY | 7 |
| C | POSITION | 6 |

- 4) Select the A4 (11 x 8 1/2) paper feed tray.
- 5) Press the [EXECUTE] key.
The focus adjustment pattern is printed.
- 6) Check the printed focus adjustment pattern for each color.
If focus is proper, the half-tone belts are printed properly. When four or five half-tone belts of each color are printed and there is no density difference in the main scanning direction (back and forth), the focus is proper both on the front and the back sides.






Check that the half-tone belts of each color are printed in good balance.

- 7) If the above condition is not satisfied, turn the focus adjustment screws on the front/rear frame sides to adjust focus.
Focus on the front side can be separately adjusted from focus on the rear side.



Front frame side



Rear frame side


Execute procedures 4 to 6 for each color.

(2) Print engine image skew adjustment (LED (writing) unit)

This adjustment must be performed in the following cases:

- When the scanner (writing) unit is replaced.
- When the scanner (writing) unit is removed from the machine.
- When the print image includes skew.
(When the scanner (reading) unit is normal and the print image of the print engine includes skew.)
- When a color image registration error occurs.
(There is an image registration difference in the main scanning direction.)
- When there is uneven density in the main scanning direction.
- When the color balance adjustment does not result in proper color matching.
- When in installation or when the installing site is changed. (Necessary depending on the case)

- 1) Enter the SIM 64-1 mode.




SIM 64-1

- 2) Set the items A and B according to the table below.

| | Parameter | Set value |
|---|---------------|-----------|
| A | PRINT PATTERN | 1 |
| B | DENSITY | 1 |



- 3) Select the A3 (11 x 17) size paper feed tray.
- 4) Select Black (K) and press the [EXECUTE] key.
The grid patter (one page) is printed.
- 5) Check the printed grid pattern. (Check for image skew (distortion).)
If the right-angle level of the traverse print line is 0.5mm or less for the longitudinal print line of paper, there is no need to adjust.




- 6) If the above conditions are not satisfied, remove the developing unit and turn the print engine image skew adjustment screw to adjust.

At that time, use SIM 7-1 to set DV CHECK DISABLE to Enable and to disable the developing unit installation detection.

If skew is made in the arrow direction A, turn the adjustment screw clockwise. If skew is made in the arrow direction B, turn the adjustment screw counterclockwise.




- 7) Enter the SIM 61-4 mode.



SIM 61-4

- 8) Select the A4 (11 x 8.5) size paper feed tray.
- 9) Press the [EXECUTE] key.
The print engine image skew adjustment pattern is printed. (One page)
- 10) Check the printed image skew (distortion) pattern.

Compare the same color print pattern on the front frame side with that on the rear frame side, and check that the difference between the two highest-density areas is within 2 steps. (Compare the same color print pattern on the front frame side with that on the rear frame side. There is no need for the positions of the highest-density areas of the print color patterns of all the colors to be aligned on a line. Compare only the same color pattern positions.)



If the above conditions are not satisfied, remove the developing unit on the left and turn the print engine image skew adjustment screw on the front frame side.

To adjust the print engine image skew of Cyan, for example, remove the Magenta developing unit. (To adjust the print engine image skew of Yellow, however, this is not required.)

At that time, use SIM 7-1 to set DV CHECK DISABLE to Enable and to disable the developing unit installation detection.

When the image pattern on the front frame side is skewed to the right (arrow direction A) with the rear frame side as the reference, turn the adjustment screw clockwise. When the image pattern is skewed to the left (arrow direction B), turn the adjustment screw counterclockwise.

When the adjustment screw is turned 1/4 rotation, the image position is shifted by one dot.

Remark: The print engine image focus adjustment is performed by changing the distance between the LED array unit and the OPC drum.

The print engine image skew adjustment is performed by changing the parallelism of the LED array unit for the OPC drum.

If either of the two adjustments is performed, it may affect the other adjustment due to the machine structure.

After completion of the above procedures, check that both of the above two adjustments are satisfied.

ADJ 4 Image registration adjustment

There are two methods of the image registration adjustment: the manual adjustment and the automatic adjustment. Either of them uses the simulation.

This adjustment is required in the following cases:

- When the scanner (writing) unit is replaced.
- When the scanner (writing) unit is removed from the machine.
- When color image mis-resist is generated in the main scanning direction.
- When color image mis-resist is generated in the sub scanning direction.
- When installation or the installing place is changed.
- When maintenance is performed. (When the OPC drum, the photoconductor cartridge, the transfer unit, or the transfer belt is replaced.)
- When U2 trouble occurs.
- When ICU PWB is replaced.
- When EEPROM on ICU PWB is replaced.

Remark: Though SIM 50-22 is not performed under the following conditions, the image registration adjustment is performed automatically.

- * When the toner cartridge is replaced.
- * At every 8,000 copies (total of print quantity and copy quantity) (When 8,000 copies is reached during a job, the machine stops after completion of the job.)

If the set item AR of SIM 44-1 is set to OFF (Disable), the above operation is not performed.

After setting the image registration to the best by SIM 50-20, when the image registration adjustment is automatically performed, the best-adjusted condition may be varied. To avoid this, set the item AR of SIM 44-1 to OFF (Disable).

Note:


Before executing this adjustment, check that the following adjustments have been properly completed.

- * Print engine image focus adjustment (Scanner (writing) unit)
- * Print engine image skew adjustment (Scanner (writing) unit)
- * Image registration sensor adjustment

ADJ 4A Image registration adjustment (Auto adjustment)

This adjustment is used to perform the image registration adjustment in the main scanning direction and in the sub scanning direction at the same time with the simulation.

- 1) Enter the SIM 50-22 mode.




SIM 50-22

- 2) Press the [EXECUTE] key.

The [EXECUTE] key is highlighted, and the image registration automatic adjustment is started. After completion of the adjustment, the [EXECUTE] key returns to the normal display.

The adjustment process status is indicated with (*) mark. It takes several minutes to complete the adjustment.

- 3) Enter the SIM 50-20 mode.




SIM 50-20

- 4) Select the A4 (11 x 8 1/2) size paper feed tray.

- 5) Press the [EXECUTE] key.

The image registration adjustment pattern is printed.

- Image registration adjustment pattern




C1 = CYAN MAIN
 C2 = CYAN SUB
 M1 = MAGENTA MAIN
 M2 = MAGENTA SUB
 Y1 = YELLOW MAIN
 Y2 = YELLOW SUB

- Check the rough adjustment print pattern position and the fine adjustment print pattern position of each color on the front and the rear frame sides.
 Check visually and use the highest-density area of each color as the center, and regard it as the reading value of shift.
 Rough adjustment print pattern check: Check that the rough adjustment print pattern is at the center for the rough adjustment reference pattern.
 Fine adjustment print pattern check: Check that the fine adjustment print pattern is at the center for the fine adjustment reference pattern.
 (If the fine adjustment print pattern is in the range of 0 ± 2 for the scale of the fine adjustment reference pattern, there is no need to adjust.)
 If the adjustment is not completed with a satisfactory result, try the manual adjustment.

ADJ 4B Image registration adjustment (Manual adjustment)

- 1) Enter the SIM 50-20 mode.



SIM 50-20

- 2) Select the A4 (11 x 8 1/2) paper feed tray.
- 3) Press the [EXECUTE] key.
The image registration adjustment pattern is printed.
- 4) Check the rough adjustment print pattern position and the fine adjustment print pattern position of each color on the front and the rear frame sides.
Check visually and use the highest-density area of each color as the center, and regard it as the reading value of shift.

Rough adjustment Check that the rough adjustment print pattern print pattern check: is at the center for the rough adjustment reference pattern.

Fine adjustment Check that the fine adjustment print pattern print pattern check: at the center for the fine adjustment reference pattern.

(If the fine adjustment print pattern is in the range of 0 ± 2 for the scale of the fine adjustment reference pattern, there is no need to adjust.)

If the above condition is not satisfied, change the adjustment value and tray again.

- 5) Select the color mode adjustment item to be adjusted with the scroll key. Change the adjustment value and to adjust.

| Display | | Adjustment item | | Set range | Default value |
|---------|--------------|---|---------|-----------|---------------|
| A | CYAN MAIN | Main scanning direction image registration adjustment value | Cyan | 12 to 88 | 50 |
| B | CYAN SUB | Sub scanning direction image registration adjustment value | Cyan | | |
| C | MAGENTA MAIN | Main scanning direction image registration adjustment value | Magenta | | |
| D | MAGENTA SUB | Sub scanning direction image registration adjustment value | Magenta | | |
| E | YELLOW MAIN | Main scanning direction image registration adjustment value | Yellow | | |
| F | YELLOW SUB | Sub scanning direction image registration adjustment value | Yellow | | |

When the adjustment value is changed by 1, the image position is shifted by one pixel.

Main scanning direction image position adjustment (Print engine section)

(1) How to read the fine adjustment pattern

The highest-density area of the color is regarded as the center and as the reading value of the shift amount.
(The reading value in the figure below is 4.)

(2) How to read the rough adjustment pattern



Judge the polarity by checking that the color line is shifted to the positive or the negative side.

The scales are made with the black line at the center as 0, the first mark as 20, the second mark as 40, and the third mark as 60.

The interval between rough adjustment marks is 20.

(For an example shown in the figure below, it is between 20 and 40 on the positive side. Therefore, the reading value is 20.)

(Example)



(3) How to calculate the adjustment value

New adjustment value = Current adjustment value + Rough adjustment pattern reading value + Fine adjustment pattern reading value

A: Current adjustment value

B: New adjustment value

X: Fine adjustment pattern reading value

Y: Rough adjustment pattern reading value

The polarity of the calculation differs depending on the polarity of the adjustment pattern reading values. There are following four cases:

1) When $Y \geq 0$, and $X \geq 0$:

$$B = A + X + Y$$

2) When $Y \geq 0$, and $X < 0$:

$$B = A + (X + 20) + Y$$

3) When $Y < 0$, and $X \geq 0$:

$$B = A + (X - 20) + Y$$


4) When $Y < 0$, and $X < 0$:

$$B = A + X + Y$$

Example


A: Providing that Current adjustment value = 48:

1) When $Y \geq 0$, and $X \geq 0$:




$$B = A + X + Y = 48 + (4) + (20) = 72$$

2) When $Y \geq 0$, and $X < 0$:




$$B = A + (X + 20) + Y = 48 + (-6 + 20) + (20) = 82$$

3) When $Y < 0$, and $X \geq 0$:







$$B = A + (X - 20) + Y = 48 + (7 - 20) + (-20) = 15$$

4) When $Y < 0$, and $X < 0$:



$$B = A + X + Y = 48 + (-5) + (-20) = 23$$



Sub scanning direction image position/print area adjustment (Print engine section)

(1) How to read the fine adjustment pattern

The highest-density area of the color is regarded as the center and as the reading value of the shift amount.
(The reading value in the figure below is 4.)

(2) How to read the rough adjustment pattern


Judge the polarity by checking that the color line is shifted to the positive or the negative side.

The scales are made with the black line at the center as 0, the first mark as 20, the second mark as 40, and the third mark as 60.

The interval between rough adjustment marks is 20.

(For an example shown in the figure below, it is between 20 and 40 on the positive side. Therefore, the reading value is 20.)

(Example)



(3) How to calculate the adjustment value

New adjustment value = Current adjustment value + Rough adjustment pattern reading value + Fine adjustment pattern reading value

A: Current adjustment value

B: New adjustment value

X: Fine adjustment pattern reading value

Y: Rough adjustment pattern reading value

The polarity of the calculation differs depending on the polarity of the adjustment pattern reading values. There are following four cases:

1) When $Y \geq 0$, and $X \geq 0$:

$$B = A + X + Y$$

2) When $Y \geq 0$, and $X < 0$:

$$B = A + (X + 20) + Y$$

3) When $Y < 0$, and $X \geq 0$:

$$B = A + (X - 20) + Y$$



4) When $Y < 0$, and $X < 0$:

$$B = A + X + Y$$

Example



A: Providing that Current adjustment value = 48:

1) When $Y \geq 0$, and $X \geq 0$:





$$B = A + X + Y = 48 + (4) + (20) = 72$$

2) When $Y \geq 0$, and $X < 0$:





$B = A + (X + 20) + Y = 48 + (-6 + 20) + (20) = 82$

3) When $Y < 0$, and $X \geq 0$:



$B = A + (X - 20) + Y = 48 + (7 - 20) + (-20) = 15$

4) When $Y < 0$, and $X < 0$:



$B = A + X + Y = 48 + (-5) + (-20) = 23$


ADJ 5 Image position/print area adjustment (Print engine section)

ADJ 5A Main scanning direction image position adjustment (Print engine section)

This adjustment must be performed in the following cases:


- When the paper tray is replaced.
- When the paper tray section is disassembled.
- When the manual paper feed tray is replaced.
- When the manual paper feed tray is disassembled.
- When the duplex section is disassembled.
- When the duplex section is installed or replaced.
- When the large capacity paper feed tray is installed or replaced.
- When the large capacity paper feed tray is disassembled.
- When a U2 trouble occurs.
- When the ICU main PWB is replaced.
- When the EEPROM of the ICU main PWB is replaced.

- 1) Enter the SIM 50-10 mode.
- 2) Select the paper feed mode to be adjusted with the scroll key.
- 3) Press the [EXECUTE] key.
The adjustment pattern is printed.
- 4) Check the adjustment pattern image position.
Measure the sizes of the void area on the front and the back edges of the adjustment pattern, and check that the following conditions are satisfied.
If $A - B = 0 \pm 4.0\text{mm}$, there is no need to adjust.
If the above condition is not satisfied, perform the following procedure.



- 5) Change the adjustment value.
(Enter the adjustment value and press the [OK] key.)
When the adjustment value is increased, the image is shifted backward.
When the adjustment value is decreased, the image is shifted forward.
A change in the set value by 1 corresponds to a change in the shift by about 0.1mm.
Repeat procedures 3) – 5) until the condition of procedure 4) is satisfied.
If the above procedure does not satisfy the condition of 4), perform the following procedure.

- 6) Loosen the paper feed tray cover fixing screw, and shift the installing position in the arrow direction.
Perform procedures from 2) again.




Perform the above procedures for all paper feed units.

ADJ 5B Sub scanning direction image position/print area adjustment (Print engine section)

This adjustment must be performed in the following cases:

- When a U2 trouble occurs.
- When the ICU PWB is replaced.
- When the EEPROM of the ICU PWB is replaced.

- 1) Enter the SIM 50-5 mode.
- 2) Select the paper feed mode with the scroll key.
- 3) Press the [EXECUTE] key.
The adjustment pattern is printed.
- 4) Check the adjustment pattern image position.



Measure the sizes of the void area on the left and the right edges of the adjustment pattern, and check that the following conditions are satisfied.

If $A = 4.0 \pm 2.0\text{mm}$ and $B = 4.0 \pm 2.0\text{mm}$, the adjustment is not required.

If the above condition is not satisfied, perform the following procedure.

- 5) Change the adjustment values of item A (DEN-C) and B (DEN-B), and press the [EXECUTE] key.
When the adjustment value of item A (DEN-C) is decreased by 1, the print start position in the sub scanning direction is shifted to the paper lead edge by 0.125mm.
When the adjustment value of item B (DEN-B) is decreased by 1, the print start position in the sub scanning direction is shifted to the paper rear edge by 0.125mm.
Repeat procedures 3) – 5) until the condition of procedure 4) is satisfied.


ADJ 6 Copy image distortion adjustment

This adjustment must be performed in the following cases:

- When the scanner (reading) section is disassembled.
- When a copy image distortion occurs.

ADJ 6A Scanner (reading) unit parallelism adjustment


- 1) Loosen the screw that is fixing the scanner unit A and the drive wire, and remove the scanner unit A from the drive wire.




- 2) Manually turn the scanner drive pulley to bring the scanner unit B into contact with the stopper.

At that time, if the scanner unit B makes contact with the two stoppers on the front and the rear frame simultaneously, the parallelism of the scanner unit B is proper.

If not, perform the following procedures.



- 3) Loosen the pulley angle fixing screw on the front frame side of the scanner unit B.



- 4) Adjust the pulley angle position on the scanner unit B front frame side so that both stoppers on the front frame and the rear frame are in contact with the scanner unit B at the same time.


- 5) Fix the pulley angle on the scanner unit B front frame side.

If the above procedure does not result in a satisfactory result, perform the following procedure.


Loosen the fixing screw of the scanner unit drive pulley that is not in contact.

Without moving the scanner unit drive shaft, manually turn the scanner unit drive pulley so that the scanner unit B is brought into contact with the stopper on the front frame side and the stopper on the rear frame side at the same time. (Change the relative positions of the scanner unit drive pulley and the drive shaft.)

Fix the scanner unit drive pulley fixing screw.




- 6) With the scanner unit B in contact with the both stoppers on the CCD mounting plate at the same time, fit the edge of the scanner unit A with the frame right edge and fix the scanner unit A with the screw.




ADJ 6B Copy image sub scanning direction distortion adjustment


- 1) Make a test chart on A3 (11" x 17") paper as shown below. (Draw a rectangular with four right angles.)



- 2) Set the test chart made in procedure 1) on the document table. (Leave a space of about 30mm between the reference position and the test chart.) With the document cover open, make a copy on A3 (11" x 17").




- 3) Check for distortion in the sub scanning direction.
If $L_a = L_b$, there is no distortion.



If there is some distortion in the sub scanning direction, perform the following procedures.

- 4) Loosen either of two fixing screws of the scanner unit drive pulley. (Either one on the front or the rear side will do.)




- 5) With the scanner unit drive shaft kept stationary, turn the scanner unit drive pulley manually to change the parallelism of scanner units A and B. (Change the relative positions of the scanner unit drive pulley and the drive shaft.)
- 6) Tighten the scanner unit drive pulley fixing screw.
Repeat procedures 2) – 6) until the condition of procedure 3) is satisfied.


If the distortion in the sub scanning direction cannot be deleted with the above procedures, perform ADJ 6D, Scan image distortion adjustment.

ADJ 6C Copy image main scanning direction distortion adjustment

- 1) Make a test chart on A3 (11" x 17") paper as shown below. (Draw a rectangle with four right angles.)




- 2) Set the test chart made in procedure 1) on the document table. With the document cover open, make a copy on A3 (11" x 17").
- 3) Check for distortion in the main scanning direction.
If the four angles of the rectangle on the copy are right angles, there is no distortion. (Completion of the adjustment)




If there is some distortion in the main scanning direction, perform the following procedures

- 4) Check the difference (distortion balance) of left and right images distortions.



There is no difference between the distortion on the right and that on the left.
 $Lc = Ld$



There is some difference between the distortion on the right and that on the left.
 $Lc \neq Ld$


If $Lc = Ld$, the distortion on the left is equal to that on the right. (The distortions are balanced.)

If the above condition is satisfied, go to procedure 6).

If the above condition is not satisfied, perform the following procedure.

- 5) Change the height balance of the front frame side scanner rail.
[Rail adjustment]
 - 1) Make a copy from the table glass, and check the copy output.
In this case, set the test chart correctly. If it is set inclined, the adjustment cannot be made correctly.
 - 2) If the check result is outside the specified range, perform the following procedure.
 - 3) Remove the front cabinet on the scanner side, and check the installing position of the MB rail.

- 4) Loosen the screw on the right side of the MB rail.



Repeat procedures 2) to 5) until the image distortions are balanced.




- 6) Without changing the balance between the front frame side scanner rail, change the overall height.
- 7) Set the test chart made in procedure 1) on the document table, and make a copy on A3 (11" x 17") paper. Check that the main scanning distortion is within the specified range.
Perform procedures 7) to 8) until the main scanning direction distortion is in the specified range.

If this adjustment cannot remove the sub scanning direction distortion, perform ADJ 6D, Scan image distortion adjustment.

ADJ 6D Scan image distortion adjustment

If scan image distortion cannot be removed with ADJ 6A, ADJ 6B, and ADJ 6C, perform this adjustment.

Change the position of the scanner unit distortion adjustment plate on the right side of the scanner unit so that the scanner image distortion becomes minimum. The scan image distortion is adjusted by adjusting the overall mechanical distortion of the scanner unit.




ADJ 7 Copy image focus (main scanning direction copy magnification ratio) adjustment (CCD unit position adjustment)

This adjustment must be performed in the following cases:

- When the CCD unit is removed from the machine.
- When the CCD unit is replaced.
- When the copy image focus is improper.
- When the copy magnification ratio in the copy image main scanning direction is not proper.
- When the MFP main PWB is replaced.
- When the EEPROM of the MFP main PWB is replaced.
- When a U2 trouble occurs.

- 1) Enter the SIM 48-1 mode.
- 2) Set the set item B to 50 (initial value).
- 3) As shown in the figure below, place a scale on the original table.




- 4) Make a normal copy on A4 paper.
- 5) Compare the scale image length and the actual scale length.
- 6) Obtain the main scanning direction copy magnification ratio according to the following formula.

$$\text{Main scanning direction copy magnification ratio} = \frac{(\text{Original dimension} - \text{Copy dimension})}{\text{Original dimension}} \times 100 [\%]$$



(Example) Fit 10mm of the scale with 10mm of the copied scale and compare them.

$$\text{Main scanning direction copy magnification ratio} = \frac{100 - 99}{100} \times 100 = 1$$



If the copy magnification ratio is not satisfactory, perform the following procedure.

- 7) Remove the original guide L and R, and remove the table glass.
 - 8) Remove the dark box cover.
 - 9) Loosen the CCD unit fixing screws.
- Draw a marking line on the CCD unit base as shown below in order to avoid a shift in the optical axis of the CCD unit.
- At that time, fix the CCD unit so that it is in parallel with the marked line in procedure 9).



* Never loosen the screws marked with "X."

If one of these screws is loosened, the CCD unit base position and angle may be changed. If so, it cannot be adjusted in the market, and therefore the whole scanner unit must be replaced.


- 10) Slide the CCD unit in the arrow direction (CCD sub scanning direction) to change the installing position.

When the copy image is longer than the original, move in the direction of B.

When the copy image is shorter than the original, move in the direction of A.

One scale of scribe line corresponds to 0.2%.

At that time, fix so that the CCD unit is in parallel with the scales on the front frame side and on the rear frame side of the CCD unit base.



At that time, fix the CCD unit so that it is in parallel with the marked line in procedure 9).

11) Make a copy, and check the copy magnification ratio.

If the copy magnification ratio is outside the range of $100\% \pm 1\%$, repeat procedures 9) to 11) until it is in the range.

Note: Due to the structure of the optical system, when the CCD unit fixing position is changed with SIM 48-1 set to 50, the copy magnification ratio is adjusted to the specified level ($100 \pm 1.0\%$) and the specified resolution is provided.


ADJ 8 Sub scanning direction copy magnification ratio adjustment

This adjustment must be performed in the following cases:

- When the copy magnification ratio in the copy image sub scanning direction is improper.
- When the scanner motor is replaced.
- When a U2 trouble occurs.
- When the MFP main PWB is replaced.
- When the EEPROM of the MFP main PWB is replaced.

Before this adjustment, perform the focus adjustment (CCD unit installing position adjustment).

1) Place a scale on the original table as shown below.




2) Enter the SIM 48-1 mode.

3) Make a normal copy and obtain the copy magnification ratios.


Copy magnification ratio

$$= \frac{(\text{Original dimension} - \text{Copy dimension})}{\text{Original dimension}} \times 100 [\%]$$


(Example 1)
Copy A
(Shorter than
the original)



Scale
(Original)



(Example 2)
Copy B
(Longer than
the original)



4) Check that the copy magnification ratio is within the specified range ($100 \pm 1.0\%$).

If the copy magnification ratio is within the specified range ($100 \pm 1.0\%$), the adjustment is completed.

If not, perform the following procedure.

5) Change the scan mode adjustment value of SIM 48-1.

When the adjustment value is increased, the sub scanning direction copy magnification ratio is increased.

A change in the adjustment value by 1 corresponds to a change in the copy magnification ratio by about 0.1%.

Repeat procedures 3) to 5) until the copy magnification ratio is within the specified range ($100 \pm 0.28\%$).

Note: Fix the adjustment value of SIM 48-1 adjustment mode (F – R) to 50.

ADJ 9 Main scanning direction copy image position adjustment (Scanner (reading) section)

This adjustment must be performed in the following cases:

When the scanner (reading) section is disassembled.

When the scanner (reading) unit is replaced.

When the RADF section is disassembled.

When the RADF unit is installed.

When the RADF unit is replaced.

When a U2 trouble occurs.


When the MFP main PWB is replaced.

When the EEPROM of the MFP main PWB is replaced.

1) Make a copy in the adjustment chart adjustment mode. (Document table or RADF)

2) Check the copy image center position.

If $A - B = \pm 4.0\text{mm}$, there is no need to adjust.



If the above condition is not satisfied, perform the following procedures.

3) Enter the SIM 50-12 mode.

4) Select the adjustment mode with the scroll key.

5) Enter the adjustment value with the 10-key and press the [OK] key. The entered value is set.

* When the set value is increased, the image is shifted to the rear side. When the set value is decreased, the image is shifted to the front side.

When the set value is change by 1, the image is shifted by about 0.4mm.

Repeat procedures 2) to 5) until the above condition is satisfied.

ADJ 10 Copy image position/image loss/void area adjustment

This adjustment must be performed in the following cases:

- When the scanner (reading) section is disassembled.
- When the scanner (reading) unit is replaced.
- When the resist roller section is disassembled.
- When a U2 trouble occurs.
- When the MFP main PWB is replaced.
- When the EEPROM of the MFP main PWB is replaced.

This adjustment uses SIM 50-2 and SIM 50-1.

The above two simulations are used in the following manner.

SIM 50-2: Rough adjustment

SIM 50-1: Fine adjustment

If the desired value is obtained by SIM 50-2, there is no need to perform SIM 50-1.

(Adjustment item)

| No. | Adjustment item | SIM 50-2 set item | SIM 50-1 set item | Adjustment value |
|-----|--|-------------------|-------------------|------------------|
| 1 | Lead edge image loss | IMAGE LOSS | IMAGE LOSS | 4.0 ± 1.0mm |
| 2 | Lead edge void area | DEN-A | DEN-A | 4.0 ± 1.0mm |
| 3 | Rear edge void area | DEN-B | DEN-B | 4.0 ± 1.0mm |
| 4 | Image reference position | | RRC-A | |
| 5 | Paper timing | | RRC-B | |
| 6 | Distance between image lead edge position and scale of 10mm x 10 | L1 | | |
| 7 | Distance between paper lead edge and image lead edge x 10 | L2 | | |


Adjustment items 1 to 3 can be adjusted either with SIM 50-1 or with SIM 50-2.

The adjustment values 6 and 7 will affect the adjustment items 4 and 5 automatically.

Therefore, adjusting the items 6 and 7 will lead to the same result as adjusting the items 4 and 5 directly.

- 1) Place a scale on the original table as shown below.

Note that the scale must be placed in parallel with the scanning direction and that the scale lead edge must be in close contact with the original guide plate.




- 2) Enter the SIM 50-2 mode.
- 3) Set IMAGE LOSS and DEN-A to "20".
- 4) Set all the set items of L1 and L2 to "0".
- 5) Make a copy at 400%. (Original table mode)

- 6) Measure the copied image dimensions X and Y.

X: Distance between the copy image lead edge and the scale of 10mm.

Y: Distance between the paper lead edge and the copy image lead edge.



- 7) Multiply X, Y, and Z (unit: mm) by 10 to obtain L1, L2 respectively. Enter the values of L1, L2, and L3.

$$L1 = X \times 10$$

$$L2 = Y \times 10$$


- 8) Cancel the simulation, make a copy, and check that the lead edge image loss and void area are within the specified range shown below.

Lead edge image loss: 4.0 ± 1.0mm

Lead edge void area: 4.0 ± 1.0mm

If the above specifications are not satisfied, perform the following procedures.

- 9) Enter the SIM 50-1 mode.
 - 10) Set a scale in the same manner as procedure 3), and make a copy at 50% and at 400% in the original table mode.
 - 11) Measure the distance between the paper lead edge and the copy image lead edge of 50% copy and of 400% copy.
 - 12) Check that there is no difference between the above distance of 50% copy and that of 400% copy.
If there is a difference of 1.5mm or above, change the adjustment value of RRC-A.
- Repeat procedures 10) to 12) until the above specification is satisfied.
- 13) If the lead edge void area is not within the specified range, change the DEN-A value.
 - 14) If the lead edge void area is not within the specified range, change the IMAGE LOSS value.
 - 15) If the rear edge void area is not within the specified range, change the DEN-B value.



| | Adjustment item | Adjustment value | Note |
|------------|----------------------|------------------|--|
| IMAGE LOSS | Lead edge image loss | 4.0 ± 1.0mm | The greater the set value is, the greater the image loss is. |
| DEN-A | Lead edge void area | 4.0 ± 1.0mm | The greater the set value is, the greater the void area is. |
| DEN-B | Rear edge void area | 4.0 ± 1.0mm | The greater the set value is, the greater the void area is. |

ADJ 11 Copy color balance/density adjustment

(1) Note for the copy color balance/density adjustment

(Necessary conditions for execution of the copy color balance/density adjustment)

Before execution of the copy color balance/density adjustment, check that all the adjustments related to the copy color balance and density have been completed properly.

The importance level is as shown below.

(Adjustment items which directly affect the copy color balance and density and must be checked or adjusted before execution of the image quality adjustment)

1) Adjustment items: ADJ 2, ADJ 3, ADJ 4

| JOB No | ADJUSTMENT ITEM LIST | | | SIMULATION |
|--------|---|--------|---|------------|
| ADJ 2 | Image density sensor adjustment | | | 44-36 |
| ADJ 3 | Image focus, image skew adjustment (LED (writing) unit) | | | 64-1/61-4 |
| ADJ 4 | Image registration adjustment | ADJ 4A | Image registration adjustment (Auto adjustment) | 50-22 |
| | | ADJ 4B | Image registration adjustment (Manual adjustment) | 50-20 |

The user color balance adjustment must be set to the center (default).

| Item | Purpose | Note |
|---|--|-------------------------------------|
| User color balance setting: Default (Center) (Special function) | Set the color balance to the standard state. | Check that it is set to the center. |

The set value of SIM 46-27 is set to the default.

| SIM No | Display/Item | | Setting (Default) | Content | Phenomenon when the set value is changed | Phenomenon occurring when the adjustment value is not within the normal value range. | Note |
|--------|--------------|------------------------|-------------------|--|--|---|--|
| 46-27 | A | BLACK TEXT (SLOPE) | 50 | Black image edge section gamma (tilt) adjustment (Black text and black line reproduction adjustment) | When the set value is increased, the contrast of black line and black text outline sections is reduced. On the contrary, when the set value is decreased, the contrast is increased. (Sharpness of black text and black lines is changed.) (Text/Printed photo, Text, Text/Photograph copy mode) | The contrast and density of lines and text outline section are changed. (Sharpness of text and lines is changed.) (Text/Printed photo, Text, Text/Photograph copy mode) | For image quality adjustment, set to 50. |
| | B | BLACK TEXT (INTERCEPT) | 50 | Black image edge section density (overall level) adjustment (Black txt and black line reproduction adjustment) | The density of black lines and black text outline is changed. (Text/Printed photo, Text, Text/Photograph copy mode) | | |

The set value of the following simulation must be set to the default.

| SIMNo | Item | Setting (Default) | Phenomenon when the set value is changed | Note |
|-------------|-------|-------------------|---|--|
| 46-1 | A – R | 50 | The density and color balance in the low density section of color copy are changed. | Set to the default when adjusting the copy quality. Do not adjust the density in the low density section by using this simulation. |
| 46-2 | A – O | 50 | The density in the low density section of monochrome copy is changed. | |
| 46-10 to 16 | A – O | 500 | The color copy density and color balance are changed. (each copy mode) | Set to the default when adjusting the copy quality. |
| 46-20 | A – O | 500 | The color copy density and color balance of all copy modes are changed. | Set to the default when adjusting the copy quality. |

The following functions (HV/HT/TC/RRM/MD) of SIM 44-1 must be set to Enable.

| Item | | Setting | Phenomenon when set to Disable | |
|--------|---|---------|---|---|
| HV | Image forming section correction (process correction) (High-density image density correction) | ENABLE | The developing bias voltage correction and the main charger grid voltage correction are not performed. | Insufficient image density, background coy, improper color balance |
| HT | Half-tone image density correction | ENABLE | The half-tone image density correction is not performed. | Improper half-tone image density, background copy, improper color balance, tone jump |
| TC | Transfer output correction | ENABLE | Correction of change due to humidity and correction of the transfer voltage are not performed. | Half-ton image section roughness, improper image density, insufficient density inside of image outlines |
| RRM | RRM speed correction | ENABLE | Correction of change due to humidity and correction of the rotate speed are not performed. | Improper color balance, roughness, background coy, toner dispersion, improper image density, image deflection, image flow, image dirt |
| MD | Photoconductor membrane decrease (sensitivity/potential) correction | ENABLE | Correction of use frequency (sensitivity change) of OPC drum is not performed. (Main charger grid voltage correction) | Improper image density, background copy |
| AR | Image registration automatic adjustment | | Does not affect during image quality adjustment. | |
| AR CHK | YES/NO of error judgment in image registration automatic adjustment | | Does not affect during image quality adjustment. | |

(Adjustment items which affect the copy color balance/density but need not to be adjusted frequently. When, however, a trouble occurs, check and adjustment must be made.)

1) Adjustment item: ADJ 1, ADJ 7, ADJ 12, ADJ 13

| JOB No | ADJUSTMENT ITEM LIST | | | SIMULATION |
|--------|---|--------|--------------------------------------|------------|
| ADJ 1 | High voltage adjustment | ADJ 1A | Main charger grid voltage adjustment | 8-2 |
| | | ADJ 1B | DV bias voltage adjustment | 8-1 |
| | | ADJ 1C | Transfer voltage adjustment | 8-6 |
| ADJ 7 | Copy image focus (main scanning direction copy magnification ratio) adjustment (CCD unit position adjustment) | | | 48-1 |
| ADJ 12 | Fusing pressure adjustment | | | |
| ADJ 13 | Fusing paper guide position adjustment | | | |

(Relationship between the service contents and the copy color balance/density adjustment)

Note that procedures before and after the copy color balance/density adjustment differ depending on the machine status and the servicing job contents.


Perform proper procedures according to the flow of the copy color balance/density adjustment.

There are following five major cases:

- 1) When installing
- 2) When periodic maintenance
- 3) When consumable part is replaced in repair work
- 4) When consumable part is not replaced in repair/checking work
- 5) Other repair/check


(2) Copy color balance/density adjustment procedure flow

Follow the flowchart to perform the copy color balance/density adjustment.



(Back page)

(Back page)



Copy color balance and density check

Check the color balance and the density by making copies of Sharp gray chart and the serviceman chart.

a. Note for the copy color balance check

To check the copy color balance and density, use the Sharp gray chart and the serviceman chart. In the (Manual) Text/Printed photo mode, set the copy density level to 3, and make a color copy and a B/W copy. At that time, all the color balance adjustments of the user adjustment mode must be set to the default (center).


Be sure to use the specified paper for color.

[Sharp gray chart] (UKOG-0162FCZZ)


The copy image density of Sharp gray chart must be as follows:

Note: Use the color test chart (UKOG-0283FCZZ) to check the color balance.

(Color copy)




(Black-and-white copy)



[Serviceman chart] (UKOG-0283FCZZ)

Check the color balance of Serviceman chart copy is as shown below.

(Color copy)



ADJ 11A CCD gamma adjustment (CCD calibration) (Normal document copy mode)

This adjustment must be performed in the following cases:


- When the CCD unit is replaced.
 - When a U2 trouble occurs.
 - When the MFP PWB is replaced.
 - When the EEPROM of the MFP PWB is replaced.
 - When replacing a part in the scanner (reading) section.
- When the CCD unit is replaced, be sure to perform this adjustment.

(1) Precautions for adjustment

- 1) Check that the table glass and No. 1, 2, 3 mirrors and lenses are free from dust and dirt. (If there is dust and dirt, clean with alcohol.)
- 2) Check that there is no dirt or scratch on BK1 and BK2 patches of SIT chart (UKOG-0280FCZZ).
If there is dirt, clean with alcohol.
If there is scratch, replace the chart with new one.

(2) Adjustment procedures

- 1) Set the SIT chart (UKOG-0280FCZZ) to the left edge of the original table, and fit the center of SIT chart with the center of the glass holder.



When SIT chart is not available, execute SIM 63-5 to set the CCD gamma to the default. This method, however, provides a lower adjustment accuracy than the method by using SIT chart.

Note: Check that the SIT chart (UKOG-0280FCZZ) is closely placed on the original table.

- 2) With the SIT chart (UKOG-0280FCZZ) fixed, close the original cover.
- 3) Enter the SIM 63-03 mode, and press the [EXECUTE] key.
The automatic adjustment is started. During the automatic adjustment, the [EXECUTE] key is highlighted. When the adjustment is completed, the key returns to the normal display.

Note: The SIT chart (UKOG-0280FCZZ) is affected by light (especially by ultraviolet rays) and temperature and humidity. Put it in a bag (clear file, etc.) and store in a dark place.

ADJ 11B Copy color balance adjustment (Auto adjustment)

This adjustment must be performed in the following cases:

- When a consumable part (developer, OPC drum, the transfer belt) is replaced.
- When the CCD unit is replaced.
- When a U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.

The color balance adjustment (auto adjustment) is the automatic adjustment of cyan, magenta, yellow, and black copy density with SIM 46-24.

(When this adjustment is performed, the color balance adjustments in all the copy modes are renewed.)

(Note for performing the color balance adjustment (Auto adjustment))

- 1) The print engine section must be properly adjusted.
- 2) CCD gamma adjustment must be properly adjusted.
- 3) When setting the color patch image (adjustment pattern) paper on the original table, place 5 sheets of white paper on the color patch image paper.
- 4) Be sure to use the specified color paper.

Before execution of the copy quality check and the copy quality adjustment, be sure to execute the following corrections forcibly to set the image forming section to the optimum state.

- Execute the process correction forcibly. (SIM 44-6)
- Execute the half-tone image correction forcibly. (SIM 44-26)

a. Outline

The color balance adjustment (auto adjustment) is the automatic adjustment of cyan, magenta, yellow, and black copy density with SIM 46-24 or user program.

There are following two modes of auto color balance adjustment:

- 1) Auto color balance adjustment by the serviceman (with SIM 46-24)
- 2) Auto color balance adjustment by the user (with the user program)
(The color balance target becomes the service target.)

The auto color balance adjustment by the user is provided in order to reduce the number of service calls.

If the copy color balance is shifted by some reason, the user performs the color balance adjustment to correct it.

If, however, there is a basic problem in the machine, or if the machine environment is changed largely, this function does not serve as an effective means.

While the automatic color balance adjustment by the serviceman allows adjustment even when the machine environment is changed largely, providing normal color balance. If there is a basic problem in the machine, repair it and adjust to provide normal color balance.

The above points must be fully understood for proper operation.

When this adjustment is performed, the color balance adjustment of all the copy modes are changed.


b. Adjustment procedure

(Auto color balance adjustment by the serviceman)

- 1) Enter the SIM 46-24 mode.
- 2) Press the [EXECUTE] key.
(A3 or 11 x 17 paper is automatically selected.)
The color patch image (adjustment pattern) is printed.
- 3) Set the color patch image (adjustment pattern) printed in procedure 2) on the original table so that the dark density side of the color patch image comes to the left side. Place 5 sheets of white paper on the color patch image (adjustment pattern) paper.
- 4) Press the FACTORY key on the operation panel and press the [EXECUTE] key.

The copy color balance adjustment (step 1) is automatically performed, and the color balance check patch image is printed. Wait for a while until the operation menu of procedure 5) is displayed.

When the color balance is customized by the manual color balance (SIM 46-21) according to the user's request and then the color balance is registered as the service target by SIM 63-7, select the service target in order to adjust to that color balance.



Note: (Descriptions on the factory and the service key button in the color balance automatic adjustment menu)

There are two kinds of gamma targets for the color balance automatic adjustment: factory and service.

The factory key button and the service key button are used to select between them.

Factory target gamma: Standard color balance (Fixed)

Service target gamma: Color balance can be customized according to the user request. (Variable)


When shipping from the factory, the service target gamma data are same as the factory target gamma data.

Both are set to the standard color balance gamma.

In the service target, a customized color balance can be registered with SIM 63-7. In the factory target, it cannot be changed.

- 5) Press the OK key on the operation panel.

The initial setup of half tone image correction is performed according to this adjustment data.




Note: When OK key is pressed, initial setup of half-tone image correction is started. During this operation, "Copy Quality is being adjusted" is displayed. It takes several minutes to complete this operation.

After completion of this operation, "Please quit this mode" is displayed.

Do not cancel the simulation until "Please quit this mode" is displayed.

- 6) Check that the color balance check patch image printed at last is within the specified range shown below.



The print density should vary gradually from the lower density to the higher density without reversion of changing direction.


The density level of each color should be almost the same.

It is acceptable for patch B not to be copied.

Patch A is not copied.

Use SIM 46-21 to print the color balance adjustment sheet and compare each process (CMY) black patch color balance and the black patch. This allows a correct check on the color balance adjustment result.


If the color balance of each process (CMY) black patch in A to O is near the black patch referring to the patch, it is judged that the color balance has been correctly adjusted.



If, however, the user requests to customize the color balance instead of using the standard color balance and the color balance is in a satisfactory level, go to Step 10).

If the color balance is not satisfactory, perform the manual color balance adjustment (ADJ 11C).

7) Execute the half tone image correction. (Forcible execution) (SIM 44-26)



When [EXECUTE] key is pressed, it is highlighted and the operation is started. It takes several minutes to complete the operation. When the operation is completed, the screen returns to the original state.

After completion of the operation, cancel the simulation.

8) Use the test chart UKOG-0283FCZZ and check the copy color balance and the density in Text/Photo mode. (Refer to the section of the copy color balance and the density.)

If the copy color balance and density are not in the satisfactory level, perform the following procedures.

9) Perform initial setup of half tone image correction. (SIM 44-21)

10) Perform half tone image correction. (Forcible execution) (SIM 44-26)

11) Use the test chart UKOG-0283FCZZ and check the copy color balance and the density in manual Text/Printed photo mode. (Refer to the section of the copy color balance and the density.)

Repeat procedures 9) to 11) until they are at the satisfactory level.

However, repetition is limited to three times.

If a satisfactory result in the copy color balance or the density cannot be obtained by repetition of the above procedures 3 times or more, there may be a problem in some other sections.

Investigate the reason and repair or fix the problem, then perform all the procedures of print quality adjustment from the beginning.

If a satisfactory result in the copy color balance or the density cannot be obtained by the automatic adjustment, use SIM46-21 (ADJ11C) (automatic adjustment).

ADJ 11C Copy color balance adjustment (Manual adjustment)

This adjustment must be performed in the following cases:

- When a consumable part (developer, OPC drum, the transfer belt) is replaced.
- When the CCD unit is replaced.
- When the scanner (reading) section is cleaned.
- When a U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.

The color balance adjustment (Manual) is used to manually adjust each color copy density (C, Y, M, K) (15 points for each color) when the result of the previous automatic adjustment is unsatisfactory or when a fine adjustment is required, or when the user requests to change (customize) the color balance.

a. Note for the adjustment

This adjustment is performed only for the color patch whose result of the previous automatic adjustment is unsatisfactory.


If the color balance is out of the normal conditions, execute SIM 46-24 to make the color balance adjustment (Auto) and then execute this adjustment. This sequence leads to a better work efficiency.

Before execution of the copy quality check and the copy quality adjustment, be sure to execute the following corrections forcibly to set the image forming section to the optimum state.

- * Execute the process correction forcibly. (SIM 44-6)
- * Execute the half tone image correction forcibly. (SIM 44-26)

b. Adjustment procedures

- * Before executing the copy color balance adjustment (Manual), perform SIM 44-6 to make a compulsory process correction, updating the developing bias voltage and the main charger voltage to the latest levels.




When [EXECUTE] key is pressed, the operation is started.

It takes several minutes to complete the operation. When the operation is completed, "COMPLETE" is highlighted.

After completion of the operation, cancel the simulation.

1) Enter the SIM 46-21 mode.



2) Select PAPER SEL with the scroll key and select A3 (11 x 17) paper.


Enter the set value corresponding to the paper feed section with A3 (11 x 17) paper in it, and press the OK key.

3) Press the [EXECUTE] key.

The color balance adjustment pattern is printed.

- 4) Check that the printed pattern is in the following specification or in the desired color balance.

If not, perform the following procedures.



The print density should vary gradually from the lower density to the higher density without reversion of changing direction.

The density level of each color should be almost the same.

It is acceptable for patch B not to be copied.

Patch A is not copied.

When, however, the color balance is adjusted according to the users request, there is no need to adjust to the standard color balance as stated above.

- 5) Select the color to be adjusted and select the adjustment point with the scroll key.
- 6) Enter the adjustment value with the 10-key and press the OK key.
The adjustment value can be selected in the range of 245 to 755 (1 to 999). When SIM 46-24 is used to perform the automatic color balance and the density adjustment, all the set values of this simulation are set to 500.

To increase the density, increase the adjustment value. To decrease the density, decrease the adjustment value.

Repeat procedures 3) to 6) until the condition of procedure 4) is satisfied.

When the overall density is low or patch A is copied with a high density, use the arrow keys to change all the adjustment values of A to O simultaneously and uniformly.

Then perform the patch density adjustment. This allows to make an efficient adjustment.

By using the black patch as the reference, adjust so that the color balance of the black patch of each process (CMY) in A to O becomes virtually same as the black patch.

In this simulation mode, press CLEAR key to return to the normal copy mode and make actual copies of the service chart and user documents. Check the adjustment result.


- 7) Execute SIM 44-21.

The initial setup of half tone image correction is performed.

This procedure is to store the copy color balance adjustment data as the reference data for half-tone correction.

This procedure should be always executed immediately after completion of ADJ 11C (Color balance adjustment (Manual)) with SIM 46-21.

When ADJ 11B (Color balance adjustment (Auto)) is performed with SIM 46-24, this procedure is automatically performed.




When [EXECUTE] key is pressed, it is highlighted and the operation is started.

It takes several minutes to complete the operation. When the operation is completed, the screen returns to the original state.

After completion of the operation, cancel the simulation.

- 8) Execute the half tone image correction. (Forcible execution) (SIM 44-26)



When [EXECUTE] key is pressed, it is highlighted and the operation is started. It takes several minutes to complete the operation. When the operation is completed, the screen returns to the original state.

After completion of the operation, cancel the simulation.

- 9) Use the test chart UKOG-0283FCZZ and check the copy color balance and the density in the Text/Printed photo mode. (Refer to the section of the copy color balance and the density check.)

If the copy color balance and the density are not in the specified level, repeat procedures 7) through 9) until they are in the specified level.

However, repetition is limited to three times. If repetition of the above procedures does not set the copy color balance and the density to the specified level, there may be some other reason.

Investigate the reason and repair or fix the problem, then perform all the procedures of print quality adjustment from the beginning.

- 10) When the color balance is customized, register the color balance as the service target by SIM 63-7.

When the color balance is not customized, there is no need to perform this work.

If the customized color balance is registered as the service target, when the color balance is adjusted in the next time, the automatic color balance adjustment mode can be used.

In the next color balance adjustment, select the service target color balance in the automatic color balance adjustment mode, and the color balance will be adjusted to the same color balance as registered this time.

(Auto color balance adjustment service target gamma setup)

a. Outline

Auto color balance adjustment is performed with a certain color balance (gamma) as a target.


There are following two kinds of targets:

Only the service target among them allows optional setup of a color balance (gamma) target.

This setup must be performed in the following cases.

- When the copy color balance and the density adjustment is manually performed. (SIM 46-21)
- When a U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM on the MFP PWB is replaced.
- When the user requests to customize the color balance.
- When the service target gamma is found to be incorrect.

Kinds of color balance (gamma) target



Note: The above figure is for a brief description, and does not show the actual state.

| Kinds | | Descriptions |
|-------|---|---|
| A | Default color balance (gamma) target (fixed) | This is the average, standard color balance (gamma) target determined by the machine design. This color balance (gamma) target is identical in all the machines, without consideration for individuality of machines. When SIM 63-8 is executed, the service color balance (gamma) target becomes the same as this target. In SIM 46-24 menu, this target is not displayed. |
| B | factory color balance (gamma) target (fixed) | This is the standard color balance (gamma) target which was registered (set) in the factory, and cannot be changed in the market. This color balance (gamma) target is set depending on individuality of each machine to obtain the standard color balance. It, therefore, differs slightly in different machines. When the service target falls into an abnormal state by some reasons, this target can be used instead of it. When shipping, this target is the same as the service color balance (gamma) target. |
| C | Service color balance (gamma) target (variable) | This is the color balance target which the serviceman can register (set). This is obtained by registering (setting) with SIM 63-7 the adjustment pattern of the color balance (gamma) which was adjusted with SIM 46-21. This color balance (gamma) target is set depending on individuality of each machine to obtain the standard color balance. It, therefore, differs slightly in different machines. However, an optional color balance (gamma) target can be set according to a user's request. When shipping, this target is the same as the factory color balance (gamma) target. When SIM 63-8 is executed, the service color balance (gamma) target becomes the same as the default color balance (gamma) target. This target is used at the auto color calibration by user. |

Note: Do not execute SIM 63-8 unless there is any special reason.

(Meaning of the service target gamma data and purpose of registration)

This work must be executed only when the color balance is customized by SIM 46-21.

If the color balance is not customized, there is no need to perform this work.

Execute SIM 46-21 to adjust the color balance (Manual) according to the user request (customized color balance). Then use the adjustment pattern printed in this mode to register the service target gamma data with SIM 63-7.

This will revise the service target gamma data.

It is recommendable to record the adjustment pattern printed in the above procedure. By using the adjustment pattern, the same color balance target can be registered in another machine. It is also useful to register the service target gamma data again.

Be careful, however, not to fold the pattern or avoid discoloration and dirt.

Basically the service target gamma data must be registered immediately after completion of the color balance adjustment (Manual) with SIM 46-21.

If a considerable time has passed after completion of the color balance adjustment (Manual) with SIM 46-21, the color balance of the adjustment pattern after a considerable time differs from that before a considerable time. Do not use such an adjustment pattern.

Whether the service target gamma data are correct or not can be determined by the following.

When the adjustment result of SIM 46-24 color balance adjustment (Auto) by selecting the service target is abnormal or unsatisfactory:

In this case, the service target gamma data may be incorrect.

The possible cause is incorrectness or abnormality of the color balance adjustment pattern used when registering the service target gamma data of the color balance adjustment (Auto) with SIM 63-7.

The color balance adjustment pattern is printed after the color balance adjustment (Manual) with SIM 46-21. The possible cause lies in this procedure.

b. Setup procedure


(Procedure to set the an optional color balance (gamma) as the service target)

- 1) Two sheets of color patch image (adjustment pattern) are outputted in the copy color balance adjustment (manual adjustment) (SIM 46-21). (ADJ 11C)

At that time, when the color balance is shifted from the standard, an adjustment is required. If not, there is no need to adjust.

If an optional color balance is required according to the user's request, an adjustment is required.

- 2) Enter the SIM 63-7 mode.



- 3) Press the SETUP key.
- 4) Set the color patch image (adjustment pattern) paper properly adjusted and printed in the copy color balance adjustment (manual adjustment) (SIM 46-21) (ADJ 11C) on the original table.


The color patch image (adjustment pattern) printed by SIM 64-2 may be used. In this case, check that the printed image is proper. (The other color patch images (adjustment patterns) printed by another machine may be used.)

Set the paper on the original table so that the darker density side comes on the left side. Then place 5 sheets of white paper on the color patch image (adjustment pattern).


If it is difficult to adjust the color balance adjustment (Manual) with SIM 46-21 satisfactorily level, do not register the service target gamma data with SIM 63-7.

- 5) Press the [EXECUTE] key.

The color patch image (adjustment pattern) is read.



- 6) Press the REPEAT key, set the second color patch image paper, and perform procedure 5) again.



The color balance (gamma) target setup level of each color can be checked with K/C/M/Y keys.

The setup level values must be in the ascending sequence of B – O. If there is no change or the sequence is reversed, it is judged as an abnormality.

In case of an abnormality, resolve the problem and check again.

- 7) Press the OK key.

The color balance (gamma) corresponding to the color patch image (adjustment pattern) printed in the copy color balance adjustment (manual adjustment) (ADJ 11C) is set as the service target.

(Procedure to set the default (standard) color balance (gamma) as the service target)


* This procedure is executed only when the service target is found abnormal when the service target gamma is selected with SIM46-24 and the automatic color balance adjustment is executed, and when the user color calibration is executed.

* When the ICU EEPROM data are destroyed by U2 trouble.

When SIM 63-8 is executed, the service target gamma data are changed to the default target gamma data determined by the machine design.

When the color balance adjustment (Auto) is executed with the service target gamma data set to the default target gamma, a virtually satisfactory result will be obtained.

- 1) Enter the SIM 63-8 mode.



- 2) Press the [EXECUTE] key.
- 3) Press the YES key.

The service target becomes the same as the default (standard) target.

ADJ 11D Copy density adjustment in low-density area (Normally unnecessary to adjust.)

NOTE for SIM 46-1 and 46-2:

The major purpose of these simulations is to delete background copy simply.

SIM 46-1 and 46-2 are used to adjust the copy density in the low-density area, and they do not affect the density in the high-density area.


Note that the tone and the color phase may be changed greatly if the set value is changed greatly.

When an extreme background copy is produced, use ADJ 11C color balance adjustment (manual adjustment) (SIM 46-21) instead of this procedure.

The adjustment result of SIM 46-1 is reflected evenly to all the color copy modes.

The adjustment result of SIM 46-2 is reflected evenly to all the monochrome copy modes.

- 1) Enter the SIM 46-1 or 46-2 mode.



- 2) Select the copy mode to be adjusted with the scroll key.
- 3) Enter the adjustment value with the 10-key, and press the [OK] key.


To increase the density in the low-density area, set a greater adjustment value. To reduce the density, set a lower adjustment value. The adjustment in the low-density area can be adjusted individually for each copy mode.

The greater the set value is, the greater the density in the low-density area is, and vice versa. (The density in the high-density area is not changed.)

- 4) Cancel the simulation mode, and make a copy in the normal mode to check the copy density in the white area and the low-density area by using the test chart (UKOG-0283FCZZ).

In this simulation mode, press CLOSE key to jump to the normal copy mode and make actual copies of the service chart and user documents. In this manner, the adjustment result can be checked.

The adjustment can be performed also by switching between the simulation mode and the normal copy mode alternately and checking the adjustment result with actual copies.



Check the copy density in the low-density area and the white area of the color patch section.

ADJ 11E Copy color balance density adjustment (each copy mode)

This adjustment must be performed in the following cases:

- * When a U2 trouble occurs.
- * When the MFP PWB is replaced.
- * When the EEPROM of the MFP PWB is replaced.

Used to adjust the gamma and the density in each copy mode individually. The adjustment in each copy mode is not required normally, but is performed when the user requests it.

- 1) Enter either of SIM 46-10 to 46-16 modes.

(Select the simulation according to the copy mode to be adjusted.)

| Copy mode | | | | | Adjustment (Simulation) | | | | | |
|--|--------------------|------------------------|--|--------------------|--|-----|--|----------|---|-----|
| | | | | | Color balance/ density adjustment of each copy mode | | Collective color balance/density adjustment of all copy modes | | Low-density area color balance/ density adjustment | |
| | | | | | Main | Sub | Main | Sub | Main | Sub |
| Full color | AUTO | | Auto (Auto document kind recognition, auto exposure) | Text | 46 | 11 | 46 | 21/20/24 | 46 | 1 |
| | | | | Text/printed photo | 12 | | | | | |
| | | | | Printed photo | 12 | | | | | |
| | | | | Photograph | 13 | | | | | |
| | | | | Text/Photograph | 14 | | | | | |
| | TEXT | NORMAL | Text | Normal | 11 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| | | COPT TO COPY | | Copy document | 10 | | | | | |
| | MAP | NORMAL | Map | Normal | 11 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| | PRINTED PHOTO | NORMAL | Printed photo | Normal | 12 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| | | COPT TO COPY | | Copy document | 10 | | | | | |
| | TEXT/PRINTED PHOTO | NORMAL | Text/printed photo | Normal | 12 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| | | COPT TO COPY | | Copy document | 10 | | | | | |
| | PHOTOGRAPH | NORMAL | Photograph | Normal | 13 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| | TEXT/PHOTO | NORMAL | Text/Photograph | Normal | 14 | | | | | |
| | | COLOR TONE ENHANCEMENT | | Color emphasis | | | | | | |
| Single color (Affected by the adjustment result of full color mode) | TEXT | NORMAL | Text | Normal | 25/(26) | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | MAP | NORMAL | Map | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | PRINTED PHOTO | NORMAL | Printed photo | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | TEXT/PRINTED PHOTO | NORMAL | Text/printed photo | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| PHOTOGRAPH | NORMAL | Photograph | Normal | | | | | | | |
| | TEXT/PHOTO | | NORMAL | Text/Photograph | Normal | | | | | |
| Monochrome | AUTO1 (* 1) | | Auto 1 (Japan) | | 15/(16) | | | 2 | | |
| | AUTO2 (* 1) | | Auto 2 (Except Japan) | | | | | | | |
| | TEXT | NORMAL | Text | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | MAP | | Map | | | | | | | |
| | PRINTED PHOTO | NORMAL | Printed photo | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | TEXT/PRINTED PHOTO | NORMAL | Text/printed photo | Normal | | | | | | |
| | | COPT TO COPY | | Copy document | | | | | | |
| | PHOTOGRAPH | | Photograph | | | | | | | |
| TEXT/PHOTO | | Text/Photograph | | | | | | | | |

* The copy color balance and the density in the color enhancement mode are automatically determined by the adjustment result of the color normal mode. The adjustment unique to this mode cannot be made.

*1: Select either one. The default setting differs depending on the destination.

- 2) Select the color to be adjusted with the color select key, and select the adjustment point with the scroll key.
- 3) Enter the adjustment value with the 10-key, and press the OK key.

The adjustment value can be selected in the range of 245 to 755. When the automatic color balance and the density are adjusted with SIM 46-24, all the set values of this simulation are set to 500.

To increase the density, increase the adjustment value. To decrease the density, decrease the adjustment value.

ADJ 11F CCD gamma adjustment (CCD calibration) (Copy document copy mode)

This adjustment is the CCD gamma adjustment (CCD calibration) for the copy document copy mode, and is different from the CCD gamma adjustment (CCD calibration) in the normal document copy mode (ADJ 11A). There are above two kinds of the CCD gamma adjustment (CCD calibration), and both adjustments are required.

This adjustment is required in the following cases:

- After execution of the CCD gamma adjustment (CCD calibration) (normal document copy mode) (ADJ11A) and when the copy color balance is customized with SIM46-21.


(1) Note before adjustment

- * Check that the table glass, No. 1/2/3 mirrors, and the lens surface are free from dirt and dust.
(If dirt or dust is found, clean with alcohol.)
- * Check that the patches of BK1 and BK2 of the SIT chart (UKOG-0280 FCZZ) are free from dirt or dust.
If dirt or dust is found, clean with alcohol.
If any damage is found, replace with a new one.
- * Since this adjustment is based on the normal document copy mode CCD gamma adjustment (CCD calibration) (ADJ 11A), the said adjustment must have been completed before execution of this adjustment.

The copy color balance must also have been adjusted properly.


(2) Adjustment procedure

- 1) Place the SIT chart (UKOG-0280FCZZ) on the left edge of the document table, and fit the center of the SIT chart with the center of the glass holder.



Note: Check that the SIT chart (UKOG-0280FCZZ) is in close contact with the document table.

- 2) Close the document cover without shifting the SIT chart (UKOG-0280FCZZ).
- 3) Make a copy in the Manual Photo mode.
(Be sure to use the specified copy paper.)
- 4) Set the copy made in procedure 3) on the document table so that the center of the copy paper comes to the center of the left edge of the document table.



- 5) Enter the SIM 63-09 mode and press the [EXECUTE] key.

The automatic adjustment is performed. During the adjustment, the [EXECUTE] key is highlighted. When the adjustment is completed, the [EXECUTE] key returns to the normal display.

- 6) Cancel the simulation mode.

Note: The SIT chart (UKOG-0280FCZZ) is affected by lights (especially ultra-violet rays) and temperature and humidity. Store it in a clear file (nylon file) in a dark place.

ADJ 11G Image edge section gamma/density adjustment (Black text and black line reproduction adjustment) (Normally unnecessary to adjust.)

The gamma or density of black toner component images is changed to adjust the reproduction of the profile of the black character and line optionally. Especially the thickness of fine black character and line is changed.


Since the black toner component image quantity differs depending on each copy mode, be careful to selection of the copy mode when checking the result of this adjustment. Check in the Text/Printed photo copy mode.

This adjustment is valid only in the Text mode, the Text/Printed photo mode, and the Text/Photograph mode.

When the adjustment value different from the default value is used, this adjustment must be performed in the following cases:

- When U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.

- 1) Enter the SIM 46-27 mode.



- 2) Enter the adjustment value with the 10-key.

BLACK TEXT Black image edge section gamma (tilt) adjustment (SLOPE): (Black text and black line reproduction adjustment)

When the adjustment value is increased, the black toner component image contrast becomes greater, and vice versa.

BLACK TEXT Black image edge section density (overall level) (INTERCEPT): adjustment (Black txt and black line reproduction adjustment)

The greater the adjustment value is, the greater the density is, and vice versa.

Normally set to the default (50).

- 3) Press the [OK] key.
- 4) Cancel the simulation, and make a copy in the Text/Printed Photo mode to check the reproduction of fine black character and line.
Use a document with black characters and lines on it for checking.

ADJ 11H Copy color balance adjustment (Single color Copy mode) (Normally unnecessary to adjust.)

This adjustment is used to adjust color balance and the density according to the user's demand.

The adjustment is made by setting the max. density level of Y, M and C in each color.

This adjustment is required in the following cases when the default was changed:


- When a consumable part (developer, photoconductor drum, transfer belt) is replaced.
- When the CCD unit is replaced.
- When the scanner (reading) section is cleaned.
- When U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.

a. Note for the adjustment

- * This adjustment is not required in the normal state, but executed only when the user requests for.

b. Adjustment procedure

- 1) Enter the SIM 46-25 mode.



- 2) Select the color to be adjusted with the scroll key.
- 3) Select the color with the color key.
- 4) Enter the adjustment value of each toner color with the 10-key.
(Default)

| Display | Content | Min value | Max value | Default value | | |
|---------|---------|-----------|-----------|---------------|-----|-----|
| | | | | C | M | Y |
| A | COLOR1 | RED | 0 | 255 | 0 | 255 |
| B | COLOR2 | GREEN | 0 | 255 | 255 | 0 |
| C | COLOR3 | BLUE | 0 | 255 | 255 | 0 |
| D | COLOR4 | YELLOW | 0 | 255 | 255 | 0 |
| E | COLOR5 | MAGENTA | 0 | 255 | 0 | 255 |
| F | COLOR6 | CYAN | 0 | 255 | 0 | 255 |

- 5) Cancel the simulation mode and make a copy in the single color copy mode to check.

ADJ 11I Auto color balance adjustment by user (Copy color balance auto adjustment enable setting and adjustment)

a. Outline

The user can perform the copy color balance and auto density adjustment in the user program mode.

SIIM 26-53 is used to Enable or Disable this operation.

Note: This setup is performed only when the user understands the copy color balance and the auto density adjustment and is capable of performing the operation.


Full explanations on the operating procedure, notes, and operations must be given to the user.

This setting is required in the following cases:

- * When a U2 trouble occurs.
- * When the PCU main PWB is replaced.
- * When the EEPROM on the PCU main PWB is replaced.

b. Setup procedure

- 1) Enter the SIM 26-53 mode.



- 2) Select Enable/Disable with the 10-key.

Disabling = 0: YES

Enabling = 1: NO


- 3) Press the OK key.

When "0: YES" (Disabling) is selected, the user auto color calibration (copy color balance, auto density adjustment) menu is not displayed in the user program mode.

(Auto color calibration by the user (Auto color balance adjustment))

Note: This adjustment is based on the service target color balance set with SIM 63-7 or 63-8. If, therefore, the above simulation is not completed normally, this adjustment will not be completed normally.


- 1) Enter the user program mode.
- 2) Enter the copy mode.
- 3) Press the auto color calibration key.



- 4) Press the [EXECUTE] key.

The color patch image (adjustment pattern) is printed.

- 5) Set the color patch image (adjustment pattern) printed in procedure 4) on the original table so that the darker density side comes to the left side. Place 5 sheets of white paper on the color patch image (adjustment pattern) paper.



- 6) Press the [EXECUTE] key. The copy color balance adjustment (step 2) is automatically performed. After completion of the adjustment, the display returns to the original menu.

ADJ 11J Background process conditions setting in the color auto copy mode, image auto recognition conditions setting, text-on-dot recognition conditions setting

This adjustment is required in the following cases when the default was changed:

- When U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.
- When a request is made by the user.

(Foundation removal operation condition setting)

This adjustment is valid only in the color auto copy mode (Text, Text/Printed photo, Text/Photograph, Printed photo, Photograph).

- 1) Enter the SIM 46-33 mode.
- 2) Select the COLOR AE mode.
- 3) Select the setting mode with the scroll key.
 - A: Foundation process judgment level setting (Judged by the ratio of printed photo in the document (ratio of dotted area).)
 - B: Foundation process judgment level setting (Judged by the document foundation color phase.)
 - C: Foundation removal quantity setting
- 4) Enter the set value with the 10-key and press the OK key to set the entered value.

(Relationship between the set value and foundation removal operation)

| Display | Set value (Display) | | Ratio of printed photo in the document (Ratio of dot areas) | | | |
|---------|---------------------|--------------|--|-----------------|---------------|-----------|
| | | | None or little | Little – Medium | Medium – Much | Very much |
| A | 0 | LOW | NO | NO | NO | NO |
| | 1 | RATHER LOW | YES | NO | NO | NO |
| | 2 (Default) | MIDDLE | YES | YES | NO | NO |
| | 3 | RATHER HIGHT | YES | YES | YES | NO |
| | 4 | HIGHT | YES | YES | YES | YES |

| Display | Set value (Display) | | Color phase in the document | | | |
|---------|---------------------|--------------|-----------------------------|---------------|-----------------|-------------|
| | | | None or Weak | Weak – Medium | Medium – Strong | Very strong |
| B | 0 | LOW | NO | NO | NO | NO |
| | 1 | RATHER LOW | YES | NO | NO | NO |
| | 2 (Default) | MIDDLE | YES | YES | NO | NO |
| | 3 | RATHER HIGHT | YES | YES | YES | NO |
| | 4 | HIGHT | YES | YES | YES | YES |

YES: Foundation removal is performed.

NO: Foundation removal is not performed.

(Foundation removal quantity setting)

| Display | Set value (Display) | Foundation removal quantity |
|---------|---------------------|-----------------------------|
| C | -4 | Little ↑ |
| | -3 | |
| | -2 | |
| | -1 | |
| | 0 | |
| | 4 (Default) | ↓ Much |
| | +1 | |
| | +2 | |
| | +3 | |
| | +4 | |

Whether the foundation removal is performed or not is determined by the AND condition of the set items A and B.

(Image auto recognition condition setting)

Used to set whether the text area is regarded important or not in judgment of printed photo and the text/printed photo or photograph and text/photograph.

- 1) Select the ORG RECOG mode.
- 2) Enter the set value with the 10-key and press the [OK] key to set the entered value.


| Display | Set value | | Content |
|---------|--------------------|--------------------------|--|
| A | TEXT PRIORITY MODE | 0 DISABLE | There must be considerable level of text area to judge as text/printed photo or text/photograph. |
| | | 1 (Default) ENABLE | Only a light level of text area is enough for judging as text/printed photo or text/photograph. |

(Text-on-dots recognition condition setting)

Used to set whether the text on dots is recognized as text or not.

- 1) Select the SEG mode.
- 2) Select the set mode A with the scroll key.
- 3) Enter the set value with the 10-key and press the [OK] key to set the entered value.

| Display | Set value | | Content |
|---------|-------------|--------|--|
| A | 0 (Default) | OFF | Text on dots is not recognized as text. |
| | 1 | ENABLE | Text on dots is recognized as text. (Priority is placed on the reproduction of text.) |



(Setting the reproduction (text recognition level) of text on dots of a document printed by the printer)

This function is effective especially when copying a document that is printed by an inkjet printer or a laser printer in the automatic color copy mode.

Some inkjet printers and laser printers express gradations with the thickness of lines. In that case, line images may be erroneously recognized as text images.

When recognized as text images, the area is printed with sharp edges and high contrast, losing gradations. In addition, dirt may appear on the print.

To cope with this problem, the text (edge) recognition level can be adjusted.



- 1) Select the SEG mode.
- 2) Select the setting mode B with the scroll key,
- 3) Enter the set value with the 10-key and press the [OK] key to set the entered value.

| Display | Set value | | Content |
|---------|----------------|-----|---|
| B | 0 (Default) | OFF | Normal mode (Normal text recognition level) Depending on the type of documents, text images may be with sharp edges and high contrast. |
| | 1 | ON | Mode for documents printed by a printer: Documents are copied in a similar picture quality. (Low text recognition level) |

ADJ 12 Fusing pressure adjustment

This adjustment must be performed in the following cases:


- When the fusing section is disassembled.
 - When a fusing trouble occurs.
 - When wrinkles are generated on paper in the fusing section.
- 1) Select A4 (8.5 x 11) paper.
 - 2) With the document cover open, press the start key of monochrome copy.
 - 3) A copy of black background is made.
 - 4) Open the left door.
 - 5) Insert paper into the pre-transfer paper guide, and turn the fusing roller knob.



- 6) With the paper squeezed in the pre-transfer paper guide, wait for about 10sec.
- 7) Turn the fusing roller knob to remove the paper from the fusing section.
- 8) Measure the dimension (L) of the center section of the glittering line made by the fusing roller. Check that the dimension is in the specified range.


Check that the pressure balance between the front and the rear frame sides is proper.

Value L = About 5.5mm



If the above conditions are not satisfied, perform the following procedure.

- 9) Turn the pressure adjustment screw on the front and the rear frame sides of the fusing unit to adjust the fusing pressure.



Repeat procedures 2) to 9) until the condition of procedure 8) is satisfied.


ADJ 13 Fusing paper guide position adjustment

This adjustment must be performed in the following cases:

- When the fusing section is disassembled.
- When a paper jam occurs in the fusing section.
- When wrinkles are generated on paper in the fusing section.
- When image deflection or unclear image is produced in the paper rear edge area.

The standard fixing position is at the center. However, change the position depending on the situations.

- When wrinkles are made on paper, shift the position upward.
- When image deflection or unclear image is produced in the paper rear edge area, shift the position downward.




ADJ 14 Document size sensor adjustment

This adjustment must be performed in the following cases:


- When the original size sensor section is disassembled.
- When the original size sensor section is replaced.
- When a U2 trouble occurs.
- When the PCU main PWB is replaced.
- When the EEPROM of the PCU main PWB is replaced.

ADJ 14A Original size sensor detection point adjustment

- 1) Enter the SIM 41-1 mode.




Gradually tilt the original detection arm unit. Loosen the original cover switch actuator adjustment screw so that the highlight display of OCSW is turned to the normal display when the height of the arm unit top from the table glass is $32 \pm 0.5\text{mm}$. Slide the actuator to adjust. (If the ON timing of the original cover switch is shifted, the original detection function may malfunction.)



ADJ 14B Original size sensor sensitivity adjustment

- 1) Enter the SIM 41-2 mode.



- 2) Make the sensor adjustment without an original.
With the original cover open and without an original on the original table, press the [EXECUTE] key.


- 3) Place A3 (11 x 17) document on the document table and press the [EXECUTE] key.

ADJ 15 Manual paper feed tray paper size sensor adjustment


This adjustment must be performed in the following cases:

- When the manual paper feed tray section is disassembled.
- When the manual paper feed tray unit is replaced.
- When a U2 trouble occurs.
- When the PCU PWB is replaced.
- When the EEPROM of the PCU PWB is replaced.


- 1) Enter the SIM 40-2 mode.



- 2) Set the manual paper feed guide to the maximum position.



- 3) Press the [EXECUTE] key.
The [EXECUTE] key is highlighted. Then it returns to the normal display. The manual paper feed guide maximum width position detection level is recognized.
- 4) Set the manual paper feed guide to A4 (11 x 8.5") size width.
- 5) Press the [EXECUTE] key.
The [EXECUTE] key is highlighted. Then it returns to the normal display. The manual paper feed guide A4 (11 x 8.5") width position detection level is recognized.
- 6) Set the manual paper feed guide to A4R (11 x 8.5"R) size width.
- 7) Press the [EXECUTE] key.
The [EXECUTE] key is highlighted. Then it returns to the normal display. The manual paper feed guide A4R (11 x 8.5" R) width position detection level is recognized.
- 8) Set the manual paper feed guide to the minimum position.



- 9) Press the [EXECUTE] key.

The [EXECUTE] key is highlighted. Then it returns to the normal display. The manual paper feed guide minimum width position detection level is recognized.


If the above procedure is not completed normally, "ERROR" is highlighted. If the above procedure is completed normally, the above data are stored and "COMPLETE" is highlighted.

ADJ 16 Touch panel coordinates setting

This adjustment must be performed in the following cases:

- When the operation panel is replaced.
- When a U2 trouble occurs.
- When the MFP PWB is replaced.
- When the EEPROM of the MFP PWB is replaced.

- 1) Enter the SIM 65-1 mode.



- 2) Touch the four cross marks on the display.

When the cross marks are pressed, the buzzer sounds and they are changed into gray display. When the touch panel adjustment is completed by pressing all the four marks, the display returns to the simulation sub code number entry menu.


If there is any abnormality, the first display is shown again.

- * When touching the crosses, never use a needle or a pin with a sharp point.

ADJ 17 Power voltage adjustment

This adjustment must be performed in the following cases:

- When a part in the DC power unit is replaced.



ADJ 17A 3.4 V power voltage adjustment


- 1) Put the multi-meter on the 3.4V line of the DC main PWB and GND.
- 2) Turn VR701 on the DC main PWB to adjust so that the voltage is 3.4V.

ADJ 17B 5.0 V power voltage adjustment

- 1) Put the multi-meter on the 5.0V line of the DC main PWB and GND.
- 2) Turn VR702 on the DC main PWB to adjust so that the voltage is 5.0V.

ADJ 18 FAX/scanner mode image loss adjustment

- 1) Enter the SIM 40-2 mode.



- 2) Select the adjustment mode with the scroll key.

| Content | Adjustment range | Default value |
|---|------------------|---------------|
| FAX mode image loss | 0 to 99 | 20 |
| Scanner modes (all except for the copy mode) image loss | 0 to 99 | 40 |

- 3) Enter the adjustment value at the selected point with the 10-key and press the OK key to set the entered adjustment value.

When the adjustment value is changed, the image losses at the four corners are changed uniformly.

[9] SIMULATION

(Diagnostics, setup, adjustment value input, data display)

1. Outline and purpose

The simulation has the following functions to grasp the machine operating status, identify the trouble position and causes in an earlier stage, and make various setups and adjustments speedily for improving the serviceability of the machine.

- 1) Various adjustments
- 2) Setup of specifications and functions
- 3) Canceling troubles
- 4) Operation check
- 5) Various counters check, setup, and clear
- 6) Machine operating status (operation history) data check, clear
- 7) Transfer of various data (adjustments, setup, operations, counters)

The operating procedures and the displays differ depending on the form of the operation panel of the machine.

2. Code-type simulation

A. Operating procedures and operations


* Entering the simulation mode

- 1) #/P key (program) ON → Asterisk (*) key ON → CLEAR key ON → Asterisk (*) key ON → Ready for input of a main code of simulation
- 2) Entering a main code with the 10-key → START key ON
- 3) Entering a sub code with the 10-key → START key ON
- 4) Select an item with the scroll key and the item key.
- 5) The machine enters the mode corresponding to the selected item.
Press START key or EXECUTE key to start the simulation operation.

To cancel the current simulation mode or to change the main code and the sub code, press the user setup key.

* Canceling the simulation mode to return to the normal mode

- 1) Press CLEAR ALL key.



B. Simulation list

(1) Main/ Sub

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|------------------------------|---|--------|-----------|--|
| Main | Sub | | | | | | |
| 1 | 1 | Used to check the operations of the scanner unit and its control circuit. | Operation test/check | Scanner (Image scanning) | | Operation | |
| | 2 | Used to check the sensors and detectors in the scanner section and the related circuits. | Operation test/check | Scanner (Image scanning) | | Operation | |
| | 5 | Used to check the scanner (scanning) unit and its control circuit. | Operation test/check | Scanner (Image scanning) | | Operation | |
| 2 | 1 | Used to check the operations of the RADF unit and the control circuit. (The document feed operation is repeatedly performed.) | Operation test/check | RADF | | Operation | |
| | 2 | Used to check the operations of the sensors and detectors in the RADF unit and the related circuits. | Operation test/check | RADF | | Operation | |
| | 3 | Used to check the operations of the loads in the RADF unit and the control circuits. | Operation test/check | RADF | | Operation | |
| 3 | 2 | Used to check the operations of the sensors and detectors in the finisher and the related circuits. | Operation test/check | Finisher | | Operation | |
| | 3 | Used to check the loads in the finisher and the control circuit. | Operation test/check | Finisher | | Operation | |
| | 10 | Used to adjust the sections in the finisher. | Operation test/check | Finisher | | Operation | |
| 4 | 2 | Used to check the operations of the desk/large capacity tray sensors and detectors and the related circuits. | Operation test/check | Paper feed | | Operation | |
| | 3 | Used to check the operations of the desk/large capacity tray loads and the control circuit. | Operation test/check | Paper feed | | Operation | |
| | 5 | Used to check the operations of the clutch TRC and the monitor. | Operation test/check | Paper feed | | Operation | |
| 5 | 1 | Used to check the operations of the display lamp (LED)/LCD on the operation panel and the control circuits. | Operation test/check | Operation (Display, procedure) | | Operation | |
| | 2 | Used to check the operations of the heater lamp and its control circuit. | Operation test/check | Fusing | | Operation | |
| | 3 | Used to check the operations of the scanner lamp and its control circuit. | Operation test/check | Scanner (reading) | | Operation | |
| | 4 | Used to check the operations of the discharge lamp and its control circuit. | Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | Others | Operation | |
| 6 | 1 | Used to check the operations of the loads (clutches and solenoids) in the paper transport system, transfer, and fusing, and the control circuit. | Operation test/check | Paper transport (paper exit, switchback, transport), transfer, fusing | | Operation | |
| | 2 | Used to check the operations of the fan motors and the control circuits. | Operation test/check | Others | | Operation | |
| 7 | 1 | Used to set the aging conditions. | Setting/Operation test/check | | | Operation | |
| | 6 | Used to set the cycle of intermittent aging. | Setting/Operation test/check | | | Operation | |
| | 8 | Used to set Yes/No of warm-up time display. | Setting/Operation test/check | | | Operation | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|--|--|--|-----------------|-----------------------------|
| Main | Sub | | | | | | |
| 7 | 9 | Used to check the image quality and operations of each color. | Operation test/check | Others | | Picture quality | |
| 8 | 1 | Used to check and adjust the operations of the developing bias voltage of each color and the control circuit. | Adjustment/ Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | | | |
| | 2 | Used to check and adjust the operation of each print mode main charger grid voltage and the control circuit. | Adjustment/ Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | | | |
| | 6 | Used to check and adjust the operation of the transfer charger current and the control circuit. | Adjustment/ Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | | Transfer | |
| 9 | 2 | Used to check the operation of the sensors and detectors in the inverter/duplex section and the control circuit. | Operation test/check | Inverter/Duplex | | Operation | |
| | 3 | Used to check the operations of the loads (motor, clutch, solenoid) in the inverter/duplex section and the control circuits. | Operation test/check | Inverter/Duplex | | Operation | |
| 14 | 0 | Used to cancel self diag troubles H3, H4, and H5. Inhibition of the color copy mode operation is canceled. | Clear/cancel (Trouble etc.) | | | Trouble | Error |
| 15 | 0 | Self diag U6-09 (large capacity paper feed tray) trouble cancel | Clear/cancel (Trouble etc.) | Paper feed | | Trouble | |
| 16 | 0 | Used to cancel self diag trouble U2. | Clear/cancel (Trouble etc.) | | | Trouble | Error |
| 17 | 0 | Used to cancel self diag troubles PF (copy inhibition command from the host computer). | Clear/cancel (Trouble etc.) | Communication (RIC/MODEM) | | Trouble | Error |
| 21 | 1 | Used to set the maintenance cycle. | Setting | | | Specifications | Counter |
| 22 | 1 | Used to check the print count value in each section and each operation mode. (Used to check the maintenance timing.) | Adjustment/Setting/ Operation data output, check (display, print) | | | Counter | |
| | 2 | Used to check the total misfeed count and the total trouble count. (If the misfeed count is considerably great, it may be judged as necessary to repair. By dividing this count by the total count, the misfeed rate can be obtained.) | Adjustment/Setting/ Operation data output, check (display, print) | | | Trouble | |
| | 3 | Used to check misfeed positions and the misfeed count of each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.) (Machine section only) | Adjustment/Setting/ Operation data output, check (display, print) | | | Trouble | Misfeed |
| | 4 | Used to check the total trouble (self diag) history. | Adjustment/Setting/ Operation data output, check (display, print) | | | Trouble | |
| | 5 | Used to check the ROM version of each unit (section). | Others | | | Software | |
| | 6 | Used to print the setting and adjustment data list. | Adjustment/Setting/ Operation data output, check (display, print) | | | Data | Setting/ Adjustment data |
| | 7 | Used to display the key operator code. (Used when the customer forgets the key operator code.) | User data output/ Check (Display/Print) | | | Data | User data |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|--|---|----------------|----------------|-----------------|
| Main | Sub | | | | | | |
| 22 | 8 | Used to check the number of uses of the staple, and the RADF. | Adjustment/Setting/ Operation data output, check (display, print) | | | Counter | |
| | 9 | Used to check the number of uses (print quantity) of each paper feed section. | Adjustment/Setting/ Operation data output, check (display, print) | Paper feed | | Counter | |
| | 10 | Used to check the system configuration (option, internal hardware). | Adjustment/Setting/ Operation data output, check (display, print) | | | Specifications | Option |
| | 12 | Used to check the misfeed positions and the number (history) of misfeed at each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.) | Adjustment/Setting/ Operation data output, check (display, print) | RADF | | Trouble | Misfeed |
| | 13 | Used to check the process cartridge counter. (If the count number is considerably great, it may be judged as necessary for repair.) | Adjustment/Setting/ Operation data output, check (display, print) | Process section | | Counter | |
| | 19 | Used to check the counters related to the network scanner. | Adjustment/Setting/ Operation data output, check (display, print) | Network scanner | | Counter | |
| 24 | 1 | Used to clear the misfeed counter, the misfeed history, the trouble counter, and the trouble history. (After completion of maintenance, the counters are cleared.) | Data clear | Memory | | Counter | |
| | 2 | Used to clear the data of the number of uses (print quantity) of each paper feed section. | Data clear | Paper feed | | Counter | Paper feed unit |
| | 3 | Used to clear the use number data of the staple, the RADF, and the scanner. | Data clear | Transport/Finisher | | Counter | |
| | 4 | Used to reset the maintenance counter. | Data clear | | | Counter | Maintenance |
| | 6 | Used to clear the counters. | Data clear | | | Counter | |
| | 7 | Used to clear the OPC drum (membrane decrease) correction counter. (This simulation is performed with the OPC drum is replaced.) | Data clear | Process (Photoconductor, developing, transfer, cleaning) | Photoconductor | Counter | Photoconductor |
| | 8 | Used to clear the waste toner counter in the transfer section. | Data clear | Process (Photoconductor, developing, transfer, cleaning) | Transfer | Counter | |
| | 9 | Used to clear the printer mode counter and the self-print mode print counter. (After completion of maintenance, the counters are cleared.) | Data clear | Printer | | Counter | Printer |
| | 15 | Used to clear the network scanner counter. | Data clear | Scanner section | | Counter | |
| 25 | 1 | Used to check the operation of the process section (excluding the image process section) and the toner remaining quantity sensor. (The toner remaining quantity sensor output can be monitored.) | Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | | Operation | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|---------|------------|--|----------------|-------------------------|
| Main | Sub | | | | | | |
| 26 | 2 | 1. Used to set the paper size of the large capacity tray. (When the paper size is changed, the software setup must be changed accordingly with this simulation.) 2. Used to detect 8.5 " x 13" (INCH Series) paper or documents and to set the display mode. (All paper feed modes) 3. Used to set the display form of the paper kind in the manual paper feed mode. | Setting | Paper feed | | Specifications | |
| | 3 | Used to set the auditor specification mode. Setting must be made according to the use conditions of the auditor. | Setting | Auditor | | Specifications | |
| | 5 | Used to set the count mode of the total counter and the maintenance counter. | Setting | | | Specifications | Counter |
| | 6 | Used to set the destination specifications (paper, fixed copy magnification ratios, image (process) correction, machine operation in case of an error, etc.). | Setting | | | Specifications | Destination |
| | 10 | Used to set the trial mode of the network scanner. | Setting | Scanner | | Specifications | |
| | 18 | Used to set YES/NO of toner save operation. (This simulation is Enable only for Japan and UK versions. It depends on SIM 26-6 (Destination) setting. For the other destinations, the same setting can be made by the user program P22. (Effective only in the monochrome copy mode) | Setting | | | Specifications | Operation mode (Common) |
| | 35 | Used to set whether the trouble history display by SIM 22-4 is displayed as one trouble or as the accumulated number of continuous troubles when two or more troubles of same kind occur continuously. | Setting | | | Specifications | |
| | 38 | Used to set "Continue/Discontinue" of printing when toner life is reached. | Setting | | | Specifications | |
| | 41 | Used to set Enable/Disable of AMS operation in the center-binding mode. | Setting | | | Specifications | |
| | 52 | Used to set YES/NO of count up of non-copy paper (cover or insertion paper). | Setting | | | Specifications | Operation mode |
| | 53 | Used by the user to set Enable/Disable auto color calibration (auto adjustment of color balance and density) | Setting | | | Specifications | Operation mode |
| | 57 | Used to set the model name for use as the status information. | Setting | | | Specifications | |
| | 65 | Used to set the finisher alarm mode. | Setting | | | Specifications | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|----------------------|----------------------------|--|----------------|-------------------------|
| Main | Sub | | | | | | |
| 27 | 1 | Used to set the specifications for operations in case of communication trouble between the host computer and MODEM (machine side). (When communication trouble occurs between the host computer MODEM and the machine, the self diag display (U7-00) is printed and setting for inhibition of print or not is made.) | Operation test/check | Communication (RIC/ MODEM) | | Specifications | Operation mode (Common) |
| | 5 | Used to enter the machine tag No. (This function allows to check the tag No. of the machine with the host computer.) | Setting | Communication (RIC/ MODEM) | | Data | User data |
| | 6 | Used to set ON/OFF of service call sending to the service center by use of RIC when trouble occurred in the machine. (The service call is not sent automatically, but sent manually.) | Setting | Communication (RIC/ MODEM) | | Specifications | Others |
| 30 | 1 | Used to check the operation of sensors and detectors in the paper feed, paper transport, paper exit sections and the related circuits. | Operation test/check | | | Operation | |
| | 2 | Used to check the operation of sensors and detectors in the paper feed section and the related circuits. (The operation of the paper feed sensors and detectors can be monitored with the LCD display.) | Operation test/check | Paper feed | | Operation | |
| 33 | 1 | Used to check the operation of the card reader and the sensors and the related circuits. (The card reader sensor operation can be monitored with the LCD display.) | Operation test/check | Others | | Operation | |
| 40 | 1 | Used to check the operation of the manual feed tray paper size detector and the related circuit. (The operation of the manual feed tray paper size detector can be monitored with the LCD display.) | Operation test/check | Paper feed | | Operation | |
| | 2 | Used to adjust the manual feed tray paper width detector detection level. | Adjustment | Paper feed | | Operation | |
| | 7 | Used to enter the adjustment value of the manual paper feed tray paper width detector detection level. (Setting) | Setting | Paper feed | | Specifications | |
| 41 | 1 | Used to check the operation of the document size sensor and the related circuit. (The operation of the document size sensor can be monitored with the LCD display.) | Operation test/check | Others | | Operation | |
| | 2 | Used to adjust the document size sensor detection level. | Adjustment | Others | | Operation | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|---|--|--|--|-----------------|-------------------------------------|
| Main | Sub | | | | | | |
| 41 | 3 | Used to check the operation of the document size sensor and the related circuit. (The document size sensor output level can be monitored with the LCD display.) | Operation test/check | Others | | Operation | |
| 43 | 1 | Used to set the fusing temperature in each operation mode. | Setting | Fixing (Fusing) | | Operation | |
| 44 | 1 | Used to set enable/disable of correction operations in the image forming (process) section. | Setting | Process (Photoconductor, developing, transfer, cleaning) | | Operation | |
| | 2 | Black image density sensor adjustment | Adjustment | | | Operation | |
| | 4 | Image forming section correction, image density sensor adjustment conditions setup | Setting | Process (Photoconductor, development, transfer) | | Picture quality | |
| | 6 | Used to forcibly execute the image forming section correction (high density process correction) (process correction). | Operation test/check | Process (Photoconductor, developing, transfer, cleaning) | | Operation | |
| | 9 | Used to check the data related to the image forming section correction (the corrected main charger grid voltage in each print mode, the developing bias voltage, etc.). (Used to check that correction is performed normally or not.) | Adjustment/Setting/Operation data output, check (display, print) | Process (Photoconductor, developing, transfer, cleaning) | | Data | Operation data (Machine conditions) |
| | 12 | Used to check the sampling toner image patch density data in the image forming section correction (high-density correction) (process correction). This simulation allows to check if the correction operation is performed normally.) | Adjustment/Setting/Operation data output, check (display, print) | Process (Photoconductor, developing, transfer, cleaning) | | Data | Operation data (Machine conditions) |
| | 13 | Color image density sensor adjustment (Adjustment by the adjustment jig) | Adjustment | Process (Transfer) | | | |
| | 14 | Used to monitor the output level of the fusing temperature sensor, the machine temperature sensor, and the humidity sensor. | Adjustment/Setting/Operation data output, check (display, print) | Others | | | |
| | 21 | Used to store color balance adjustment data. (Half tone image correction initial setting) (After execution of color balance adjustment with SIM 46-21, this simulation must be executed.) | Setting | | | Picture quality | |
| | 22 | Used to check each color toner patch image density UITU in half tone image forming section correction (process correction). (This simulation allows to check if correction operation is performed normally.) | Adjustment/Setting/Operation data output, check (display, print) | Process (Photoconductor, developing, transfer, cleaning) | | Data | Operation data (Machine conditions) |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|---|--|--|--|-----------------|-------------------------------------|
| Main | Sub | | | | | | |
| 44 | 24 | Used to check the half tone correction result. (This simulation allows to check if correction is executed properly or not.) | Adjustment/Setting/Operation data output, check (display, print) | Process (Photoconductor, developing, transfer, cleaning) | | Data | Operation data (Machine conditions) |
| | 25 | Setting the half tone correction conditions. | Adjustment/Setting/Operation data output, check (display, print) | Process (Photoconductor, developing, transfer, cleaning) | | Data | Operation data (Machine conditions) |
| | 26 | Used to execute half tone correction compulsorily. | Adjustment | Process (Photoconductor, developing, transfer, cleaning) | | Picture quality | |
| | 27 | Used to clear the half tone correction data and set to the default level. | Data clear | Process (Photoconductor, developing, transfer, cleaning) | | Data | |
| | 36 | Color image density sensor and black image density sensor adjustment (simple adjustment) | Adjustment | Process (Transfer) | | | |
| 46 | 1 | Used to adjust the copy density of each color copy mode in the low-density area. The copy densities of all colors in the low-density areas are changed. | Adjustment | Process (Photoconductor, developing, transfer, cleaning) | | Picture quality | Density |
| | 2 | Used to adjust the copy density of the low-density area in each monochrome copy mode. The copy density of the low-density area is changed. | Adjustment | | | Picture quality | Density |
| | 4 | Used to adjust the image density (color mode) in the network scan mode. | Adjustment | Scanner (reading) | | Picture quality | Density |
| | 5 | Used to adjust the image density (monochrome mode) in the network scan mode. | Adjustment | Scanner (reading) | | Picture quality | Density |
| | 6 | 1) Used to set the CCD black level offset level. 2) Used to set the CCD white level gain. | Adjustment | Scanner (reading) | | Picture quality | |
| | 10 | Used to adjust the copy color balance (color) (copy document mode) (gamma/density adjustment for each color) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 11 | Used to adjust the copy color balance (color) (text mode/map mode) (gamma/density adjustment for each color) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 12 | Used to adjust the copy color balance (color) (text/printed photo mode/Photograph mode) (gamma/density adjustment for each color) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 13 | Used to adjust the copy color balance (color) (photograph mode) (gamma/density adjustment for each color) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 14 | Used to adjust the copy color balance (color) (text/photograph mode) (gamma/density adjustment for each color) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 15 | Used to adjust the gamma and density. (Monochrome mode) | Adjustment | Image process (ICU) | | Picture quality | Density |
| | 16 | Used to adjust the gamma and density. (Monochrome mode) (The adjustment check pattern is printed.) | Adjustment | Image process (ICU) | | Picture quality | Density |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|---|------------|------------------------|--|-----------------|---------------------------|
| Main | Sub | | | | | | |
| 46 | 19 | Used to select the half tone density (gamma) in the auto exposure mode and to set the auto exposure operation mode. | Adjustment | Image process (ICU) | | Picture quality | Density |
| | 20 | Used to adjust copy color balance (All color copy mode gamma/density adjustment) (All color copy mode color balance/ gamma/density are changed.) Same as SIM 46-21, however, printing is not performed. | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 21 | Used to adjust copy color balance (All color copy mode gamma/density adjustment) (All color copy mode color balance/ gamma/density are changed.) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 23 | Used to set Enable/Disable of half-tone high-density correction. | Adjustment | | | Picture quality | Color balance |
| | 24 | Used to adjust the copy color balance automatically. (All color copy mode gamma/density adjustment) | Adjustment | | | Picture quality | Color balance |
| | 25 | Used to adjust copy color balance (Single color mode) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 26 | Used to set the copy color balance adjustment to the default. (Single color copy mode) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 27 | Used to adjust the gamma/ density in the black edge section of the copy mode image. (Black text and black line reproduction adjustment) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 28 | Used to check pre-scanning operation for automatic recognition of document in the color auto copy mode. (This simulation is used only in production, and not used in the market.) | Adjustment | Image process (ICU) | | Picture quality | Color balance |
| | 33 | Used to set the foundation process conditions in the color auto copy mode, the image auto recognition conditions, and the text recognition conditions. | Setting | Image process (ICU) | | Picture quality | |
| 48 | 1 | Used to adjust the copy magnification ratio (main scanning and sub scanning directions). | Adjustment | | | Picture quality | Size/ magnification ratio |
| | 6 | Used to adjust each motor RPM. | Adjustment | | | Operation | |
| 49 | 1 | Used for firmware version up (Machine/FAX). | Version up | Firmware (Machine/FAX) | | Operation | |
| | 2 | Used to set the data communication speed in version up of the machine firmware. | Version up | Firmware | | Operation | |
| | 10 | Used for firmware version up (Desk unit). | Version up | Firmware (Desk unit) | | Operation | |
| 50 | 1 | Used to adjust the copy image position and the void area (image loss) on print paper in the copy mode. (The similar adjustment can be made also by SIM 50-2 (Simple method).) | Adjustment | | | Picture quality | Image position |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|--|--|----------|-----------------|----------------|
| Main | Sub | | | | | | |
| 50 | 2 | Used to adjust the copy image position and the void area (image loss) on print paper in the copy mode. (Simple method) (The same content of SIM 50-1. However this simulation is easier to perform.) | Adjustment | | | Picture quality | Image position |
| | 5 | Used to adjust the image position and print area in the sub scanning direction. (Print engine section) | Adjustment | ICU/Printer | | Picture quality | |
| | 10 | Used to adjust the print image center position. (Adjustment is performed in each paper feed position separately.) | Adjustment | Image process (ICU) | | Picture quality | Image position |
| | 12 | Used to adjust the print image center position. (The adjustment is performed in each document mode separately.) | Adjustment | Image process (ICU) | | Picture quality | Image position |
| | 20 | Used to adjust the image registration. (Manual adjustment) | Adjustment | | | Picture quality | Image position |
| | 22 | Used to adjust the image registration. (Automatic adjustment) | Adjustment | | | Picture quality | Image position |
| | 24 | Used to display the adjustment data of automatic registration. | Adjustment | | | Picture quality | Image position |
| | 27 | Used to adjust image loss in the FAX/scanner mode. | Adjustment | FAX/Scanner | | Picture quality | |
| 51 | 1 | Used to adjust the transfer voltage ON timing. | Adjustment | Process (Photoconductor, developing, transfer, cleaning) | Transfer | Operation | |
| | 2 | Used to adjust the contact pressure of paper on the resist roller of each section (each paper feed and duplex feed of the copier). (This adjustment is required when the print image position variations are considerably great or when paper jams occur frequently.) | Adjustment | Paper transport (Paper exit, switchback, transport) | | Operation | |
| 52 | 1 | Used to adjust the duplex print mode stacking capacity (Used to adjust the stop position of the duplex unit paper tray width alignment plate. The home position of the width alignment plate is changed by software.) | Adjustment | Duplex | | Operation | |
| 53 | 1 | Used to adjust the document stop position in each operation mode of the RADF. | Adjustment | RADF | | Operation | |
| | 2 | Used to adjust the optical sensor sensitivity in RADF. | Adjustment | RADF | | Operation | |
| 60 | 1 | Used to check the operation of ICU PWB image DRAM read/write. | Operation test/check | ICU (Memory) | | Operation | |
| 61 | 4 | Used to adjust the scanner (writing) unit (LED array unit) skew. | Adjustment | Scanner (writing) | | Operation | |
| 63 | 1 | Used to check the result of shading correction. (The shading correction data are displayed.) | Adjustment/Setting/ Operation data output, check (display, print) | Scanner (Exposure) | | Operation | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|--|--|--------------------------------|--|-----------------|---------------|
| Main | Sub | | | | | | |
| 63 | 3 | Used to adjust the CCD color balance (gamma). | Adjustment | Scanner (reading) | | Picture quality | Color balance |
| | 5 | Used to set the CCD color balance (gamma) default. | Setting | Scanner (reading) | | Picture quality | Color balance |
| | 6 | Used to check the color balance (gamma) check patch. | Adjustment/Setting/ Operation data output, check (display, print) | Image process (ICU) | | Picture quality | Color balance |
| | 7 | Used to set the target color balance (gamma) for auto color balance adjustment. The standard color balance (gamma) or an optional color balance (gamma) is set as the service target. | Setting | Image process (ICU) | | Picture quality | Color balance |
| | 8 | Used to set the target color balance (gamma) for auto color balance adjustment (SIM 46-24). The service target is set to the default (standard) color balance (gamma). | Setting | Scanner (reading) | | Picture quality | Color balance |
| | 9 | Used to adjust the CCD gamma (CCD calibration) (copy document mode). | Setting | Scanner (reading) | | Picture quality | Color balance |
| | 10 | Used to set the copy document mode color balance (gamma) default. | Setting | Scanner (reading) | | Picture quality | Color balance |
| 64 | 1 | Used to adjust the operations of the printer section (self-print operation/color). (The print pattern, paper feed mode, print mode, print quantity, and density can be changed optionally.) | Operation test/check | Printer | | Operation | |
| | 2 | Used to print the color patch image (adjustment pattern). The above color patch image (adjustment pattern) is outputted according to the currently adjusted color balance (gamma). Use SIM 63-7 to read the color patch image (adjustment pattern), which can be used as the service target of the automatic color balance (gamma) adjustment. | Adjustment/Setting/ Operation data output, check (display, print) | Printer | | Operation | |
| | 3 | Used to check the operations of the printer section (self-print operation/BW). (The print pattern, the paper feed mode, the print mode, the print quantity, and the density can be set optionally.) | Operation test/check | Printer | | Operation | |
| 65 | 1 | Used to adjust the touch panel (LCD display section) detection position. | Adjustment | Operation (Display, procedure) | | | |
| | 2 | Used to check the result of the touch panel (LCD display) detection position adjustment. (The coordinates are displayed.) | Adjustment/Setting/ Operation data output, check (display, print) | Operation (Display, procedure) | | | |
| 67 | 1 | Used to check the operations of printer DRAM read/write. | Operation test/check | Printer | | Operation | |
| | 11 | Used to set the printer parallel I/F SELECT IN signal. | Setting | Printer | | Operation | |
| | 14 | Used to perform version up of the firmware. (Printer) | Version up | Firmware (Printer) | | Operation | |
| | 17 | Used to clear NVRAM. (Printer) | Data clear | Printer | | Others | |

| Code | | Function (Purpose) | Purpose | Section | | Item | |
|------|-----|---|------------|---------|--|--------|--|
| Main | Sub | | | | | | |
| 67 | 18 | Used to clear the Flash data. (Printer) | Data clear | Printer | | Others | |

C. Details

| | | |
|-----------------------------|---|--|
| 1 | -1 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operations of the scanner unit and its control circuit. | |
| Section | Scanner (Image scanning) | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the copy (scanning) magnification ratio with the zoom key. The magnification ratio can be increased or decreased with the [ZOOM] key by the increment of 1%. The selected magnification ratio is displayed on the magnification ratio display. 2. Press the [EXECUTE] key. | |


Scanning is performed at the magnification ratio set in procedure 1 is executed.

During scanning, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed under this state, the operation is interrupted.

After completion of scanning, the [EXECUTE] key returns to the normal display.

To resume scanning, start with procedure 2. To change the magnification ratio, start with procedure 1.


Scanning is performed at the max. scanning length (432 mm). If, however, the magnification ratio is set to a value greater than 100% in procedure 1, the scanning length is changed accordingly.



| | | |
|-----------------------------|--|--|
| 1 | -2 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the sensors and detectors in the scanner section and the related circuits. | |
| Section | Scanner (Image scanning) | |
| Item | Operation | |
| Operation/ Procedure | The operations of sensors and detectors in the scanner section are displayed. | |

The active sensors and detectors are highlighted.

- The light source unit is at the home position. a MHPS is highlighted.
- The light source unit is not at the home position. a MHPS is displayed normally.




| | | |
|-----------------------------|--|--|
| 1 | -5 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the scanner (scanning) unit and its control circuit. | |
| Section | Scanner (Image scanning) | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the copy (scanning) magnification ratio with the key (touch panel). The magnification ratio can be increased or decreased with the [ZOOM] key by the increment of 1%. The selected magnification ratio is displayed on the magnification ratio display. 2. Select the scan mode (Color / B/W). 3. Press the [EXECUTE] key. | |

1. Select the copy (scanning) magnification ratio with the key (touch panel). The magnification ratio can be increased or decreased with the [ZOOM] key by the increment of 1%. The selected magnification ratio is displayed on the magnification ratio display.
2. Select the scan mode (Color / B/W).
3. Press the [EXECUTE] key.

Scanning is repeated under the conditions set in procedures 1 and 2.

During scanning, the [EXECUTE] key is highlighted.


Scanning is repeatedly performed until the [EXECUTE] key or the interruption key is pressed.



| | | |
|-----------------------------|---|--|
| 2 | -1 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operations of the RADF unit and the control circuit. (The document feed operation is repeatedly performed.) | |
| Section | RADF | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the aging mode with the key. When selection is made, the selected item is highlighted. [1:SIDE]: Single copy aging mode [2:SIDE]: Duplex copy aging mode 2. Press the [EXECUTE] key. | |

Aging of the document feeder is executed under the conditions specified with procedure 1. During aging, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed while it is highlighted, the operation is interrupted.

To resume aging, execute with procedure 1. To change the conditions for aging, execute with procedure 1.




2 -2

| | |
|-----------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the sensors and detectors in the RADF unit and the related circuits. |
| Section | RADF |
| Item | Operation |
| Operation/ Procedure | The operations of the sensors and detectors in the RADF are displayed. The active sensors and detectors are highlighted. |

[When the RADF is installed]

| | |
|------|---|
| DSS | Empty sensor |
| DFD | Resist sensor |
| DTD | Timing sensor |
| DRS | Reverse sensor |
| DES | Paper exit sensor |
| AUOD | RADF open/close sensor |
| FGOD | Paper feed section cover open/close sensor |
| DEOS | Paper repulsion section cover open/close sensor |
| DWS1 | Tray width sensor (297mm) |
| DWS2 | Tray width sensor (11") |
| DWS3 | Tray width sensor (257mm) |
| DWS4 | Tray width sensor (210/8.5") |
| DWS5 | Tray width sensor (182mm) |
| DLS1 | Tray width sensor (240mm) |
| DLS2 | Tray width sensor (300mm) |
| DWS | Document width sensor |




2 -3

| | |
|-----------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the loads in the RADF unit and the control circuits. |
| Section | RADF |
| Item | Operation |
| Operation/ Procedure | 1. The names of the loads that can be operated are displayed. Select the load to be checked with the key, and the selected load is highlighted. 2. Press the [EXECUTE] key. |

[When RADF is installed]

| | |
|-------------|--|
| FM FORWARD | Paper feed motor forward rotation |
| DFM REVERSE | Paper feed motor reverse rotation |
| DTM FORWARD | Transport motor forward rotation |
| DTM REVERSE | Transport motor reverse rotation |
| DRM FORWARD | Paper expulsion motor forward rotation |
| DRSOL | Paper reverse solenoid |



3

3 -2


| | |
|-----------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the sensors and detectors in the finisher and the related circuits. |
| Section | Finisher |
| Item | Operation |
| Operation/ Procedure | The operating status of the sensors and detectors of the finisher is displayed. The active sensor/detector display is highlighted. |

(Sensors to be detected)

| | |
|--------|---------------------------------|
| FES | Inlet sensor |
| FPHPS | Paddle HP sensor |
| FARHPS | Bundle roller HP sensor |
| FFJHPS | Alignment HP sensor (F) |
| FRJHPS | Alignment HP sensor (R) |
| FAS | Alignment tray sensor |
| FOBHPS | Paper exit belt HP sensor |
| FBES | Tray paper sensor |
| FSLS | Paper surface sensor |
| FFPS | Binding position sensor |
| FFHPS | Binding HP sensor |
| FFRHPS | Binding roller HP sensor |
| FFES | Binding paper sensor |
| FFE | Binding clock sensor |
| FULS | Lift upper limit sensor |
| FLLS | Lift lower limit sensor |
| FLE | Lift clock sensor |
| FSHPS | Slide HP sensor |
| FSPS | Self prime sensor |
| FFDS | Front door sensor |
| FCS | Upper cover sensor |
| FFDSW | Front door switch |
| FJS | Joint switch |
| FSSS | Stapler safety switch |
| FPTS | Punch timing sensor |
| FPSS1 | Punch side resist sensor 1 |
| FPSS2 | Punch side resist sensor 2 |
| FPSS3 | Punch side resist sensor 3 |
| FPSS4 | Punch side resist sensor 4 |
| FPDS | Punch dust sensor |
| FPUC | Punch connection |
| FPSHPS | Punch side resist home position |
| FPE | Punch motor encoder |

[When the sorter is installed]

| | |
|---------|---------------------|
| SBPED | Sensor in bin |
| SLDHP | Lead cam HP sensor |
| SGBHP | Guide bar HP sensor |
| SBUHP | Bin unit HP sensor |
| SPPD | Paper exit sensor |
| SJSW | Joint switch |
| SPSW2 | Push switch 2 |
| SPSW3 | Push switch 3 |
| SDIPSW1 | DIP switch (SW1) |
| SDIPSW2 | DIP switch (SW2) |
| SDIPSW3 | DIP switch (SW3) |
| SDIPSW4 | DIP switch (SW4) |
| SDIPSW5 | DIP switch (SW5) |
| SDIPSW6 | DIP switch (SW6) |



| | |
|----------------------------|---|
| 3 | -3 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the loads in the finisher and the control circuit. |
| Section | Finisher |
| Item | Operation |
| Operation/Procedure | <ol style="list-style-type: none"> 1. The names of the loads that can be checked are displayed. Select a load to be checked with the key. 2. Press the [EXECUTE] key. The selected load operates. |


During the load operation, the [EXECUTE] key and the load key are highlighted. Under this state, pressing the [EXECUTE] key interrupts the load operation.

(Loads to be selected)

| | | | |
|------|---------------------|------|---------------------------|
| FFM | Transport motor | FFSM | Stapler motor |
| FPM | Paddle motor | FLM | Shift motor |
| FAM | Bundle exit motor | FPNM | Punch motor |
| FFJM | Alignment motor (F) | FPSM | Puncher side resist motor |
| FRJM | Alignment motor (R) | FFC | Folding clutch |
| FSM | Slide motor | | |


(When the sorter is installed)

| | |
|------|-----------------------|
| SBSM | Bin unit shift motor |
| SPFM | Transport motor |
| SGBM | Guide bar drive motor |



| | |
|----------------------------|--|
| 3 | -10 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to adjust the sections in the finisher. |
| Section | Finisher |
| Item | Operation |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment item with the scroll key. 2. Enter the adjustment value with the 10-key and press the OK key to set the value. |


| | Item | Set range | Initial value |
|---|--|-----------|---------------|
| A | Saddle binding position adjustment | 0 - 400 | 200 |
| B | Saddle folding position adjustment | 0 - 400 | 200 |
| C | Front alignment position adjustment | 0 - 20 | 10 |
| D | Rear alignment position adjustment | 0 - 20 | 10 |
| E | Staple rear one-point binding position adjustment | 0 - 200 | 100 |
| F | Staple front one-point binding position adjustment | 0 - 200 | 100 |
| G | Staple two-point binding center adjustment | 0 - 200 | 100 |
| H | Staple two-point binding pitch adjustment | 0 - 100 | 50 |
| I | Punch center adjustment | 47 - 53 | 50 |
| J | Punch hole position adjustment | 0 - 100 | 50 |



| | |
|----------------------------|--|
| 4 | -2 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the desk/large capacity tray sensors and detectors and the related circuits. |
| Section | Paper feed |
| Item | Operation |
| Operation/Procedure | The operating conditions of the sensors and detectors in the paper feed section are displayed. The active sensors and detectors are highlighted. |

(Sensors to be detected)

| | |
|--------|---|
| DLUD1 | Desk 1cs upper limit detection |
| DLUD2 | Desk 2cs upper limit detection |
| DLUD3 | Desk 3cs upper limit detection |
| DPED1 | Desk 1cs paper empty detector |
| DPED2 | Desk 2cs paper empty detection |
| DPED3 | Desk 3cs paper empty detection |
| DCSPS1 | Desk 1cs remaining quantity detection |
| DCSPS2 | Desk 2cs remaining quantity detection |
| DCSPS3 | Desk 3cs remaining quantity detection |
| DPPD1 | Desk paper transport detection 1 |
| DPPD2 | Desk paper transport detection 2 |
| DPPD3 | Desk paper transport detection 3 |
| DLUID1 | Desk 1cs lift unit installation detection |
| DLUID2 | Desk 2cs lift unit installation detection |
| DLUID3 | Desk 3cs lift unit installation detection |
| DDOPD | Desk door open detection |
| DCSS11 | Desk 1cs paper size detection 1 |
| DCSS12 | Desk 1cs paper size detection 2 |
| DCSS13 | Desk 1cs paper size detection 3 |
| DCSS14 | Desk 1cs paper size detection 4 |
| DCSS21 | Desk 2cs paper size detection 1 |
| DCSS22 | Desk 2cs paper size detection 2 |
| DCSS23 | Desk 2cs paper size detection 3 |
| DCSS24 | Desk 2cs paper size detection 4 |
| DCSS31 | Desk 3cs paper size detection 1 |
| DCSS32 | Desk 3cs paper size detection 2 |
| DCSS33 | Desk 3cs paper size detection 3 |
| DCSS34 | Desk 3cs paper size detection 4 |
| LRE | LCC remaining quantity detection |
| LUD | LCC upper limit detection |
| LDD | LCC lower limit detection |
| LPED | LCC paper empty detection |
| LPFD | LCC paper exit detection |
| LDSW | LCC door open detection |
| LTOD | LCC release detection |
| 24V | LCC 24V detection |
| LCD | LCC cassette detection |



4 -3


| | |
|---------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the desk/large capacity tray loads and the control circuit. |
| Section | Paper feed |
| Item | Operation |

| | |
|-----------------------------|--|
| Operation/ Procedure | <ol style="list-style-type: none"> 1. The names of the loads that can be checked are displayed. Select a load to be checked with the key, and the selected load is highlighted. 2. Press the [EXECUTE] key. The load selected in procedure 1 starts the operation. |
|-----------------------------|--|

During the operation of the load, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed while it is highlighted, the operation is stopped.

(Loads to be selected)

| | |
|-------|----------------------------------|
| DM | Desk transport motor |
| DLM1 | Desk 1cs lift-up motor |
| DLM2 | Desk 2cs lift-up motor |
| DLM3 | Desk 3cs lift-up motor |
| DPFC1 | Desk 1cs paper feed clutch |
| DPFC2 | Desk 2cs paper feed clutch |
| DPFC3 | Desk 3cs paper feed clutch |
| DTRC | Desk transport clutch |
| DPFS1 | Desk 1cs paper feed solenoid |
| DPFS2 | Desk 2cs paper feed solenoid |
| DPFS3 | Desk 3cs paper feed solenoid |
| LPFM | LCC transport motor |
| LLM | LCC lift motor up-down operation |
| LPFC | LCC paper feed clutch |
| LPFS | LCC paper feed solenoid |
| LLED | LCC door open LED |
| LTRC | LCC transport clutch |




4 -5

| | |
|---------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the clutch TRC and the monitor. |
| Section | Paper feed |
| Item | Operation |

| | |
|-----------------------------|--|
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [TRC ON] key. (The load operates.) 2. Press the [TRC OFF] key to terminate checking. |
|-----------------------------|--|

When the [TRC ON] key or the [TRC OFF] key is pressed, the TRC clutch is turned ON or OFF.

If the response of monitoring TRC ON/OFF is made, DESK SENSOR TRC ON/OFF is displayed.



5

5 -1

| | |
|---------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the display lamp (LED)/ LCD on the operation panel and the control circuits. |
| Section | Operation (Display, procedure) |
| Item | Operation |

| | |
|-----------------------------|--|
| Operation/ Procedure | The LCD shows the following message. (The contrast changes in the sequence of Current level → MAX → MIN → Current level → MAX → MIN in every 2sec.) During that period, each LED is lighted for 12sec. |
|-----------------------------|--|



↓ 6sec

TEST SIMULATION NO. 00-00




5 -2

| | |
|---------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the heater lamp and its control circuit. |
| Section | Fusing |
| Item | Operation |

| | |
|-----------------------------|---|
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the lamp to be checked with the key. 2. Press the [EXECUTE] key. |
|-----------------------------|---|

The selected heater lamp repeats ON/OFF in the frequency of 500msec for 10sec. (The [EXECUTE] key is highlighted.) Then the [EXECUTE] key returns to the normal display. When the [EXECUTE] key is pressed during ON/OFF operation of the heater lamp, the heater lamp is turned OFF and the [EXECUTE] key returns to the normal display.


| | |
|-----------------------|--------------------------------|
| HL1 (UPPER) | Upper heater lamp |
| HL2 (LOWER) | Lower heater lamp |
| HL1&2 (UPPER & LOWER) | Upper/lower fusing heater lamp |




5 -3

| | |
|---------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the scanner lamp and its control circuit. |
| Section | Scanner (Image scanning) |
| Item | Operation |

| | |
|----------------------------|--|
| Operation/Procedure | When the [EXECUTE] key is pressed, the scanner lamp is lighted for 10 sec. While the scanner lamp is lighted, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed under this state, the lamp is turned OFF. After 10 sec, the scanner lamp is turned OFF. At that time, the [EXECUTE] key returns to the normal display. |
|----------------------------|--|



| | | |
|----------------------------|---|--------|
| 5 | -4 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operations of the discharge lamp and its control circuit. | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | Others |
| Item | Operation | |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the target discharge lamp with the [K], [C], [M], and [Y] keys. (K: Black, C: Cyan, M: Magenta, Y: Yellow) 2. When the [EXECUTE] key is pressed, the key is highlighted and the selected discharge lamp is lighted for 30sec. If the [EXECUTE] key is pressed while the lamp is lighted, the lamp is turned OFF. | |




| | | |
|----------------------------|--|--|
| 6 | -1 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operations of the loads (clutches and solenoids) in the paper transport system, transfer, and fusing, and the control circuit. | |
| Section | Paper transport (paper exit, switchback, transport), transfer, fusing | |
| Item | Operation | |
| Operation/Procedure | <ol style="list-style-type: none"> 1. The names of the loads that can be checked are displayed. Select the load to be checked with the key, and the selected load is highlighted. 2. Press the [EXECUTE] key. The selected load starts the operation. During the operation of the load, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed while it is highlighted, the operation is stopped. | |

(Loads to be selected)

| | |
|------|---------------------------------------|
| CPFC | Cassette transport clutch |
| TRC | Cassette paper feed clutch |
| MTRC | Manual paper feed clutch |
| MPFC | Manual transport clutch |
| GSS | Paper exit gate select solenoid |
| RRM | Resist roller motor (PSM) |
| PFM | Paper feed motor (Vertical transport) |
| FUM | Fusing motor |
| BLUM | Lift motor |

| | |
|----------|---|
| BLUM (R) | * Lift motor (Reverse rotation/waste toner transport motor) |
| OSM | Offset motor (Job separator) |
| CARB | Calibration plate |


- * When BLUM is ON, the belt moves up.
When BLUM is OFF, the belt moves down.



| | | |
|----------------------------|--|--|
| 6 | -2 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operations of the fan motors and the control circuits. | |
| Section | Others | |
| Item | Operation | |
| Operation/Procedure | <ol style="list-style-type: none"> 1. The loads that can be checked are displayed. Select one to be checked. 2. Press the [EXECUTE] key. The selected load is operated. During operation, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed while it is highlighted, the operation is stopped. | |

(Loads to be selected.)

| | |
|--------|---------------------|
| VFM1 | Fusing fan 1 |
| VFM2 | Fusing fan 2 |
| PSFM | Power fan |
| PRTCFM | Process exhaust fan |




| | | |
|----------------------------|--|--|
| 7 | -1 | |
| Purpose | Setting/Operation test/check | |
| Function (Purpose) | Used to set the aging conditions. | |
| Item | Operation | |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press each corresponding key to set for the aging operation. (Set items of each key) The selected key is highlighted. 2. Press the [EXECUTE] key. Aging is set and the display returns to the simulation main code entry menu. | |

- * The setup contents of this simulation remain unchanged until the power is turned off. When this simulation is executed, SIM 7-8 (Warm-up time display setting) is canceled.

(Set content)


| | |
|--------------------|--|
| [AGING] | Jam detection setup |
| [INTERVAL] | Intermittent setup |
| [MISFEED DISABLE] | Jam detection YES/NO setup |
| [FUSING DISABLE] | Fusing operation YES/NO detection |
| [WARMUP DISABLE] | Warm-up saving setup |
| [DV CHECK DISABLE] | Developing tank detection YES/NO setup |
| [SHADING DISABLE] | Shading saving setup |



7 -6

| | |
|-----------------------------|---|
| Purpose | Setting/Operation test/check |
| Function (Purpose) | Used to set the cycle of intermittent aging. |
| Item | Operation |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Enter the interval aging cycle time (sec) with the 10-key pad. 2. Press [OK] key (or B/W Start key, Color Start key) to set the entered cycle time. |


* The interval time set range is 1 - 999sec. [Default: 3]



7 -8

| | |
|-----------------------------|---|
| Purpose | Setting/Operation test/check |
| Function (Purpose) | Used to set Yes/No of warm-up time display. |
| Item | Operation |
| Operation/ Procedure | <p>Press the [EXECUTE] key to set the warm-up time display.</p> <p>When the [EXECUTE] key is pressed, the warm-up time display setting is executed and the display returns to the simulation main code entry display.</p> |

* The setup contents of this simulation remain unchanged until the power is turned off. When SIM 7-1 is executed, the setup contents are canceled.




7 -9

| | |
|-----------------------------|--|
| Purpose | Setting/Operation test/check |
| Function (Purpose) | Used to check the image quality and operations of each color. |
| Section | Others |
| Item | Picture quality |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the color of image quantity and operation check with the key. 2. Press the START key. |

Copying is performed with the color selected in procedure 1).

When no print color is selected, the operation is made with the all colors.



8

8 -1


| | |
|-----------------------------|---|
| Purpose | Adjustment/Operation test/check |
| Function (Purpose) | Used to check and adjust the operations of the developing bias voltage of each color and the control circuit. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Operation/ Procedure | <p>(The developing bias output voltage in each of the following print modes can be adjusted and checked.)</p> <p>(Adjustment range)</p> <p>180 - 700 (Default: See below)</p> <ol style="list-style-type: none"> 1. Select the color mode with the [K], [C], [M], or [Y] key. 2. Select the copy mode with the scroll key. 3. Enter the adjustment value with the 10-key pad. 4. Press the [EXECUTE] key. |

The [EXECUTE] key is highlighted. When the adjustment value entered in procedure 2) and the corresponding voltage is outputted.

The voltage is outputted for 30sec, then the [EXECUTE] key returns to the normal display. When the EXECUTE key is pressed during output of the voltage, the output is stopped and the [EXECUTE] key returns to the normal display.

(Set value)

| Color | Item | Operation mode | Adjustment value | | Developing bias voltage | | | |
|-------|-----------------|--|------------------|---------------------------|-----------------------------------|-----------|---------|----------------|
| | | | Adjustment range | Specified value (Default) | Monitor (High voltage PWB) | | Pin No. | Actual voltage |
| | | | | | Monitor voltage (Specified value) | Connector | | |
| K | A: HIGH SPEED | High speed (140mm/s) (B & W) | 180 – 700 | 315 | 7.43 ± 0.1V | CNMONK | 3 | –315v |
| | B: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 315 | 7.43 ± 0.1V | CNMONK | 3 | –315v |
| | C: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 285 | 6.45 ± 0.1V | CNMONK | 3 | –285v |
| C | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 265 | 5.76 ± 0.1V | CNMON | 1 | –265v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 235 | 4.75 ± 0.1V | CNMON | 1 | –235v |
| M | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 265 | 5.76 ± 0.1V | CNMON | 5 | –265v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 235 | 4.75 ± 0.1V | CNMON | 5 | –235v |
| Y | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 240 | 4.75 ± 0.1V | CNMON | 9 | –240v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 210 | 3.78 ± 0.1V | CNMON | 9 | –210v |



| | |
|-----------------------------|---|
| 8 | -2 |
| Purpose | Adjustment/Operation test/check |
| Function (Purpose) | Used to check and adjust the operation of each print mode main charger grid voltage and the control circuit. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Operation/ Procedure | (The charging/grid output voltage in each print mode can be adjusted and checked.) 1. Select the color mode with the [K], [C], [M], and [Y] keys. 2. Select the print mode with [↑] key and [↓] key. 3. Enter the adjustment value with the 10-key pad. 4. Press the [EXECUTE] key. |


The [EXECUTE] key is highlighted, the adjustment value entered in procedure 2 is set, and the voltage corresponding to the set value is outputted.

The voltage is supplied for 30 sec, then the [EXECUTE] key returns to the normal display.

If the [EXECUTE] key is pressed while the voltage is supplied, the voltage output is stopped and the [EXECUTE] key returns to the normal display.

(Set value)

| Color | Item | Operation mode | Adjustment value | | Main charger grid voltage | | | |
|-------|-----------------|--|------------------|---------------------------|-----------------------------------|-----------|---------|----------------|
| | | | Adjustment range | Specified value (Default) | Monitor (High voltage PWB) | | Pin No. | Actual voltage |
| | | | | | Monitor voltage (Specified value) | Connector | | |
| K | A: HIGH SPEED | High speed (140mm/s) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMONK | 1 | –620v |
| | B: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMONK | 1 | –620v |
| | C: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMONK | 1 | –590v |
| C | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 3 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 3 | –590v |
| M | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 7 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 7 | –590v |
| Y | A: MIDDLE SPEED | Middle speed (117mm/s) (Color) (B & W) | 180 – 700 | 620 | 53.5 ± 0.2v | CNMON | 11 | –620v |
| | B: LOW SPEED | Low speed (58.5mm/s) (Color) (B & W) (Special paper) | 180 – 700 | 590 | 50.6 ± 0.2v | CNMON | 11 | –590v |



8 -6

| | |
|-----------------------------|---|
| Purpose | Adjustment/Operation test/check |
| Function (Purpose) | Used to check and adjust the operation of the transfer charger current and the control circuit. |
| Section | Process (Photoconductor, developing, Transfer transfer, cleaning) |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the color mode with the [K], [C], [M], and [Y] keys. 2. Select the copy mode with the scroll key. 3. Enter the adjustment value with the 10-key pad. 4. Press the [EXECUTE] key. |

The [EXECUTE] key is highlighted, the adjustment value entered in procedure 2 is set, and the voltage corresponding to the set value is outputted.


The voltage is supplied for 30 sec, then the [EXECUTE] key returns to the normal display.

If the [EXECUTE] key is pressed while the voltage is supplied, the voltage output is stopped and the [EXECUTE] key returns to the normal display.

In this simulation, when the transfer voltage is supplied, the transfer belt and the OPC drum rotates at the same time. Therefore, the above parts are not damaged.

(Items to be selected/replaced)

| Item | | Print mode | | | Standard setting value (Default) | | | | Adjustment range | Output voltage (Kv) | | | |
|------|-----------------|------------|----------------------------|----------|----------------------------------|-----|-----|-----|------------------|---------------------|-----|-----|-----|
| | | | | | K | C | M | Y | | K | C | M | Y |
| A | PLAIN_SPX_CL | Color | Normal paper | 117mm/s | 173 | 159 | 132 | 132 | 51 - 255 | 2.4 | 2.4 | 2.4 | 2.4 |
| B | PLAIN_DPX_CL | Color | Normal paper(Duplex mode) | 117mm/s | 188 | 173 | 142 | 142 | | 2.7 | 2.7 | 2.7 | 2.7 |
| C | OHP1_CL | Color | Transparency film 1 | 117mm/s | 204 | 187 | 153 | 153 | | 3 | 3 | 3 | 3 |
| D | OHP2_CL | Color | Transparency film 2 | 58.5mm/s | 137 | 150 | 153 | 163 | | 1.7 | 2.2 | 3 | 3.3 |
| E | HEAVY_P1_SPX_CL | Color | Thick paper 1 | 58.5mm/s | 158 | 146 | 122 | 122 | | 2.1 | 2.1 | 2.1 | 2.1 |
| F | HEAVY_P1_DPX_CL | Color | Thick paper 1(Duplex mode) | 58.5mm/s | 188 | 173 | 142 | 142 | | 2.7 | 2.7 | 2.7 | 2.7 |
| G | HEAVY_P2_CL | Color | Thick paper 2 | 58.5mm/s | 173 | 159 | 132 | 132 | | 2.2 | 2.2 | 2.2 | 2.2 |
| H | ENV_CL | Color | Envelope | 117mm/s | 163 | 150 | 125 | 125 | | 2.2 | 2.2 | 2.2 | 2.2 |
| I | PLAIN_SPX_BW | B & W | Normal paper | 140mm/s | 168 | | | | | 2.3 | | | |
| J | PLAIN_DPX_BW | B & W | Normal paper(Duplex mode) | 140mm/s | 178 | | | | | 2.5 | | | |
| K | OHP1_BW | B & W | Transparency film 1 | 117mm/s | 204 | | | | | 3 | | | |
| L | OHP2_BW | B & W | Transparency film 2 | 58.5mm/s | 137 | | | | | 1.7 | | | |
| M | HEAVY_P1_SPX_BW | B & W | Thick paper 1 | 58.5mm/s | 147 | | | | | 1.9 | | | |
| N | HEAVY_P1_DPX_BW | B & W | Thick paper 1(Duplex mode) | 58.5mm/s | 178 | | | | | 2.5 | | | |
| O | HEAVY_P2_BW | B & W | Thick paper 2 | 58.5mm/s | 163 | | | | | 2.2 | | | |
| P | ENV_BW | B & W | Envelope | 140mm/s | 168 | | | | | 2.3 | | | |



9


9 -2

| | |
|-----------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of the sensors and detectors in the inverter/duplex section and the control circuit. |
| Section | Inverter/Duplex |
| Item | Operation |
| Operation/ Procedure | <p>The operations of sensors and detectors in the inverter/ duplex section are displayed.</p> <p>The active sensors and detectors are highlighted.</p> |

(Check item)

| | |
|-------|--------------------------------|
| BPID | Inverter paper entry detection |
| BPPD1 | Inverter transport detection 1 |
| BPPD2 | Inverter transport detection 2 |
| BPRD | Inverter reverse detection |
| BPOD | Inverter paper exit detection |
| BPFD | Inverter full detection |

| | |
|---------|-----------------------------------|
| BDD1 | Inverter door detection 1 |
| BDD2 | Inverter door detection 2 |
| APPD1 | ADU transport detection 1 |
| APPD2 | ADU transport detection 2 |
| APHP5 | ADU alignment plate home position |
| POD1 | Machine paper exit detection |
| BYSET | Inverter installation detection |
| ADUDSET | ADU installation detection |
| ADUSET | ADU door open/close detection |




| | |
|----------------------------|--|
| 9 | -3 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of the loads (motor, clutch, solenoid) in the inverter/duplex section and the control circuits. |
| Section | Inverter/Duplex |
| Item | Operation |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the load to be checked with the 10-key pad. 2. Press the [EXECUTE] key. |

The load selected in procedure 1 operates.

While the load operates, the [EXECUTE] key is highlighted.

When the [EXECUTE] key is pressed under this state, the operation of the load can be interrupted.


| | |
|-------|---|
| BIM | Inverter paper entry motor |
| BRMFW | Inverter reverse motor (Normal rotation) |
| BRMRV | Inverter reverse motor (Reverse rotation) |
| BGSOL | Inverter gate solenoid |
| BTMFW | Inverter transport motor (Normal rotation) |
| BTMRV | Inverter transport motor (Reverse rotation) |
| ATM | ADU transport motor |
| APAM | ADU alignment motor |
| ATRC | ADU transport clutch |




| | |
|----------------------------|---|
| 14 | -0 |
| Purpose | Clear/cancel (Trouble etc.) |
| Function (Purpose) | Used to cancel self diag troubles H3, H4, and H5. Inhibition of the color copy mode operation is canceled. |
| Item | Trouble Error |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. (YES/NO key display) 2. When YES key is pressed, the following troubles are cleared. (Cancel with NO key.) |

(Trouble codes to be canceled)

| Target trouble codes | Descriptions |
|----------------------|--|
| H3-00 | Heat roller high temperature detection (HL1) |
| H3-01 | Heat roller high temperature detection (HL2) |
| H4-00 | Heat roller low temperature detection (HL1) |
| H4-01 | Heat roller low temperature detection (HL2) |
| H5-01 | Five continuous detections of POD1 not-reached jam |




| | |
|----------------------------|--|
| 15 | -0 |
| Purpose | Clear/cancel (Trouble etc.) |
| Function (Purpose) | Self diag U6-09 (large capacity paper feed tray) trouble cancel |
| Section | Paper feed |
| Item | Trouble Error |
| Operation/Procedure | <ol style="list-style-type: none"> Press the [EXECUTE] key to cancel the trouble. * Press the [CLOSE] key to terminate the simulation. |



| | |
|----------------------------|---|
| 16 | -0 |
| Purpose | Clear/cancel (Trouble etc.) |
| Function (Purpose) | Used to cancel self diag trouble U2. |
| Item | Trouble Error |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. (YES/NO key display) 2. When YES key is pressed, the following troubles are cleared. (Cancel with NO key.) |

(Trouble codes to be canceled)

| Target trouble codes | Descriptions |
|----------------------|-------------------------------|
| U2-00 | EEPROM read/write error (OPE) |
| U2-11 | EEPROM check sum error (OPE) |
| U2-80 | EEPROM read/write error (SCN) |
| U2-81 | EEPROM check sum error (SCN) |
| U2-90 | EEPROM read/write error (PCU) |
| U2-91 | EEPROM check sum error (PCU) |




17

| | | |
|----------------------------|---|-------|
| 17 | -0 | |
| Purpose | Clear/cancel (Trouble etc.) | |
| Function (Purpose) | Used to cancel self diag troubles PF (copy inhibition command from the host computer). | |
| Section | Communication (RIC/MODEM) | |
| Item | Trouble | Error |
| Operation/Procedure | 1. Press the [EXECUTE] key. (YES/NO key display) 2. When YES key is pressed, the following troubles are cleared. (Cancel with NO key.) | |

(Trouble codes to be canceled)

| Target trouble codes | Descriptions |
|----------------------|-------------------------------------|
| PF-00 | PC copy inhibition signal reception |



21


| | | |
|----------------------------|--|---------|
| 21 | -1 | |
| Purpose | Setting | |
| Function (Purpose) | Used to set the maintenance cycle. | |
| Item | Specifications | Counter |
| Operation/Procedure | 1. The current setup is displayed. (Highlighted) 2. When the maintenance cycle is selected with the key, the selected key is highlighted. | |

The maintenance message is displayed in every selected cycle.

When FREE is selected, the maintenance display is not shown.

(Cycle to be set)

| Item | Set value | Content | Default |
|-------|-----------|---------|---------|
| CYCLE | 0 | 5K | 100K |
| | 1 | 10K | |
| | 2 | 15K | |
| | 3 | 40K | |
| | 4 | 50K | |
| | 5 | 100K | |
| BELT | 6 | FREE | 100K |
| | 50 | 100K | |
| FUSER | 100 | 100K | 100K |
| | 50 | 100K | |
| | 100 | 100K | |




22

| | | |
|----------------------------|--|--|
| 22 | -1 | |
| Purpose | Adjustment/Setting/Operation data output and check (display, print) | |
| Function (Purpose) | Used to check the print count value in each section and each operation mode. (Used to check the maintenance timing.) | |
| Item | Counter | |
| Operation/Procedure | The counter values are displayed. | |

(Counter values to be displayed)


| | |
|-----------------|-----------------------------------|
| TOTAL BW | All valid paper counters (B/W) |
| TOTAL COL | All valid paper counters (Color) |
| PRINTER BW | Print counter (B/W) |
| PRINTER COL | Print counter (Color) |
| SINGLE COLOR | Single color |
| COPY BW | Copy counter (B/W) |
| COPY COL | Copy counter (Color) |
| FAX PRINT | FAX print counter (B/W only) |
| OTHERS BW | Other counter (B/W only) |
| OTHERS COL | Other counter (Color) |
| MAINTENANCE ALL | Maintenance counter (Total) |
| MAINTENANCE COL | Maintenance counter (Color) |
| BELT UNIT | Transfer unit print counter |
| BELT UNIT RANGE | Transfer unit accumulated mileage |
| BELT UNIT DAY | Transfer unit use days |
| FUSER UNIT | Fusing unit print counter |
| FUSER ACUM DAY | Fusing unit use days |



| | | |
|----------------------------|--|--|
| 22 | -2 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the total misfeed count and the total trouble count. (If the misfeed count is considerably great, it may be judged as necessary to repair. By dividing this count by the total count, the misfeed rate can be obtained.) | |
| Item | Trouble | |
| Operation/Procedure | The counter values are displayed. | |

(Display contents)

| Display | Content |
|-------------|---------------------|
| MACHINE JAM | Machine jam counter |
| RADF JAM | ADF jam counter |
| TROUBLE | Trouble counter |



| | |
|-----------------------------|---|
| 22 | -3 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check misfeed positions and the misfeed count of each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.) (Machine section only) |
| Item | Trouble Misfeed |
| Operation/ Procedure | Used to display the misfeed history. |


The misfeed history sections are displayed sequentially from the latest one. Max. 50 items of information can be stored, and the oldest one is deleted sequentially. The trouble position may be presumed with this data.

(Jam code list)

| Group | Sensor | Display | Comment |
|------------|--|------------|--|
| Paper feed | — | ***** | |
| | PFD1 | TRAY1 | Tray 1 paper feed jam (PFD1 not-reached jam) |
| | | PFD1_ND1 | PFD1 not-reached jam (Desk 1 feed paper) |
| | | PFD1_ND2 | PFD1 not-reached jam (Desk 2 feed paper) |
| | | PFD1_ND3 | PFD1 not-reached jam (Desk 3 feed paper) |
| | | PFD1_NDU | PFD1 not-reached jam (Desk duplex tray feed paper) |
| | | PFD1_NLC | PFD1 not-reached jam (LCC feed paper) |
| | | PFD1_ST1 | PFD1 remaining jam (Tray 1 feed paper) |
| | | PFD1_SD1 | PFD1 remaining jam (Desk 1 feed paper) |
| | | PFD1_SD2 | PFD1 remaining jam (Desk 2 feed paper) |
| | | PFD1_SD3 | PFD1 remaining jam (Desk 3 feed paper) |
| | | PFD1_SDU | PFD1 remaining jam (Desk duplex tray feed paper) |
| | | Paper feed | PFD1 |
| PPD1_NT1 | PPD1 not-reached jam (Tray 1 feed paper) | | |
| PPD1_ND1 | PPD1 not-reached jam (Desk 1 feed paper) | | |
| PPD1_ND2 | PPD1 not-reached jam (Desk 2 feed paper) | | |
| PPD1_ND3 | PPD1 not-reached jam (Desk 3 feed paper) | | |
| PPD1_NDU | PPD1 not-reached jam (Desk duplex tray feed paper) | | |
| PPD1 | PPD1_NLC | | PPD1 not-reached jam (LCC feed paper) |
| | PPD1_ST1 | | PPD1 remaining jam (Tray 1 feed paper) |
| | PPD1_SD1 | | PPD1 remaining jam (Desk 1 feed paper) |
| | PPD1_SD2 | | PPD1 remaining jam (Desk 2 feed paper) |
| | PPD1_SD3 | | PPD1 remaining jam (Desk 3 feed paper) |
| | PPD1_SDU | | PPD1 remaining jam (Desk duplex tray feed paper) |
| | PPD1_SLC | | PPD1 remaining jam (LCC feed paper) |

| Group | Sensor | Display | Comment |
|------------------|--------|----------|---|
| Paper feed | PPD2 | BPT | Manual feed tray paper feed jam (PPD2 not-reached) |
| | | PPD2_NT1 | PPD2 not-reached jam (Tray 1 feed paper) |
| | | PPD2_ND1 | PPD2 not-reached jam (Desk 1 feed paper) |
| | | PPD2_ND2 | PPD2 not-reached jam (Desk 2 feed paper) |
| | | PPD2_ND3 | PPD2 not-reached jam (Desk 3 feed paper) |
| | | PPD2_NDU | PPD2 not-reached jam (Desk duplex tray feed paper) |
| | | PPD2_NLC | PPD2 not-reached jam (LCC feed paper) |
| | | PPD2_BPT | PPD2 remaining jam (Manual paper feed tray feed paper) |
| | | PPD2_ST1 | PPD2 remaining jam (Tray 1 feed paper) |
| | | PPD2_SD1 | PPD2 remaining jam (Desk 1 feed paper) |
| | | PPD2_SD2 | PPD2 remaining jam (Desk 2 feed paper) |
| | | PPD2_SD3 | PPD2 remaining jam (Desk 3 feed paper) |
| | | PPD2_SDU | PPD2 remaining jam (Desk duplex tray feed paper) |
| | | PPD2_SLC | PPD2 remaining jam (LCC feed paper) |
| Transport system | PPD2 | PPD2_PRE | PPD2 jam (Image ready signal is not supplied from PRT.) |
| | | PPD2_PRI | PPD2 jam (Print request is not supplied from PRT.) |
| | BPD | BPD_N | BPD not-reached jam |
| | | BPD_S | BPD remaining jam |
| | POD1 | POD1_N | POD1 not-reached jam |
| | | POD1_S | POD1 remaining jam |
| | POD2 | POD2_N | POD2 not-reached jam |
| | | POD2_S | POD2 remaining jam |
| Desk | DPPD1 | DPPD1_N | Desk transport sensor 1 (DPPD1) not-reached jam |
| | | DPPD1_S | Desk transport sensor 1 (DPPD1) remaining jam |
| | DPPD2 | DPPD2_N | Desk transport sensor 2 (DPPD2) not-reached jam |
| | | DPPD2_S | Desk transport sensor 2 (DPPD2) remaining jam |
| | DPPD3 | DPPD3_N | Desk transport sensor 3 (DPPD3) not-reached jam |
| | | DPPD3_S | Desk transport sensor 3 (DPPD3) remaining jam |
| LCC | LPFD | LCC | LCC paper feed jam (LPFD not-reached) |
| | | LPFD_S | LCC unit LPFD remaining jam |
| Inverter | BPPD1 | BPPD1_N | Reverse unit transport sensor 1 (BPPD1) not-reached jam |
| | | BPPD1_S | Reverse unit transport sensor 1 (BPPD1) remaining jam |
| | BPPD2 | BPPD2_N | Reverse unit transport sensor 2 (BPPD2) not-reached jam |
| | | BPPD2_S | Reverse unit transport sensor 2 (BPPD2) remaining jam |
| | BPPD3 | BPPD3_N | Reverse unit transport sensor 3 (BPPD3) not-reached jam |
| | | BPPD3_S | Reverse unit transport sensor 3 (BPPD3) remaining jam |

| Group | Sensor | Display | Comment |
|----------|--------|---------|---|
| Inverter | BPOD | BPOD_N | Reverse unit paper exit sensor (BPOD) not-reached jam |
| | | BPOD_S | Reverse unit paper exit sensor (BPOD) remaining jam |
| | BPRD | BPRD_N | Reverse unit reverse sensor (BPRD) not-reached jam |
| | | BPRD_S | Reverse unit reverse sensor (BPRD) remaining jam |
| ADU | APPD1 | APPD1_N | ADU transport sensor 1 (APPD1) not-reached jam |
| | | APPD1_S | ADU transport sensor 1 (APPD1) remaining jam |
| | APPD2 | APPD2_N | ADU transport sensor 2 (APPD2) not-reached jam |
| | | APPD2_S | ADU transport sensor 2 (APPD2) remaining jam |
| | APPD3 | APPD3_N | ADU transport sensor 3 (APPD3) not-reached jam |
| | | APPD3_S | ADU transport sensor 3 (APPD3) remaining jam |
| Finisher | FES | FES_N | Inlet port sensor (FES) not-reached jam |
| | | FES_S | Inlet port sensor (FES) remaining jam |
| | FFPS | FFPS_N | Binding position sensor (FFPS) not-reached jam |
| | | FFPS_S | Binding position sensor (FFPS) remaining jam |
| | FSTPL | FSTPL | Staple (FSTPL) jam |
| | FPNCH | FPNCH | Punch (FPNCH) jam |
| | FDOP | FDOP | Door open (FDOP) jam |
| Sorter | SPPD | SPPD_N | Sorter transport sensor (SPPD) not-reached jam |
| | | SPPD_S | Sorter transport sensor (SPPD) remaining jam |
| | SDOP | SDOP | Sorter door open (SDOP) jam |



| | |
|----------------------------|--|
| 22 | -4 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the total trouble (self diag) history. |
| Item | Trouble |
| Operation/Procedure | Used to display the total trouble history. |

The trouble history error codes are displayed sequentially from the latest one. Max. 30 items of information can be stored, and the oldest one is deleted sequentially. The machine condition can be presumed according to this data.

(Trouble code list)

| Detection models | Main code | Sub code | Content |
|------------------|-----------|----------|---|
| All | C2 | 10 | Image density sensor error/Transfer charger error (Black) |

| Detection models | Main code | Sub code | Content |
|------------------|-----------|----------|---|
| All | E7 | 01 | Image data memory trouble |
| | | 10 | Shading trouble (Black correction) |
| | | 11 | Shading trouble (White correction) |
| | | 20 | LED controller initial trouble (Black) |
| | | 21 | LED controller initial trouble (Cyan) |
| | | 22 | LED controller initial trouble (Magenta) |
| | | 23 | LED controller initial trouble (Yellow) |
| | | 24 | LED controller output trouble (Black) |
| | | 25 | LED controller output trouble (Cyan) |
| | | 26 | LED controller output trouble (Magenta) |
| | | 27 | LED controller output trouble (Yellow) |
| | | 28 | LED control ASIC connection abnormality |
| | | 40 | Color correction data write error |
| | | 41 | Color correction data transfer error |
| | | 80 | ICU-SCN communication trouble |
| | | 90 | ICU-PCU communication trouble |
| | F1 | 00 | Finisher communication trouble (PCU detection) |
| | | 02 | Finisher transport motor trouble (Finisher detection) |
| | | 03 | Finisher paddle motor trouble |
| | | 06 | Finisher slide motor trouble |
| | | 10 | Finisher staple motor abnormality (Finisher detection) |
| | | 11 | Finisher bundle process motor abnormality (Finisher detection) |
| | | 15 | Finisher tray lift motor abnormality (Finisher detection) |
| | | 19 | Finisher front alignment motor abnormality (Finisher detection) |
| | | 20 | Finisher rear alignment motor abnormality (Finisher detection) |
| | | 31 | Finisher folding sensor trouble |
| | | 32 | Finisher punch unit communication trouble |
| | | 33 | Finisher punch side resist motor trouble |
| | | 34 | Finisher punch motor trouble |
| | | 35 | Finisher punch side resist sensor trouble |
| | | 36 | Finisher punch resist sensor trouble |
| | | 37 | Finisher backup RAM trouble |
| | | 38 | Finisher punch backup ROM trouble |
| | | 39 | Finisher punch dust sensor trouble |
| | | 40 | Finisher punch power off trouble |
| | | 83 | Sorter push bar motor abnormality |
| | | 89 | Sorter bin shift motor abnormality |
| | | 91 | Paper sensor abnormality in the sorter bin |
| | F2 | 15 | Drum unit initial detection trouble (Black) |
| | | 16 | Drum unit initial detection trouble (Cyan) |
| | | 17 | Drum unit initial detection trouble (Magenta) |
| | | 18 | Drum unit initial detection trouble (Yellow) |
| | | 19 | Transfer unit initial detection trouble |
| | | 39 | Process thermistor trouble |
| | | 40 | Toner empty sensor abnormality (Black) |
| | | 41 | Toner empty sensor abnormality (Cyan) |
| | | 42 | Toner empty sensor abnormality (Magenta) |
| | | 43 | Toner empty sensor abnormality (Yellow) |
| | 44 | | Image density sensor (for black) trouble (Transfer belt surface reflection ratio abnormality) |
| | | 45 | Image density sensor (for color) trouble (Calibration plate surface reflection ratio abnormality) |

| Detection models | Main code | Sub code | Content |
|------------------|-----------|----------|--|
| All | F2 | 58 | Process humidity sensor trouble |
| | | 70 | Developing unit improper cartridge detection (Black) |
| | | 71 | Developing unit improper cartridge detection (Cyan) |
| | | 72 | Developing unit improper cartridge detection (Magenta) |
| | | 73 | Developing unit improper cartridge detection (Yellow) |
| | | 74 | Developing unit CRUM trouble (Black) |
| | | 75 | Developing unit CRUM trouble (Cyan) |
| | | 76 | Developing unit CRUM trouble (Magenta) |
| | | 77 | Developing unit CRUM trouble (Yellow) |
| | | 78 | Registration trouble |
| | | 80 | Half-tone process control 1st batch error (Black) |
| | | 81 | Half-tone process control 1st batch error (Cyan) |
| | | 82 | Half-tone process control 1st batch error (Magenta) |
| | | 83 | Half-tone process control 1st batch error (Yellow) |
| | | 84 | Half-tone process control 2nd batch error (Black) |
| | | 85 | Half-tone process control 2nd batch error (Cyan) |
| | | 86 | Half-tone process control 2nd batch error (Magenta) |
| | | 87 | Half-tone process control 2nd batch error (Yellow) |
| | | 90 | Half-tone process control limit error |
| | F3 | 12 | Cassette 1 lift-up trouble |
| | F9 | 00 | |
| | | 01 | |
| | | 03 | |
| | | 20 | |
| | H2 | 00 | Thermistor open (HL1) |
| | | 01 | Thermistor open (HL2) |
| | H3 | 00 | Fusing section high temperature trouble (HL1) |
| | | 01 | Fusing section high temperature trouble (HL2) |
| | H4 | 00 | Fusing section low temperature trouble (HL1) |
| | | 01 | Fusing section low temperature trouble (HL2) |
| | H5 | 01 | 3 continuous detections of POD1 not-reached jam |
| | H8 | 01 | Fusing unit initial detection trouble |
| | L1 | 00 | Mirror feed trouble |
| | L3 | 00 | Mirror return trouble |
| | L4 | 02 | Paper feed motor lock trouble |
| | | 06 | Transfer belt lift motor trouble |
| | | 11 | Shift motor trouble |
| | L8 | 01 | No full wave signal |
| | | 02 | Full wave signal width abnormality |
| | | 04 | Main switch abnormality detection |
| | PF | 00 | RIM copy inhibit signal reception |
| | U0 | 00 | ICU-OPE communication trouble (ICU/OPE detection) |
| | U1 | 02 | RTC read trouble |

| Detection models | Main code | Sub code | Content |
|------------------|-----------|----------|--|
| All | U2 | 00 | EEPROM read/write error (SCN detection) |
| | | 11 | EEPROM check sum error (SCN detection) |
| | | 22 | SRAM memory check sum error |
| | | 30 | Manufacturing No. data discrepancy (ICU ↔ PCU) |
| | U2 | 80 | EEPROM read/write error (SCN detection) |
| | | 81 | EEPROM check sum error (SCN detection) |
| | | 90 | EEPROM read/write error (PCU detection) |
| | | 91 | EEPROM check sum error (PCU detection) |
| | U4 | 02 | ADU alignment plate operation abnormality |
| | U5 | 00 | ADF communication trouble |
| | | 01 | ADF resist sensor trouble |
| | | 02 | ADF repulsion sensor trouble |
| | | 03 | ADF timing sensor trouble |
| | | 11 | Paper feed motor operation abnormality |
| | U6 | 00 | Desk communication trouble |
| | | 01 | Desk tray 1 lift motor trouble |
| | | 02 | Desk tray 2 lift motor trouble |
| | | 03 | Desk tray 3 lift motor trouble |
| | | 10 | Desk transport motor trouble |
| | U7 | 00 | RIC communication trouble |

| | | | | |
|--------------------------|-------|-------|-------|-------|
| TEST SIMULATION NO.22 04 | | | | CLOSE |
| TROUBLE CONF DATA DISP | | | | |
| XX-XX | XX-XX | XX-XX | XX-XX | |
| XX-XX | XX-XX | XX-XX | XX-XX | ↑ |
| XX-XX | XX-XX | XX-XX | XX-XX | |
| XX-XX | XX-XX | XX-XX | XX-XX | ↓ |
| XX-XX | XX-XX | XX-XX | XX-XX | 1/1 |

| | |
|----------------------------|--|
| 22 | -5 |
| Purpose | Others |
| Function (Purpose) | Used to check the ROM version of each unit (section). |
| Item | Software |
| Operation/Procedure | If there is any problem in the software, check the ROM version of each section with this simulation and replace with a new version if necessary. |


(Sections to be displayed)

| | |
|--------------|---------------------------|
| ICU | ICU control |
| PCU | Engine control section |
| SCN | Scanner control section |
| COL REV DATA | Color correction ROM |
| OPE PROG | OPE control section |
| PRT BOOT | PRT boot |
| PRT PROG | PRT control section |
| FAX | FAX control section |
| FIN-SORTER | Finisher/Sorter |
| PUNCH | Punch unit |
| DSK | Desk |
| LCC | Large capacity cassette |
| ADF | Automatic document feeder |
| NIC | NIC |


| | | | | |
|--------------------------|---------|-----|---------|-------|
| TEST SIMULATION NO.22 05 | | | | CLOSE |
| S/N : ***** | | | | |
| PRT | : V0.00 | FIN | : V0.00 | |
| OPE | : V0.00 | DSK | : V0.00 | ↑ |
| ENG | : V0.00 | ADF | : V0.00 | |
| SCN | : V0.00 | ADU | : V0.00 | ↓ |
| FAX1 | : V0.00 | CFT | : V0.00 | 1/2 |

| | | |
|-----------------------------|--|-------------------------|
| 22 | -6 | |
| Purpose | Adjustment/Setting/Operation data output, check, (display, print) | |
| Function (Purpose) | Used to print the setting and adjustment data list. | |
| Item | Data | Setting/Adjustment data |
| Operation/ Procedure | <p>When installing or servicing, execute this simulation to print and store the adjustment values and setting data for use in the next servicing. (Memory trouble, PWB replacement, etc.)</p> <p>In this case, the print conditions can be set optionally.</p> <ol style="list-style-type: none"> 1. Select the setup item. (The selected item is highlighted.) 2. Set the item and conditions with the 10-key pad. 3. Press the [EXECUTE] key to print various data. | |

| Item | Display item | Low | High | Default | Description |
|------|--------------|-----|------|---------|--------------------|
| A | DATA PATTERN | 1 | 1 | 1 | |
| | =1 | | | | |
| B | PAPER SELECT | 1 | 6 | 2 | Cassette selection |
| | =1 MANUAL | | | | Manual paper feed |
| | =2 CAS1 | | | | Cassette 1 |
| | =3 CAS2 | | | | Cassette 2 |
| | =4 CAS3 | | | | Cassette 3 |
| | =5 CAS4 | | | | Cassette 4 |
| | =6 LCC | | | | LCC |




| | | |
|-----------------------------|--|-----------|
| 22 | -7 | |
| Purpose | User data output/Check (Display/Print) | |
| Function (Purpose) | Used to display the key operator code. (Used when the customer forgets the key operator code.) | |
| Item | Data | User data |
| Operation/ Procedure | The key operator code is displayed. | |




| | | |
|-----------------------------|---|--|
| 22 | -8 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the number of uses of the staple, and the RADF. | |
| Item | Counter | |
| Operation/ Procedure | <p>Various counter values are displayed.</p> <p>This data is used to check the use frequency of each section. According to this data, maintenance is executed.</p> <p>(Counter values to be displayed with this simulation)</p> | |

| Display | Content |
|-------------|------------------|
| MIRROR SCAN | Scan counter |
| RADF | ADF counter |
| STAPLER | Staple counter |
| PUNCHER | Puncher counter |
| INVERTER | Inverter counter |



| | | |
|-----------------------------|---|--|
| 22 | -9 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the number of uses (print quantity) of each paper feed section. | |
| Section | Paper feed | |
| Item | Counter | |
| Operation/ Procedure | <p>The counter values are displayed.</p> <p>This data is used to check the use frequency of each paper feed section. According to this data, maintenance is performed.</p> <p>(Counter values to be displayed with this simulation)</p> | |

| Display | Content |
|-----------|---|
| MFT TOTAL | Manual paper feed (total) counter |
| MFT CB1 | Manual paper feed (heavy paper 1) counter |
| MFT CB2 | Manual paper feed (heavy paper 2) counter |
| MFT OHP1 | Manual paper feed (OHP1) counter |
| MFT OHP2 | Manual paper feed (OHP2) counter |
| MFT ENV | Manual paper feed (Envelope) counter |
| TRAY1 | Tray 1 counter |
| TRAY2 | Tray 2 counter |
| TRAY3 | Tray 3 counter |
| TRAY4 | Tray 4 counter |
| LCC | LCC counter |
| ADU | Duplex counter |



| | | |
|-----------------------------|---|--------|
| 22 | -10 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the system configuration (option, internal hardware). | |
| Item | Specifications | Option |
| Operation/ Procedure | The counter values are displayed. | |

This simulation allows to check the system configuration. The devices and the option units which are installed are displayed with the model names, etc.

| | |
|------------|---------------------------|
| ADF | Automatic document feeder |
| DESK/ADU | Desk/Duplex unit |
| LCC | Large capacity cassette |
| INVERTER | Bypass module |
| FIN/SORTER | Rear process unit |

| | |
|-----------------|----------------------|
| PUNCHER | Punch unit |
| FAX | FAX |
| FAX MEMORY | FAX expansion memory |
| HAND SET | Handset |
| SDAM | SDRAM capacity |
| PRINTER | Printer |
| PRINTER MEMORY | Printer memory |
| HDD | Hard disk capacity |
| NIC | NIC |
| NETWORK SCANNER | Network scanner |
| FONT ROM | Kanji font |

When installed: Each model name is displayed.

When not installed: "NONE" is displayed.

| | |
|-----------------------------|--|
| 22 | -12 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the misfeed positions and the number (history) of misfeed at each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.) |
| Section | RADF Option |
| Item | Trouble Misfeed |
| Operation/ Procedure | The misfeed counter value is displayed. |

The misfeed history positions in RADF are displayed with the names of sensors and detectors from the latest one. Max. 50 items of information can be stored, and the oldest one is deleted sequentially. The machine condition can be estimated according to this data.

| | |
|-----------------------------|---|
| 22 | -13 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the process cartridge counter. (If the count number is considerably great, it may be judged as necessary for repair.) |
| Section | Process section |
| Item | Counter |
| Operation/ Procedure | The process counter value of the process cartridge is displayed. |

(Counter values to be displayed)

| Display | Content |
|--------------|--|
| DRUM CTRG K | Drum cartridge print counter (K) |
| DRUM CTRG C | Drum cartridge print counter (C) |
| DRUM CTRG M | Drum cartridge print counter (M) |
| DRUM CTRG Y | Drum cartridge print counter (Y) |
| DRUM RANGE K | Drum cartridge accumulated mileage time (mm) (K) |

| Display | Content |
|---------------|---|
| DRUM RANGE C | Drum cartridge accumulated mileage time (mm) (C) |
| DRUM RANGE M | Drum cartridge accumulated mileage time (mm) (M) |
| DRUM RANGE Y | Drum cartridge accumulated mileage time (mm) (Y) |
| TONER RANGE K | Toner cartridge accumulated mileage time (mm) (K) |
| TONER RANGE C | Toner cartridge accumulated mileage time (mm) (C) |
| TONER RANGE M | Toner cartridge accumulated mileage time (mm) (M) |
| TONER RANGE Y | Toner cartridge accumulated mileage time (mm) (Y) |

| | |
|-----------------------------|--|
| 22 | -19 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the counters related to the network scanner. |
| Section | Network scanner |
| Item | Counter |
| Operation/ Procedure | The counter values related to the network scanner are displayed. |

(Counter values to be displayed)

| Display | Content |
|-----------------------|--|
| NETWORK SCANNER (BW) | Network scanner document scan number counter (B/W) |
| NETWORK SCANNER (COL) | Network scanner document scan number counter (Color) |
| SCANNER E-MAIL | Scanner e-mail transmit counter |
| SCANNER FTP | Scanner FTP transmit counter |
| TRIAL MODE | Trial mode counter |

| | |
|-----------------------------|--|
| 24 | -1 |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the misfeed counter, the misfeed history, the trouble counter, and the trouble history. (After completion of maintenance, the counters are cleared.) |
| Section | Memory |
| Item | Counter |
| Operation/ Procedure | 1. Select the counter to be cleared. 2. Press the [EXECUTE] key. The display for reconfirmation to clear is shown. 3. Select YES or NO to clear the counter. YES: Clear NO: Not clear |

(Counter to be cleared)

| Display | Content |
|-------------|---------------------|
| MACHINE JAM | Machine JAM counter |
| RADF JAM | ADF JAM counter |
| TROUBLE | Trouble counter |

| | |
|----------------------------|---|
| 24 | -2 |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the data of the number of uses (print quantity) of each paper feed section. |
| Section | Paper feed |
| Item | Counter Paper feed unit |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. (The selected key highlighted.) 2. Press the [EXECUTE] key. The display for reconfirmation to clear is shown. 3. Select YES or NO to clear the counter. YES: Clear NO: Not clear |

After completion of maintenance, the following counters are cleared.

(Counters to be cleared)

| | |
|-----------|---|
| MFT TOTAL | Manual paper feed (total) counter |
| MFT CB1 | Manual paper feed (heavy paper 1) counter |
| MFT CB2 | Manual paper feed (heavy paper 2) counter |
| MFT OHP1 | Manual paper feed (OHP1) counter |
| MFT OHP2 | Manual paper feed (OHP2) counter |
| MFT ENV | Manual paper feed (Envelope) counter |
| TRAY1 | Tray 1 counter |
| TRAY2 | Tray 2 counter |
| TRAY3 | Tray 3 counter |
| TRAY4 | Tray 4 counter |
| ADU | Duplex unit counter |
| LCC | Large capacity tray counter |

| | |
|----------------------------|---|
| 24 | -3 |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the use number data of the staple, the RADF, and the scanner. |
| Section | Transport/Finisher |
| Item | Counter |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. (The selected key highlighted.) 2. Press the [EXECUTE] key. The display for reconfirmation to clear is shown. 3. Select YES or NO to clear the counter. YES: Clear NO: Not clear |

(Counters to be cleared)

| Display | Content |
|-------------|------------------|
| MIRROR SCAN | Scan counter |
| RADF | ADF counter |
| STAPLER | Staple counter |
| PUNCHER | Puncher counter |
| INVERTER | Inverter counter |

| | |
|----------------------------|---|
| 24 | -4 |
| Purpose | Data clear |
| Function (Purpose) | Used to reset the maintenance counter. |
| Item | Counter Maintenance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. The display for reconfirmation to clear is shown. 2. Select YES or NO to clear the counter. YES: Clear NO: Not clear |

(Counters to be cleared)

| | |
|-------------|-----------------------------|
| MAINT (COL) | Maintenance counter (Color) |
| MAINT (ALL) | Maintenance counter (Total) |
| BELT UNIT | Transfer unit print counter |
| FUSER UNIT | Fusing unit print counter |

| | |
|----------------------------|---|
| 24 | -6 |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the counters. |
| Item | Counter |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. 2. Press the [EXECUTE] key. The display for reconfirmation to clear is shown. 3. Select YES or NO to clear the counter. YES: Clear NO: Not clear |


(Counters to be cleared)

| Display | Content |
|--------------|------------------------|
| COPY BW | Copier (B/W) counter |
| COPY COL | Copier (Color) counter |
| SINGLE COLOR | Single color |

| | | |
|-----------------------------|--|----------------|
| 24 | -7 | |
| Purpose | Data clear | |
| Function (Purpose) | Used to clear the OPC drum (membrane decrease) correction counter. (This simulation is performed with the OPC drum is replaced.) | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | Photoconductor |
| Item | Counter | Photoconductor |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. 2. Press the [EXECUTE] key. <p>The display for reconfirmation to clear is shown. Select YES or NO to clear the counter. YES: Clear NO: Not clear</p> | |


After replacement of the OPC drum, the following counters are cleared.
(Counters to be cleared)

| Display | Content |
|-------------|--------------------|
| DRUM CTRG K | Drum cartridge (K) |
| DRUM CTRG C | Drum cartridge (C) |
| DRUM CTRG M | Drum cartridge (M) |
| DRUM CTRG Y | Drum cartridge (Y) |



| | | |
|-----------------------------|--|----------|
| 24 | -8 | |
| Purpose | Data clear | |
| Function (Purpose) | Used to clear the waste toner counter in the transfer section. | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | Transfer |
| Item | Counter | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. <p>The display for reconfirmation to clear is shown. Select YES or NO to clear the counter. YES: Clear NO: Not clear</p> | |


After removing waste toner from the transfer section, the counter is cleared.



| | | |
|---------------------------|--|---------|
| 24 | -9 | |
| Purpose | Data clear | |
| Function (Purpose) | Used to clear the printer mode counter and the self-print mode print counter. (After completion of maintenance, the counters are cleared.) | |
| Section | Printer | |
| Item | Counter | Printer |

| | |
|-----------------------------|--|
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. 2. Press the [EXECUTE] key. <p>The display for reconfirmation to clear is shown.</p> <ol style="list-style-type: none"> 3. Select YES or NO to clear the counter. <p>YES: Clear NO: Not clear</p> |
|-----------------------------|--|


| | |
|-----------|---------------------------------------|
| PRINT BW | Printer mode print counter (B/W) |
| PRINT COL | Printer mode print counter (Color) |
| OTHER BW | Self print mode print counter (B/W) |
| OTHER COL | Self print mode print counter (Color) |



| | | |
|-----------------------------|--|--|
| 24 | -15 | |
| Purpose | Data clear | |
| Function (Purpose) | Used to clear the network scanner counter. | |
| Section | Scanner section | |
| Item | Counter | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the counter to be cleared. 2. Press the [EXECUTE] key. <p>The display for reconfirmation to clear is shown.</p> <ol style="list-style-type: none"> 3. Select YES or NO to clear the counter. <p>YES: Clear NO: Not clear</p> | |

(Counters to be cleared)


| | |
|-----------------------|--|
| NETWORK SCANNER (BW) | Network scanner document scan quantity counter (B/W) |
| NETWORK SCANNER (COL) | Network scanner document scan quantity counter (Color) |
| SCANNER E-MAIL | Scanner e-mail send counter |
| SCANNER FTP | Scanner FTP send counter |



25

| | | |
|-----------------------------|--|--|
| 25 | -1 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operation of the process section (excluding the image process section) and the toner remaining quantity sensor. (The toner remaining quantity sensor output can be monitored.) | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the color to check the toner remaining quantity. 2. Press the [EXECUTE] key. The selected toner key is highlighted, and all the drum motors rotate (117m/s), and the specified toner remaining quantity sensor level is displayed. After 10min, the motors stop, and the [EXECUTE] key returns to the normal display. | |

When the [EXECUTE] key is pressed during rotation of the motors, the motors will stop and the [EXECUTE] key will return to the normal display.



26

| | |
|-----------------------------|--|
| 26 | -2 |
| Purpose | Setting |
| Function (Purpose) | <ol style="list-style-type: none"> Used to set the paper size of the large capacity tray. (When the paper size is changed, the software setup must be changed accordingly with this simulation.) Used to detect 8.5" x 13" (INCH Series) paper or documents and to set the display mode. (All paper feed modes) Used to set the display form of the paper kind in the manual paper feed mode. |
| Section | Paper feed |
| Item | Specifications |
| Operation/ Procedure | <ol style="list-style-type: none"> Used to set the paper size of the large capacity tray. Used to set to allow 8.5" x 13" size paper to be treated as a selectable size. Used to set the paper kind display mode in the manual paper feed mode. <p>* Documents or paper of 8.5" x 13" are treated as a selectable size.</p> |

(Selection item)

| | Used unit | Destination | Set value | |
|----------|------------------------|------------------------|-----------------------|---------------|
| | | | 0 (Default) (Disable) | 1 (Enable) |
| Document | AR-RF2 | Japan | A4R | A4R *5 |
| | | AB series (SUK/SEEG) | A4R | A4R *5 |
| | | AB series (SCA/Others) | A4R | 8.5" x 13" *3 |
| | | Inch series (SEC/SECL) | 8.5" x 14" | 8.5" x 14" *5 |
| | | Inch series (Others) | 8.5" x 14" | 8.5" x 13" *1 |
| Paper | Machine | Document table | Japan/EX | 8.5" x 13" *2 |
| | | Japan AB series | B4 | 8.5" x 13" *2 |
| | | Inch series | 8.5" x 14" | 8.5" x 13" *1 |
| Paper | Manual paper feed tray | All destinations | 8.5" x 14" | 8.5" x 13" *4 |
| | | Paper feed tray | All destinations | —*6 |
| | AR-LC5 (LCC) | All destinations | | — |

*1: An original of 8.5" x 14" is detected as 8.5" x 13".

*2: An original of B4 size is detected as 8.5" x 13".

*3: An original of A4R size is detected as 8.5" x 13".

*4: An original of 8.5" x 14" is detected as 8.5" x 13".


*5: Applicable by replacing the AR-RF2 original tray.

*6: Can be set with the key operator program.

*7: Determined by the paper type of the destination.

| Item | Set value | Content |
|------|-----------|-----------------------------|
| LCC | 0 | No size specified (Default) |
| | 1 | 8.5 x 11 |
| | 2 | A4 |

| Item | Set value | Content |
|------------------------|-----------|--------------------|
| Legal (Inch series) *7 | 0 | 8.5 x 14 (Default) |
| | 1 | 8.5 x 13 |
| Legal (AB series) *7 | 0 | B4 (Default) |
| | 1 | 8.5 x 13 |



| | |
|-----------------------------|--|
| 26 | -3 |
| Purpose | Setting |
| Function (Purpose) | Used to set the auditor specification mode. Setting must be made according to the use conditions of the auditor. |
| Section | Auditor |
| Item | Specifications |
| Operation/ Procedure | Enter the code number corresponding to the auditor specification mode. |

| Mode | Content |
|----------|--------------------------------|
| [P10] | Built-in auditor mode |
| [AR-EC1] | Card counter mode (only Japan) |
| [MODE1] | Coin vendor mode 1 |
| [MODE2] | Coin vendor mode 2 |
| [MODE3] | Coin vendor mode 3 |

[Copy vendor mode]


| Diag setting | Specified number completed with money left | Lack of money during a copy job | | Specified number completed with no money left |
|-----------------|--|---------------------------------|-------------------------|---|
| | | BW/Color (with no money left) | Color (with money left) | |
| | Case 1 | Case 2 | Case 3 | Case 4 |
| 26-3=3 MODE1 | Operation 1 | Operation 2 | Operation 2 | Operation 1 |
| 26-3=4 MODE2 | Operation 1 | Operation 1 | Operation 2 | Operation 1 |
| 26-3=5 MODE3 | Operation 1 | Operation 3 | Operation 2 | Operation 3 |

Operation 1: The set status remains until the auto clear set time has passed. (Default: 60sec Changeable with key operations.)

Operation 2: Auto clear is not made.


Operation 3: Setting is immediately cleared, and the display returns to the standby menu.

Case 1/Case 2 (with money left): B/W copy is allowed. If, however, charge money for color copy is exhausted during a color copy job, when sufficient money for the job is supplied, only the color start key of the READY lamp lights up.



| | | |
|----------------------------|---|---------|
| 26 | -5 | |
| Purpose | Setting | |
| Function (Purpose) | Used to set the count mode of the total counter and the maintenance counter. | |
| Item | Specifications | Counter |
| Operation/Procedure | Used to set the single count-up or double count-up for the total counter, the maintenance counter, and the developer counter when printing is performed with A3, 11 x 17" paper. 1. Select the kind of the counter with the scroll key. 2. Enter "1" or "2" with the 10-key pad and press the [OK] key. | |

| Item | Content | Set range | Default |
|--------------|-----------------------|-----------|---------|
| A TOTAL(B/W) | Total counter (B/W) | 1 – 2 | 2 |
| B TOTAL(COL) | Total counter (Color) | 1 – 2 | 2 |
| C MAINT(B/W) | Maintenance (B/W) | 1 – 2 | 2 |
| D MAINT(COL) | Maintenance (Color) | 1 – 2 | 2 |



| | | |
|----------------------------|---|-------------|
| 26 | -6 | |
| Purpose | Setting | |
| Function (Purpose) | Used to set the destination specifications (paper, fixed copy magnification ratios, image (process) correction, machine operation in case of an error, etc.). | |
| Item | Specifications | Destination |
| Operation/Procedure | The current destination is highlighted. Select a desired destination. | |

(Destinations to be selected)


| Destination | |
|-------------|--|
| U.S.A. | United States of America |
| Canada | Canada |
| Inch | Inch series, other destinations |
| Japan | Japan |
| AB_B | AB series (B5 detection), other destinations |
| Europe | Europe |
| U.K. | United Kingdom |
| Aus. | Australia |
| AB_A | AB series (A5 detection), other destinations |
| China | China |

| SIM No. | Content | U.S.A | Canada | Inch | Japan | AB_B |
|---------------|---|----------------|----------------|----------------|----------------|----------------|
| SIM26-02 | Manual feed paper kind display | 1 (LBS) | 1 (LBS) | 1 (LBS) | 0 (GRAM) | 0 (GRAM) |
| SIM26-02 | Legal set value | 0 (8.5 x 14) | 0 (8.5 x 14) | 0 (8.5 x 14) | 0 (8.5 x 14) | 0 (8.5 x 14) |
| SIM26-41 | Center binding AMS setting | 0 (No support) | 0 (No support) | 0 (No support) | 0 (No support) | 0 (No support) |
| SIM26-52 | White paper exit count-up setting | 1 (Counts up.) | 1 (Counts up.) | 1 (Counts up.) | 0 (No counts) | 1 (Counts up.) |
| SIM46-19 | B/W auto exposure mode setting | 2 (EX Japan) | 2 (EX Japan) | 2 (EX Japan) | 1 (Japan) | 2 (EX Japan) |
| SIM43-01A | Normal paper HL1 control temperature | 175 | 175 | 175 | 170 | 170 |
| SIM43-01B | Normal paper HL2 control temperature | 140 | 140 | 140 | 140 | 140 |
| SIM43-01C | HL1 control temperature in the ready state | 170 | 170 | 170 | 165 | 165 |
| SIM43-01F | Heavy motor 1 HL2 control temperature | 136 | 136 | 136 | 135 | 135 |
| SIM43-01Q | Fusing motor rotation start temperature in warming up | 155 | 155 | 155 | 155 | 155 |
| Key operation | Language setting | 0 x 50 | 0 x 50 | 0 x 5c | 0 x 51 | 0 x 5c |
| Key operation | LCC size setting | 1 (8.5 x 11) | 1 (8.5 x 11) | 1 (8.5 x 11) | 2 (A4) | 2 (A4) |
| Key operation | Manual feed size setting | 1 (8.5 x 11) | 1 (8.5 x 11) | 1 (8.5 x 11) | 2 (A4) | 2 (A4) |
| Key operation | Document detection setting | 1 (INCH_1) | 1 (INCH_1) | 1 (INCH_1) | 3 (AB_1) | 3 (AB_1) |
| Key operation | Auto summer time setting | 0 (Disable) | 0 (Disable) | 0 (Disable) | 0 (Disable) | 0 (Disable) |
| Key operation | Tray 1 special size | 8.5 x 11 | 8.5 x 11 | 8.5 x 11 | A4 | A4 |
| Key operation | Tray 2 special size | 8.5 x 11 | 8.5 x 11 | 8.5 x 11 | A4 | A4 |
| Key operation | Tray 3 special size | 8.5 x 11 | 8.5 x 11 | 8.5 x 11 | A4 | A4 |
| Key operation | Tray 4 special size | 8.5 x 11 | 8.5 x 11 | 8.5 x 11 | A4 | A4 |

| SIM No. | Content | Europe | U.K. | Aus. | AB_A | China |
|-----------|---|-----------------|-----------------|---------------|----------------|----------------|
| SIM26-02 | Manual feed paper kind display | 0 (GRAM) | 0 (GRAM) | 0 (GRAM) | 0 (GRAM) | 0 (GRAM) |
| SIM26-02 | Legal set value | 0 (8.5x14) | 0 (8.5x14) | 1 (8.5x13) | 0 (8.5x14) | 0 (8.5x14) |
| SIM26-41 | Center binding AMS setting | 1 (AMS setting) | 1 (AMS setting) | 0 (Disable) | 0 (Disable) | 0 (Disable) |
| SIM26-52 | B/W paper exit count-up setting | 1 (Counts up.) | 1 (Counts up.) | 0 (No counts) | 1 (Counts up.) | 1 (Counts up.) |
| SIM43-01A | Normal paper HL1 control temperature | 175 | 175 | 175 | 175 | 175 |
| SIM43-01B | Normal paper HL2 control temperature | 140 | 140 | 140 | 140 | 140 |
| SIM43-01C | HL1 control temperature in the ready state | 170 | 170 | 170 | 170 | 170 |
| SIM43-01F | Heavy paper 1 HL2 control temperature | 136 | 136 | 136 | 136 | 136 |
| SIM43-01Q | Fusing motor rotation start temperature in warming up | 155 | 155 | 155 | 155 | 155 |

| SIM No. | Content | Europe | U.K. | Aus. | AB_A | China |
|---------------|--------------------------------|--------------|--------------|--------------|--------------|--------------|
| SIM46-19 | B/W auto exposure mode setting | 2 (EX Japan) | 2 (EX Japan) | 2 (EX Japan) | 2 (EX Japan) | 2 (EX Japan) |
| Key operation | Language setting | 0x5c | 0x5c | 0x5c | 0x5c | 0x5b |
| Key operation | LCC size detection | 2 (A4) | 2 (A4) | 2 (A4) | 2 (A4) | 2 (A4) |
| Key operation | Manual fee size setting | 2 (A4) | 2 (A4) | 2 (A4) | 2 (A4) | 2 (A4) |
| Key operation | Document detection setting | 3 (AB_1) | 3 (AB_1) | 4 (AB_2) | 3 (AB_1) | 3 (AB_1) |
| Key operation | Auto summer time setting | 1 (Enable) | 0 (Disable) | 1 (Enable) | 0 (Disable) | 0 (Disable) |
| Key operation | Tray 1 special size | A4 | A4 | A4 | A4 | A4 |
| Key operation | Tray 2 special size | A4 | A4 | A4 | A4 | A4 |
| Key operation | Tray 3 special size | A4 | A4 | A4 | A4 | A4 |
| Key operation | Tray 4 special size | A4 | A4 | A4 | A4 | A4 |


Language setup: 0x50 American English, 0x51 Japanese, 0x5c Chinese



| | |
|----------------------------|---|
| 26 | -10 |
| Purpose | Setting |
| Function (Purpose) | Used to set the trial mode of the network scanner. |
| Section | Scanner |
| Item | Specifications |
| Operation/Procedure | <ol style="list-style-type: none"> Set ON/OFF of the trial mode with the 10-key pad, and press the [OK] key. <p>* The B/W start key or the color start key can be used instead of the [OK] key in the above procedure.</p> |

(Trial mode setting)


| Item | Content | Set range | Default |
|------|--------------------|-----------------|---------|
| A | Trial mode setting | 0: NO 1: YES | 0 |



| | |
|----------------------------|--|
| 26 | -18 |
| Purpose | Setting |
| Function (Purpose) | Used to set YES/NO of toner save operation. (This simulation is Enable only for Japan and UK versions. It depends on SIM 26-6 (Destination) setting. For the other destinations, the same setting can be made by the user program P22. (Effective only in the monochrome copy mode)) |
| Item | Specifications Operation mode (Common) |
| Operation/Procedure | Enter the code number corresponding to the condition (the toner save YES/NO) with the 10-key and press the [OK] Key. |


(Toner save mode setting)

| Item | | Content | Set range | Default |
|------|-------------------------|---|---------------|---------|
| A | COPY (0:NO 1:YES) | Copy mode toner save mode inhibit | 0:NO 1:YES | 0 |
| B | FAX (0:NO 1:YES) | FAX mode toner save mode inhibit | 0:NO 1:YES | 0 |
| C | PRINTER (0:NO 1:YES) | Printer mode toner save mode inhibit | 0:NO 1:YES | 0 |



| | |
|----------------------------|--|
| 26 | -35 |
| Purpose | Setting |
| Function (Purpose) | Used to set whether the trouble history display by SIM 22-4 is displayed as one trouble or as the accumulated number of continuous troubles when two or more troubles of same kind occur continuously. |
| Item | Specifications |
| Operation/Procedure | Used to set whether the trouble history display by SIM 22-4 is displayed as one trouble or as the accumulated number of continuous troubles when two or more troubles of same kind occur continuously. <ol style="list-style-type: none"> Select the number corresponding to the display mode with the 10-key and press the [OK] key. |

| Item | Set value | Default |
|---|-----------|---------|
| The trouble history display by SIM 22-4 is displayed as it is when two or more troubles occur continuously. | 1 | 0 |
| The trouble history display by SIM 22-4 is displayed as one trouble when two or more troubles occur continuously. | 0 | |



| | |
|-----------------------------|--|
| 26 | -38 |
| Purpose | Setting |
| Function (Purpose) | Used to set "Continue/Stop" of printing when the maintenance timing (replacement timing of each consumable part) is reached. |
| Item | Specifications |
| Operation/ Procedure | When the maintenance timing (replacement timing of each consumable part) is reached, set "Continue/Stop" of printing by entering the code number with the 10-key, referring to the table below. Then press the [OK] key. |

[Target item]

* Maintenance preset counter (Depending on the set value of SIM21-1.)

* Consumable part replacement timing


Transfer belt (Depending on the set value of SIM21-1.)

Fusing unit (Depending on the set value of SIM21-1.)

OPC drum

When the toner cartridge is emptied, printing is stopped regardless of this setup.


| Item | Content | Set value | Default |
|-----------------------|--|-----------|---------------------|
| A (0:CONTINUE 1:STOP) | Used to set "Continue/Stop" of printing when the maintenance timing (replacement timing of each consumable part) is reached. | 0 | Continues printing. |
| | | 1 | Stops printing. |



| | |
|-----------------------------|---|
| 26 | -41 |
| Purpose | Setting |
| Function (Purpose) | Used to set Enable/Disable of AMS operation in the center-binding mode. |
| Item | Specifications |
| Operation/ Procedure | Enter the corresponding code of Enable/Disable of AMS operation in the center-binding mode with the 10-key pad, and press the [OK] key. * The B/W start key or the color start key can be used instead of the [OK] key in the above procedure. |

(Setting of AMS in the center binding mode)


| Item | Content | Set value | Default |
|----------------|---|-----------|----------------------------|
| A (0:NO 1:YES) | Setting of AMS operation in the center binding mode | 0 | AMS operation is disabled. |
| | | 1 | AMS operation is enabled. |



| | |
|-----------------------------|---|
| 26 | -52 |
| Purpose | Setting |
| Function (Purpose) | Used to set YES/NO of count up of non-copy paper (cover or insertion paper). |
| Item | Specifications |
| Operation/ Procedure | 1. Enter the set value corresponding to the operation mode with the 10-key. 2. Press the [OK] key. * The B/W start key or the color start key can be used instead of the [OK] key in the above procedure. |

(B/W count up setting)


| Item | Content | Set value | Default |
|------------------|---------------------------------|-----------|---------------|
| A (0:DON'T 1:DO) | Non-copy paper count-up setting | 0 | Not count up. |
| | | 1 | Counts up. |



| | |
|-----------------------------|--|
| 26 | -53 |
| Purpose | Setting |
| Function (Purpose) | Used by the user to set Enable/Disable auto color calibration (auto adjustment of color balance and density) |
| Item | Specifications |
| Operation/ Procedure | 1. Select Enable or Disable with the 10-key. Disable 0: YES Enable 1: NO 2. Press the [OK] key. |

| Set value | Content | Default |
|-----------|---|---------|
| 0 | Disable auto color calibration (automatic adjustment of copy color balance and density) | 1 |
| 1 | Enable auto color calibration (automatic adjustment of copy color balance and density) | |

When "Disable" is selected, the user program does not show the menu of the user auto color calibration (automatic adjustment of copy color balance and density).




| | |
|-----------------------------|--|
| 26 | -57 |
| Purpose | Setting |
| Function (Purpose) | Used to set the model name for use as the status information. |
| Item | Specifications |
| Operation/ Procedure | Press the corresponding key to the model name, and the model name is set and the selected key is highlighted. The model name information set in this simulation is used in the RIC/MIB system. |

(For Japan)

| Model | |
|-----------|--------------------------|
| AR-C260S | Copier model |
| AR-C260M | Copier/printer model |
| AR-C260F | Copier/FAX model |
| AR-C260FP | Copier/FAX/printer model |


(When the destination is outside of Japan)

| Model | |
|----------|----------------------|
| AR-C260 | Copier model |
| AR-C260M | Copier/printer model |



| | |
|-----------------------------|--|
| 26 | -65 |
| Purpose | Setting |
| Function (Purpose) | Used to set the finisher alarm mode. |
| Item | Specifications |
| Operation/ Procedure | Press the key which shows the staple limit quantity. The entered number is set and the pressed key is highlighted. |

| Item | Content | Set value | Default |
|--------------|-----------------------|-----------|---------|
| STAPLE LIMIT | Staple limit quantity | 30 | 30 |
| | | 50 | |




27

| | |
|-----------------------------|--|
| 27 | -1 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to set the specifications for operations in case of communication trouble between the host computer and MODEM (machine side). (When communication trouble occurs between the host computer MODEM and the machine, the self diag display (U7-00) is printed and setting for inhibition of print or not is made.) |
| Section | Communication (RIC/MODEM) |
| Item | Specifications Operation mode (Common) |
| Operation/ Procedure | Enter the code number corresponding to the operation mode with the 10-key and press the [OK] key. Used to set Enable/Disable of U7-00 trouble detection. |


| Set value | Set content | Default |
|-----------|--|---------|
| 0 | U7-00 trouble detection is made. (Default) | 0 |
| 1 | U7-00 trouble detection is not made. | |

0: Though a communication trouble occurs between the host computer and the MODEM (machine side), the machine is not affected.

1: When a communication trouble occurs between the host computer and the MODEM (machine side), the self diag display (U7-00) is displayed.




| | |
|-----------------------------|---|
| 27 | -5 |
| Purpose | Setting |
| Function (Purpose) | Used to enter the machine tag No. (This function allows to check the tag No. of the machine with the host computer.) |
| Section | Communication (RIC/MODEM) |
| Item | Data User data |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. When entering the tag No. newly or changing the tag No., enter the value (max. 8 digits) with the 10-key. The entered number is displayed in the column of "NEW" 2. Press the [SET] key. The new tag No. entered in procedure 1 is set. It is advisable to enter the machine's serial No. for machine management and servicing. |



Note: To perform this setting, the host computer and the machine must be connected through MODEM.

| | |
|-----------------------------|---|
| 27 | -6 |
| Purpose | Setting |
| Function (Purpose) | Used to set ON/OFF of service call sending to the service center by use of RIC when trouble occurred in the machine. (The service call is not sent automatically, but sent manually.) |
| Section | Communication (RIC/MODEM) |
| Item | Specifications Others |
| Operation/ Procedure | Enter the value corresponding to the set content and press the [OK] key. Manual service call Enable/Disable setting can be made. |

| Set value | Set content | Default |
|-----------|---|---------|
| 0 | Manual service call is allowed. (Default) | 0 |
| 1 | Manual service call is inhibited. | |




30

30 -1

| | |
|-----------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of sensors and detectors in the paper feed, paper transport, paper exit sections and the related circuits. |
| Item | Operation |
| Operation/ Procedure | The active sensors and detectors are highlighted. |

(Sensors to be checked)

| Sensor name | Content |
|-------------|--|
| PFD1 | Paper feed detection 1 (Tray 1) |
| PPD1 | Transport detection 1 |
| PPD2 | Transport detection 2 |
| POD1 | Paper exit detection 1 |
| POD2 | Paper exit detection 2 (Top tray paper exit) |
| DSWF | Front door switch |
| DSWR | Right door switch |
| DSWL | Left door switch |
| FUCHin | Fusing installation detection |
| BELTch | Belt unit installation detection |
| BLUD | Belt unit upper limit detection |
| BTNF | Belt waste toner full detection |
| TFD | Side tray paper full detection |
| HPOS | Shifter home position detection |
| TFD2 | Top tray paper full detection |




30 -2

| | |
|-----------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of sensors and detectors in the paper feed section and the related circuits. (The operation of the paper feed sensors and detectors can be monitored with the LCD display.) |
| Section | Paper feed |
| Item | Operation |
| Operation/ Procedure | The active sensors and detectors are highlighted. |

(Sensors to be checked)

| Sensor name | Content |
|-------------|---|
| LUD1 | Paper feed tray upper limit detection (Tray 1) |
| PED1 | Paper feed tray paper empty detection (Tray 1) |
| C1PD1 | Paper feed tray remaining paper quantity detection (Tray 1) |
| C1SS1 | Paper feed tray size detection 1 (Tray 1) |
| C1SS2 | Paper feed tray size detection 2 (Tray 1) |
| C1SS3 | Paper feed tray size detection 3 (Tray 1) |
| C1SS4 | Paper feed tray size detection 4 (Tray 1) |
| MPLD1 | Manual feed size length detection 1 |
| MPLD2 | Manual feed size length detection 2 |
| MTOP1 | Manual feed tray pull-out detection 1 |
| MTOP2 | Manual feed tray pull-out detection 2 |
| MPED | Manual feed tray paper empty detection |




33

33 -1

| | |
|-----------------------------|--|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of the card reader and the sensors and the related circuits. (The card reader sensor operation can be monitored with the LCD display.) |
| Section | Others |
| Item | Operation |
| Operation/ Procedure | Active/Inactive of the card reader is displayed. |

(Sensors to be checked)

| Sensor name | Content |
|-------------|----------------------------------|
| CARD | Card insertion detection |
| DATA | Card number signal detection |
| CLOCK | Reference clock signal detection |




40


40 -1

| | |
|-----------------------------|---|
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of the manual feed tray paper size detector and the related circuit. (The operation of the manual feed tray paper size detector can be monitored with the LCD display.) |
| Section | Paper feed |
| Item | Operation |
| Operation/ Procedure | The active sensors and detectors are highlighted. Press the [CLOSE] key to terminate the simulation. |

| | |
|-------|---------------------------------------|
| MPLD1 | Manual feed size length detection 1 |
| MPLD2 | Manual feed size length detection 2 |
| MTOP1 | Manual feed tray pull-put detection 1 |
| MTOP2 | Manual feed tray pull-out detection 2 |



| | | |
|-----------------------------|---|--|
| 40 | -2 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the manual feed tray paper width detector detection level. | |
| Section | Paper feed | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Set the manual paper feed guide to the maximum size. 2. Press the [EXECUTE] key. The [EXECUTE] key is highlighted then it returns to the normal display. The manual paper feed guide max. width position detection level is recognized. 3. Set the manual paper feed guide to A4 (11 x 8.5") size. 4. Press the [EXECUTE] key. The key is highlighted then it returns to the normal display. The manual paper feed guide A4 (11 x 8.5") detection level is recognized. 5. Set the manual paper feed guide to A4R (11 x 8.5R) size. 6. Press the [EXECUTE] key. The key is highlighted then it returns to the normal display. The manual paper feed guide A4 R (11 x 8.5"R) detection level is recognized. 7. Set the manual paper feed guide to the minimum size. 8. Press the [EXECUTE] key. The key is highlighted then it returns to the normal display. The manual paper feed guide minimum size detection level is recognized. <p>If the above operation is not performed properly, the ERROR display is highlighted. If performed properly, the above data is stored and the COMPLETE is highlighted.</p> | |




| | | |
|-----------------------------|---|--|
| 40 | -7 | |
| Purpose | Setting | |
| Function (Purpose) | Used to enter the adjustment value of the manual paper feed tray paper width detector detection level. (Setting) | |
| Section | Paper feed | |
| Item | Specifications | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the item (setting) to be entered with the scroll key. 2. Enter the adjustment value with the 10-key pad. 3. Press the [OK] key. | |

* This simulation is not normally used. Adjustment is made with SIM 40-02.

(Set range)

| | Item | Set range | Default |
|---|--------------|-----------|---------|
| A | MAX POSITION | 0 – 255 | 241 |
| B | P1 POSITION | 0 – 255 | 231 |
| C | P2 POSITION | 0 – 255 | 140 |
| D | MIN POSITION | 0 – 255 | 19 |




41


| | | |
|-----------------------------|---|--|
| 41 | -1 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operation of the document size sensor and the related circuit. (The operation of the document size sensor can be monitored with the LCD display.) | |
| Section | Others | |
| Item | Operation | |
| Operation/ Procedure | The active sensors and detectors are highlighted. | |

(Sensors to be detected)


| OCSW | OC cover open/close detection | Open: Highlighted, Close: Normal |
|------|-------------------------------|---|
| PD1 | Document sensor 1 | No document (not detected): Normal |
| PD2 | Document sensor 2 | |
| PD3 | Document sensor 3 | Document loaded (detected): Highlighted |
| PD4 | Document sensor 4 | |
| PD5 | Document sensor 5 | |
| PD6 | Document sensor 6 | |
| PD7 | Document sensor 7 | |



| | | |
|-----------------------------|--|--|
| 41 | -2 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the document size sensor detection level. | |
| Section | Others | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Open the document table, and press the [EXECUTE] key without document on the document table. The sensor level setting with no document on the table is performed. 2. Set an A3 paper (11" x 17") and press the [EXECUTE] key. The sensor level setting with document is performed. 3. The message of completion of the adjustment is displayed. | |



| | |
|----------------------------|---|
| 41 | -3 |
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operation of the document size sensor and the related circuit. (The document size sensor output level can be monitored with the LCD display.) |
| Section | Others |
| Item | Operation |
| Operation/Procedure | The detection output level of each sensor (PD1 ~ PD7) is displayed in real time. * The value in [] shown at the right of each sensor name is the threshold value. PD1 ~ PD7 light receiving (A/D value) and threshold value (A/D value) range is 1 ~ 255. The default of the threshold value is 128. |




| | |
|----------------------------|---|
| 43 | -1 |
| Purpose | Setting |
| Function (Purpose) | Used to set the fusing temperature in each operation mode. |
| Section | Fixing (Fusing) |
| Item | Operation |
| Operation/Procedure | 1. Select the kind of lamps and the operation mode with the scroll key. 2. Enter the set value with the 10-key. 3. Press the [OK] key to set the fusing temperature set in procedure 2. |

(Display items)

| Display | Content | Set range | Default | | |
|---------|--------------------------------------|-----------|-------------|-------------|-------------|
| | | | 100v Series | 120v Series | 200v Series |
| A | Normal paper HL1 set value | 70 ~ 230 | 170 | 175 | 175 |
| B | Normal paper HL2 set value | 30 ~ 200 | 140 | 140 | 140 |
| C | HL1 set value in ready state | 70 ~ 230 | 165 | 170 | 170 |
| D | HL2 set value in ready state | 30 ~ 200 | 120 | 120 | 120 |
| E | Heavy paper 1 HL1 set value | 70 ~ 230 | 170 | 175 | 175 |
| F | Heavy paper 1 HL2 set value | 70 ~ 230 | 135 | 136 | 136 |
| G | Heavy paper 2 HL1 set value | 70 ~ 230 | 175 | 175 | 175 |
| H | Heavy paper 2 HL2 set value | 70 ~ 230 | 145 | 145 | 145 |
| I | OHP1 HL1 set value | 70 ~ 230 | 170 | 170 | 170 |
| J | OHP1 HL2 set value | 70 ~ 230 | 155 | 155 | 155 |
| K | OHP2 HL1 set value | 70 ~ 230 | 170 | 170 | 170 |
| L | OHP2 HL2 set value | 70 ~ 230 | 155 | 155 | 155 |
| M | Envelope HL1 set value | 70 ~ 230 | 180 | 180 | 180 |
| N | Envelope HL2 set value | 70 ~ 230 | 145 | 145 | 145 |
| O | Temperature set value in pre-heating | 70 ~ 200 | 143 | 143 | 143 |

| Display | Content | Set range | Default | | |
|---------|--|-----------|-------------|-------------|-------------|
| | | | 100v Series | 120v Series | 200v Series |
| P | Set temperature at which print is ready by heating up from the preheat mode. (Black and white copy mode) | 70 ~ 200 | 165 | 165 | 165 |
| Q | Set temperature at which the fusing motor starts rotation in warming up operation. | 70 ~ 200 | 155 | 155 | 155 |
| R | When set to "1," the upper and the lower heat rollers are ready for print only when they reach the specified temperature. (Used when abnormal fusing occurs under low temperature environment.) When set to "0," the operation is performed in the normal mode. That is, print is ready when the upper heat roller reaches the specified temperature.) | 0 ~ 1 | 0 | 0 | 0 |



44

| | |
|----------------------------|---|
| 44 | -1 |
| Purpose | Setting |
| Function (Purpose) | Used to set enable/disable of correction operations in the image forming (process) section. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Operation |
| Operation/Procedure | 1. Select the process item to enable the operation. 2. Press the [EXECUTE] key. (The operations of all process items must be enabled.) |

(Items to be selected)


| Display | Content |
|---------|---|
| HV | Image forming section correction (Process correction) (High-density image density correction) |
| HT | Half-tone image density correction |
| TC | Transfer output correction |
| RRM | RRM speed correction |
| MD | Photoconductor membrane decrease (sensitivity/potential) correction |
| AR | Image resist auto adjustment *1 |
| AR CHK | Image resist auto adjustment error judgment YES/NO *2 |

*1: When SIM 50-20 is used to adjust the image resist to the best and the image resist adjustment is performed under the following condition automatically, the best adjustment state may be changed. To avoid this, set the adjustment item AR to Disable. When the adjustment item AR is set to Disable (ON), the image resist adjustment is automatically performed under the following conditions.

Normally set to ON condition.

*2: When the image registration automatic adjustment operation is abnormal, it is judged as an error or not.


- After replacement of a toner cartridge
- At every 8000 copies (total of print and copy)
(When, however, 8000 copies is reached during a job, the operation is stopped after completion of the job.)



| | |
|-----------------------------|--|
| 44 | -2 |
| Purpose | Adjustment |
| Function (Purpose) | Black image density sensor adjustment |
| Section | Process (Transfer) |
| Item | Operation |
| Operation/ Procedure | <p>1. Press the [EXECUTE] key.</p> <p>The amplifier gain adjustment of the black image density sensor is automatically performed. After completion of the adjustment, the result is displayed and the [EXECUTE] key display returns to the original state.</p> |

(Display items)

| | Display | Content | Min Value | Max Value | Default value |
|---|---------------|---|-----------|-----------|---------------|
| A | PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |
| B | PCS_K LED ADJ | Black image density sensor LED current adjustment value | 1 | 255 | 51 |
| C | PCS_K GAIN | Black image density sensor output gain (AMP) adjustment value | 0 | 15 | 0 |
| D | PCS_K DARK | Black image density sensor dark voltage level | 0 | 255 | 0 |
| E | PCS_K GRND | Black image density sensor transfer belt surface detection level | 0 | 255 | 0 |
| F | BELTMAX | Transfer belt surface max. detection level (Black image sensor) | 0 | 255 | 0 |
| G | BELTMIN | Transfer belt surface min. detection level (Black image sensor) | 0 | 255 | 0 |
| H | BELTDIF | Difference between max. and min. of the transfer belt surface detection level (BELTmax-BELTMIN) | 0 | 255 | 0 |




If the adjustment is not completed normally, "ERROR" is displayed. In case of an error, the contents of the adjustment are not revised.

| | |
|-----------------------------|---|
| 44 | -4 |
| Purpose | Setting |
| Function (Purpose) | Image forming section correction, image density sensor adjustment conditions setup |
| Section | Process (Photoconductor, development, transfer) |
| Item | Picture quality |
| Operation/ Procedure | <p>1. Select the item to be set by the scroll key.</p> <p>2. Enter the set value with the 10-key, and press the [OK] key. (The entered value is set.)</p> <p>Set all to the default values.</p> |

(Display items)

| | Display | Content | Min Value | Max Value | Default value |
|---|----------------------|--|-----------|-----------|---------------|
| A | PCS_C TARGET | Color image density sensor adjustment target value | 1 | 255 | 108 |
| B | PCS_K TARGET | Black image density sensor adjustment target value | 1 | 255 | 201 |
| C | LED_C OUTPUT | Initial current level in color image density sensor adjustment | 1 | 255 | 51 |
| D | LED_K OUTPUT | Initial current level in black image density sensor adjustment | 1 | 255 | 51 |
| E | PCS ADJUSTMENT LIMIT | Allowable error level in adjustments | 1 | 255 | 2 |
| F | BELT GROUND DIF | Error judgment level for the belt surface detection level difference | 1 | 255 | 255 |
| G | BIAS_CL STANDARD DIF | Set value (color) of the developing basis correction start voltage difference in high density image correction | 0 | 255 | 50 |
| H | BIAS_BK STANDARD DIF | Set value (black) of the developing basis correction start voltage difference in high density image correction | 0 | 255 | 75 |
| I | BIAS PATCH INTERVAL | Patch forming developing bias voltage interval (voltage difference) in high density image correction | 1 | 255 | 50 |
| J | Y_PAT TARGET ID | Base target density level (Y) in high density image correction | 1 | 255 | 88 |
| K | M_PAT TARGET ID | Base target density level (M) in high density image correction | 1 | 255 | 95 |
| L | C_PAT TARGET ID | Base target density level (C) in high density image correction | 1 | 255 | 94 |
| M | K_PAT TARGET ID | Base target density level (K) in high density image correction | 1 | 255 | 22 |

| Display | | Content | Min Value | Max Value | Default value |
|---------|----------------------|---|-----------|-----------|---------------|
| N | HV BK_GROUND LIMIT | Error judgment level for belt surface detection level difference (Allowable range of transfer belt surface detection level difference (mix. - min.) of black toner image patch position) | 1 | 255 | 29 |
| O | PCS_C MARKET TARGET | Adjustment target value (Color image density sensor) when adjusting the primary LED current value by using the calibration plate in SIM44-36. | 1 | 255 | 120 |
| P | PCS_C MARKET LED-REV | In SIM44-36, the toner patch density is read by three kinds of LED currents with the primary LED current adjustment value as the center value in order to obtain PCS C LED ADJ value. This is the deflection range of the current value in the above case. (Color image density sensor) | 1 | 255 | 10 |




| | | |
|----------------------------|---|--|
| 44 | -6 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to forcibly execute the image forming section correction (high density process correction) (process correction). | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | |
| Item | Operation | |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key, and the image forming section correction is started. 2. If the operation is normally completed, COMPLETE is displayed and the correction result becomes valid. If the operation is not normally completed, ERRORPR is highlighted and the detail of the trouble is displayed. The detail of correction can be checked with SIM 44-9 and SIM 44-12. | |

(Result/Detail messages list)

| Result display | Content |
|-------------------------|--|
| COMPLETE | Correction is normally completed. |
| ERROR | An error occurred during correction. (The previous correction result is maintained.) |
| COMPULSORY INTERRUPTION | Compulsory interruption |

| Error display | Content |
|-------------------------------|---|
| COLOR_SENSOR_ADJUSTMENT_ERROR | Color image density sensor adjustment error |

| Error display | Content |
|-------------------------------|--|
| BLACK_GAIN_ADJUSTMENT_ERROR | Black image density sensor gain adjustment error |
| BLACK_SENSOR_ADJUSTMENT_ERROR | Black image density sensor adjustment error |
| BLACK_PROCON_ERROR | High-density image density correction (process correction) error (K) |
| CYAN_PROCON_ERROR | High-density image density correction (process correction) error (C) |
| MAGENTA_PROCON_ERROR | High-density image density correction (process correction) error (M) |
| YELLOW_PROCON_ERROR | High-density image density correction (process correction) error (Y) |
| CONNECTION_ERROR | Sensor-PCU PWB communication trouble |



| | | |
|----------------------------|---|-------------------------------------|
| 44 | -9 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the data related to the image forming section correction (the corrected main charger grid voltage in each print mode, the developing bias voltage, etc.). (Used to check that correction is performed normally or not.) | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | |
| Item | Data | Operation data (Machine conditions) |
| Operation/Procedure | <ol style="list-style-type: none"> 1. By scrolling with the scroll key, each data of the image forming section correction result. can be checked. | |

2. [CPY/PRN] key selected: Process control mode is displayed.
[CAD] key selected: Drawing mode is displayed. (Printer, etc.)
[OTHER] key selected: The environment area and the number of execution of process control are displayed.

(Displayed items)

| Display | Content |
|---------------------------|---|
| P (PROCON MODE) | Main charger grid voltage/developing bias voltage by high density image correction (Y, M, C, K) |
| N (NORMAL MODE (MIDDLE)) | Actual main charger grid voltage/developing bias voltage (Normal, medium speed mode) (Y, M, C, K) |
| N (NORMAL MODE (LOW)) | Actual main charger grid voltage/developing bias voltage (Normal, low speed mode) (Y, M, C, K) |
| N (NORMAL MODE (HIGH)) | Actual main charger grid voltage/developing bias voltage (Normal, high-speed mode) (Y, M, C, K) |
| TS (TONER SAVE MODE) | Actual main charger grid voltage /Developing bias voltage (toner save high/medium/low speed mode) (K) |
| D (DRAWING MODE (MIDDLE)) | Actual main charger grid voltage/developing bias voltage (Drawing, medium speed mode) (Y, M, C, K) |

| Display | Content |
|-----------------------|---|
| D (DRAWING MODE (LOW) | Actual main charger grid voltage /Developing bias voltage (drawing, low speed mode) (YMCK) |
| TEMP AREA | Temperature area |
| TEMP | Temperature (HEX value) |
| HUMIDITY AREA | Humidity |
| HUMIDITY | Humidity (HEX value) |
| MD X STEP (M/L/H) | Photoconductor drum membrane decrease correction step (Max. 4 steps) /Correction voltage |
| CONVERSION | Discrimination of Sharp version and other company version of toner cartridge (0: SHARP, 1: Other company) |
| DESTINATION | Destination of toner cartridge stored in the machine memory |
| MODEL TYPE | Toner cartridge application model (DM/AR) |
| CRUM DESTINATION (X) | Toner cartridge destination |
| DV X STEP (X) | Developing bias voltage correction step (correction voltage) for toner cartridge life |
| HV | Number of corrections of high density image density |
| HT | Number of corrections of half-tone image density |

| | |
|-----------------------------|---|
| 44 | -12 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the sampling toner image patch density data in the image forming section correction (high-density correction) (process correction). This simulation allows to check if the correction operation is performed normally.) |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Data Operation data (Machine conditions) |
| Operation/ Procedure | The [TARGET] key and the [PATCH] key are used to select the display of the correction target level of each color and the toner image patch density sampling data. |

(Display items)

| Display | Content |
|-----------|---|
| CARB DATA | Color image density sensor output level when the calibration plate is detected by the basis of the color image density sensor LED current adjustment value. |
| ID (YMC) | Actual target density level in high density image correction |
| ID (K) | Actual target density level in high density image correction |
| n-1 | Toner patch density (previous patch of nth patch data) in high density image correction (Center voltage - 50v) (n = 1 to 10)) |
| n-2 | Toner patch density (Medium patch of nth patch data) in high density image correction (Center voltage) (n = 1 to 10)) |
| n-3 | Toner patch density (following patch of nth patch data) in high density image correction (Center voltage + 50v) (n = 1 to 10)) |

| | |
|-----------------------------|--|
| 44 | -13 |
| Purpose | Adjustment |
| Function (Purpose) | Color image density sensor adjustment (Adjustment by the adjustment jig) |
| Section | Process (Transfer) |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Open the front cover of the machine. 2. Install the color image density sensor adjustment jig to the transfer unit frame, and close the left cabinet. 3. With the front cover of the machine open (cover open/close switch OFF), turn on the power. 4. Enter the SIM44-13 mode. 5. Close the front cover of the machine. 6. Press the [EXECUTE] key. Adjustment is performed automatically. After completion of adjustment, the result is displayed and the [EXECUTE] key display returns to the original state. 7. Remove the color image density sensor adjustment jig. |

(Set items)

| | Display | Content | Min Value | Max Value | Default value |
|---|----------------|--|-----------|-----------|---------------|
| A | PCS_C CARB ADJ | Color image density sensor LED current adjustment target value | 1 | 255 | 108 |
| B | PCS_C DARK | Color image density sensor dark voltage level | 0 | 255 | 0 |
| C | PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |

If the adjustment is not completed normally, "ERROR" is displayed. In case of an error, the contents of the adjustment are not revised.

| | |
|-----------------------------|---|
| 44 | -14 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to monitor the output level of the fusing temperature sensor, the machine temperature sensor, and the humidity sensor. |
| Section | Others |
| Operation/ Procedure | The fusing temperature, the fusing thermistor temperature, and the machine temperature and humidity are displayed. |

(Display items)

| Display | Content |
|-----------------------------|---|
| FUSER TEMPERATURE CHECK HL1 | Fusing temperature display Upper (Temperature/AD value) |
| FUSER TEMPERATURE CHECK HL2 | Fusing temperature display Lower (Temperature/AD value) |

| Display | Content |
|---------------------|--|
| PROCESS TEMPERATURE | Image process correction temperature sensor temperature display (Temperature/AD value) |
| PROCESS HUMIDITY | Image process correction humidity sensor humidity display (Relative humidity/AD value) |

When the value exceeds the detection range, "-" is displayed.

Developing temperature: -20.0 to 40.0

Humidity: 0.0 to 99.9

Board temperature: -20.0 to 80.0

| | |
|-----------------------------|--|
| 44 | -21 |
| Purpose | Setting |
| Function (Purpose) | Used to store color balance adjustment data. (Half tone image correction initial setting) (After execution of color balance adjustment with SIM 46-21, this simulation must be executed.) |
| Section | Picture quality |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key, and it is highlighted and the operation of color balance adjustment data (half-tone correction initial data) storing is started. After completion of the execution, the [EXECUTE] key returns to the normal display <p>* In case of an error in the above operation, "ERROR" is displayed and the color balance adjustment data (half-tone initial data) are not stored.</p> |

| | |
|-----------------------------|--|
| 44 | -22 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check each color toner patch image density UITU in half tone image forming section correction (process correction). (This simulation allows to check if correction operation is performed normally.) |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Data Operation data (Machine conditions) |
| Operation/ Procedure | <p>The toner image patch density data in half-tone correction are displayed.</p> <p>[1ST STEP]: The toner image patch density sampling data in the 1ST STEP are displayed.</p> <p>[2ND STEP]: The toner image patch density sampling data in the 2ND STEP are displayed.</p> |

(Display items)

| Display | Content |
|----------|--|
| 1ST STEP | Correction operation 1ST STEP toner image patch density detection level (n=1 – 5) |
| 2ND STEP | Correction operation 2ND STEP toner image patch density detection level (n=1 – 16) |


| ID-n | PTK/GND | PTC | PTM | PTY |
|------|---|--|---|--|
| | Black image patch density detection level/Transfer belt element detection level | Cyan image patch density detection level | Magenta image patch density detection level | Yellow image patch density detection level |

| | |
|-----------------------------|---|
| 44 | -24 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the half tone correction result. (This simulation allows to check if correction is executed properly or not.) |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Data Operation data (Machine conditions) |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select a page with the scroll key. 2. Select the color mode with [K], [C], [M], and [Y] keys. 3. When [NEXT] key is pressed repeatedly, the display changes from Coefficient to Reference Value then to Correction Value in this sequence. <ul style="list-style-type: none"> • When the displayed item is not yet executed, "-" is displayed. In case of an error, "ERR" is displayed. • For the reference value and the correction value, an error display is not made, but the previous value is displayed. |


| | |
|-----------------------------|--|
| 44 | -25 |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Setting the half tone correction conditions. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Data Operation data (Machine conditions) |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the color mode with [K], [C], [M], and [Y] keys. 2. Select the set item with the scroll key. 3. Enter the set value with the 10-key and press the [OK] key to store the set value. <p>Note: Do not set to other value than the default.</p> <p>(Items to be set)</p> |

| | Item | Default setting value | Set range | Content |
|---|-----------|-----------------------|-----------|--|
| A | 1ST PATCH | 40 | 0 – 255 | Half-tone process control 1st step 1st patch print gradation |
| B | 2ND PATCH | 60 | 0 – 255 | Half-tone process control 1st step 2nd patch print gradation |

| Item | Default setting value | Set range | Content |
|-------------|-----------------------|-----------|--|
| C 3RD PATCH | 80 | 0 – 255 | Half-tone process control 1st step 3rd patch print gradation |
| D 4TH PATCH | 100 | 0 – 255 | Half-tone process control 1st step 4th patch print gradation |
| E 5TH PATCH | 255 | 0 – 255 | Half-tone process control 1st step 5th patch print gradation |




| | |
|-----------------------------|--|
| 44 -26 | |
| Purpose | Adjustment |
| Function (Purpose) | Used to execute half tone correction compulsorily. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Picture quality |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key, and it is highlighted. The half tone correction is started. When the compulsory execution is completed, the [EXECUTE] key returns to the normal display. <p>* In the case of abnormal completion, ERROR is displayed and the correction data are not stored.</p> |



| | |
|-----------------------------|--|
| 44 -27 | |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the half tone correction data and set to the default level. |
| Section | Process (Photoconductor, developing, transfer, cleaning) |
| Item | Data |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. The [YES] and [NO] keys become active. 2. Press the [YES] key, and the half tone correction data is set to the default level. (If the [NO] key is pressed, it is canceled.) |


* After replacement of the OPC drum, be sure to execute this simulation.



| | |
|-----------------------------|---|
| 44 -36 | |
| Purpose | Adjustment |
| Function (Purpose) | Color image density sensor and black image density sensor adjustment (simple adjustment) |
| Section | Process (Transfer) |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Enter the SIM44-36 mode. 2. Press the [EXECUTE] key. <p>Adjustment is performed automatically. After completion of adjustment, the result is displayed and the [EXECUTE] key display returns to the original state.</p> <p>SIM44-36 is used to adjust both the color image density sensor and the black image density sensor.</p> |

(Adjustment items)

| Display | Content | Min Value | Max Value | Default value |
|----------------|---|-----------|-----------|---------------|
| PCS_C CARB ADJ | Color image density sensor LED current adjustment target value | 1 | 255 | 108 |
| PCS_C DARK | Color image density sensor dark voltage level | 0 | 255 | 0 |
| PCS_C LED ADJ | Color image density sensor current adjustment value | 1 | 255 | 51 |
| PCS K LED ADJ | Black image density sensor LED current adjustment value | 1 | 255 | 51 |
| PCS_K GAIN | Black image density sensor output gain (AMP) adjustment value | 0 | 15 | 0 |
| PCS_K DARK | Black image density sensor dark voltage level | 0 | 255 | 0 |
| PCS_K GRND | Black image density sensor transfer belt surface detection level | 0 | 255 | 0 |
| BELTMAX | Transfer belt surface max. detection level (Black image sensor) | 0 | 255 | 0 |
| BELTMIN | Transfer belt surface min. detection level (Black image sensor) | 0 | 255 | 0 |
| BELTDIF | Difference between the max. value and the min. value of transfer belt surface detection level (BELTMAX-BELTMIN) | 0 | 255 | 0 |



If the adjustment is not completed normally, "ERROR" is displayed. In case of an error, the contents of the adjustment are not revised.

(NOTE)

If the adjustment jig is not available, use the simple adjustment (SIM44-36). Depending on the machine conditions, however, the adjustment accuracy is insufficient. Carefully note that.

If toner, the OPC drum, and the transfer belt are not new ones or almost new ones, use of the simple adjustment method is not recommendable.

Though the machine conditions are so well as to use the simple adjustment (without the adjustment jig), it is better to perform the adjustment by using the adjustment jig for higher adjustment accuracy.

After the color image density sensor adjustment (adjustment by the adjusting jig) with SIM44-13, do not execute SIM44-36 unnecessarily.

If SIM44-36 is executed, the contents of the color image density sensor adjustment (adjustment by the adjustment jig) are erased and the adjustment result of SIM44-36 are saved.

When the color image density sensor adjustment is executed with SIM44-13 and the black image density sensor adjustment is executed with SIM44-2, there is no need to execute the adjustment with SIM44-36.


To adjust the black image density sensor, the adjustment jig is not required.

46

| | | |
|----------------------------|---|---------|
| 46 | -1 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the copy density of each color copy mode in the low-density area. The copy densities of all colors in the low-density area are changed. | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | |
| Item | Picture quality | Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the copy mode for copy density adjustment with the scroll key. 2. Enter the set value with the 10-key and press the [OK] key, and the set value is stores. | |

(Items to be set)


| | Display | Copy mode (Color) | Min. Value | Max. Value | Default |
|---|---|--|------------|------------|---------|
| A | AUTO | Auto (Auto document kind recognition, auto exposure) | 1 | 99 | 50 |
| B | TEXT | Text | 1 | 99 | 50 |
| C | TEXT/PRINTED PHOTO | Text/Printed photo | 1 | 99 | 50 |
| D | TEXT/PHOTO | Text/Photograph | 1 | 99 | 50 |
| E | PRINTED PHOTO | Printed photo | 1 | 99 | 50 |
| F | PHOTOGRAPH | Photograph | 1 | 99 | 50 |
| G | MAP | Map | 1 | 99 | 50 |
| H | TEXT (COPY TO COPY) | Text (Copy document) | 1 | 99 | 50 |
| I | TEXT/PRINTED PHOTO (COPY TO COPY) | Text/Print (Copy document) | 1 | 99 | 50 |
| J | PRINTED PHOTO (COPY TO COPY) | Printed photo | 1 | 99 | 50 |
| K | TEXT (COLOR TONE ENHANCEMENT) | Text (Color emphasis) | 1 | 99 | 50 |
| L | TEXT/PRINTED PHOTO (COLOR TONE ENHANCEMENT) | Text/Print (Color emphasis) | 1 | 99 | 50 |
| M | TEXT/PHOTO (COLOR TONE ENHANCEMENT) | Color/Photograph (Color emphasis) | 1 | 99 | 50 |
| N | PRINTED PHOTO (COLOR TONE ENHANCEMENT) | Printed photo (Color emphasis) | 1 | 99 | 50 |
| O | PHOTOGRAPH (COLOR TONE ENHANCEMENT) | Photograph (Color emphasis) | 1 | 99 | 50 |
| P | MAP (COLOR TONE ENHANCEMENT) | Map (Color emphasis) | 1 | 99 | 50 |
| Q | SINGLE COLOR | Single color | 1 | 99 | 50 |
| R | SINGLE COLOR (COPY TO COPY) | Single color (Copy document) | 1 | 99 | 50 |



| | | |
|----------------------------|--|---------|
| 46 | -2 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the copy density of the low-density area in each monochrome copy mode. The copy density of the low-density area is changed. | |
| Section | Process (Photoconductor, developing, transfer, cleaning) | |
| Item | Picture quality | Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the copy mode for copy density adjustment with the scroll key. 2. Enter the set value with the 10-key and press the [OK] key, and the entered value is set. | |

(Items to be set)


| | Display | Copy mode (Color) | Min. Value | Max. Value | Default |
|---|-----------------------------------|------------------------------------|------------|------------|---------|
| A | AUTO1 (*1) | Auto 1 (Japan) | 1 | 99 | 50 |
| B | AUTO2 (*2) | Auto 2 (Except Japan) | 1 | 99 | 50 |
| C | TEXT | Text | 1 | 99 | 50 |
| D | TEXT/PRINTED PHOTO | Text/Printed photo | 1 | 99 | 50 |
| E | TEXT/PHOTO | Text/Photograph | 1 | 99 | 50 |
| F | PRINTED PHOTO | Printed photo | 1 | 99 | 50 |
| G | PHOTOGRAPH | Photograph | 1 | 99 | 50 |
| H | MAP | Map | 1 | 99 | 50 |
| I | TEXT (COPY TO COPY) | Text (Copy document) | 1 | 99 | 50 |
| J | TEXT/PRINTED PHOTO (COPY TO COPY) | Text/Printed photo (Copy document) | 1 | 99 | 50 |
| K | PRINTED PHOTO (COPY TO COPY) | Printed photo (Copy document) | 1 | 99 | 50 |



| | | |
|----------------------------|---|---------|
| 46 | -4 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the image density (color mode) in the network scan mode. | |
| Section | Scanner (reading) | |
| Item | Picture quality | Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the scan mode with the scroll key. 2. Enter the adjustment value with the 10-key and press the [OK] key, and the entered value is set. <p>The adjustment result is valid only for the network scan mode.</p> | |

(Items to be set)

| | Display | Network scan color mode | Min. Value | Max. Value | Default |
|---|--------------------|-------------------------|------------|------------|---------|
| A | TEXT | Text | 1 | 99 | 50 |
| B | TEXT/PRINTED PHOTO | Text/Printed photo | 1 | 99 | 50 |
| C | TEXT/PHOTO | Text/Photograph | 1 | 99 | 50 |
| D | PRINTED PHOTO | Printed photo | 1 | 99 | 50 |
| E | PHOTOGRAPH | Photograph | 1 | 99 | 50 |
| F | MAP | Map | 1 | 99 | 50 |




46 -5

| | |
|----------------------------|---|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the image density (monochrome mode) in the network scan mode. |
| Section | Scanner (reading) |
| Item | Picture quality Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the scan mode with the scroll key. 2. Enter the adjustment value with the 10-key and press the [OK] key, and the entered value is set. <p>The adjustment result is valid only for the network scan mode.</p> |

(Items to be set)

| | Display | Network scan monochrome mode | Min. Value | Max. Value | Default |
|---|-----------------------|------------------------------|------------|------------|---------|
| A | AUTO TEXT | Text (Auto) | 1 | 99 | 50 |
| B | AUTO TEXT/PRINT PHOTO | Text/Printed photo (Auto) | 1 | 99 | 50 |
| C | AUTO TEXT/PHOTO | Text/Photograph (Auto) | 1 | 99 | 50 |
| D | TEXT | Text | 1 | 99 | 50 |
| E | TEXT/PRINTED PHOTO | Text/Printed photo | 1 | 99 | 50 |
| F | TEXT/PHOTO | Text/Photograph | 1 | 99 | 50 |
| G | PRINTED PHOTO | Printed photo | 1 | 99 | 50 |
| H | PHOTOGRAPH | Photograph | 1 | 99 | 50 |
| I | MAP | Map | 1 | 99 | 50 |




46 -6

| | |
|---------------------------|--|
| Purpose | Adjustment |
| Function (Purpose) | <ol style="list-style-type: none"> 1) Used to set the CCD black level offset level. 2) Used to set the CCD white level gain. |
| Section | Scanner (reading) |
| Item | Picture quality |

| | |
|----------------------------|---|
| Operation/Procedure | <p>Only one color button can be selected. The selected key is highlighted. (Default: [B])</p> <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the copy mode for the copy density adjustment with the scroll key. 3. Select the color mode with the color key (RGB). (The currently set adjustment value is displayed.) 4. Enter the set value with the 10-key and press the [OK] key, and the entered value is set. |
|----------------------------|---|

Set the following set value.

| | Display | Content | Min. Value | Max. Value | Default |
|---|-------------|---|------------|------------|---------|
| A | GAIN EVEN | Gain adjustment start value (Even number) | 0 | 255 | 0 |
| B | GAIN ODD | Gain adjustment start value (Odd number) | 0 | 255 | 0 |
| C | BLACK LEVEL | Output black level | 0 | 255 | 32 |
| D | AD INPUT | Analog IC function control | 0 | 31 | 2 |



46 -10


| | |
|----------------------------|--|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance (color) (copy document mode) (gamma/density adjustment for each color) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.

(Items to be set)

| | Display | Min. Value | Max. Value | Default |
|---|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| O | POINT15 | 245 | 755 | 500 |

Common to KCMY.




| | |
|----------------------------|---|
| 46 | -11 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance (color) (text mode/map mode) (gamma/density adjustment for each color) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the [2], [4] keys. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.

(Items to be set)

| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |




| | |
|----------------------------|--|
| 46 | -12 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance (color) (text/printed photo mode/Photograph mode) (gamma/density adjustment for each color) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.

(Items to be set)

| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |




| | |
|----------------------------|--|
| 46 | -13 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance (color) (photograph mode) (gamma/density adjustment for each color) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.

(Items to be set)

| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |




| | |
|----------------------------|--|
| 46 | -14 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance (color) (text/photograph mode) (gamma/density adjustment for each color) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.

(Items to be set)


| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |



| | | |
|----------------------------|--|---------|
| 46 | -15 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the gamma and density. (Monochrome mode) | |
| Section | Image process (ICU) | |
| Item | Picture quality | Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment point with the scroll key. 2. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) | |

(Items to be set)


| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |



| | | |
|----------------------------|---|---------|
| 46 | -16 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the gamma and density. (Monochrome mode) (The adjustment check pattern is printed.) | |
| Section | Image process (ICU) | |
| Item | Picture quality | Density |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment point with the scroll key. 2. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) <p>When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.</p> | |

(Items to be set)


| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |



| | | |
|----------------------------|---|---------------|
| 46 | -19 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to select the half-tone density (gamma) in the auto exposure mode and to set the auto exposure operation mode. | |
| Section | Image process (ICU) | |
| Item | Picture quality | Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Set the half-tone density (Gamma) with the [MODE1] key and the [MODE2] key. 2. Set the auto exposure operation mode with [ON] / [OFF]key. | |

| Display | Set mode | Content | Destination | Default |
|---------|-----------------|---|--------------|-------------------------------|
| AE MODE | MODE 1 (AUTO 1) | The half-tone density is higher than that of AUTO 2 mode. | Japan | Japan: MODE 1 (AUTO 1) |
| | MODE 2 (AUTO 2) | The half-tone density is lower than that of AUTO 1 mode. | Except Japan | Except Japan: MODE 2 (AUTO 2) |


| Display | Set mode | Content | Default |
|--------------|----------|--|---------|
| AE STOP MODE | OFF | Auto density (exposure) control is performed in real time. (The density level is changed in real time according to the document pattern.) | OFF |
| | ON | The density at the tip of a document is scanned, and the overall density (exposure) level is determined according to the density at the tip. (The overall density level is fixed.) | |



| | | |
|----------------------------|--|---------------|
| 46 | -20 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust copy color balance (All color copy mode gamma/density adjustment) (All color copy mode color balance/gamma/density are changed.) Same as SIM 46-21, however, printing is not performed. | |
| Section | Image process (ICU) | |
| Item | Picture quality | Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) | |

(Items to be set)

| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |




| | | |
|---------------------------|---|---------------|
| 46 | -21 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust copy color balance (All color copy mode gamma/density adjustment) (All color copy mode color balance/gamma/density are changed.) | |
| Section | Image process (ICU) | |
| Item | Picture quality | Color balance |

| | |
|----------------------------|---|
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (K/C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) <p>When the [EXECUTE] key is pressed, the color balance adjustment check pattern corresponding to the entered adjustment value is printed.</p> |
|----------------------------|---|


(Items to be set)

| Display | | Min. Value | Max. Value | Default |
|---------|---------|------------|------------|---------|
| A | POINT1 | 245 | 755 | 500 |
| ↓ | ↓ | ↓ | ↓ | ↓ |
| O | POINT15 | 245 | 755 | 500 |



| | |
|----------------------------|---|
| 46 | -23 |
| Purpose | Setting |
| Function (Purpose) | Used to set Enable/Disable of half-tone high-density correction. |
| Item | Picture quality Color balance |
| Operation/Procedure | <p>[ENABLE]: Correction is enabled.</p> <p>[DISABLE]: Correction is disabled.</p> <p>Default set: DISABLE</p> |


When tone gap occurs in the high density area in the photo copy mode, set this function to ENABLE, and the max. density level will fall, reducing tone gap.



| | |
|----------------------------|---|
| 46 | -24 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy color balance automatically. (All color copy mode gamma/density adjustment) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. (A3 or 11 x 17 paper is automatically selected.) The color patch image (adjustment pattern) is printed. |

2. Set the color patch image printed in procedure 1 on the document table.
3. Press the FACTORY key on the operation panel, and press the [EXECUTE] key.
The copy color balance adjustment (step 1) is automatically performed and the color balance check patch image is printed.
4. Press the REPEAT key on the operation panel.
5. Press the [EXECUTE] key.
The color patch image (adjustment pattern) is printed.
6. Set the color patch image (adjustment pattern) printed in procedure 5 on the document table. (Place the darker patch on the left side.)
7. Press the FACTORY key on the operation panel, and press the [EXECUTE] key.
The copy color balance adjustment (step 2) is automatically performed and the color balance check patch image is printed.
8. Press the [OK] key on the operation panel.


The initial setting of the half-tone image correction is performed according to this adjustment data.



| | |
|----------------------------|--|
| 46 | -25 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust copy color balance (Single color mode) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (C/M/Y). 2. Select the adjustment point with the scroll key. 3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.) |

(Items to be set)


| Display | | Content | Min. Value | Max. Value | Default | | |
|---------|--------|---------|------------|------------|---------|-----|-----|
| A | COLOR1 | RED | 0 | 255 | C | M | Y |
| B | COLOR2 | GREEN | 0 | 255 | 255 | 0 | 255 |
| C | COLOR3 | BLUE | 0 | 255 | 255 | 255 | 0 |
| D | COLOR4 | YELLOW | 0 | 255 | 0 | 0 | 255 |
| E | COLOR5 | MAGENTA | 0 | 255 | 0 | 255 | 0 |
| F | COLOR6 | CYAN | 0 | 255 | 255 | 0 | 0 |



| | |
|----------------------------|---|
| 46 | -26 |
| Purpose | Adjustment |
| Function (Purpose) | Used to set the copy color balance adjustment to the default. (Single color copy mode) |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key. (YES/NO keys are displayed.) 2. Press the [YES] key, and the copy color balance is set to the default. (Press the [NO] key to cancel.) |

(Standard value reset items)

1. RED setup ratio
2. GREEN setup ratio
3. BLUE setup ratio
4. YELLOW setup ratio
5. MAGENTA setup ratio
6. CYAN setup ratio



| | | |
|----------------------------|--|---------------|
| 46 | -27 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the gamma/density in the black edge section of the copy mode image. (Black text and black line reproduction adjustment) | |
| Section | Image process (ICU) | |
| Item | Picture quality | Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the color to be adjusted with the color key (C/M/Y). 2. Select the adjustment item with the scroll key. | |


3. Enter the adjustment value of the selected point with the 10-key and press the [OK] key. (The entered value is set.)

Text and line edge area reproduction is adjusted by changing the gamma and the overall density level in the image edge section. For especially thin text, the boldness of lines is changed.

The greater the adjustment value is, the higher the image density in the edge area is, and vice versa.

(Items to be set)

| | Display | Content | Min. Value | Max. Value | Default |
|---|------------------------|---|------------|------------|---------|
| A | BLACK TEXT (SLOPE) | Black image edge section gamma (tilt) adjustment (Black text and black line reproduction adjustment) | 1 | 99 | 50 |
| B | BLACK TEXT (INTERCEPT) | Black image edge section density (overall level) adjustment (Black text and black line reproduction adjustment) | 1 | 99 | 50 |




| | | |
|----------------------------|--|---------------|
| 46 | -28 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to check pre-scanning operation for automatic recognition of document in the color auto copy mode. (This simulation is used only in production, and not used in the market.) | |
| Section | Image process (ICU) | |
| Item | Picture quality | Color balance |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the item to be set with the scroll key. 2. Enter the set value of the selected item with the 10-key and press the [OK] key. (The scan area is set.) | |

3. Press the [EXECUTE] key to scan the area corresponding to the set scan area. Then the scan information is displayed. Press [SETUP] key to return to the initial display. (Set content display)

Though the above set value is changed, the document auto recognition is not affected in an actual color auto copy mode.

(Items to be set)

| | Display | Content | Min. Value | Max. Value | Default |
|---|-------------------------|----------------------------------|------------|------------|---------|
| A | ORIGINAL MAIN SIZE (mm) | Main scanning document size (mm) | 100 | 297 | 297 |
| B | ORIGINAL SUB SIZE (mm) | Sub scanning document size | 139 | 432 | 210 |



| | | |
|----------------------------|---|--|
| 46 | -33 | |
| Purpose | Setting | |
| Function (Purpose) | Used to set the foundation process conditions in the color auto copy mode, the image auto recognition conditions, and the text recognition conditions. | |
| Section | Image process (ICU) | |
| Item | Picture quality | |
| Operation/Procedure | (Foundation removal operation condition setting) <ol style="list-style-type: none"> 1. Select the COLOR AE mode. 2. Remove the foundation. 3. Select the setting mode with the scroll key. <ol style="list-style-type: none"> A. Foundation process judgment level setting (Judged by the ratio of printed photo in the document (ratio of dots areas).) B. Foundation process judgment level setting (Judged by the ratio of color phase in the document foundation.) C. Foundation removal quantity setting 4. Enter the set value and press the [OK] key to set the entered value. | |

(Relationship between the set value and foundation removal operation)

| Display | Set value (Display) | Ratio of printed photo in the document (Ratio of dot areas) | | | |
|---------|---------------------|---|-----------------|---------------|-----------|
| | | None or little | Little – Medium | Medium – Much | Very much |
| A | 0 | LOW | NO | NO | NO |
| | 1 | RATHER LOW | YES | NO | NO |
| | 2 (Default) | MIDDLE | YES | YES | NO |
| | 3 | RATHER HIGHT | YES | YES | YES |
| | 4 | HIGHT | YES | YES | YES |

| Display | Set value (Display) | Color phase in the document | | | |
|---------|---------------------|-----------------------------|---------------|-----------------|-------------|
| | | None or Weak | Weak – Medium | Medium – Strong | Very strong |
| B | 0 | LOW | NO | NO | NO |
| | 1 | RATHER LOW | YES | NO | NO |
| | 2 (Default) | MIDDLE | YES | YES | NO |
| | 3 | RATHER HIGHT | YES | YES | YES |
| | 4 | HIGHT | YES | YES | YES |

YES: Foundation removal is performed.

NO: Foundation removal is not performed.

(Foundation removal quantity setting)

| Display | Set value (Display) | Foundation removal quantity |
|---------|---------------------|-----------------------------|
| C | -4 | 0 |
| | -3 | 1 |
| | -2 | 2 |
| | -1 | 3 |
| | 0 | 4 (Default) |
| | +1 | 5 |
| | +2 | 6 |
| | +3 | 7 |
| | +4 | 8 |

Whether the foundation removal is performed or not is determined by the AND condition of the set items A and B.

(Image auto recognition condition setting)

Used to set whether the text area is regarded important or not in judgment of printed photo and the text/printed photo or photograph and text/photograph.

1. Select the ORG RECOG mode.
2. Enter the set value with the 10-key and press the [OK] key to set the entered value.

| Display | Set value | Content |
|---------|-------------------------|---|
| A | 0 TEXT PRIORITY MODE | DISABLE There must be considerable level of text area to judge as text/printed photo or text/photograph. |
| | 1 (Default) | ENABLE Only a light level of text area is enough for judging as text/printed photo or text/photograph. |

(Text-on-dots recognition condition setting)

Used to set whether the text on dots is recognized as text or not.

1. Select the SEG mode.
2. Enter the set value with the 10-key and press the [OK] key to set the entered value.


| Display | Set value | Content |
|---------|----------------|---|
| A | 0 (Default) | OFF Text on dots is not recognized as text. |
| | 1 | ENABLE Text on dots is recognized as text. (Priority is placed on the reproduction of text.) Note that a dark density image may be copied as black. |

(Setting the reproduction (text recognition level) of text on dots of a document printed by the printer)

If text recognition is not performed normally, the text recognition level can be adjusted. This function is effective especially when copying a document printed by an inkjet printer or a laser printer.

1. Select the SEG mode.
2. Select the setting mode B with the scroll key.
3. Enter the set value with the 10-key and press the [OK] key to set the entered value.

| Display | Set value | Content |
|---------|----------------|--|
| B | 0 (Default) | OFF Normal mode (Normal text recognition level) Depending on the type of documents, text images may be with sharp edges and high contrast. |
| | 1 | ON Mode for documents printed by a printer: Documents are copied in a similar picture quality. (Low text recognition level) |




48

-1

| | |
|-----------------------------|--|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy magnification ratio (main scanning and sub scanning directions). |
| Item | Picture quality Size/magnification ratio |
| Operation/ Procedure | 1. Select the adjustment mode with the scroll key. 2. Enter the adjustment value with the 10-eky and press the [OK] key to set the entered value. |

- a. Sub scanning direction magnification ratio adjustment: By changing the scanning speed in the paper transport direction, the print magnification of images in the paper transport direction is adjusted.
[Adjustment range]: 35 ~99 (Default: 50)
- b. Main scanning direction magnification ratio adjustment. The print magnification ratio in the vertical direction of images (vertical to the paper transport direction) is adjusted by software in the (F/R) image process section.
[Adjustment range]: 1~99 (Default: 50)





48

-6

| | |
|-----------------------------|---|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust each motor RPM. |
| Item | Operation |
| Operation/ Procedure | 1. Select the motor to be adjusted with the scroll key. 2. Enter the adjustment value with the 10-key and press the [OK] key to set the entered value. |


(Items to be set)

| Item | Set range | Default |
|------------------------|-----------|---------|
| A RRM (BW) | 1 - 99 | 50 |
| B RRM (CL) | 1 - 99 | 50 |
| C BTM | 1 - 99 | 44 |
| D FSM | 1 - 99 | 80 |
| E DM (BW) | 1 - 99 | 60 |
| F DM (CL) | 1 - 99 | 60 |
| G PFM_CS | 1 - 99 | 55 |
| H PFM_MAN | 1 - 99 | 70 |
| I FSM(L) | 1 - 99 | 85 |
| J FSM(FSM(HEAVY PAPER) | 1 - 99 | 85 |
| K FSM(ENV) | 1 - 99 | 70 |
| L PFM_CS(DESK) | 1 - 99 | 55 |
| M PFM_CS(ADU) | 1 - 99 | 55 |
| N PFM_CS(LCC) | 1 - 99 | 55 |




49

| | |
|-----------------------------|--|
| 49 | -1 |
| Purpose | Version up |
| Function (Purpose) | Used for firmware version up (Machine/FAX). |
| Section | Firmware (Machine/FAX) |
| Item | Operation |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key to enter the Flash ROM writing mode. 2. Start the download program on the PC side and perform Flash ROM writing. |



| | |
|-----------------------------|---|
| 49 | -2 |
| Purpose | Version up |
| Function (Purpose) | Used to set the data communication speed in version up of the machine firmware. |
| Section | Firmware |
| Item | Operation |
| Operation/ Procedure | Press the key corresponding to the data communication speed on the PC side. Unit (bps: bit per second) |




| | |
|-----------------------------|--|
| 49 | -10 |
| Purpose | Version up |
| Function (Purpose) | Used for firmware version up (Desk unit). |
| Section | Firmware (Desk unit) |
| Item | Operation |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key to enter the Flash ROM writing mode. 2. Start the download program on the PC side and perform Flash ROM writing. |

50

| | |
|-----------------------------|--|
| 50 | -1 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy image position and the void area (image loss) on print paper in the copy mode. (The similar adjustment can be made also by SIM 50-2 (Simple method).) |
| Item | Picture quality Image position |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the adjustment item with the scroll key. 2. Enter the adjustment value with the 10-key. 3. Press the [OK] key. |

| | Display | Content | Min. Value | Max. Value | Default |
|---|------------|---------------------------------------|------------|------------|---------|
| A | RRC-A | Document lead edge reference position | 1 | 80 | 50 |
| B | RRC-B | Paper lead edge position | 1 | 99 | 50 |
| C | DEN-A | Lead edge void area | 1 | 99 | 40 |
| D | DEN-B | Rear edge void area | 1 | 99 | 40 |
| E | IMAGE LOSS | Lead edge image loss | 0 | 99 | 40 |

- Document lead edge reference position --- (RRC-A) This set value is used to adjust timing from when the document scanning is started to when the image lead edge signal (Set range: 1 – 30) (Default value: 50)
- Paper lead edge position --- (RRC-B) Used to adjust timing of turning on the resist roller after receiving the resist signal (LD_START). (Set range: 1 – 99) (Default value: 50)
- Lead edge void area --- (DEN-A) Used to specify the void area at the lead edge of the document. (Set range: 1=99) (Default value: 40)
- Rear edge void area --- (DEN-B) Used to specify the void area at the rear edge of the document. (Set range: 1 – 99) (Default value: 30)
- Lead edge image loss --- (IMAGE LOSS) Used to specify the image loss. (Set range: 0~99) (Default value: 40)



| | |
|---------------------------|--|
| 50 | -2 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the copy image position and the void area (image loss) on print paper in the copy mode. (Simple method) (The same content of SIM 50-1. However this simulation is easier to perform.) |
| Item | Picture quality Image position |

- Operation/Procedure**
1. Select the adjustment item with the scroll key.
 2. Enter the adjustment value with the 10-key.
 3. Press the [OK] key.

This simulation is used to perform the lead edge adjustment by directly entering the lead edge shift in 400% copy.

| Display | Content | Min. Value | Max. Value | Default |
|--------------|--|------------|------------|---------|
| A L1 | Document lead edge reference position | 0 | 999 | 240 |
| B L2 | Paper lead edge position | 0 | 999 | 40 |
| C DEN-A | Lead edge void area | 1 | 99 | 40 |
| D DEN-B | Rear edge void area | 1 | 99 | 40 |
| E IMAGE LOSS | Document lead edge image loss adjustment value | 0 | 99 | 40 |

(Default values)

- Document lead edge reference position --- (L1) 240
- Paper lead edge position --- (L2) 40
- Lead edge void area --- (DEN-A) 40
- Rear edge void area --- (DEN-B) 40
- IMAGE LOSS --- 40

50 -5

| | |
|----------------------------|--|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the image position and print area in the sub scanning direction. (Print engine section) |
| Section | ICU/Printer |
| Item | Picture quality |
| Operation/Procedure | 1. Select the adjustment mode (DEN-B/DEN-C) with the scroll key. |

2. Enter the adjustment value of the selected point with the 10-key, and press the [OK] key. (The entered adjustment value is set. The [EXECUTE] key or the scroll key can be used instead of the [OK] key in the above procedure.)
3. Select the paper feed mode.
4. Press the [EXECUTE] key.

The test pattern corresponding to the entered adjustment value is printed.

When the adjustment value of item A (DEN-C) is decreased by 1, the print start position in the sub scanning direction shifts 0.125mm toward the paper lead edge.

When the adjustment value of item B (DEN-B) is decreased by 1, the print start position in the sub scanning direction shifts 0.125mm toward the paper rear edge.

(Descriptions on Set values)

| Display | Content | Min. Value | Max. Value | Default |
|---------------|--|------------|------------|---------|
| A DEN-C | Sub scanning print lead edge adjustment | 1 | 99 | 40 |
| B DEN-B | Sub scanning print area adjustment | 1 | 99 | 40 |
| C MULTI COUNT | Print quantity | 1 | 999 | 1 |
| D PAPER | Paper feed tray selection (MFT, CS1, CS2, CS3, CS4, LCC) | 1 | 6 | 2 (CS1) |
| E EXIT TRAY | Paper exit tray selection (R, S) | 1 | 2 | 1 (R) |
| F DUPLEX | Duplex print selection (NO, YES) | 1 | 2 | 1 (NO) |

TEST SIMULATION NO.50-05

LEAD EDGE ADJUSTMENT VALUE (PRINTER)

A : 40 A : 40 DEN-C

B : 40 DEN-B

C : 1 MULTI COUNT

D : 2 PAPER:CS1

[1 ~ 99]

EXECUTE OK


50 -10

| | |
|----------------------------|---|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the print image center position. (Adjustment is performed in each paper feed position separately.) |
| Section | Image process (ICU) |
| Item | Picture quality |
| Operation/Procedure | 1. Select the adjustment mode (DEN-B/DEN-C) with the scroll key. |

2. Enter the adjustment value of the selected point with the 10-key, and press the [OK] key. (The entered adjustment value is set. The [EXECUTE] key or the scroll key can be used instead of the [OK] key in the above procedure.)
3. Press the [EXECUTE] key. The test pattern corresponding to the entered adjustment value is printed.

| Display | Content | Min. value | Max. value | Default |
|---------|-------------|--|------------|---------|
| A | MFT | Print off-center adjustment value (Manual paper feed) | 1 - 99 | 50 |
| B | CS1 | Print off-center adjustment value (1 cassette) | 1 - 99 | 50 |
| C | CS2 | Print off-center adjustment value (2 cassette) | 1 - 99 | 50 |
| D | CS3 | Print off-center adjustment value (3 cassette) | 1 - 99 | 50 |
| E | CS4 | Print off-center adjustment value (4 cassette) | 1 - 99 | 50 |
| F | LCC | Print off-center adjustment value (LCC) | 1 - 99 | 50 |
| G | ADU | Print off-center adjustment value (ADU) | 1 - 99 | 50 |
| H | MULTI COUNT | Print quantity | 1 - 999 | 1 |
| I | PAPER | Paper feed tray selection (MFT, CS1, CS2, CS3, CS4, LCC) | 1 - 6 | 2 (CS1) |
| J | EXIT TRAY | Paper exit tray selection (R, S) | 1 or 2 | 1 |
| K | DUPLEX | Duplex print selection (NO, YES) | 1 or 2 | 1 |


- When the adjustment value of items A~G is decreased by 1, the main scanning print position shifts 0.1mm toward the front side.
- When the adjustment value of items A~G is increased by 1, the main scanning print position shifts 0.1mm toward the rear side.
- To execute item G (ADU adjustment), the ADU must be installed. In this case, item K (DUPLEX) must be set to 2.



| | |
|----------------------------|--|
| 50 | -12 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the print image center position. (The adjustment is performed in each document mode separately.) |
| Section | Image process (ICU) |
| Item | Picture quality Image position |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment mode with the scroll key. 2. Enter the adjustment value with the 10-key and press the [OK] key to set the entered value. <p>* When the set value is increased, the image is shifted to the rear side. When the set value is decreased, the image is shifted to the front side.</p> |

(Items to be set)

| Display | | Content | Min. Value | Max. Value | Default |
|---------|-----|------------------------------|------------|------------|---------|
| A | OC | Platen mode (Document table) | 1 | 99 | 50 |
| B | ADF | RADF mode | 1 | 99 | 50 |




| | |
|----------------------------|---|
| 50 | -20 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the image registration. (Manual adjustment) |
| Item | Picture quality Image position |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment mode (DEN-B/DEN-C) with the scroll key. 2. Enter the adjustment value of the selected point with the 10-key, and press the [OK] key. (The entered adjustment value is set.) 3. Press the [EXECUTE] key, and the registration adjustment pattern in the main scanning direction is printed. |

(Set items)

| Display | Content | Min. value | Max. value | Default | Display |
|---------|---------------|---|------------|---------|---------|
| A | MAIN-REGIST C | Main scanning direction registration adjustment (C) | 12 | 88 | 50 |
| B | SUB-REGIST C | Sub scanning direction registration adjustment (C) | 1 | 132 | 50 |
| C | MAIN-REGIST M | Main scanning direction registration adjustment (M) | 12 | 88 | 50 |
| D | SUB-REGIST M | Sub scanning direction registration adjustment (M) | 1 | 132 | 50 |

| Display | Content | Min. value | Max. value | Default | Display |
|---------|---------------|--|------------|---------|---------|
| E | MAIN-REGIST Y | Main scanning direction registration adjustment (Y) | 12 | 88 | 50 |
| F | SUB-REGIST Y | Sub scanning direction registration adjustment (Y) | 1 | 132 | 50 |
| G | MULTI COUNT | Adjustment pattern print quantity | 1 | 999 | 1 |
| H | PAPER | Paper feed tray selection 8MFT, CS1, CS2, CS3, CS4, LCC) | 1 | 6 | 2 (CS1) |
| I | EXIT TRAY | Paper exit tray selection (R, S) | 1 | 2 | 1 |
| J | DUPLEX | Duplex print selection (NO, YES) | 1 | 2 | 1 |

- * When the adjustment value of items A, C, and E is decreased by 1, the adjustment target color image shifts by one pixel in the main scanning direction.
- * When the adjustment value of items B, D, and E is decreased by 1, the adjustment target color image shifts by one pixel in the sub scanning direction.




| | |
|----------------------------|---|
| 50 | -22 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the image registration. (Automatic adjustment) |
| Item | Picture quality |
| Operation/Procedure | <p>Press the [EXECUTE] key. The color registration adjustment (automatic adjustment) in the main scanning direction and the sub scanning direction is performed. The process of the adjustment is displayed as follows: "NOW EXECUTING... S[*****]E"</p> <p>When the adjustment is completed, the [EXECUTE] key returns to the normal display. In case of an error, the cause is displayed.</p> |

(Display items)

| Display | Content | Min. Value | Max. Value | Default |
|--------------|---|------------|------------|---------|
| CYAN MAIN | Main scanning direction registration adjustment (C) | 12 | 88 | 50 |
| CYAN SUB | Main scanning direction registration adjustment (M) | 1 | 132 | 50 |
| MAGENTA MAIN | Main scanning direction registration adjustment (Y) | 12 | 88 | 50 |
| MAGENTA SUB | Sub scanning direction registration adjustment (C) | 1 | 132 | 50 |
| YELLOW MAIN | Sub scanning direction registration adjustment (M) | 1 | 132 | 50 |
| YELLOW SUB | Sub scanning direction registration adjustment (Y) | 1 | 132 | 50 |

| Error display | Content |
|-------------------------|-------------------------------|
| SENSOR_ADJUSTMENT_ERROR | Sensor adjustment abnormality |
| BLACK_DENSITY_ERROR | Black density error |
| CYAN_DENSITY_ERROR | Cyan density error |
| MAGENTA_DENSITY_ERROR | Magenta density error |

| Error display | Content |
|---------------------------|--|
| YELLOW_DENSITY_ERROR | Yellow density error |
| CYAN_MAIN_FINE_ERROR | Cyan main scanning fine adjustment error |
| MAGENTA_MAIN_FINE_ERROR | Magenta main scanning fine adjustment error |
| YELLOW_MAIN_FINE_ERROR | Yellow main scanning fine adjustment error |
| CYAN_SUB_FINE_ERROR | Cyan sub scanning fine adjustment error |
| MAGENTA_SUB_FINE_ERROR | Magenta sub scanning fine adjustment error |
| YELLOW_SUB_FINE_ERROR | Yellow sub scanning fine adjustment error |
| CYAN_MAIN_ROUGH1_ERROR | Cyan main scanning rough adjustment 1 error |
| MAGENTA_MAIN_ROUGH1_ERROR | Magenta main scanning rough adjustment 1 error |
| YELLOW_MAIN_ROUGH1_ERROR | Yellow main scanning rough adjustment 1 error |
| CYAN_SUB_ROUGH1_ERROR | Cyan sub scanning rough adjustment 1 error |
| MAGENTA_SUB_ROUGH1_ERROR | Magenta sub scanning rough adjustment 1 error |
| YELLOW_SUB_ROUGH1_ERROR | Yellow sub scanning rough adjustment 1 error |
| CYAN_MAIN_ROUGH2_ERROR | Cyan main scanning rough adjustment 2 error |
| MAGENTA_MAIN_ROUGH2_ERROR | Magenta main scanning rough adjustment 2 error |
| YELLOW_MAIN_ROUGH2_ERROR | Yellow main scanning rough adjustment 2 error |
| CYAN_SUB_ROUGH2_ERROR | Cyan sub scanning rough adjustment 2 error |
| MAGENTA_SUB_ROUGH2_ERROR | Magenta sub scanning rough adjustment 2 error |
| YELLOW_SUB_ROUGH2_ERROR | Yellow sub scanning rough adjustment 2 error |
| OTHERS_ERROR | Other errors |



| | |
|-----------------------------|---|
| 50 | -24 |
| Purpose | Adjustment |
| Function (Purpose) | Used to display the adjustment data of automatic registration. |
| Item | Picture quality Image position |
| Operation/ Procedure | <p>When [PARTCH] is selected, the patch scan data in the automatic registration adjustment performed with SIM 50-22 is displayed.</p> <p>When [OTHER] is selected, the sensor calibration data/ belt element data in the automatic registration adjustment performed with SIM 50-22 are displayed.</p> <ol style="list-style-type: none"> 1. Select the color to be set with the color key. (CMY) 2. Select the item to be set with the scroll key. |

(Display items)

| Display | Content | Min. Value | Max. Value |
|-----------|---|------------|------------|
| MAIN FINE | Patch scan data (11 patches) in the main scanning direction fine adjustment | 0 | 9999 |

| Display | Content | Min. Value | Max. Value |
|-----------------|---|------------|------------|
| MAIN ROUGH1 | Patch scan data (4 patches) in the main scanning direction rough adjustment 1 | 0 | 9999 |
| MAIN ROUGH2 | Patch scan data (2 patches) in the main scanning direction rough adjustment 2 | 0 | 9999 |
| RESULT | Current adjustment value | 1 | 132 |
| SUB FINE | Patch scan data (11 patches) in the sub scanning direction fine adjustment | 0 | 9999 |
| SUB ROUGH1 | Patch scan data (4 patches) in the sub scanning direction rough adjustment 1 | 0 | 9999 |
| SUB ROUGH2 | Patch scan data (3 patches) in the sub scanning direction rough adjustment 2 | 0 | 9999 |
| SENSOR OUTPUT | Adjusted LED current in sensor calibration | 0 | 255 |
| SENSOR INPUT | Sensor transfer belt surface detection level in sensor calibration | 0 | 255 |
| ERROR RECODE *1 | Error history (Latest 5 items) | 0 | 99 |
| DENSITY CHECK K | Toner patch density value (K) | 0 | 9999 |
| DENSITY CHECK C | Toner patch density value (C) | 0 | 9999 |
| DENSITY CHECK M | Toner patch density value (M) | 0 | 9999 |
| DENSITY CHECK Y | Toner patch density value (Y) | 0 | 9999 |
| REGIST COUNT | Registration count (Transfer belt mileage: A4 size is counted as 1.) | 0 | 9999 |
| EXECUTE COUNT | Number of execution (Number of execution / Number of execution condition) | 0 | 9999 |

*1: Error code and its content

- 00: No error
- 01: Belt element defect
- 02: Insufficient Black patch density
- 03: Insufficient Cyan patch density
- 04: Insufficient Magenta patch density
- 05: Insufficient Yellow patch density
- 06: Main scanning direction fine adjustment Cyan patch print error
- 07: Main scanning direction fine adjustment Magenta patch print error
- 08: Main scanning direction fine adjustment Yellow patch print error
- 09: Sub scanning direction fine adjustment Cyan patch print error
- 10: Sub scanning direction fine adjustment Magenta patch print error
- 11: Sub scanning direction fine adjustment Yellow patch print error
- 12: Main scanning direction rough adjustment 1 Cyan patch print error
- 13: Main scanning direction rough adjustment 1 Magenta patch print error
- 14: Main scanning direction rough adjustment 1 Yellow patch print error
- 15: Sub scanning direction rough adjustment 1 Cyan patch print error
- 16: Sub scanning direction rough adjustment 1 Magenta patch print error
- 17: Sub scanning direction rough adjustment 1 Yellow patch print error
- 18: Main scanning direction rough adjustment 2 Cyan patch print error
- 19: Main scanning direction rough adjustment 2 Magenta patch print error
- 20: Main scanning direction rough adjustment 2 Yellow patch print error

- 21: Sub scanning direction rough adjustment 2 Cyan patch print error
 22: Sub scanning direction rough adjustment 2 Magenta patch print error
 23: Sub scanning direction rough adjustment 2 Yellow patch print error
 99: Other error

| | |
|----------------------------|--|
| 50 | -27 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust image loss in the FAX/scanner mode. |
| Section | FAX/Scanner |
| Item | Picture quality Image position |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment mode with the scroll key. 2. Enter the adjustment value at the selected point, and press the [OK] key. The entered value is set. |

When the adjustment value is changed, the image losses at the four corners are changed uniformly.

| Display | Content | Min. Value | Max. Value | Default |
|---------|--|------------|------------|---------|
| A | FAX mode image loss | 0 | 99 | 20 |
| B | Scanner mode (all modes except for the copy mode) image loss | 0 | 99 | 40 |

51

| | |
|----------------------------|---|
| 51 | -01 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the transfer voltage ON timing. |
| Section | Process (Photoconductor, developing, transfer, cleaning) Transfer |
| Item | Operation |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment mode with the scroll key. 2. Enter the set value with the 10-key and press the [OK] key to set the entered value. |

| Item | Description on item | Set range | Default |
|------|--|-----------|---------|
| A | NORMAL ON TIMING Used to set the transfer ON timing for the paper lead edge except for OHP. | 1 – 99 | 40 |
| B | NORMAL OFF TIMING Used to set the transfer OFF timing for the paper rear edge except for OHP. | 1 – 99 | 60 |
| C | OHP ON TIMING Used to set the transfer ON timing for the lead edge of OHP. | 1 – 99 | 50 |

| Item | Description on item | Set range | Default |
|------|---|-----------|---------|
| D | OHP OFF TIMING Used to set the transfer OFF timing for the rear edge of OHP. | 1 – 99 | 44 |

- When the set value is 50 at transfer ON timing, the transfer operation is turned on immediately when the paper lead edge passes beneath the drum.
- When the set value is 50 at transfer OFF timing, the transfer operation is turned off immediately when the paper rear edge passes beneath the drum.
- When the transfer ON/OFF timing value is decreased, the transfer ON/OFF timing is advanced for the paper.
- When the transfer ON/OFF timing value is increased, the transfer ON/OFF timing is delayed for the paper.
- Change of ± 1 corresponds to about 10ms. The set range is –490 to +490ms


| | |
|----------------------------|---|
| 51 | -02 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the contact pressure of paper on the resist roller of each section (each paper feed and duplex feed of the copier). (This adjustment is required when the print image position variations are considerably great or when paper jams occur frequently.) |
| Section | Paper transport (Paper exit, switchback, transport) |
| Item | Operation |
| Operation/Procedure | <ol style="list-style-type: none"> 1. Select the adjustment mode with the scroll key. 2. Enter the set value with the 10-key and press the [OK] key to set the entered value. |

(Items to be set)

| Display | Content | Min. value | Max. value | Default | Display |
|---------|------------------------|---|------------|---------|---------|
| A | TRAY | Cassette tray resist adjustment value | 1 | 99 | 25 |
| B | LCC | LCC tray resist adjustment value | 1 | 99 | 35 |
| C | ADU | ADU resist adjustment value | 1 | 99 | 30 |
| D | MANUAL PLAIN PAPER (S) | Manual feed tray resist adjustment value (Normal paper, small size) | 1 | 99 | 50 |
| E | MANUAL HEAVY PAPER1 | Manual feed tray resist adjustment value (Heavy paper 1) | 1 | 99 | 50 |
| F | MANUAL HEAVY PAPER2 | Manual feed tray resist adjustment value (Heavy paper 2) | 1 | 99 | 50 |
| G | MANUAL OHP1 | Manual feed tray resist adjustment value (OHP 1) | 1 | 99 | 50 |
| H | MANUAL OHP2 | Manual feed tray resist adjustment value (OHP 2) | 1 | 99 | 50 |

| Display | Content | Min. value | Max. value | Default | Display |
|---------|-----------------------|---|------------|---------|---------|
| I | MANUAL ENV | Manual feed tray resist adjustment value (Envelope) | 1 | 99 | 50 |
| J | DESK(S) | Desk tray resist adjustment value (Small size) | 1 | 99 | 30 |
| K | DESK(L) | Desk tray resist adjustment value (Large size) | 1 | 99 | 30 |
| L | MANUAL PLAIN PAPER(L) | Manual feed tray resist adjustment value (Normal paper, large size) | 1 | 99 | 50 |
| M | TRAY(L) | Cassette tray deflection adjustment value (Large size) | 1 | 99 | 25 |
| N | ADU(L) | ADU deflection adjustment value (Large size) | 1 | 99 | 30 |

- Used to set the resist roller clutch (RRC) ON timing. When the adjustment value is increased, the timing is delayed and the pressure of paper onto the resist roller is increased.
- When the set value is changed by 1, the timing is changed by about 1.0ms.
- Paper size judgment method
In the cassette tray paper feed, the paper size smaller than 170mm is regarded as the small size.
In the desk tray or ADU paper feed, the paper size of 216mm or smaller is regarded as the small size.
In the manual paper feed tray paper feed, the paper area of 49128mm² (184 x 267) or less is regarded as the small size.



52


| | |
|-----------------------------|---|
| 52 | -01 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the duplex print mode stacking capacity (Used to adjust the stop position of the duplex unit paper tray width alignment plate. The home position of the width alignment plate is changed by software.) |
| Section | Duplex |
| Item | Operation |
| Operation/ Procedure | <ol style="list-style-type: none"> Select the adjustment mode with the scroll key. <ul style="list-style-type: none"> When the machine is not ready for paper feed, "NOT READY" is displayed. When the corresponding tray is unable to feed, "FEED UNABLE" is displayed. If it is able to feed, "FEED ABLE" is displayed. Enter the set value with the 10-key and press the [OK] key to set the entered value. Press the [EXECUTE] key. <ul style="list-style-type: none"> If there is no paper on the duplex tray, one sheet of the selected paper is fed and transported to the duplex tray. Then the entered value in procedure 3 is set and the alignment plate moves according to the home position corresponding to the entered value. |

- The paper sizes which can be used for transport and alignment plate adjustment with SIM52-01 are LT, LTR, A4, A4R, B5, B5R, 16K, and 16KR only. (For the other sizes, "FEED ENABLE" occurs.)

(Set items)

| | Item | Set range | Default |
|---|--|-----------|---------|
| A | Intermediate tray alignment plate adjustment value (Manual feed) | 0 – 99 | 50 |
| B | Intermediate tray alignment plate adjustment value (Cassette 1) | 0 – 99 | 50 |
| C | Intermediate tray alignment plate adjustment value (Cassette 3) | 0 – 99 | 50 |
| D | Intermediate tray alignment plate adjustment value (Cassette 4) | 0 – 99 | 50 |
| E | Intermediate tray alignment plate adjustment value (LCC) | 0 – 99 | 50 |

- When the set value is changed by 1, it is changed by about 0.2mm. When the set value is increased, the alignment plate paper width is narrowed. The adjustment value can be adjusted in the increment of ± 50 with 50 as the center value.




53

| | |
|-----------------------------|--|
| 53 | -01 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the document stop position in each operation mode of the RADF. |
| Section | RADF |
| Item | Operation |
| Operation/ Procedure | <ol style="list-style-type: none"> Select the adjustment mode with the scroll key. Enter the set value with the 10-key and press the [OK] key to set the entered value. <p>This simulation is used to adjust the stop timing of the document transport belt.</p> |

(Items to be set)


| | Item | Set range | Default |
|---|---|-----------|---------|
| A | NORMAL (S) Document stop position adjustment with normal paper in single copy | 1 – 15 | 8 |
| B | NORMAL (D) Document stop position adjustment with normal paper in duplex copy | 1 – 15 | 8 |



| | | |
|-----------------------------|--|--|
| 53 | -02 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the optical sensor sensitivity in RADF. | |
| Section | RADF | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. The sensor names are displayed. Select the sensor to be adjusted with the key. 2. Press the [EXECUTE] key. The adjustment of the sensor selected in procedure 1 is started. During execution of the adjustment, the [EXECUTE] key is highlighted. If the [EXECUTE] key is pressed under this state, the adjustment can be interrupted. <p>* After completion of the adjustment, the COMPLETE display is shown. In case of an abnormality, the INCOMPLETE display is shown.</p> | |


(Set items (sensors))

| Display | Content | Note |
|------------|-----------------------------------|--|
| RESIST | Resist sensor | |
| REVERSE | Reverse sensor | |
| TIMING | Timing sensor | |
| TRAYVOLA4R | Tray A4R (11 x 8.5R) width sensor | After selecting TRAYVOLA4R, set the tray document guide to A4R (11 x 8.5R) position, and press the [EXECUTE] key. |
| TRAYVOLMIN | Tray paper min. width detection | After selecting TARYVOLMIN, set the tray document guide to the minimum width position, and press the [EXECUTE] key. |
| TRAYVOLMAX | Tray paper max. width detection | After selecting TARYVOLMAX, set the tray document guide to the maximum width position, and press the [EXECUTE] key. |
| TRAYVOLB5 | Tray B5 width detection | After selecting TARYVOLB5, set the tray document guide to the A4R (11 x 8.5R) width position, and press the [EXECUTE] key. |



60

| | | |
|-----------------------------|--|--|
| 60 | -01 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to check the operation of ICU PWB image DRAM read/write. | |
| Section | ICU (Memory) | |
| Item | Operation | |
| Operation/ Procedure | <p>Press the [EXECUTE] key, and memory read/write operation check is started.</p> <p>After completion of check, the result is displayed with NG or OK.</p> | |




61

| | | |
|-----------------------------|---|--|
| 61 | -04 | |
| Purpose | Adjustment | |
| Function (Purpose) | Used to adjust the scanner (writing) unit (LED array unit) skew. | |
| Section | Scanner (writing) | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Set the print conditions of the scanner (writing) unit (LED array unit) skew adjustment pattern. 2. Press the [EXECUTE] key. <p>The scanner (writing) unit (LED array unit) skew adjustment pattern is printed.</p> | |

(Items to be set)

| | Display | Content | Min. Value | Max. Value | Default |
|---|-------------|--|------------|------------|---------|
| A | PATTERN | Print pattern specification 1: SKEW--- Used to check scan tilt. 2: FOCUS --- Used to check/adjust focus. | 1 | 2 | 1 |
| B | LINE PITCH | Dot print width (N-1) specification | 1 | 10 | 7 |
| C | POSITION | Pattern output area selection | 1 | 12 | 6 |
| D | MULTI COUNT | Print quantity | 1 | 999 | 1 |
| E | PAPER | Paper feed tray selection (MFT, CS1, CS2, CS3, CS4, LCC) | 1 | 6 | 2 (CS1) |
| F | EXIT TRAY | Paper exit tray selection (R, S) | 1 | 2 | 1 (R) |



63

| | | |
|-----------------------------|--|--|
| 63 | -01 | |
| Purpose | Adjustment/Setting/Operation data output, check (display, print) | |
| Function (Purpose) | Used to check the result of shading correction. (The shading correction data are displayed.) | |
| Section | Scanner (Exposure) | |
| Item | Operation | |
| Operation/ Procedure | <p>Used to display the latest shading correction result.</p> <p>Data for each color can be separately checked with the color keys.</p> <ol style="list-style-type: none"> 1. Select the color to be set with the color keys (CMY). 2. The display page can be shifted with the scroll key. | |

| | |
|-----------------------------|---|
| 63 | -03 |
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the CCD color balance (gamma). |
| Section | Scanner (Image scanning) |
| Item | Picture quality Color balance |
| Operation/ Procedure | Set the SIT chart (UKOG-0280FCZZ) on the document table, and press the [EXECUTE] key. The color coefficient automatic adjustment pattern reading is started to calculate and display the color coefficient data. The color coefficient data of each color can be displayed with the color key. |


| | |
|-----------------------------|--|
| 63 | -05 |
| Purpose | Setting |
| Function (Purpose) | Used to set the CCD color balance (gamma) default. |
| Section | Scanner (Image scanning) |
| Item | Picture quality Color balance |
| Operation/ Procedure | 1. Press the [EXECUTE] key, and the [YES] and [NO] keys become active. 2. When the [YES] key is pressed, the CCD color balance value is set to the default. |

| | |
|-----------------------------|---|
| 63 | -06 |
| Purpose | Adjustment/Operation data output check (display, print) |
| Function (Purpose) | Used to check the color balance (gamma) check patch. |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/ Procedure | 1. Set the color balance check patch printed with SIM 46-21 on the document table. 2. Press the [EXECUTE] key, and the reading is started and the data are displayed on the display. |


| | |
|-----------------------------|--|
| 63 | -07 |
| Purpose | Setting |
| Function (Purpose) | Used to set the target color balance (gamma) for auto color balance adjustment. The standard color balance (gamma) or an optional color balance (gamma) is set as the service target. |
| Section | Image process (ICU) |
| Item | Picture quality Color balance |
| Operation/ Procedure | 1. In the copy color balance adjustment (manual adjustment) (SIM 46-21) mode, the color patch image (adjustment pattern) is outputted. (This must be adjusted properly.) 2. Press the [SETUP] key. 3. Set the color patch image (adjustment pattern) paper printed in the copy color balance adjustment (manual adjustment) (SIM 46-21) mode on the document table. 4. Press the [EXECUTE] key. The color patch image (adjustment pattern) is read. 5. Press the REPEAT key and perform procedure 4 again. 6. Press the [OK] key. The color balance corresponding to the color patch image (adjustment pattern) printed in the copy color balance adjustment (manual adjustment) is set as the service target. |

| | |
|-----------------------------|--|
| 63 | -08 |
| Purpose | Setting |
| Function (Purpose) | Used to set the target color balance (gamma) for auto color balance adjustment (SIM 46-24). The service target is set to the default (standard) color balance (gamma). |
| Section | Scanner (Image scanning) |
| Item | Picture quality Color balance |
| Operation/ Procedure | 1. Press the [EXECUTE] key. 2. Press the [YES] key. The service target is set to the default (standard) color balance (gamma). |

| | | |
|-----------------------------|--|---------------|
| 63 | -09 | |
| Purpose | Setting | |
| Function (Purpose) | Used to adjust the CCD gamma (CCD calibration) (copy document mode). | |
| Section | Scanner (Image scanning) | |
| Item | Picture quality | Color balance |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Set the SIT chart (UKOG-0280FCZZ) on the document table, and make a copy in the manual photo mode. 2. Set the copied SIT chart on the document table. 3. Enter the simulation 63-9 mode. 4. Press the [EXECUTE] key. <p>The color coefficient automatic adjustment pattern reading is started to calculate and display the color coefficient data. The color coefficient data of each color can be displayed with the color key.</p> | |



| | | |
|-----------------------------|--|---------------|
| 63 | -10 | |
| Purpose | Setting | |
| Function (Purpose) | Used to set the copy document mode color balance (gamma) default. | |
| Section | Scanner (Image scanning) | |
| Item | Picture quality | Color balance |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Press the [EXECUTE] key, and the [YES] and [NO] keys become active. 2. When the [YES] key is pressed, the color balance value is set to the default. | |



| | | |
|-----------------------------|---|--|
| 64 | -01 | |
| Purpose | Operation test/check | |
| Function (Purpose) | Used to adjust the operations of the printer section (self-print operation/color). (The print pattern, paper feed mode, print mode, print quantity, and density can be changed optionally.) | |
| Section | Printer | |
| Item | Operation | |
| Operation/ Procedure | <ol style="list-style-type: none"> 1. Select the color to be self-printed with the color keys (CMYK). (Two or more colors can be selected together.) 2. Select the set item with the scroll key. 3. Enter the print conditions with the 10-key, and press the [OK] key to set the entered value. 4. Press the [EXECUTE] Key. The self-print pattern is printed. | |


(Items to be set)

| | Display | Content | Set range | Default |
|---|---------------|--|-----------|---------|
| A | PRINT PATTERN | Print pattern specification (* For details, refer to the following.) | 1 – 23 | 1 |
| B | DENSITY | Print gradation specification | 1 – 255 | 5 |
| C | MULTI COUNT | Print quantity | 1 – 999 | 1 |
| D | EXPOSURE | Exposure mode specification 1: THROUGH --- No process (Through) 2: CHAR/RIC --- Text/Printed photo 3: CHAR/PRPIC --- Text/Photograph 4: CHAR --- Text 5: PRITN PIC --- Printed photo 6: PRINT PAPER --- Photograph 7: MAP --- Map 8: STANDARD DITCH --- No correction, dither | 1 – 8 | 1 |
| E | PAPER | Paper feed tray selection (MFT, CS1, CS2, CS3, CS4, LCC) | 1 – 6 | 2 (CS1) |
| F | EXIT TRAY | Paper exit tray selection (R, S) | 1 – 2 | 1 (R) |
| G | DUPLEX | Duplex print selection (NO, YES) | 1 – 2 | 1 (NO) |
| H | PAPER TYPE | Paper kind selection 1: PLAIN 2: HEAVY 1 3: HEAVY 2 4: OHP 1 5: OHP 2 6: ENVELOPE | 1 – 6 | 1 |

(Print pattern descriptions)

| No. | Content | Pattern generating device | Color selection | | Gradation selection | Density selection |
|-----|---------------------------------------|---------------------------|-------------------|----------|---------------------|-------------------|
| | | | Condition | No color | | |
| 1 | Grid pattern | LED | ○ | K only | Line width | × |
| 2 | Dot print | LED | ○ | K only | ○ | × |
| 3 | 16 gradations: Sub scan | LED | ○ (Max. 3 colors) | K only | × | × |
| 4 | 16 gradations: Main scan | LED | ○ (Max. 3 colors) | K only | × | × |
| 5 | Even pitch pattern (1 by 4): Sub scan | LED | ○ | K only | ○ | × |
| 6 | Even pitch pattern (1 by 4): Sub scan | LED | ○ | K only | ○ | × |
| 7 | Even pitch pattern (2 by 6): Sub scan | LED | ○ | K only | ○ | × |
| 8 | Even pitch pattern (2 by 6): Sub scan | LED | ○ | K only | ○ | × |

| No. | Content | Pattern generating device | Color selection | | Gradation selection | Density selection |
|-----|---|---------------------------|--------------------|----------|----------------------|-------------------|
| | | | Condition | No color | | |
| 9 | Each color 10% (A4/A4R) density print | LED | × (4 colors fixed) | — | Pattern width | × |
| 10 | 8 color band print | LED | × (4 colors fixed) | — | ○ | × |
| 11 | Even pitch pattern (1 by N-1) sub scan direction gradation | LED | ○ (Max. 3 colors) | K only | Interval width (N-1) | × |
| 12 | Grid pattern | Input process | ○ | K only | Grid pattern | ○ |
| 13 | Dot print | Input process | ○ | K only | ○ | ○ |
| 14 | 256 gradations: Sub scan | Input process | ○ (Max. 3 colors) | K only | None | ○ |
| 15 | 256-gradation pattern (Fixed gradation) | Input process | ○ (Max. 3 colors) | K only | None | ○ |
| 16 | 256-gradation pattern (Certain gradation) (Gradation specified from external) | Input process | ○ (Max. 3 colors) | K only | None | ○ |
| 17 | Whole background (half-tone) | Half tone | ○ (Max. 3 colors) | K only | ○ | ○ |
| 18 | 256-gradation pattern (Other dither) | Half tone | ○ (Max. 3 colors) | K only | None | ○ |
| 19 | 256-gradatin pattern (Text dither) | Half tone | ○ (Max. 3 colors) | K only | None | ○ |
| 20 | 2-color background print | LED | ○ | K only | ○ | × |
| 21 | 2-color dot print | LED | ○ | K only | ○ | × |
| 22 | 4-color background print | LED | × (4 colors fixed) | — | ○ | × |
| 23 | 4-color dot print | LED | × (4 colors fixed) | — | ○ | × |



64 -02

Purpose Adjustment/Setting/Operation data output, check (display, print)

Function (Purpose) Used to print the color patch image (adjustment pattern). The above color patch image (adjustment pattern) is outputted according to the currently adjusted color balance (gamma). Use SIM 63-7 to read the color patch image (adjustment pattern), which can be used as the service target of the automatic color balance (gamma) adjustment.

Section Printer

Item Operation


Operation/Procedure

1. Select mode A with the scroll key.
2. Enter the print quantity with the 10-key.
3. Press the [OK] key.
4. Select mode C with the scroll key.
5. Enter the paper kind with the 10-key.
6. Press the [OK] key.
7. Select mode B with the scroll key.
8. Enter (select) the print pattern with the 10-key.
9. Press the [OK] key.
10. Press the [EXECUTE] key. The color patch image (adjustment pattern) is outputted.

Set Item B to "2". Print out is made under half tone correction.

| Display | Content | Min. Value | Max. Value | Default |
|------------|------------------------------------|------------|------------|---------|
| A COPIES | Print quantity | 1 | 999 | 999 |
| B PROC ADJ | Reflection of half tone correction | 1 | 2 | 2 |

| Set value (B: PROC ADJ) | Reflection of half tone correction |
|-------------------------|------------------------------------|
| 1 | NO |
| 2 | YES |



64 -03

Purpose Operation test/check

Function (Purpose) Used to check the operations of the printer section (self-print operation/BW). (The print pattern, the paper feed mode, the print mode, the print quantity, and the density can be set optionally.)

Section Printer

Item Operation

Operation/Procedure

1. Select the set item with the scroll key.
2. Enter the print conditions with the 10-key and press the [OK] key to set the entered value.
3. Press the [EXECUTE] key. The self-print pattern is printed.

(Items to be set)


| Display | Content | Set range | Default |
|-----------------|--|-----------|---------|
| A PRINT PATTERN | Print pattern specification (* For details, refer to the following.) | 1 – 23 | 1 |
| B DENSITY | Print gradation specification | 1 – 255 | 5 |
| C MULTI COUNT | Print quantity | 1 – 999 | 1 |

| Display | Content | Set range | Default |
|---------|--|-----------|---------|
| D | EXPOSURE Exposure mode specification 1: THROUGH --- No process (Through) 2: CHAR/RIC --- Text/Printed photo 3: CHAR/PRPIC --- Text/Photograph 4: CHAR --- Text 5: PRITN PIC --- Printed photo 6: PRINT PAPER --- Photograph 7: MAP --- Map 8: STANDARD DITCH --- No correction, dither | 1 – 8 | 1 |
| E | PAPER Paper feed tray selection (MFT, CS1, CS2, CS3, CS4, LCC) | 1 – 6 | 2 (CS1) |
| F | EXIT TRAY Paper exit tray selection (R, S) | 1 or 2 | 1 (R) |
| G | DUPLEX Duplex print selection (NO, YES) | 1 or 2 | 1 (NO) |
| H | PAPER TYPE Paper kind selection 1: PLAIN 2: HEAVY 1 3: HEAVY 2 4: OHP 1 5: OHP 2 6: ENVELOPE | 1 – 6 | 1 |

• Details of each print pattern in item A

| No. | Content | Pattern generating device | Gradation selection | Density selection |
|-----|---|---------------------------|----------------------|-------------------|
| 1 | Grid pattern | LED | Line width | × |
| 2 | Dot pattern | LED | ○ | × |
| 3 | 16-gradation: sub scan | LED | × | × |
| 4 | 16-gradation: main scan | LED | × | × |
| 5 | Even pitch pattern (1 by 4): sub scan | LED | ○ | × |
| 6 | Even pitch pattern (1 by 4): sub scan | LED | ○ | × |
| 7 | Even pitch pattern (2 by 6): sub scan | LED | ○ | × |
| 8 | Even pitch pattern (2 by 6): sub scan | LED | ○ | × |
| 9 | Each color 10% (A4/A4R) density print | LED | Pattern width | × |
| 10 | 8-color band print | LED | ○ | × |
| 11 | Even pitch pattern (1 by N-1) sub scan direction gradation | LED | Interval width (N-1) | × |
| 12 | Grid pattern | Input process | Line width | ○ |
| 13 | Dot pattern | Input process | ○ | ○ |
| 14 | 256 gradations: sub scan | Input process | None | ○ |
| 15 | 256-gradation pattern (Fixed gradation) | Input process | None | ○ |
| 16 | 256-gradation pattern (Certain gradation) (Gradation specified from external) | Input process | None | ○ |
| 17 | Whole background (half tone) | Half tone | ○ | ○ |
| 18 | 256-gradation pattern (Other dither) | Half tone | None | ○ |
| 19 | 256-gradation pattern (Text dither) | Half tone | None | ○ |
| 20 | Half background print | LED | ○ | × |

| No. | Content | Pattern generating device | Gradation selection | Density selection |
|-----|---------------------------|---------------------------|---------------------|-------------------|
| 21 | Half background dot print | LED | ○ | × |
| 22 | 1/4 background print | LED | ○ | × |
| 23 | 1/4 background dot print | LED | ○ | × |



65

65 -01


| | |
|-----------------------------|--|
| Purpose | Adjustment |
| Function (Purpose) | Used to adjust the touch panel (LCD display section) detection position. |
| Section | Operation (Display, procedure) |
| Operation/ Procedure | 1. Touch the four cross marks. The coordinates at the pressed point are set. |

When the coordinates are properly set, the mark "+" on the display turns to gray. When all the four points are pressed, the display returns to the normal display.




65 -02

| | |
|-----------------------------|--|
| Purpose | Adjustment/Setting/Operation data output, check (display, print) |
| Function (Purpose) | Used to check the result of the touch panel (LCD display) detection position adjustment. (The coordinates are displayed.) |
| Section | Operation (Display, procedure) |
| Operation/ Procedure | When the touch panel is pressed, the AD value in each of X and Y directions at that point and the coordinate values are displayed in () as well as the coordinate values of each point. It is based on the coordinates set with SIM 65-1. |




| | |
|----------------------------|--|
| 67 -01 | |
| Purpose | Operation test/check |
| Function (Purpose) | Used to check the operations of printer DRAM read/write. |
| Section | Printer |
| Item | Operation |
| Operation/Procedure | When the machine enters the simulation mode, the printer DRAM read/write operation check is started. After completion of check, "ERROR" or "MEMORY SIZE" is displayed. If no memory is installed, "NA" is displayed. |



| | |
|----------------------------|--|
| 67 -11 | |
| Purpose | Setting |
| Function (Purpose) | Used to set the printer parallel I/F SELECT IN signal. |
| Section | Printer |
| Item | Operation |
| Operation/Procedure | Enter the set value with the 10-key, and press the [OK] key. When a trouble occurs in communication between PC and the printer by use of the printer parallel I/F, change the setup content of this simulation. |

| Display | Content | Set range | Default |
|--------------------------|--|-----------|---------|
| A SELECT-IN (0:OFF 1:ON) | Centro I/F SELECT IN signal YES/NO setting | 0 - 1 | 1 |




| | |
|----------------------------|--|
| 67 -14 | |
| Purpose | Version up |
| Function (Purpose) | Used to perform version up of the firmware. (Printer) |
| Section | Firmware (Printer) |
| Item | Operation |
| Operation/Procedure | 1. When the machine enters the simulation mode, it enters the printer firmware version up mode at the same time. |

2. Use "fcopy" command on the PC side to download the firmware file. When the firmware data are normally downloaded and written into the Flash ROM, "COMPLETE" is displayed.


In case of an error, the following message is displayed.

- * When the Flash ROM kind is improper:
"ROM KIND ERROR" is displayed.
- * When an error occurs during initializing the Flash ROM:
"FLASH ERROR" is displayed.


- * When an error occurs during verifying:
"UPDATE ERROR" is displayed.



| | |
|----------------------------|--|
| 67 -17 | |
| Purpose | Data clear |
| Function (Purpose) | Used to clear NVRAM. (Printer) |
| Section | Printer |
| Item | Others |
| Operation/Procedure | 1. Press the [EXECUTE] key. The confirmation message to clear is displayed. 2. Select YES/NO to clear the NVRAM. YES: Clear NO: Not clear When the printer NVRAM is normally cleared, "COMPLETE" is displayed. In case of an error, "ERROR" is displayed. |



| | |
|----------------------------|--|
| 67 -18 | |
| Purpose | Data clear |
| Function (Purpose) | Used to clear the Flash data. (Printer) |
| Section | Printer |
| Item | Others |
| Operation/Procedure | 1. Press the [EXECUTE] key. The confirmation message to clear the Flash data is displayed. 2. Select YES/NO to clear the Flash data. YES: Clear NO: Not clear When the printer Flash data are normally cleared, "COMPLETE" is displayed. In case of an error, "ERROR" is displayed. |



[10] MAINTENANCE LIST

1. Maintenance system table

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|--|-----|--|--------------|--|------|------|------|------|------|------|------|---|
| Drum peripheral section | 1 | Drum (B/W, Color) | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Charging unit | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 3 | Cleaner blade | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 4 | Toner reception seal | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 5 | Drum cartridge | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | When replacing the unit |
| Developing section (integrated with toner cartridge) | | Toner cartridge | | Replaced by user when toner empty (or at the specified distance covered) | | | | | | | | |
| Transfer section | 1 | Transfer belt | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Transfer roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 3 | Transfer belt cleaning blade | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 4 | Transfer discharge sheet | | × | ○ | × | ○ | × | ○ | × | ○ | |
| | 5 | Transfer belt cleaning roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Transfer drive roller | | × | × | × | × | × | × | × | × | |
| | 7 | Transfer follower roller | | × | × | × | × | × | × | × | × | |
| | 8 | Transfer cleaning brush | | × | × | × | × | × | × | × | × | |
| | 9 | Sensors | | × | × | × | × | × | × | × | × | |
| | 10 | Waste toner tank unit | ▲ | × | ▲ | × | ▲ | × | ▲ | × | ▲ | When waste toner full is detected. |
| | 11 | Transfer belt unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |
| Fusing section | 1 | Upper heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Lower heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 3 | Heat roller gear | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 4 | Heat roller bearing | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 5 | Separation pawl | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Thermistor | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 7 | Bearings | × | × | × | × | × | × | × | × | × | |
| | 8 | Gears | × | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 9 | Paper guides | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 10 | Paper exit roller | × | × | × | × | × | × | × | × | × | |
| | 11 | Fusing unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |
| Optical section | 1 | CCD, mirror, lens, reflector | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 2 | Table glass, sensors | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 3 | Shading glass | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 4 | Rails | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 5 | Drive wire, pulley, pulley belt | × | × | × | × | × | × | × | × | × | |
| Paper feed section | 1 | Cassette section paper feed rollers | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | Replace according to the counter of each paper feed port or within 2 years. |
| | 2 | Torque limiter | × | | × | | × | | × | | × | |
| | 3 | Manual feed section paper feed rollers | ○ | × | × | × | × | × | × | × | × | Replace according to the counter of each paper feed port or within 2 years. |
| | 4 | Torque limiter | × | × | × | × | × | × | × | × | × | |
| Transport section | 5 | Transport rollers | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 6 | Transport paper guides | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| Image-related sections | | | × | × | × | × | × | × | × | × | × | |
| LED | 1 | LED lens | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| Filters | 1 | Ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Sub ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| Drive section | 3 | Gears | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 4 | Belts | × | × | × | × | × | × | × | × | × | |
| Others | 5 | Sensors | × | | × | | × | | × | | × | |

2. List

A. Drum peripheral section

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace Δ: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|-------------------------|-----|----------------------|--------------|-----|------|------|------|------|------|------|------|-------------------------|
| Drum peripheral section | 1 | Drum (B/W, Color) | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Charging unit | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 3 | Cleaner blade | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 4 | Toner reception seal | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 5 | Drum cartridge | | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | When replacing the unit |



B. Developing section

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace Δ: Adjust ☆: Lubricate □: Shift position





| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|---|-----|-----------------|--------------|---|------|------|------|------|------|------|------|--------|
| Developing section (integrated with toner cartridge) | | Toner cartridge | | Replaced by user when toner empty (or at the specified distance covered) | | | | | | | | |



C. Transfer section

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position





| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|------------------|-----|-------------------------------|--------------|-----|------|------|------|------|------|------|------|---|
| Transfer section | 1 | Transfer belt | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Transfer roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 3 | Transfer belt cleaning blade | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 4 | Transfer discharge sheet | | × | ○ | × | ○ | × | ○ | × | ○ | |
| | 5 | Transfer belt cleaning roller | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Transfer drive roller | | × | × | × | × | × | × | × | × | |
| | 7 | Transfer follower roller | | × | × | × | × | × | × | × | × | |
| | 8 | Transfer cleaning brush | | × | × | × | × | × | × | × | × | |
| | 9 | Sensors | | × | × | × | × | × | × | × | × | |
| | 10 | Waste toner tank unit | ▲ | × | ▲ | × | ▲ | × | ▲ | × | ▲ | When waste toner full is detected. |
| | 11 | Transfer belt unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |



D. Fusing section

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|----------------|-----|---------------------|--------------|-----|------|------|------|------|------|------|------|---|
| Fusing section | 1 | Upper heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 2 | Lower heat roller | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace at 100K or within 2 years. |
| | 3 | Heat roller gear | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 4 | Heat roller bearing | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 5 | Separation pawl | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 6 | Thermistor | × | × | ▲ | × | ▲ | × | ▲ | × | ▲ | |
| | 7 | Bearings | × | × | × | × | × | × | × | × | × | |
| | 8 | Gears | × | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 9 | Paper guides | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 10 | Paper exit roller | × | × | × | × | × | × | × | × | × | |
| | 11 | Fusing unit | | × | ▲ | × | ▲ | × | ▲ | × | ▲ | Replace the unit at 100K or within 2 years. |



E. Optical section (Scanner section)

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|-----------------|-----|---------------------------------|--------------|-----|------|------|------|------|------|------|------|--------|
| Optical section | 1 | CCD, mirror, lens, reflector | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 2 | Table glass, sensors | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 3 | Shading glass | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 4 | Rails | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 5 | Drive wire, pulley, pulley belt | × | × | × | × | × | × | × | × | × | |



F. Paper feed section, transport section

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|--------------------|-----|--|--------------|-----|------|------|------|------|------|------|------|---|
| Paper feed section | 1 | Cassette section paper feed rollers | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | Replace according to the counter of each paper feed port or within 2 years. |
| | 2 | Torque limiter | × | | × | | × | | × | | × | |
| | 3 | Manual feed section paper feed rollers | ○ | × | × | × | × | × | × | × | × | Replace according to the counter of each paper feed port or within 2 years. |
| | 4 | Torque limiter | × | × | × | × | × | × | × | × | × | |
| Transport section | 5 | Transport rollers | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 6 | Transport paper guides | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |



G. LED

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position


| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|-----------|-----|-----------|--------------|-----|------|------|------|------|------|------|------|--------|
| LED | 1 | LED lens | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |



H. Filters, drive section, others

×: Check (Clean, replace, or adjust as necessary.) ○: Clean ▲: Replace △: Adjust ☆: Lubricate □: Shift position

| Unit Name | No. | Part name | When calling | 50K | 100K | 150K | 200K | 250K | 300K | 350K | 400K | Remark |
|---------------|-----|------------------|--------------|-----|------|------|------|------|------|------|------|--------|
| Filters | 1 | Ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| | 2 | Sub ozone filter | × | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | ▲ | |
| Drive section | 3 | Gears | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | ☆ | |
| | 4 | Belts | × | × | × | × | × | × | × | × | × | |
| Others | 5 | Sensors | × | | × | | × | | × | | × | |



[11] TROUBLESHOOTING

1. Outline

In case of a trouble in the machine, or when a consumable part has nearly reached or already reach the lifetime, the machine detects it, analyze it, and displays it on the display section and notifies the user and the serviceman by a voice message.

The user and the serviceman are bale to perform the proper counter-measures according to a voice message. In case of a trouble, the machine is stopped to restrict damage to a minimum in addition to a voice message.

2. Functions and purposes

- 1) Assures safety. (The machine is stopped when a trouble is detected.)
- 2) Restricts damage to a minimum. (The machine is stopped when a trouble is detected.)
- 3) By displaying the trouble content, the trouble position can be identified immediately and accurately. (An accurate repair work can be performed, improving the repair efficiency.)
- 4) By providing a preparatory warning when the lifetime of a consumable part is nearly reached, arrangement of the consumable part can be made in advance. (Stopping the machine by exhaustion of a consumable part is avoidable.)

3. Kinds of self diagnostic messages

The self diagnostic messages are classified as follows:

| | | |
|---------|---------|---|
| Class 1 | User | Troubles and warning messages (paper jam, consumable part life expiration, etc.) which can be processed by the user |
| | Service | Troubles and warning messages (motor trouble, maintenance, etc.) which can be processed only by a serviceman |
| | Other | — |
| Class 2 | Warning | Warning messages (consumable part life expiration, etc.) for the user, which are not directly related to any machine trouble. |
| | Trouble | Related to a machine trouble. The machine is stopped. |
| | Other | — |

4. Self diagnostic operation

A. Self diagnostic operation and work flow

The machine always monitors its own status.

When the machine detects a trouble, it stops operations and displays a trouble message.


A warning message is provided mainly when a consumable part is nearly or completely exhausted.

When a warning message is provided, the machine may be stopped or may not be stopped depending on the message.

The trouble and warning messages are indicated with the LCD and lamps.

Some trouble messages may be automatically cleared after removing the trouble, and some must be cleared with the simulation.

Some warning messages of consumable parts are automatically cleared when the trouble is repaired. Some other warning messages must be cleared by a simulation.



5. List

| Model | Main code | Sub code | Content |
|---------------------|-----------|----------|---|
| AR-C260 AR-C260M | C2 | 10 | Image density sensor error/Transfer charger error (Black) |
| | | | |
| | E7 | 01 | Image data memory trouble |
| | | 10 | Shading trouble (Black correction) |
| | | 11 | Shading trouble (White correction) |
| | | 20 | LED controller initial trouble (Black) |
| | | 21 | LED controller initial trouble (Cyan) |
| | | 22 | LED controller initial trouble (Magenta) |
| | | 23 | LED controller initial trouble (Yellow) |
| | | 24 | LED controller output trouble (Black) |
| | | 25 | LED controller output trouble (Cyan) |
| | | 26 | LED controller output trouble (Magenta) |
| | | 27 | LED controller output trouble (Yellow) |
| | | 28 | LED control ASIC connection abnormality |
| | | 40 | Color correction data writing abnormality |
| | | 41 | Color correction data transfer abnormality |
| | | 80 | ICU-SCN communication trouble (ICU detection) |
| | | 90 | ICU-PCU communication trouble (ICU detection) |
| | F1 | 00 | Finisher communication trouble (PCU detection) |
| | | 02 | Finisher transport motor trouble (Finisher detection) |
| | | 03 | Finisher paddle motor trouble |
| | | 06 | Finisher slide motor trouble |
| | | 10 | Finisher staple motor abnormality (Finisher detection) |
| | | 11 | Finisher bundle process motor abnormality (Finisher detection) |
| | | 15 | Finisher tray lift motor abnormality (Finisher detection) |
| | | 19 | Finisher front alignment motor abnormality (Finisher detection) |
| | | 20 | Finisher rear alignment motor abnormality (Finisher detection) |
| | | 31 | Finisher fold sensor trouble |
| | | 32 | Finisher punch unit communication trouble |
| | | 33 | Finisher punch side registration motor trouble |
| | | 34 | Finisher punch motor trouble |
| | | 35 | Finisher punch side registration sensor trouble |
| | | 36 | Finisher punch registration sensor trouble |
| | | 37 | Finisher/sorter backup RAM trouble |
| | | 38 | Finisher punch backup RAM trouble |
| | | 39 | Finisher punch dust sensor trouble |
| | | 40 | Finisher punch power disconnection trouble |
| | | 83 | Sorter guide bar oscillation motor (M3) lock |
| | | 89 | Sorter bin shift motor lock (M1) |
| | | 91 | Sorter bin paper sensor automatic adjustment trouble |

| Model | Main code | Sub code | Content |
|---------------------|-----------|----------|---|
| AR-C260 AR-C260M | F2 | 15 | Drum unit initial detection trouble (Black) |
| | | 16 | Drum unit initial detection trouble (Cyan) |
| | | 17 | Drum unit initial detection trouble (Magenta) |
| | | 18 | Drum unit initial detection trouble (Yellow) |
| | | 19 | Transfer unit initial detection trouble |
| | | 39 | Process thermistor breakdown |
| | | 40 | Toner empty sensor abnormality (Black) |
| | | 41 | Toner empty sensor abnormality (Cyan) |
| | | 42 | Toner empty sensor abnormality (Magenta) |
| | | 43 | Toner empty sensor abnormality (Yellow) |
| | | 44 | Black image density sensor trouble (Transfer belt surface reflection ratio abnormality) |
| | | 45 | Color image density sensor trouble (Calibration plate surface reflection ratio abnormality) |
| | | 58 | Process humidity sensor breakdown |
| | | 70 | Developing unit improper cartridge detection (Black) |
| | | 71 | Developing unit improper cartridge detection (Cyan) |
| | | 72 | Developing unit improper cartridge detection (Magenta) |
| | | 73 | Developing unit improper cartridge detection (Yellow) |
| | | 74 | Developing unit CRUM trouble (Black) |
| | | 75 | Developing unit CRUM trouble (Cyan) |
| | | 76 | Developing unit CRUM trouble (Magenta) |
| | | 77 | Developing unit CRUM trouble (Yellow) |
| | | 78 | Trouble of image density sensor for registration (Transfer belt surface reflection ratio abnormality) |
| | | 80 | Half-tone process control 1st batch error (Black) |
| | | 81 | Half-tone process control 1st batch error (Cyan) |
| | | 82 | Half-tone process control 1st batch error (Magenta) |
| | | 83 | Half-tone process control 1st batch error (Yellow) |
| | | 84 | Half-tone process control 2nd batch error (Black) |
| | | 85 | Half-tone process control 2nd batch error (Cyan) |
| | | 86 | Half-tone process control 2nd batch error (Magenta) |
| | | 87 | Half-tone process control 2nd batch error (Yellow) |
| | | 90 | Half-tone process control limit error |
| | F3 | 12 | Cassette 1 lift up trouble |
| | F9 | 00 | ICU-PRT communication trouble (ICU detection) |
| | | 01 | PRT DRAM trouble |
| | | 02 | NIC port check error |
| | | 20 | HDD trouble (PRT controller detection) |
| | H2 | 00 | Thermistor open (HL1) |
| | | 01 | Thermistor open (HL2) |
| | H3 | 00 | Fusing section high temperature trouble (HL1) |
| | | 01 | Fusing section high temperature trouble (HL2) |

| Model | Main code | Sub code | Content |
|---------------------|-----------|----------|--|
| AR-C260 AR-C260M | H4 | 00 | Fusing section low temperature trouble (HL1) |
| | | 01 | Fusing section low temperature trouble (HL2) |
| | H5 | 01 | Five continuous detections of POD1 not-reached jam |
| | H8 | 01 | Fusing unit initial detection trouble |
| | L1 | 00 | Mirror feed trouble |
| | L3 | 00 | Mirror return trouble |
| | L4 | 02 | Paper feed motor lock trouble |
| | | 06 | Transfer belt lift motor trouble |
| | | 07 | Transfer belt motor trouble |
| | | 11 | Shift motor trouble |
| | L8 | 01 | Full wave signal not provided |
| | | 02 | Full wave signal width abnormality |
| | | 04 | Main power switch abnormality detection |
| | PF | 00 | RIC copy inhibit signal reception |
| | U0 | 00 | ICU-OPE communication trouble (ICU/OPE detection) |
| | U1 | 02 | RTC read trouble |
| | U2 | 00 | EEPROM read/write error (ICU detection) |
| | | 11 | EEPROM check sum error (ICU detection) |
| | | 30 | Production No. data discrepancy (ICU ⇄ ICU) |
| | | 80 | EEPROM read/write error (SCN detection) |
| | | 81 | EEPROM check sum error (SCN detection) |
| | | 90 | EEPROM read/write error (PCU detection) |
| | | 91 | EEPROM check sum error (PCU detection) |
| | U4 | 02 | ADU alignment plate operation abnormality |
| | U5 | 00 | ADF communication trouble |
| | | 01 | ADF resist sensor defect |
| | | 02 | ADF repulsion sensor defect |
| | | 03 | ADF timing sensor defect |
| | | 11 | Paper feed motor operation abnormality |
| | U6 | 00 | Desk communication trouble |
| | | 01 | Desk tray 1 lift motor trouble |
| | | 02 | Desk tray 2 lift motor trouble |
| | | 03 | Desk tray 3 lift motor trouble |
| | | 10 | Desk transport motor trouble |
| | U7 | 00 | RIC communication trouble |

6. Details

| Main code | Sub code | Title | Image density sensor error/ Transfer charger error (Black) | |
|-----------|----------|------------|---|---|
| C2 | 10 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Black image density sensor trouble /Transfer trouble (Black) /The deference between the transfer belt surface detection level and the black toner patch density detection level is normal. (Judged in black image density sensor calibration) |
| | | | Section | Transfer |
| | | Case 1 | Cause | Black image density sensor trouble |
| | | | Check & Remedy | Black density image sensor cleaning, replacement |
| | | Case 2 | Cause | Transfer voltage trouble |
| | | | Check & Remedy | Check and adjust the transfer voltage. |
| | | Case 3 | Cause | High voltage PWB trouble |
| | | | Check & Remedy | Replace the high voltage PWB. |
| | | Case 4 | Cause | Transfer unit trouble |
| | | | Check & Remedy | Check the transfer belt surface for dirt and scratches. Replace the transfer belt, replace the cleaning blade, replace the transfer unit. |
| | | Case 5 | Cause | PCU PWB trouble |
| | | | Check & Remedy | PCU PWB replacement |
| | | Case 6 | Cause | Photoconductor unit trouble |
| | | | Check & Remedy | Replace the photoconductor unit. |
| | | Case 7 | Cause | Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit |
| | | Case 8 | Cause | Connector, harness trouble (PCU PWB, high voltage PWB, image density sensor, photoconductor unit, transfer unit, developing unit) |
| | | | Check & Remedy | Check contact. Replace the harness. Replace the PWB. |

| Main code | Sub code | Title | Image data memory trouble | |
|-----------|-----------|------------|---------------------------|---|
| E7 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The ICU image data memory (SDRAM) cannot be detected as 256MB or more. The required SDRAM capacity for the model is not provided. |
| | | | Section | ICU PWB |
| | | Case 1 | Cause | The SDRAM of ICU PWB is not installed. The SDRAM of ICU PWB is improperly installed. |
| | | | Check & Remedy | Check installation of the SDRAM of ICU ASIC PWB. |
| | | Case 2 | Cause | The SDRAM of ICU PWB does not operate properly. |
| | | | Check & Remedy | Use SIM 60-01 to check the capacity of the SDRAM. Replace the SDRAM of ICU PWB. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | Shading trouble (Black correction) | |
|-----------|-----------|------------|------------------------------------|--|
| E7 | 10 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CCD black reading level abnormality when the copy lamp is off. |
| | | | Section | CCD unit |
| | | Case 1 | Cause | Improper installation of the flat cable to the CCD unit. |
| | | | Check & Remedy | Check installation of the flat cable to the CCD unit. |
| | | Case 2 | Cause | CCD unit abnormality |
| | | | Check & Remedy | Check the CCD unit. |
| | | Case 3 | Cause | MFP PWB abnormality |
| | | | Check & Remedy | Check the MFP PWB. |

| Main code | Sub code | Title | Shading trouble (White correction) | |
|-----------|-----------|------------|------------------------------------|--|
| E7 | 11 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CCD white reading level abnormality when the copy lamp is off. |
| | | | Section | CCD unit |
| | | Case 1 | Cause | Improper installation of the flat cable to the CCD unit. |
| | | | Check & Remedy | Check installation of the flat cable to the CCD unit. |
| | | Case 2 | Cause | Dirt on the mirror, the lens, or the reference white plate. |
| | | | Check & Remedy | Clean the mirror, the lens, or the reference white plate. |
| | | Case 3 | Cause | CCD unit abnormality |
| | | | Check & Remedy | Check the CCD unit. |
| | | Case 4 | Cause | MFP PWB abnormality |
| | | | Check & Remedy | Check the MFP PWB. |

| Main code | Sub code | Title | LED controller initial trouble (Black) | |
|-----------|-----------|------------|--|---|
| E7 | 20 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The initial process of the LED controller cannot be completed properly. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | LED controller initial trouble (Cyan) | |
|-----------|-----------|------------|---------------------------------------|---|
| E7 | 21 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The initial process of the LED controller cannot be completed properly. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | LED controller initial trouble (Magenta) | |
|-----------|-----------|------------|--|---|
| E7 | 22 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The initial process of the LED controller cannot be completed properly. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED controller initial trouble (Yellow) |
|-----------|----------|------------|----------------|---|
| E7 | 23 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The initial process of the LED controller cannot be completed properly. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED controller output trouble (Magenta) |
|-----------|----------|------------|----------------|---|
| E7 | 26 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When printing, the print end signal for each page is not properly provided. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED controller output trouble (Black) |
|-----------|----------|------------|----------------|---|
| E7 | 24 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When printing, the print end signal for each page is not properly provided. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED controller output trouble (Yellow) |
|-----------|----------|------------|----------------|---|
| E7 | 27 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When printing, the print end signal for each page is not properly provided. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED controller output trouble (Cyan) |
|-----------|----------|------------|----------------|---|
| E7 | 25 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When printing, the print end signal for each page is not properly provided. |
| | | | Section | LED/ICU PWB |
| | | Case 1 | Cause | Disconnection of the LED head connector. |
| | | | Check & Remedy | Check connection of the LED head connector. |
| | | Case 2 | Cause | Disconnection of the harness inside the LED head. |
| | | | Check & Remedy | Replace the LED head unit. |
| | | Case 3 | Cause | ICU PWB abnormality |
| | | | Check & Remedy | Replace the ICU PWB. |

| Main code | Sub code | Title | | LED control ASIC connection abnormality |
|-----------|----------|------------|----------------|---|
| E7 | 28 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Access error between the PCU PWB CPU and the LED control ASIC |
| | | | Section | ICU/PCU PWB |
| | | Case 1 | Cause | Disconnection of the ICU/PCU PWB communication connector |
| | | | Check & Remedy | Check connection of the ICU/PCU PWB communication connector |
| | | Case 2 | Cause | ICU/PCU PWB communication harness trouble. |
| | | | Check & Remedy | Check the ICU/PCU PWB communication harness. |
| | | Case 3 | Cause | ICU PWB/PCU PWB trouble |
| | | | Check & Remedy | Check grounding of the machine. Replace the ICU PWB or the PCU PWB. |

| Main code | Sub code | Title | | Color correction data write error |
|-----------|-----------|------------|----------------|--|
| E7 | 40 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Data write error to the Nand-Flash for holding color correction data |
| | | | Section | MFP PWB |
| | | Case 1 | Cause | Color correction data rewrite error |
| | | | Check & Remedy | Perform rewriting of color correction data again. |
| | | Case 2 | Cause | MFP PWB trouble |
| | | | Check & Remedy | Replace the MFP PWB. |

| Main code | Sub code | Title | | Color correction data transfer abnormality |
|-----------|-----------|------------|----------------|--|
| E7 | 41 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Data transfer error from the Nand-Flash for holding color correction data to the FC-RAM for holding color correction image process |
| | | | Section | MFP PWB |
| | | Case 1 | Cause | MFP PWB trouble |
| | | | Check & Remedy | Replace the MFP PWB. |

| Main code | Sub code | Title | | ICU-SCN communication trouble (ICU detection) |
|-----------|-----------|------------|----------------|--|
| E7 | 80 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication establishment error, framing, parity, protocol error |
| | | | Section | ICU/MFP PWB |
| | | Case 1 | Cause | Disconnection of the ICU/ MFP PWB scanner communication connector. Defective harness of the ICU PWB and the MFP PWB. |
| | | | Check & Remedy | Check connection of the ICU PWB and the MFP PWB. Check the harness. |
| | | Case 2 | Cause | ICU/MFP PWB trouble |
| | | | Check & Remedy | Check grounding of the machine. Replace the ICU PWB or the MFP PWB. |

| Main code | Sub code | Title | | ICU-PCU communication trouble (ICU detection) |
|-----------|-----------|------------|----------------|--|
| E7 | 90 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication establishment error, framing, parity, protocol error |
| | | | Section | ICU/PCU PWB |
| | | Case 1 | Cause | Disconnection of the ICU/ PCU PWB scanner communication connector. Defective harness of the ICU PWB and the PCU PWB. |
| | | | Check & Remedy | Check connection of the ICU PWB and the PCU PWB. Check the harness. |
| | | Case 2 | Cause | ICU/PCU PWB trouble |
| | | | Check & Remedy | Check grounding of the machine. Replace the ICU PWB or the PCU PWB. |

| Main code | Sub code | Title | | Finisher communication trouble (Machine detection) |
|-----------|-----------|------------|----------------|---|
| F1 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication line test error when turning on the power or after canceling the exclusive simulation. Communication error with the finisher. |
| | | | Section | PCU PWB and finisher |
| | | Case 1 | Cause | Disconnection of the PCU-finisher connector, defective contact or disconnection of the harness. |
| | | | Check & Remedy | Check the connector and the harness of the communication line. |
| | | Case 2 | Cause | Finisher control PWB trouble |
| | | | Check & Remedy | Replace the finisher control PWB. |
| | | Case 3 | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |
| | | Case 4 | Cause | Malfunctions by noises |
| | | | Check & Remedy | — |
| | | Common | Cancel method | Can be canceled by turning OFF/ON the power. |

| Main code | Sub code | Title | | Finisher transport motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|---|
| F1 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Transport motor drive trouble |
| | | | Section | Transport |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the transport motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher paddle motor trouble |
|-----------|-----------|------------|----------------|---|
| F1 | 03 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Paddle motor operation trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher slide motor trouble |
|-----------|-----------|------------|----------------|---|
| F1 | 06 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Slide motor operation trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher staple motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|--|
| F1 | 10 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Stapling operation trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher bundle process motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|--|
| F1 | 11 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Bundle process motor trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher tray lift motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|---|
| F1 | 15 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Lift motor trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher front alignment motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|---|
| F1 | 19 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Front alignment motor trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | | Finisher rear alignment motor trouble (Finisher detection) |
|-----------|-----------|------------|----------------|--|
| F1 | 20 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Rear alignment motor trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | | Case 2 | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 4 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher fold sensor trouble | |
|-----------|-----------|------------|------------------------------|--|
| F1 | 31 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Sensor input value abnormality |
| | | | Section | Finisher |
| | Case 1 | | Cause | Sensor breakage |
| | | | Check & Remedy | Use SIM 3-2 to check the sensor operation. |
| | Case 2 | | Cause | Harness disconnection |
| | | | Check & Remedy | Same as case 1. |
| | Case 3 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher punch unit communication trouble | |
|-----------|-----------|---------------|--|---|
| F1 | 32 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication error between the console finisher and the punch unit |
| | | | Section | Finisher |
| | Case 1 | | Cause | Improper connection or disconnection of the connector and the harness of the console finisher and the punch unit. |
| | | | Check & Remedy | Check the connector and the harness of the communication line. |
| | Case 2 | | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |
| | Case 3 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Replace the console finisher control PWB. |
| | Case 4 | | Cause | Malfunction by noises |
| | | | Check & Remedy | |
| | Common | Cancel method | Can be canceled by turning OFF/ON the power. | |

| Main code | Sub code | Title | Finisher punch side registration motor trouble | |
|-----------|-----------|------------|--|--|
| F1 | 33 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Punch side registration motor operation trouble |
| | | | Section | Finisher |
| | Case 1 | | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | Case 2 | | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | Case 3 | | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | Case 4 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher punch motor trouble | |
|-----------|-----------|------------|------------------------------|--|
| F1 | 34 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Punch motor operation trouble |
| | | | Section | Finisher |
| | Case 1 | | Cause | Motor lock |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |
| | Case 2 | | Cause | Motor RPM abnormality |
| | | | Check & Remedy | Same as Case 1. |
| | Case 3 | | Cause | Over current to the motor |
| | | | Check & Remedy | Same as Case 1. |
| | Case 4 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher punch side registration sensor trouble | |
|-----------|-----------|------------|---|--|
| F1 | 35 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Sensor input value abnormality |
| | | | Section | Finisher |
| | Case 1 | | Cause | Sensor breakage |
| | | | Check & Remedy | Use SIM 3-2 to check the sensor operation. |
| | Case 2 | | Cause | Harness disconnection |
| | | | Check & Remedy | Same as case 1. |
| | Case 3 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher punch registration sensor trouble | |
|-----------|-----------|------------|--|--|
| F1 | 36 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Sensor input value abnormality |
| | | | Section | Finisher |
| | Case 1 | | Cause | Sensor breakage |
| | | | Check & Remedy | Use SIM 3-2 to check the sensor operation. |
| | Case 2 | | Cause | Harness disconnection |
| | | | Check & Remedy | Same as case 1. |
| | Case 3 | | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher/sorter backup RAM trouble | |
|-----------|-----------|----------------|------------------------------------|--|
| F1 | 37 | Display | Lamp/Message | |
| | | Phenomenon | Detail | <ul style="list-style-type: none"> Abnormal transformation of backup RAM contents Writing to the backup RAM is started but is not completed in 250msec. When writing to the backup RAM, if the write data do not coincide with the read data, writing is performed again. After writing again, the write data still do not coincide with the read data. Backup RAM trouble Sorter control PWB trouble |
| | | | Section | Finisher/sorter |
| | | Case 1 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Replace the console finisher control PWB. |
| | | Case 2 | Cause | Malfunction caused by noises |
| | | | Check & Remedy | |
| | | Case 3 | Cause | Sorter control PWB trouble |
| | | | Check & Remedy | Turn OFF/ON the machine power, and check that the trouble is canceled or not. Replace the sorter controller PWB, and execute the bin paper sensor sensitivity adjustment and the guide bar motor oscillation range adjustment. (For the adjustment procedures, refer to pages 5-1 and 5-2 (AR-S11 S/M).) |

| Main code | Sub code | Title | Finisher punch backup RAM trouble | |
|-----------|-----------|----------------|-----------------------------------|---|
| F1 | 38 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Abnormal transformation of punch unit backup RAM contents |
| | | | Section | Finisher |
| | | Case 1 | Cause | Punch control PWB trouble |
| | | | Check & Remedy | Replace the punch control PWB. |
| | | Case 2 | Cause | Malfunction caused by noises |
| | | | Check & Remedy | |

| Main code | Sub code | Title | Finisher punch dust sensor trouble | |
|-----------|-----------|----------------|------------------------------------|--|
| F1 | 39 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Punch dust sensor detection trouble |
| | | | Section | Finisher |
| | | Case 1 | Cause | Sensor breakage |
| | | | Check & Remedy | Use SIM 3-2 to check the sensor operation. |
| | | Case 2 | Cause | Harness disconnection |
| | | | Check & Remedy | Same as Case 1. |
| | | Case 3 | Cause | Console finisher control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Finisher punch power disconnection trouble | |
|-----------|-----------|----------------|--|--|
| F1 | 40 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The power disconnection of the punch unit is detected. |
| | | | Section | Finisher |
| | | Case 1 | Cause | Harness disconnection |
| | | | Check & Remedy | Use SIM 3-3 to check the punching operation. |
| | | Case 2 | Cause | Punch control PWB trouble |
| | | | Check & Remedy | Same as Case 1. |

| Main code | Sub code | Title | Sorter guide bar oscillation motor (M3) lock | |
|-----------|-----------|----------------|--|---|
| F1 | 83 | Display | Lamp/Message | |
| | | Phenomenon | Detail | <ul style="list-style-type: none"> When returning to the home position, the operation is not completed in 2sec. When moving from the home position, the home position sensor keeps ON after 20-pulse operation. Guide bar drive motor trouble Guide bar home position sensor trouble Guide bar mechanism section trouble Circuit breaker operates. Sorter control PWB trouble Check the guide bar drive motors and sensors with SIM 3-2, 3. |
| | | | Section | Sorter |
| | | Case 1 | Cause | Guide bar home position sensor (PI3) trouble |
| | | | Check & Remedy | Check the guide bar home position sensor. Is it normal? Replace the sensor. |

| Main code | Sub code | Title | Sorter guide bar oscillation motor (M3) lock | |
|-----------|----------|--------|--|--|
| F1 | 83 | Case 2 | Cause | Cable trouble |
| | | | Check & Remedy | Check connection of the cable between the guide bar oscillation motor and the sorter controller PWB. Is it proper? Connect properly. |
| | | Case 3 | Cause | Circuit breaker trouble |
| | | | Check & Remedy | Check that the circuit breaker (CB1) on the sorter controller PWB. Did it operate? Remove the cause that operated the circuit breaker, and push the circuit breaker. |
| | | Case 4 | Cause | Guide bar trouble |
| | | | Check & Remedy | Check for any mechanical obstruction on the moving path of the guide bar. Is there any obstruction? Repair the mechanism. |
| | | Case 5 | Cause | Sorter control PWB trouble |
| | | | Check & Remedy | Replace the guide bar oscillation motor (M3) and check that the trouble is canceled or not. Replace the sorter controller PWB, and execute the bin paper sensor sensitivity adjustment and the guide bar motor oscillation range adjustment. (For the adjustment procedures, refer to pages 5-1 and 5-2 (AR-S11 S/M).) |

| Main code | Sub code | Title | Sorter bin shift motor lock (M1) | |
|-----------|----------|------------|----------------------------------|--|
| F1 | 89 | Display | Lamp/Message | |
| | | Phenomenon | Detail | <ul style="list-style-type: none"> The operation is not completed in the time which is 4 times greater than the specified time after starting the bin shift motor. When driving the bin shift motor, the signal from the shift motor lock sensor is not detected for 250msec. When shifting to the home position, the operation is not completed in 30 sec. Bin shift motor trouble Lead cam position sensor trouble Bin shift mechanism trouble Circuit breaker operation Sorter control PWB trouble Check the operation of the bin shift motor and the sensor with SIM 3-3. |
| | | | Section | Sorter |

| Main code | Sub code | Title | Sorter bin shift motor lock (M1) | |
|-----------|----------|--------|----------------------------------|--|
| F1 | 89 | Case 1 | Cause | Cable trouble |
| | | | Check & Remedy | Check that the cable between the bin shift motor and the sorter controller PWB is properly connected. Connect properly. |
| | | Case 2 | Cause | Circuit breaker trouble |
| | | | Check & Remedy | Check that the circuit breaker (CB1) on the sorter controller PWB is operating. Remove the cause of the circuit breaker operation, and press the circuit breaker. |
| | | Case 3 | Cause | Bin shift motor (M1) trouble |
| | | | Check & Remedy | Check that the voltage between the connector J8-1 and J8-2 on the bin shift motor driver PWB is about 24V at the operating timing of the bin shift motor (M1). Check the wiring to the bin shift motor. If it is normal, replace the bin shift motor. Replace the sorter controller PWB, and perform the bin paper sensor sensitivity adjustment and the guide bar motor oscillation range adjustment. (For the procedures, refer to pages 5-1 to 5-2 (AR-S11 S/M).) |

| Main code | Sub code | Title | Sorter bin paper sensor automatic adjustment trouble | |
|-----------|----------|------------|--|---|
| F1 | 91 | Display | Lamp/Message | |
| | | Phenomenon | Detail | <ul style="list-style-type: none"> The sensor output abnormality in the sensor detection level adjustment Bin paper sensor trouble Sorter control PWB trouble Check the sensor output with SIM 3-2. |
| | | | Section | Sorter |
| | | Case 1 | Cause | Cable trouble |
| | | | Check & Remedy | Check that the cable between the sorter controller PWB and the bin unit is properly connected. Connect properly. |
| | | Case 2 | Cause | Cable trouble |
| | | | Check & Remedy | Check that the cable between the bin paper sensor light emitting side (S1) and the light receiving side (S2) is properly connected. Connect properly. |

| Main code | Sub code | Title | Sorter bin paper sensor automatic adjustment trouble | |
|-----------|-----------|---------------|--|---|
| F1 | 91 | Case 3 | Cause | Installation of bin paper sensor light emitting side (S1) and light receiving side (S2) trouble |
| | | | Check & Remedy | Check that the bin paper sensor light emitting side (S1) and the light receiving side (S2) are properly installed. Connect properly. When the bin paper sensor light emitting side (S1) and the light receiving side (S2) are installed again, perform the bin paper sensor sensitivity adjustment. (For the procedure, refer to page 5-1 (AR-S11 S/M).) |
| | | Case 4 | Cause | Bin paper sensor light emitting side (S1) and light receiving side (S2) trouble Sorter controller PWB trouble |
| | | | Check & Remedy | When the bin paper sensor light emitting side (S1) and the light receiving side (S2) are replaced and the bin paper sensor sensitivity adjustment is performed, the trouble is canceled. Replace the bin paper sensor light emitting side (S1) and the light receiving side (S2) and perform the bin paper sensor sensitivity adjustment. (For the procedure, refer to page 5-1 (AR-S11 S/M).) Replace the sorter controller PWB, and perform the bin paper sensor sensitivity adjustment and the guide bar motor oscillation range adjustment. (For the procedures, refer to pages 5-1 to 5-2 (AR-S11 S/M).) |

| Main code | Sub code | Title | Drum cartridge initial detection trouble (Black) | |
|-----------|-----------|----------------|--|---|
| F2 | 15 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Drum cartridge initial detection trouble |
| | | | Section | Drum cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the drum cartridge initial sensor. → Connect it properly. 2. Check connection of the connector harness and the PCU PWB. → Connect it properly. 3. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Drum cartridge initial detection trouble (Cyan) | |
|-----------|-----------|----------------|---|---|
| F2 | 16 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Drum cartridge initial detection trouble |
| | | | Section | Drum cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the drum cartridge initial sensor. → Connect it properly. 2. Check connection of the connector harness and the PCU PWB. → Connect it properly. 3. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Drum cartridge initial detection trouble (Magenta) | |
|-----------|-----------|----------------|--|---|
| F2 | 17 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Drum cartridge initial detection trouble |
| | | | Section | Drum cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the drum cartridge initial sensor. → Connect it properly. 2. Check connection of the connector harness and the PCU PWB. → Connect it properly. 3. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Drum cartridge initial detection trouble (Yellow) | |
|-----------|-----------|----------------|---|---|
| F2 | 18 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Drum cartridge initial detection trouble |
| | | | Section | Drum cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the drum cartridge initial sensor. → Connect it properly. 2. Check connection of the connector harness and the PCU PWB. → Connect it properly. 3. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Transfer unit initial detection trouble | |
|-----------|-----------|------------|---|---|
| F2 | 19 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Transfer unit initial detection trouble |
| | | | Section | Transfer unit |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | Check connection of the transfer unit initial sensor. Check connection of the connector and the harness of the PCU PWB. Check for disconnection of the harness. |
| | | Case 2 | Cause | Unit trouble |
| | | | Check & Remedy | Replace the unit. |

| Main code | Sub code | Title | Process thermistor breakdown | |
|-----------|-----------|------------|------------------------------|--|
| F2 | 39 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Process thermistor open |
| | | | Section | Drum cartridge |
| | | Case 1 | Cause | Process thermistor trouble |
| | | | Check & Remedy | Replace the process thermistor. |
| | | Case 2 | Cause | Disconnection of the process thermistor harness. |
| | | | Check & Remedy | Check connection of the connector and the harness of the process thermistor. |
| | | Case 3 | Cause | PCU PWB trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Toner empty sensor abnormality (Black) | |
|-----------|-----------|------------|--|---|
| F2 | 40 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Toner empty sensor output abnormality |
| | | | Section | Cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the toner empty sensor. → Connect it properly. 2. Check connection of the connector harness to the PCU PWB. → Connect it properly. 3. Check connection of the cartridge. → Connect it properly. 4. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Toner empty sensor abnormality (Cyan) | |
|-----------|-----------|------------|---------------------------------------|---|
| F2 | 41 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Toner empty sensor output abnormality |
| | | | Section | Cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the toner empty sensor. → Connect it properly. 2. Check connection of the connector harness to the PCU PWB. → Connect it properly. 3. Check connection of the cartridge. → Connect it properly. 4. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Toner empty sensor abnormality (Magenta) | |
|-----------|-----------|------------|--|---|
| F2 | 42 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Toner empty sensor output abnormality |
| | | | Section | Cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the toner empty sensor. → Connect it properly. 2. Check connection of the connector harness to the PCU PWB. → Connect it properly. 3. Check connection of the cartridge. → Connect it properly. 4. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Toner empty sensor abnormality (Yellow) | |
|-----------|-----------|------------|---|---|
| F2 | 43 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Toner empty sensor output abnormality |
| | | | Section | Cartridge |
| | | Case 1 | Cause | Connector harness trouble, connector disconnection |
| | | | Check & Remedy | 1. Check connection of the toner empty sensor. → Connect it properly. 2. Check connection of the connector harness to the PCU PWB. → Connect it properly. 3. Check connection of the cartridge. → Connect it properly. 4. Check for disconnection of the harness. → Replace the harness. |
| | | Case 2 | Cause | Cartridge trouble |
| | | | Check & Remedy | Replace the cartridge. |

| Main code | Sub code | Title | Black image density sensor trouble (Transfer belt surface reflection ratio abnormality) | |
|-----------|-----------|------------|---|---|
| F2 | 44 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Before starting process control, the transfer belt surface is scanned with the image density sensor to adjust the sensor gain so that the output becomes a fixed value. However, when the sensor gain is changed, the output is not within the specified range. |
| | | | Section | |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in SIM 44-2: 1. Dirt/defect of the image density sensor 2. Disconnection of the harness between the PCU PWB and the image density sensor 3. Calibration plate solenoid operation trouble |
| | | | Check & Remedy | 1. Clean/replace the image density sensor. 2. Connect/replace the harness between the PCU PWB and the image density sensor. 3. Replace the calibration plate solenoid. |
| | | Case 2 | Cause | When SIM 44-2 is completed: 1. Insufficient cleaning of the transfer belt. |
| | | | Check & Remedy | 1. Check the transfer belt surface. |

| Main code | Sub code | Title | Color image density sensor trouble (Calibration plate surface reflection ratio abnormality) | |
|-----------|-----------|------------|---|---|
| F2 | 45 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Before starting process control, the calibration plate surface is scanned with the image density sensor to adjust the sensor gain so that the output becomes a fixed value. However, when the sensor gain is changed, the output is not within the specified range. |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in SIM 44-2: 1. Dirt/defect of the image density sensor 2. Disconnection of the harness between the PCU PWB and the image density sensor |
| | | | Check & Remedy | 1. Clean/replace the image density sensor. 2. Connect/replace the harness between the PCU PWB and the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 is completed: 1. Dirt on the calibration plate, calibration plate solenoid operation trouble |
| | | | Check & Remedy | 1. Clean the calibration plate. Replace the calibration plate solenoid. |

| Main code | Sub code | Title | Process humidity sensor breakdown | |
|-----------|-----------|------------|-----------------------------------|--|
| F2 | 58 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Process humidity sensor open |
| | | | Section | Process |
| | | Case 1 | Cause | Process humidity sensor harness disconnection |
| | | | Check & Remedy | Check connection of the process humidity sensor harness. |
| | | Case 2 | Cause | Process humidity sensor trouble |
| | | | Check & Remedy | Replace the process humidity sensor. |
| | | Case 3 | Cause | PCU PWB trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Developing unit improper cartridge detection (Black) | |
|-----------|----------|------------|--|---|
| F2 | 70 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When detecting the normal CRUM of the cartridge, improper data are detected in the CRUM contents. |
| | | | Section | Developing |
| | | Case 1 | Cause | Insertion of an improper cartridge. Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |

| Main code | Sub code | Title | Developing unit improper cartridge detection (Cyan) | |
|-----------|----------|------------|---|---|
| F2 | 71 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When detecting the normal CRUM of the cartridge, improper data are detected in the CRUM contents. |
| | | | Section | Developing |
| | | Case 1 | Cause | Insertion of an improper cartridge. Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |

| Main code | Sub code | Title | Developing unit improper cartridge detection (Magenta) | |
|-----------|----------|------------|--|---|
| F2 | 72 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When detecting the normal CRUM of the cartridge, improper data are detected in the CRUM contents. |
| | | | Section | Developing |
| | | Case 1 | Cause | Insertion of an improper cartridge. Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |

| Main code | Sub code | Title | Developing unit improper cartridge detection (Yellow) | |
|-----------|----------|------------|---|---|
| F2 | 73 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When detecting the normal CRUM of the cartridge, improper data are detected in the CRUM contents. |
| | | | Section | Developing |
| | | Case 1 | Cause | Insertion of an improper cartridge. Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |

| Main code | Sub code | Title | Developing unit CRUM trouble (Black) | |
|-----------|----------|------------|--------------------------------------|---|
| F2 | 74 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CRUM read/write error |
| | | | Section | Developing |
| | | Case 1 | Cause | Improper connection or disconnection of the connector and the harness between the PCU and the CRUM. |
| | | | Check & Remedy | Check the connector and the harness between the PCU and the CRUM. |
| | | Case 2 | Cause | Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |
| | | Case 3 | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Developing unit CRUM trouble (Cyan) | |
|-----------|----------|------------|-------------------------------------|---|
| F2 | 75 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CRUM read/write error |
| | | | Section | Developing |
| | | Case 1 | Cause | Improper connection or disconnection of the connector and the harness between the PCU and the CRUM. |
| | | | Check & Remedy | Check the connector and the harness between the PCU and the CRUM. |
| | | Case 2 | Cause | Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |
| | | Case 3 | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Developing unit CRUM trouble (Magenta) | |
|-----------|----------|------------|--|---|
| F2 | 76 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CRUM read/write error |
| | | | Section | Developing |
| | | Case 1 | Cause | Improper connection or disconnection of the connector and the harness between the PCU and the CRUM. |
| | | | Check & Remedy | Check the connector and the harness between the PCU and the CRUM. |
| | | Case 2 | Cause | Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |
| | | Case 3 | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Developing unit CRUM trouble (Yellow) | |
|-----------|-----------|------------|---------------------------------------|---|
| F2 | 77 | Display | Lamp/Message | |
| | | Phenomenon | Detail | CRUM read/write error |
| | | | Section | Developing |
| | | Case 1 | Cause | Improper connection or disconnection of the connector and the harness between the PCU and the CRUM. |
| | | | Check & Remedy | Check the connector and the harness between the PCU and the CRUM. |
| | | Case 2 | Cause | Developing unit trouble |
| | | | Check & Remedy | Replace the developing unit. |
| | | Case 3 | Cause | Control PWB (PCU) trouble |
| | | | Check & Remedy | Replace the PCU PWB. |

| Main code | Sub code | Title | Trouble of image density sensor for registration (Transfer belt surface reflection ratio abnormality) | |
|-----------|-----------|------------|---|---|
| F2 | 78 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Before starting registration, the transfer belt surface is scanned with the image density sensor to adjust the sensor gain so that the output becomes a fixed value. However, when the sensor gain is changed, the value is not within the specified range. |
| | | | Section | — |
| | | Case 1 | Cause | Image density sensor trouble, disconnection of the harness between the PCU PWB and the image density sensor, dirt on the image density sensor. |
| | | | Check & Remedy | Check the sensor and the harness. |
| | | Case 2 | Cause | Calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the calibration plate solenoid operation. |
| | | Case 3 | Cause | Insufficient cleaning of the transfer belt. |
| | | | Check & Remedy | Check the transfer belt surface. |

| Main code | Sub code | Title | Half-tone process control 1st batch trouble (Black) | |
|-----------|-----------|------------|---|--|
| F2 | 80 | Display | Lamp/Message | |
| | | Phenomenon | Detail | First step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 1st batch trouble (Cyan) | |
|-----------|-----------|------------|--|--|
| F2 | 81 | Display | Lamp/Message | |
| | | Phenomenon | Detail | First step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 1st batch trouble (Magenta) | |
|-----------|-----------|----------------|---|--|
| F2 | 82 | Display | Lamp/Message | |
| | | Phenomenon | Detail | First step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 2nd batch trouble (Black) | |
|-----------|-----------|----------------|---|--|
| F2 | 84 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Second step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 1st batch trouble (Yellow) | |
|-----------|-----------|----------------|--|--|
| F2 | 83 | Display | Lamp/Message | |
| | | Phenomenon | Detail | First step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 2nd batch trouble (Cyan) | |
|-----------|-----------|----------------|--|--|
| F2 | 85 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Second step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 2nd batch trouble (Magenta) | |
|-----------|-----------|------------|---|--|
| F2 | 86 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Second step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process control 2nd batch trouble (Yellow) | |
|-----------|-----------|------------|--|--|
| F2 | 87 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Second step operation error during half-tone process control |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Half-tone process limit error | |
|-----------|-----------|------------|-------------------------------|---|
| F2 | 90 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The difference between the correction value after execution of half-tone process control and the previous correction value exceeds the specified max. value of each color. <The error is recorded in the trouble history, but F2 trouble is not indicated on the display and the previous correction value is remained.> |
| | | | Section | — |
| | | Common | Check | Use SIM 44-2 to adjust the process control sensor gain. |
| | | Case 1 | Cause | When "Error" occurs in the gain adjustment of SIM 44-2: 1. Disconnection of the harness between the PCU PWB and the image density sensor. 2. Image density sensor dirt/trouble |
| | | | Check & Remedy | 1. Check connection of the harness between the PCU PWB and the image density sensor. 2. Clean/replace the image density sensor. |
| | | Case 2 | Cause | When SIM 44-2 gain adjustment is completed: Insufficient cleaning of the transfer belt, calibration plate solenoid operation trouble |
| | | | Check & Remedy | Check the drum surface and the belt surface. |

| Main code | Sub code | Title | Cassette 1 lift-up trouble | |
|-----------|-----------|------------|----------------------------|---|
| F3 | 12 | Display | Lamp/Message | |
| | | Phenomenon | Detail | LUD1 does not turn on within the specified time. |
| | | | Section | — |
| | | Case 1 | Cause | LUD1 sensor trouble, disconnection of harness among the PCU PWB, the lift-up unit, and the paper feed unit. |
| | | | Check & Remedy | Check LUD1, its harness, and the connector. |
| | | Case 2 | Cause | Cassette 1 lift-up motor trouble |
| | | | Check & Remedy | Check the lift-up unit. |

| Main code | Sub code | Title | | ICU-PRT communication trouble (ICU detection) |
|-----------|-----------|------------|----------------|--|
| F9 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication establishment error, framing, parity, protocol error |
| | | | Section | — |
| | | Case 1 | Cause | Defective connection of the ICU/PRT PWB communication connector, defective harness between the ICU PWB and the PRT PWB, defective ICU PWB/ PRT PWB |
| | | | Check & Remedy | Check connection and the harness between the ICU PWB and the MFP PWB. Check the machine earth. Replace the ICU or the PRT PWB. |

| Main code | Sub code | Title | | PRT DRAM trouble |
|-----------|-----------|------------|----------------|--|
| F9 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | DRAM in the PRT PWB cannot be accessed. |
| | | | Section | — |
| | | Case 1 | Cause | Defective DRAM, defective installation of the DRAM |
| | | | Check & Remedy | Replace the DRAM. Check connection of the DRAM. |

| Main code | Sub code | Title | | NIC port check error |
|-----------|-----------|------------|----------------|---|
| F9 | 03 | Display | Lamp/Message | |
| | | Phenomenon | Detail | NIC port check error |
| | | | Section | — |
| | | Case 1 | Cause | Defective connection of the NIC connector, defective NIC PWB, defective PRT PWB |
| | | | Check & Remedy | Check the NIC connector again. Replace the HDD. Replace the PRT PWB. |

| Main code | Sub code | Title | | HDD trouble (PRT controller detection) |
|-----------|-----------|------------|----------------|---|
| F9 | 20 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The HDD (option) does not operate normally in the machine with the HDD. |
| | | | Section | — |
| | | Case 1 | Cause | Defective connection of the HDD connector, defective HDD, defective PRT PWB |
| | | | Check & Remedy | Check the HDD again. Replace the HDD. Replace the PRT PWB. |

| Main code | Sub code | Title | | Thermistor open (HL1) |
|-----------|-----------|------------|----------------|---|
| H2 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Thermistor open |
| | | | Section | Fusing |
| | | Case 1 | Cause | Disconnection of the fusing section connector |
| | | | Check & Remedy | Check the connector and the harness between the thermistor and the control PWB. |
| | | Case 2 | Cause | The fusing unit is not installed. |
| | | | Check & Remedy | Install the fusing unit. |
| | | Case 3 | Cause | Thermistor trouble, control PWB trouble, AC power supply trouble |
| | | | Check & Remedy | Replace the thermistor or the control PWB. Check the AC power supply. |

| Main code | Sub code | Title | | Thermistor open (HL2) |
|-----------|-----------|------------|----------------|---|
| H2 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Thermistor open |
| | | | Section | Fusing |
| | | Case 1 | Cause | Disconnection of the fusing section connector |
| | | | Check & Remedy | Check the connector and the harness between the thermistor and the control PWB. |
| | | Case 2 | Cause | The fusing unit is not installed. |
| | | | Check & Remedy | Install the fusing unit. |
| | | Case 3 | Cause | Thermistor trouble, control PWB trouble, AC power supply trouble |
| | | | Check & Remedy | Replace the thermistor or the control PWB. Check the AC power supply. |

| Main code | Sub code | Title | | Fusing section high temperature trouble (THS1) |
|-----------|-----------|------------|----------------|--|
| H3 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The fusing temperature exceeds 230°C. |
| | | | Section | Fusing |
| | | Common | Check | Use SIM 5-2 to check the heater lamp flashing operation. |
| | | | Cause | The heater lamp flashes properly with SIM 5-2. Thermistor trouble, disconnection of the fusing section connector |
| | | Case 1 | Cause | The heater lamp flashes properly with SIM 5-2. Thermistor trouble, disconnection of the fusing section connector |
| | | | Check & Remedy | Check the thermistor and its harness. Cancel the error with SIM 14. |
| | | Case 2 | Cause | The heater lamp keeps ON with SIM 5-2. Control PWB trouble, AC power supply trouble |
| | | | Check & Remedy | Check the AC PWB and the control PWB lamp control circuit. Cancel the error with SIM 14. |

| Main code | Sub code | Title | Fusing section high temperature trouble (THS2) | |
|-----------|----------|------------|--|--|
| H3 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The fusing temperature exceeds 230°C. |
| | | | Section | Fusing |
| | | Common | Check | Use SIM 5-2 to check the heater lamp flashing operation. |
| | | Case 1 | Cause | The heater lamp flashes properly with SIM 5-2. Thermistor trouble, disconnection of the fusing section connector |
| | | | Check & Remedy | Check the thermistor and its harness. Cancel the error with SIM 14. |
| | | Case 2 | Cause | The heater lamp keeps ON with SIM 5-2. AC power supply trouble, control PWB trouble |
| | | | Check & Remedy | Check the AC PWB and the control PWB lamp control circuit. Cancel the error with SIM 14. |

| Main code | Sub code | Title | Fusing section low temperature trouble (HL1) | |
|-----------|----------|------------|--|---|
| H4 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The fusing temperature is not reached within the specified time after turning on the power relay. |
| | | | Section | Fusing |
| | | Common | Check | Use SIM 5-2 to check the heater lamp flashing operation. |
| | | Case 1 | Cause | The heater lamp flashes properly with SIM 5-2. Thermistor trouble, PCU PWB (thermistor input circuit) trouble |
| | | | Check & Remedy | Check the thermistor and its harness. Check the PCU PWB thermistor input circuit. Cancel the error with SIM 14. |
| | | Case 2 | Cause | The heater lamp keeps ON with SIM 5-2. Heater lamp trouble, thermostat trouble, interlock switch trouble, AC power supply trouble, PCU PWB (lamp control circuit) trouble |
| | | | Check & Remedy | Check for disconnection of the heater lamp and the thermostat. Check the interlock switch. Check the AC PWB and the PUC PWB lamp control circuit. Cancel the error with SIM 14. |

| Main code | Sub code | Title | Fusing section low temperature trouble (HL2) | |
|-----------|----------|------------|--|---|
| H4 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The fusing temperature is not reached within the specified time after turning on the power relay. |
| | | | Section | Fusing |
| | | Common | Check | Use SIM 5-2 to check the heater lamp flashing operation. |
| | | Case 1 | Cause | The heater lamp flashes properly with SIM 5-2. Thermistor trouble, PCU PWB (thermistor input circuit) trouble |
| | | | Check & Remedy | Check the thermistor and its harness. Check the PCU PWB thermistor input circuit. Cancel the error with SIM 14. |
| | | Case 2 | Cause | The heater lamp keeps ON with SIM 5-2. Heater lamp trouble, thermostat trouble, interlock switch trouble, AC power supply trouble, PCU PWB (lamp control circuit) trouble |
| | | | Check & Remedy | Check for disconnection of the heater lamp and the thermostat. Check the interlock switch. Check the AC PWB and the PUC PWB lamp control circuit. Cancel the error with SIM 14. |

| Main code | Sub code | Title | Five continuous detections of POD1 not-reached jam | |
|-----------|----------|------------|--|--|
| H5 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | POD1 not-reached jams are detected for five times continuously. |
| | | | Section | Fusing |
| | | Case 1 | Cause | A fusing jam is not canceled completely. (Jam paper remains inside the machine.) |
| | | | Check & Remedy | Check remaining jam paper (winding). Cancel the error with SIM 14. |
| | | Case 2 | Cause | POD1 sensor trouble, or harness disconnection |
| | | | Check & Remedy | Check POD1 sensor harness. Cancel the error with SIM 14. |
| | | Case 3 | Cause | Improper installation of the fusing unit |
| | | | Check & Remedy | Check installation of the fusing unit. Cancel the error with SIM 14. |

| Main code | Sub code | Title | | Fusing unit initial detection trouble |
|-----------|----------|------------|----------------|---|
| H8 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Fusing unit initial detection trouble |
| | | | Section | Fusing |
| | | Case 1 | Cause | Disconnection of the connector |
| | | | Check & Remedy | Check connection of the fusing unit initial sensor. Check connection of the connector and the harness to the PCU PWB. |
| | | Case 2 | Cause | Connector harness trouble |
| | | | Check & Remedy | Check for disconnection of the harness. |
| | | Case 3 | Cause | Fusing unit trouble |
| | | | Check & Remedy | Replace the fusing unit. |

| Main code | Sub code | Title | | Mirror feed trouble |
|-----------|----------|------------|----------------|---|
| L1 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Mirror feed is not completed within the specified time. |
| | | | Section | — |
| | | Case 1 | Cause | Mirror unit trouble, mirror wire breakage |
| | | | Check & Remedy | Use SIM 1-1 to check the mirror operation. |

| Main code | Sub code | Title | | Mirror return trouble |
|-----------|----------|------------|----------------|---|
| L3 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Mirror return is not completed within the specified time. |
| | | | Section | — |
| | | Case 1 | Cause | Mirror unit trouble, mirror wire breakage |
| | | | Check & Remedy | Use SIM 1-1 to check the mirror operation. |

| Main code | Sub code | Title | | Paper feed motor lock trouble |
|-----------|----------|------------|----------------|--|
| L4 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | In warm-up, or in canceling a jam, the paper feed motor is rotated, and the lock signal is not detected within 1sec. |
| | | | Section | Paper feed |
| | | Case 1 | Cause | Paper feed motor trouble, disconnection of the harness between the PCU PWB and the paper feed motor, control circuit trouble |
| | | | Check & Remedy | Use SIM 6-1 to check the paper feed motor operation. Check the harness and the connector between the PCU PWB and the paper feed motor. |

| Main code | Sub code | Title | | Transfer belt lift motor trouble |
|-----------|----------|------------|----------------|--|
| L4 | 06 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When the belt motor lifts up or down, the change in the belt home position sensor characteristics is not detected within the specified time. (When the motor lifts up, the lower limit sensor remains ON after the specified time.) (When the motor lifts down, the lower limit sensor does not turn on after the specified time.) |
| | | | Section | Paper feed |
| | | Case 1 | Cause | Belt lift motor trouble, disconnection of the harness between the PCU PWB and the belt lift motor, control circuit trouble |
| | | | Check & Remedy | Use SIM 6-1 to check the belt lift motor operation. Check the harness and the connector between the PCU PWB and the belt lift motor. |

| Main code | Sub code | Title | | Transfer belt motor trouble |
|-----------|----------|------------|--------------|--|
| L4 | 07 | Display | Lamp/Message | |
| | | Phenomenon | Detail | 1) Before driving the drum, the calibration plate is opened with the process control BK sensor, and light is emitted with the gain value of 0 and with the light emitting quantity fixed to 120. The average of ten light quantities repeats to be 5 or less for 3 times continuously. 2) Immediately after driving the drum, the calibration plate is opened with the process control BK sensor, and one whole turn of the belt surface is scanned with the gain value of 0 and with the light emitting quantity at the optimum value (120 ~ 50). The difference between the max. value and the min. value of the scanned data is 5 or less. |
| | | | Section | Paper feed |
| | | | | |

| Main code | Sub code | Title | Transfer belt motor trouble | |
|-----------|-----------|--------|-----------------------------|---|
| L4 | 07 | Case 1 | Cause | Transfer belt motor connector disconnection, process control sensor connector disconnection, process control BK sensor defect, defective connection of the harness between the PCU PWB and the transfer belt motor, defective control circuit |
| | | | Check & Remedy | Check the transfer belt motor operation with SIM25-1. Check the process control sensor operation with SIM44-2. Check the harness and the connector between the PCU PWB and the transfer belt motor. |

| Main code | Sub code | Title | Full wave signal width abnormality | |
|-----------|-----------|------------|------------------------------------|--|
| L8 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | An abnormality of the full wave signal frequency is detected. (The detected frequency is 65kHz or above, or 45kHz or below.) |
| | | | Section | — |
| | | Case 1 | Cause | PCU PWB trouble |
| | | | Check & Remedy | Replace the PCU PWB. |
| | | Case 2 | Cause | Power supply unit trouble |
| | | | Check & Remedy | Replace the power supply unit. |
| | | Case 3 | Cause | Harness trouble |
| | | | Check & Remedy | Check connection of the harness and the connector. |

| Main code | Sub code | Title | Shift motor trouble | |
|-----------|-----------|------------|---------------------|--|
| L4 | 11 | Display | Lamp/Message | |
| | | Phenomenon | Detail | When initializing the shift motor, the change in the shift motor home position sensor characteristics is not detected within the specified time. |
| | | | Section | Paper feed |
| | | Case 1 | Cause | Shift motor trouble, disconnection of the harness between the PCU PWB and the shift motor, control circuit trouble |
| | | | Check & Remedy | Use SIM 6-1 to check the shift motor operation. Use SIM 30-1 to check the shift motor home position sensor. Check the harness and the connector between the PCU PWB and the shift motor. |

| Main code | Sub code | Title | Main power switch abnormality detection | |
|-----------|-----------|------------|---|---|
| L8 | 04 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Though the PCU program is operating (the power is supplied), the main power switch OFF is detected. |
| | | | Section | — |
| | | Case 1 | Cause | Main power switch trouble |
| | | | Check & Remedy | Replace the main power switch. |
| | | Case 2 | Cause | Power supply unit trouble |
| | | | Check & Remedy | Replace the power supply unit. |
| | | Case 3 | Cause | Harness trouble |
| | | | Check & Remedy | Check connection of the harness and the connector. |

| Main code | Sub code | Title | Full wave signal not provided | |
|-----------|-----------|------------|-------------------------------|--|
| L8 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The full wave signal is not provided. |
| | | | Section | — |
| | | Case 1 | Cause | PCU PWB trouble |
| | | | Check & Remedy | Replace the PCU PWB. |
| | | Case 2 | Cause | Power supply unit trouble |
| | | | Check & Remedy | Replace the power supply unit. |
| | | Case 3 | Cause | Harness trouble |
| | | | Check & Remedy | Check connection of the harness and the connector. |

| Main code | Sub code | Title | RIC copy inhibit signal reception | |
|-----------|-----------|------------|-----------------------------------|--|
| PF | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The copy inhibit signal from RIC (host) is received. |
| | | | Section | — |
| | | Case 1 | Cause | Depends on a judgment by the host. |
| | | | Check & Remedy | Make notification to the host. Use SIM 27-1 to ignore. |

| Main code | Sub code | Title | ICU-OPE communication trouble (ICU/OPE detection) | |
|-----------|-----------|------------|---|---|
| U0 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication establishment error, framing/parity/protocol error |
| | | | Section | — |
| | | Case 1 | Cause | Disconnection of the operation panel communication connector of the ICU/MFP PWB, harness trouble between the ICU PWB and the MFP PWB. |
| | | | Check & Remedy | Check the connector and the harness between the ICU PWB and the MFP PWB. |
| | | Case 2 | Cause | ICU/MFP PWB trouble |
| | | | Check & Remedy | Check grounding of the machine. Replace the ICU PWB or the MFP PWB. |

| Main code | Sub code | Title | RTC read trouble | |
|-----------|-----------|------------|------------------|---|
| U1 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Abnormal value is read from the RTC on the ICU PWB. |
| | | | Section | — |
| | | Case 1 | Cause | RTC circuit abnormality |
| | | | Check & Remedy | Set the time again with the key operation, and check that time advances properly. Check the RTC circuit. |

| Main code | Sub code | Title | EEPROM read/write error (ICU detection) | |
|-----------|-----------|------------|---|--|
| U2 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM version error EEPROM write error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble. EEPROM is not initialized. |
| | | | Check & Remedy | 1. Check that the EEPROM is properly set. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | ICU PWB EEPROM access circuit trouble |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the ICU PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | EEPROM check sum error (ICU detection) | |
|-----------|-----------|------------|--|--|
| U2 | 11 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM (ICU) check sum error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble |
| | | | Check & Remedy | 1. Check that the EEPROM is properly set. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | Control circuit freeze by noises. ICU PWB EEPROM access circuit trouble. |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the ICU PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | Production No. data discrepancy | |
|-----------|-----------|------------|---------------------------------|---|
| U2 | 30 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The production No. recorded in the PCU differs from that recorded in the ICU. |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM is not exchanged when replacing the PCU/ICU PWB. |
| | | | Check & Remedy | Check that the EEPROM is properly installed. When replacement, check that the EEPROM before replacement is inserted to the board after replacement. |

| Main code | Sub code | Title | | EEPROM read/write error (SCN) |
|-----------|-----------|------------|----------------|--|
| U2 | 80 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM version error EEPROM write error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble, Insertion of EEPROM which is not initialized or defective. |
| | | | Check & Remedy | 1. Check that the EEPROM is properly inserted. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | SCN PWB EEPROM access circuit trouble |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the SCN PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | | EEPROM read/write error (PCU) |
|-----------|-----------|------------|----------------|--|
| U2 | 90 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM version error EEPROM write error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble, Insertion of EEPROM which is not initialized or defective. |
| | | | Check & Remedy | 1. Check that the EEPROM is properly inserted. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | PCU PWB EEPROM access circuit trouble |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the PCU PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | | Adjustment value check sum error (SCN) |
|-----------|-----------|------------|----------------|--|
| U2 | 81 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM (SCN) check sum error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble |
| | | | Check & Remedy | 1. Check that the EEPROM is properly inserted. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | SCN PWB EEPROM access circuit trouble |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the SCN PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | | Adjustment value check sum error (PCU) |
|-----------|-----------|------------|----------------|--|
| U2 | 91 | Display | Lamp/Message | |
| | | Phenomenon | Detail | EEPROM (PCU) check sum error |
| | | | Section | — |
| | | Case 1 | Cause | EEPROM trouble |
| | | | Check & Remedy | 1. Check that the EEPROM is properly inserted. 2. Use SIM 16 to cancel the error. |
| | | Case 2 | Cause | Control circuit freeze caused by noises, PCU PWB EEPROM access circuit trouble |
| | | | Check & Remedy | 1. To prevent against deletion of the counter data and the adjustment data, record them with the simulation. (When a printer option is installed, use SIM 22-1 to record the counter data and the adjustment data.) 2. Replace the PCU PWB. 3. Use SIM 16 to cancel the error. |

| Main code | Sub code | Title | | ADU alignment plate operation abnormality |
|-----------|-----------|------------|----------------|---|
| U4 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | The alignment plate does not move from the home position within 1sec when it must move. Return to the home position is not detected for 5sec or more. |
| | | | Section | ADU |
| | | Case 1 | Cause | Home position sensor trouble |
| | | | Check & Remedy | Use SIM 9-2 to detect the home position sensor. |
| | | Case 2 | Cause | Alignment plate shift motor trouble |
| | | | Check & Remedy | Use SIM 9-4 to check the alignment plate operation. |
| | | Case 3 | Cause | Disconnection of the harness between the ADU control PWB and the motor sensor. |
| | | | Check & Remedy | Check connection of the harness between the ADU control PWB and the motor sensor. |
| | | Case 4 | Cause | Alignment plate operation belt, gear breakage or improper adjustment |
| | | | Check & Remedy | Remove the ADU, and check for breakage of the gear and the belt. |

| Main code | Sub code | Title | | ADF resist sensor trouble |
|-----------|-----------|------------|----------------|---|
| U5 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | ADF resist sensor detection trouble |
| | | | Section | ADF |
| | | Case 1 | Cause | Sensor trouble |
| | | | Check & Remedy | Use SIM 2-2 to check the resist sensor detection. |
| | | Case 2 | Cause | Disconnection of the harness in the ADF. |
| | | | Check & Remedy | Check the harness in the ADF. |
| | | Case 3 | Cause | ADF control PWB trouble |
| | | | Check & Remedy | Replace the ADF control PWB. |

| Main code | Sub code | Title | | ADF repulsion sensor trouble |
|-----------|-----------|------------|----------------|---|
| U5 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | ADF paper feed/reverse sensor detection trouble |
| | | | Section | ADF |
| | | Case 1 | Cause | Sensor trouble |
| | | | Check & Remedy | Use SIM 2-2 to check the resist sensor detection. |
| | | Case 2 | Cause | Disconnection of the harness in the ADF. |
| | | | Check & Remedy | Check the harness in the ADF. |
| | | Case 3 | Cause | ADF control PWB trouble |
| | | | Check & Remedy | Replace the ADF control PWB. |

| Main code | Sub code | Title | | ADF communication trouble |
|-----------|-----------|------------|----------------|--|
| U5 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Communication test error when turning on the power or after canceling the exclusive simulation. Communication error with the ADF |
| | | | Section | ADF |
| | | Case 1 | Cause | Improper connection or disconnection of the connector and the harness |
| | | | Check & Remedy | Check the connector and the harness in the communication line. Turn OFF/ON the power to cancel the error. |
| | | Case 2 | Cause | ADF control PWB trouble, control PWB (MFP) trouble, malfunction caused by noises |
| | | | Check & Remedy | Check the ADF control PWB and the control PWB (MFP). Turn OFF/ON the power to cancel the error. |

| Main code | Sub code | Title | | ADF timing sensor trouble |
|-----------|-----------|------------|----------------|---|
| U5 | 03 | Display | Lamp/Message | |
| | | Phenomenon | Detail | ADF timing sensor detection trouble |
| | | | Section | ADF |
| | | Case 1 | Cause | Sensor trouble |
| | | | Check & Remedy | Use SIM 2-2 to check the resist sensor detection. |
| | | Case 2 | Cause | Disconnection of the harness in the ADF. |
| | | | Check & Remedy | Check the harness in the ADF. |
| | | Case 3 | Cause | ADF control PWB trouble |
| | | | Check & Remedy | Replace the ADF control PWB. |

| Main code | Sub code | Title | | Paper feed motor operation abnormality |
|-----------|-----------|------------|----------------|---|
| U5 | 11 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Paper feed motor operation abnormality |
| | | | Section | ADF |
| | | Case 1 | Cause | Motor lock, motor RPM abnormality, Over current to the motor, ADF control PWB trouble |
| | | | Check & Remedy | Use SIM 2-2/3/4 to check the paper feed motor operation. |

| Main code | Sub code | Title | | Desk communication trouble |
|-----------|-----------|------------|---|---|
| U6 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Desk communication error, communication test error when turning on the power or after canceling the exclusive simulation. |
| | | | Section | Desk |
| | Case 1 | Cause | Improper connection or disconnection of the connector and the harness. | |
| | | | Check & Remedy | Check the connector and the harness in the communication line. Turn OFF/ON the power to cancel the error. |
| | Case 2 | Cause | Desk control PWB trouble, control PWB (PCU) trouble, malfunction caused by noises | |
| | | | Check & Remedy | Turn OFF/ON the power to cancel the error. |

| Main code | Sub code | Title | | Desk cassette 1 lift-up trouble |
|-----------|-----------|------------|--|---|
| U6 | 01 | Display | Lamp/Message | |
| | | Phenomenon | Detail | DLUD1 does not turn on within the specified time. |
| | | | Section | Desk |
| | Case 1 | Cause | DLUD1 sensor trouble, paper feed unit harness disconnection | |
| | | | Check & Remedy | Check DLUD1 and the harness and the connector. |
| | Case 2 | Cause | Cassette 1 lift-up motor trouble, desk PWB, lift-up unit trouble | |
| | | | Check & Remedy | Check the lift-up unit. |

| Main code | Sub code | Title | | Desk cassette 2 lift-up trouble |
|-----------|-----------|------------|--|---|
| U6 | 02 | Display | Lamp/Message | |
| | | Phenomenon | Detail | DLUD2 does not turn on within the specified time. |
| | | | Section | Desk |
| | Case 1 | Cause | DLUD2 sensor trouble, paper feed unit harness disconnection | |
| | | | Check & Remedy | Check DLUD2 and the harness and the connector. |
| | Case 2 | Cause | Cassette 2 lift-up motor trouble, desk PWB, lift-up unit trouble | |
| | | | Check & Remedy | Check the lift-up unit. |


| Main code | Sub code | Title | | Desk cassette 3 lift-up trouble |
|-----------|-----------|------------|--|---|
| U6 | 03 | Display | Lamp/Message | |
| | | Phenomenon | Detail | DLUD3 does not turn on within the specified time. |
| | | | Section | Desk |
| | Case 1 | Cause | DLUD3 sensor trouble, paper feed unit harness disconnection | |
| | | | Check & Remedy | Check DLUD3 and the harness and the connector. |
| | Case 2 | Cause | Cassette 3 lift-up motor trouble, desk PWB, lift-up unit trouble | |
| | | | Check & Remedy | Check the lift-up unit. |

| Main code | Sub code | Title | | Desk transport motor trouble |
|-----------|-----------|------------|--|--|
| U6 | 10 | Display | Lamp/Message | |
| | | Phenomenon | Detail | Desk transport motor operation trouble |
| | | | Section | — |
| | Case 1 | Cause | Motor lock, motor RPM abnormality, Over current to the motor, console finisher control PWB trouble | |
| | | | Check & Remedy | Use SIM 3-3 to check the staple motor operation. |

| Main code | Sub code | Title | | RIC communication trouble |
|-----------|-----------|------------|--|--|
| U7 | 00 | Display | Lamp/Message | |
| | | Phenomenon | Detail | RIC communication error, communication test error when turning on the power or after canceling the exclusive simulation. |
| | | | Section | — |
| | Case 1 | Cause | Improper connection or disconnection of the connector and the harness | |
| | | | Check & Remedy | Check the connector and the harness in the communication line. Turn OFF/ON the power to cancel the error. |
| | Case 2 | Cause | RIC control PWB trouble, control PWB (PCU) trouble, malfunction caused by noises | |
| | | | Check & Remedy | Turn OFF/ON the power to cancel the error. |

1. Outline

The following ROM's are used in the machine, and their versions are revised.



In the following cases, version up of ROM is required.

- AR-C260/C260M ROM VERSION UP 12 - 1

C. Flash ROM version up method

(In the case of PCU ROM, ICU ROM, Operation control ROM, Scanner control ROM, FAX control ROM)

There are following two methods of Flash Rom version up.

- 1) By connecting a computer with the ICU PWB, the program data of Flash ROM is written from the computer to the Flash ROM on the ICU MAIN PWB.

This method has the following two variations.

- a) All data in the PWB programs and the Flash ROM copy (ROM-ROM) program are written: (Making of the source ROM)

In this method, the Flash ROM on the writing side needs capacity of 32Mbit x 2

(In order to make a source ROM, the capacity of the Flash ROM must be as shown above.)

- b) Only each PWB program is written.

- 2) Two Flash ROM sockets on the ICU MAIN PWB are used to copy the program in the source ROM to another Flash ROM. (It normally takes 30 to 60 sec.)

In this method, the Flash ROM (source ROM) made by the method of using a computer and writing the program to the Flash ROM is required.


(Note)

To make version up of several Flash ROM's of several machines, it is the most effective to make a source ROM by the method of 1) -a) and copy the data to several Flash ROM's by the method of 2).

- (1)-a Method of writing the program data from a PC to the ICU MAIN PWB Flash ROM


(Making of source ROM)

The program for each PWB and the Flash ROM copy program are copied into the Flash ROM on the Write side socket.




- (1)-b Method of writing the program data from a PC to the ICU MAIN PWB Flash ROM

The program for each PWB is copied to the Flash ROM on the Write socket.



- (2) Method of copying with two Flash ROM sockets on the ICU MAIN PWB

The program for each PWB in the Flash ROM (source ROM) on the Read socket is copied to the Flash ROM (target ROM) on the Write socket.



Relationship between copy (write) method and copy contents

(1)-a Method of writing the program data from a PC to the ICU MAIN PWB Flash ROM (Making of source ROM)

The program for each PWB and the Flash ROM copy program are copied into the Flash ROM on the Write side socket.

| PC side | | | Write side Flash Rom (Flash ROM B) | | | | Note |
|---|---|-----------------|------------------------------------|------------|---|---|---|
| Content | | File name | Name | Capacity | Copied content | | |
| Program for PCU Flash ROM | Program for Flash ROM copy (ROM to ROM) | xPcuxxx_src.pgm | For PCU Flash ROM | 32bit x 2 | Program for PCU Flash ROM | Program for Flash ROM copy (ROM to ROM) | The ICU Flash ROM with the copy (write) program in it must be connected to the Read side Flash ROM socket. When shipping, from the factory, the copy (write) program is provided for use. By this method with two Flash ROM sockets on the ICU PWB, the Flash ROM for copying is made. |
| Program for ICU Flash ROM | Program for Flash ROM copy (ROM to ROM) | xlCuxxx_src.pgm | For ICU Flash ROM | 32bit x 2 | Program for ICU Flash ROM | Program for Flash ROM copy (ROM to ROM) | |
| Program for operation control Flash ROM | Program for Flash ROM copy (ROM to ROM) | xOpexxx_src.pgm | For operation control Flash ROM | 32bit x 2 | Program for operation control Flash ROM | Program for Flash ROM copy (ROM to ROM) | |
| Program for scanner control Flash ROM | Program for Flash ROM copy (ROM to ROM) | WScnXXX_src.pgm | For scanner control Flash ROM | 32Mbit x 2 | Program for scanner control Flash ROM | Program for Flash ROM copy (ROM to ROM) | |
| Program for FAX control Flash ROM | Program for Flash ROM copy (ROM to ROM) | | For FAX control Flash ROM | 32Mbit x 2 | Program for FAX control Flash ROM | Program for Flash ROM copy (ROM to ROM) | |

(1)-b Method of writing the program data from PC to the Flash ROM on the ICU PWB

The program for each PWB is copied to the Flash ROM on the Write socket.

| PC side | | | Write side Flash Rom (Flash ROM D) | | | | Note |
|---|--|---------------|------------------------------------|------------|---|--|--|
| Content | | File name | Name | Capacity | Copied content | | |
| Program for PCU PWB Flash ROM | | xpcuxxx_d.pgm | For PCU Flash ROM | 8Mbit | Program for PCU Flash ROM | | The ICU MAIN PWB Flash ROM with the copy (write) program in it must be connected to the Read side Flash ROM socket. When shipping, from the factory, the copy (write) program is provided for use. |
| Program for ICU PWB Flash ROM | | xlCuxxx_d.pgm | For ICU Flash ROM | 32Mbit x 2 | Program for ICU Flash ROM | | |
| Program for operation control Flash ROM | | xOpexxx_d.pgm | For operation control Flash ROM | 16Mbit x 2 | Program for operation control Flash ROM | | |
| Program for scanner control Flash ROM | | WScnXXX_d.pgm | For scanner control Flash ROM | 16Mbit | Program for scanner control Flash ROM | | |
| Program for FAX control Flash ROM | | | For FAX control Flash ROM | 8Mbit x 2 | Program for FAX control Flash ROM | | |

(2) Method of copying with two Flash ROM sockets on the ICU MAIN PWB

The program for each PWB in the Flash ROM (Source ROM) on the Read side Flash ROM socket is copied to a Flash ROM on the Write side socket.

| Read side Flash ROM (ROM B) (*1) | | | Write side Flash ROM (Flash ROM C) | | | Note |
|----------------------------------|---|---|---------------------------------------|------------|---|--|
| Capacity | Content | | Name | Capacity | Copied content | |
| 32Mbit x 2 | Program for PCU Flash ROM | Program for Flash ROM Copy (ROM to ROM) | For PCU Flash ROM | 8Mbit | Program for PCU Flash ROM | The Flash ROM on the Read side is the source ROM for PCU, which was made by writing the program data from PC to the Flash ROM. |
| 32Mbit x 2 | Program for ICU Flash ROM | Program for Flash ROM copy (ROM to ROM) | For ICU Flash ROM | 32Mbit x 2 | Program for ICU Flash ROM | The Flash ROM on the Read side is the source ROM for ICU, which was made by writing the program data from PC to the Flash ROM. |
| 32Mbit x 2 | Program for operation control Flash ROM | Program for Flash ROM copy (ROM to ROM) | For operation control Flash ROM | 16Mbit x 2 | Program for operation control Flash ROM | The Flash ROM on the Read side is the source ROM for operation control PWB, which was made by writing the program data from PC to the Flash ROM. |
| 32Mbit x 2 | Program for scanner control Flash ROM | Program for Flash ROM copy (ROM to ROM) | Program for scanner control Flash ROM | 16Mbit | Program for scanner control Flash ROM | |
| 32Mbit x 2 | Program for FAX control Flash ROM | | Program for FAX control Flash ROM | 8Mbit x 2 | Program for FAX control Flash ROM | |

*1: This Flash ROM was made by writing the program data from PC to the ICU MAIN PWB Flash ROM.

NOTE: Besides this method of Flash ROM version up, there is another method by use of a machine of the AR-350/450 series.

This method, however, allows the version up work in a shorter time.

For details, refer to Technical Report ARE-352 (ARJ-390).

(Desk control ROM)

The desk unit control program is installed in the Flash ROM in the CPU of the desk unit control PWB.

Therefore, this Flash ROM cannot be replaced physically.

The PC is connected with the desk unit control PWB, and the Flash Rom program is written from the PC to the Flash Rom in the CPU.

| PC side | | Write side (Flash ROM in the CPU on the Desk unit control PWB) |
|--|---------------|--|
| Content | File name | Copied content |
| Program for Desk control PWB Flash ROM | WDskxxx_d.pgm | Program for Desk control PWB Flash ROM |

2. Precautions

A. Relationship between each ROM and version up

When making version up of ROM, check the combination with the version of ROM installed to the other PWB including options.

In some combination of ROM versions, the machine may not operate normally.

If all the ROM's are of the latest versions, there is no problem.

3. Necessary items for version up (copy) of Flash ROM

Necessary items for Flash ROM version up

(In the case of PCU ROM, ICU ROM, Operation control ROM, Scanner control ROM, FAX control ROM)

- (1)-a Method of writing the program data from a PC to the Flash ROM on the ICU MAIN PWB. (Making of the source ROM)
The program for each PWB and the Flash ROM copy program are copied to a Flash ROM on the Write socket.

| Necessary item | Note |
|--|--|
| Level converter | UKOG-0002QSZZ (with serial cable)/UKOG-0003QSZZ (without serial cable) |
| PC | Windows 95/98/2000 environment |
| Download program file | Software to write the program data from a PC to the Flash ROM (Mainte_XXXX.exe) |
| (PCU MAIN PWB Flash ROM program/Flash ROM copy (ROM to ROM) program) file | xPcuxxx_src.pgm |
| (ICU MAIN PWB Flash ROM program/Flash ROM copy (ROM to ROM) program) file | xlculxxx_src.pgm |
| (Operation control PWB Flash ROM program/Flash ROM copy (ROM to ROM) program) file | xOpexxx_src.pgm |
| Program for scanner control Flash ROM/Program for Flash ROM copy (ROM to ROM) | WScnXXX_src.pgm |
| Program for FAX control Flash ROM/Program for Flash ROM copy (ROM to ROM) | |
| ICU MAIN PWB Flash ROM (including the program for MAIN ICU PWB and the Flash ROM copy (PC - ROM) program) (32Mbit x 2) (Flash ROM A) | Flash ROM which has the function of writing the program data from PC to the Flash ROM on the ICU |
| Writing Flash ROM (32Mbit x 2) (Flash ROM B) | Flash ROM to make a source ROM |

- (1)-b Method of writing the program data from a PC to the ICU MAIN PWB Flash ROM.
The program for each PWB is copied to the Flash ROM on the Write side socket.

| Necessary item | Note |
|--|--|
| Level converter | UKOG-0002QSZZ (with serial cable)/UKOG-0003QSZZ (without serial cable) |
| PC | Windows 95/98/2000 environment |
| Download program file | Software for writing the program data from a PC to the Flash ROM (Mainte.exe) |
| PCU Flash ROM program file | xPcuxxx_d.pgm |
| ICU Flash ROM program file | xlculxxx_d.pgm |
| Operation control PWB Flash ROM program file | xOpexxx_d.pgm |
| Scanner control Flash ROM program | WScnXXX_d.pgm |
| FAX control Flash ROM program | |
| Flash Rom for ICU (including the program for Main ICU PWB and the Flash ROM copy (PC - ROM) program (32Mbit x 2) (Flash ROM A) | Flash ROM (ICU PWB) having the function to write program data from PC to the Flash ROM on the ICU PWB. |

| Necessary item | Note |
|---|--|
| Writing Flash ROM (16Mbit x 2/ 16Mbit/8Mbit/32Mbit x 2/8Mbit x 2) | The type (capacity) of the Flash ROM depends on which Flash ROM is made among the CPU PWB, the ICU PWB, and the operation PWB. |

- (2) Method of copying with two Flash ROM sockets on the ICU MAIN PWB
The program for each PWB in the Flash ROM (source ROM) on the Read side Flash ROM socket is copied to the Flash ROM on the Write side socket.

| Necessary item | Note |
|---|--|
| Flash Rom including the ICU program and the Flash ROM copy (ROM to ROM) program (Flash ROM B) (32Mbit x 2) | Flash ROM made by writing the program data from PC to the Flash ROM (32Mbit x 2) |
| Flash Rom including the PCU program and the Flash ROM copy (ROM to ROM) program (Flash ROM B) (32Mbit x 2) | Flash ROM made by writing the program data from PC to the Flash ROM (32Mbit x 2) |
| Flash Rom including the program for the operation control PWB and the Flash ROM copy (ROM to ROM) program (Flash ROM B') (32Mbit x 2) | Flash ROM made by writing the program data from PC to the Flash ROM (32Mbit x 2) |
| Program for scanner control Flash ROM/Flash ROM copy (ROM to ROM) program | Flash ROM made by writing the program data from PC to the Flash ROM (32Mbit x 2) |
| Program for FAX control Flash ROM/Flash ROM copy (ROM to ROM) program | Flash ROM made by writing the program data from PC to the Flash ROM (32Mbit x 2) |
| Writing Flash ROM/16Mbit x 2/ 16Mbit/8Mbit/32Mbit x 2) (Flash ROM C) | The type (capacity) of Flash ROM is determined depending on the kind of Flash ROM (in the PCU PWB, in the ICU PWB, or in the operation control PWB). |

(In the case of Desk control ROM)


| Necessary item | Note |
|-------------------------------------|--|
| Level converter | UKOG-0002QSZZ (with serial cable)/ UKOG-0003QSZZ (without serial cable) |
| PC | Windows 95/98/2000 environment |
| Download program file | Software to write the program data from PC to the Flash ROM. (Mainte_XXXX.exe) |
| Desk control Flash ROM program file | WDskxxx_d.pgm |

4. Flash ROM version up procedure


(In the case of PCU ROM, ICU ROM, Operation control ROM, Scanner control ROM, FAX control ROM)

(Preliminary procedure)

- 1) Remove the machine paper tray cabinet. (2 screws)




- 2) Remove the shield plate. (2 screws)




A. By using a computer and the ICU PWB, the program data of Flash ROM is written from the computer to the Flash ROM of the ICU PWB.

- 1) Check that the power of the machine is turned off. Install the Flash ROM which is to be upgraded (copied) to the write socket of the ICU PWB.




- 2) Connect the computer with the level converter.



- 3) Connect the serial I/F connector on the ICU MAIN PWB with the level converter.
- 4) Turn on the computer to start Windows.
- 5) Turn on the machine.
- 6) Set the communication speed on the computer side.

In the case of Windows 95/98:


- (6-1) Open the "Control panel."



- (6-2) Open the "System."




- (6-3) Click the "Device manager." Click the "Port (COM/LPT)" and double-click the "Communication port (COM*)" to be used.



- (6-4) Open the "Port setup" tab, and enter "115200" in the column of bit/sec.


If the above communication speed cannot be set, select and set one of the following speeds.

9600/19200/38600/57600




In the case of Windows 2000:


- (6-1) Open the "Control panel."




- (6-2) Open the "System."




- (6-3) Select the "Device manager (D)" on the hardware menu.



- (6-4) Click the "Port (COM/LPT)" and double-click the "Communication port (COM*)" to be used.




- (6-5) Open the "Port setup" tab, and enter "115200" in the column of bit/sec.
If the above communication speed cannot be set, select and set one of the following speeds.
9600/19200/38600/57600



- 7) Set the communication speed on the machine side. The set value of communication speed on the computer side must be the same as that on the machine side.


(7-1) Enter the simulation 49-2 mode.




- (7-2) Press the key of the same communication speed as what is set in procedure 8). (The set communication speed is highlighted.)

(7-3) Cancel the simulation 49-2.


- 8) Enter the simulation mode 49-1 mode, and press the ENTER key. (The machine enters the download (Flash ROM writing) mode.)



- 9) Start the download program on the computer side. (Double-click the Maint.exe file.)




- 10) Select the communication speed on the option menu. (Set the communication speed same as what is set in procedures 6) and 7).)



- 11) Select the data file to be copied (written) to the Flash ROM installed to the Write socket on the ICU MAIN PWB in procedure 1).

(11-1) Double-click the "Simulation Command List" holder.




(11-2) Double-click the "Special" holder.


(11-3) Double-click the "Program Download" file.

(11-4) The message of "Program Download OK ?" is displayed. Press the OK button.

(11-5) Select the data (PWB name) to be written and click the START button.



(11-6) Select the data file to be written, and click the "Open" button.



With the above procedure, downloading (writing to the Flash ROM) is started.

(NOTE) Selection of data files to be written determines whether a source ROM (which includes the latest version program and the Flash ROM copy program) or a ROM which has only the latest version program is made.

- 12) Confirm that downloading (copying to the Flash ROM) is completed on the computer display and on the LCD display. It normally takes 5 to 7 minutes to copy (write) to the Flash ROM.


When downloading is normally completed, the following indications are shown.

- * LED3 on the ICU PWB are turned off, and LED1 and LED2 flash at a low speed.
- * "FIRMWARE UPGRADE FINISHED" is displayed on the LCD.

- 13) Cancel the simulation 49-1, and turn off the power of the machine.

B. Method using two Flash ROM sockets on the ICU MAIN PWB to copy between Flash ROM's

- 1) Check that the power of the machine is OFF. Install the Flash ROM (of either of ICU PWB, PCU PWB, or operation control PWB) to the ICU PWB Write socket.



(NOTE)

The monitor displays before and after and during the Flash ROM version up (copy) operation are shown below. If the Flash ROM version up operation is not completed normally or if the Flash ROM is not installed to the socket properly, a trouble code is displayed. In that case, perform the countermeasures shown in the table below.

- (1) ICU MAIN PWB monitor LED lighting specification

The monitor LED status during copy (write) operation of PC to Flash ROM and Flash ROM to Flash ROM is shown below. In the copy mode of Flash ROM to Flash ROM, the machine status is indicated only with the monitor LED.

While in the copy mode of PC to Flash ROM, the status is indicated on the operation panel or the PC monitor.

Status LED lighting specifications

| | LED1 | LED2 | LED3 | Mode |
|--|---------------------|---------------------|---------------------|----------------------------------|
| Status 1 | Low-speed flashing | Low-speed flashing | OFF | Normal operation |
| Status 2 | High-speed flashing | High-speed flashing | High-speed flashing | System down |
| Display when writing the program data from PC to Flash ROM | | | | |
| Status 3 | ON | OFF | OFF | Download SIM start |
| Status 4 | OFF | Flashing | OFF | Download ROM not-installed error |
| Status 5 | Flashing | ON | OFF | During data transfer from PC |
| Status 6 | Flashing | Flashing | OFF | Data transfer error from PC |
| Status 7 | ON | ON | OFF | Flash deleting |
| Status 8 | OFF | Flashing | OFF | Flash deleting error |
| Status 9 | Flashing | ON | OFF | Flash writing |
| Status 10 | Flashing | Flashing | OFF | Flash writing error |
| Status 11 | ON | ON | OFF | Verifying |
| Status 12 | ON | Flashing | OFF | Verifying error |
| Status 13 | Low-speed flashing | Low-speed flashing | OFF | Normal completion |

- (Note) If the Flash ROM is removed from or installed to the machine with the machine power ON, the Flash ROM may be destroyed. Be sure to turn off the power of the machine before removing or installing the Flash ROM.

- 14) Remove the Flash ROM (which was upgraded) installed to the ICU MAIN PWB Write socket in procedure 1).

When another Flash ROM is to be upgraded, install it to the ICU PWB Write socket and turn on the power, and perform procedures 11) through 14).

- 2) Install the source Flash ROM (which has the program data of either of ICU PWB, PCU PWB, or operation control PWB) to the ICU PWB Read socket.

- 3) Turn on the power of the machine. Copying is started. When copying is completed, LED3 on the ICU PWB are turned off, and LED1 and LED2 flash at a low speed. It normally takes 30 to 60 sec to copy (write) to the Flash ROM.

- 4) Turn off the power of the machine, and remove the Flash ROM's from the Read and the Write sockets.

(After work)

- 1) Installed the copied Flash ROM to the specified PWB.
- 2) Turn on the power of the machine and check that the machine operates normally.
- 3) Use the simulation 22-5 to check each ROM version.
- 4) Install the shield plate and the stopper shift. (3 screws)
- 5) Attach the right upper cabinet of the machine. (2 screws)

| | LED1 | LED2 | LED3 | Mode |
|---|--------------------|--------------------|------|----------------------------------|
| Display when copying data from Flash ROM to Flash ROM | | | | |
| Status 14 | ON | ON | OFF | ROM copy start |
| Status 15 | OFF | Flashing | OFF | Download ROM not-installed error |
| Status 16 | ON | ON | OFF | ROM capacity checking |
| Status 17 | ON | Flashing | OFF | ROM capacity check error |
| Status 18 | ON | ON | OFF | Flash deleting |
| Status 19 | OFF | Flashing | OFF | Flash deleting error |
| Status 20 | Flashing | ON | OFF | Flash writing |
| Status 21 | Flashing | Flashing | OFF | Flash writing error |
| Status 22 | ON | ON | OFF | Verifying |
| Status 23 | ON | Flashing | OFF | Verifying error |
| Status 24 | Low-speed flashing | Low-speed flashing | OFF | Normal completion |

Status in bold means an error

(2) Operation panel display specifications (SIM 49-1)


The operation panel display status in PC to Flash ROM copying (writing) is shown in the table below.

| Display message | Operation/Content | Countermeasures |
|--|--|---|
| NOW EXECUTING ... | Simulation start | |
| THIS COPIER IS NOT CONNECTED TO PC. | The cable is not connected. | Turn off the power of the copier machine, and check the connection again. |
| FLASH ROM ISN'T INSERTED INTO A CONNCTOR. | The writing Flash ROM is not inserted into the socket. | Turn off the copier machine, insert the Flash ROM. |
| WAITING FOR DATA | Waiting for starting the Flash ROM writing software on PC side | Boot the software for writing to Flash ROM on PC. |
| ERASING FLASH ... | Deleting | |
| WRITING FLASH ... | Writing | |
| VERIFYING FLASH ... | Verifying | |
| FLASH ERASE ERROR. | Failure in erase of Flash ROM for writing | Try again, or replace the Flash ROM. |
| FLASH WRITE ERROR. | Failure in copy (write) of Flash ROM for writing | Try again, or replace the Flash ROM. |
| FLASH VERIFY ERROR. | Failure in verifying Flash ROM content for writing | Try again, or replace the Flash ROM. |
| DOWNLOADING NOW ... | Data downloading | |
| DOWNLOAD ERROR. | Data transfer failure | Tray data transfer again, or tray simulation again. |
| FIRMWARE UPGRADE FINISHED. | Data transfer complete | |
| THIS SIMULATION DOES NOT WORK IN THIS ROM VERSION. | Displayed when ICU Flash ROM does not support this simulation. | ICU Flash ROM Version up |


When the power of PC is down during data transfer, data transfer is performed from the beginning.

(In the case of Desk control PWB)

- 1) Remove the desk unit power source cover. (One screw)



- 2) Check that the machine power is off, and connect the PC and the level converter desk unit serial I/F connector and the level converter.




- 3) Turn on the PC, and start Windows.

- 4) Set the data transfer speed of PC.

In the case of Windows 95/98:


- (4-1) Open the "Control panel."




- (4-2) Open the "System."



- (4-3) Click the "Device manager" and click the "Port (COM/LPT)," and double-click the "Communication port (COM*)" to be used.




- (4-4) Set the bit/sec of port set menu to 38400.
If 38400 cannot be set, set either of the following communication speeds.
9600/19200




In the case of Windows 2000:


- (4-1) Open the "Control panel."




- (4-2) Open the "System."





- (4-3) Open the "Device manager" on the hardware menu.




- (4-4) Click the "Port (COM/LPT)", and double-click the "Communication port (COM*)" to be used.




- (4-5) Set the bit/sec of the port set menu to 38400, and click the OK button to close the communication port (COM*) property.
If 38400 cannot be set, set either of the following communication speeds.
9600/19200




- 9) Select the data file to be written.
(9-1) Double-click the Simulation Command List folder.
(9-2) Double-click the Special (Whale Desk) folder.



- (9-3) Double-click the file Program Download, and the following dialog is displayed. Click the OK button.




- (9-4) Then the following dialog is displayed. Click the START button.




- (9-5) The file selection dialog is displayed. Select the data file to be written, and click the Open button.




- 5) Turn on the power of the machine.
6) Enter the simulation 49-10 mode. (Press the EXECUTE key to enter the download (Flash ROM writing) mode.)




- 7) Start the download program on the PC side by double-clicking the Maint.exe file. The following window is indicated.




- 8) Select the communication setup in the option menu, and set the communication speed same as which is set in procedure 4).



- 10) With the above procedures, writing is started and the following display is shown.



- 11) Check on the PC display that writing is completed. (When writing is normally completed, the following dialog is displayed.)




- 12) Turn off the machine power, and disconnect the level converter.

(NOTE) When connecting or disconnecting the level converter, be sure to turn off the machine power in advance. If the level converter is connected or disconnected with the power ON, the level converter may be damaged.


[13] ELECTRIC DIAGRAM

1. Block diagram


A. PCU PWB




B. ICU PWB




C. MFP PWB



D. PRINT CONTROL PWB




2. AC power line diagram




AC POWER LINE DIAGRAM (200V series)

2/2




3. DC power line diagram




(1) POWER SECTION (100V series)




(1) POWER SECTION (200V series)




(2) DRUM DRIVE/DSW SECTION




(3) IMAGE PROCESS SECTION




(4) HIGH VOLTAGE SECTION




(5) MOTOR-DRIVER SECTION




(6) PCU-ICU SECTION




(7) PAPER TRANSPORT SECTION




(8) TRANSFER BELT SECTION




(9) FUSING SECTION (100V series)




(9) FUSING SECTION (200V series)




(10) PAPER EXIT SECTION




(11) MANUAL PAPER FEED SECTION




(12) LED-HEAD SECTION




(13) DESK SECTION




(14) IMAGE SCANNER SECTION



(15) OPERATION SECTION



(16) ICU SECTION



5. Signal list

| Signal name | Name | Function/Operation | Section |
|----------------------|---|---|----------------|
| AOSW | ADF open switch | Detects ADF open. | AR-RF3 |
| APAM | Alignment motor | Aligns paper in ADU. | AR-D19 |
| APHPS | Alignment plate home position detection | Detects the alignment plate in ADU. | AR-D19 |
| APPD1 | ADU transport sensor 1 | Detects paper transport in ADU. | AR-D19 |
| APPD2 | ADU transport sensor 2 | Detects paper transport in ADU. | AR-D19 |
| ARHPS | Bundle roller HP sensor | | AR-F13 |
| AS | Alignment tray sensor | | AR-F13 |
| ATM | ADU transport motor | Drives the paper transport section in ADU. | AR-D19 |
| ATRC | ADU transport clutch | Controls ON/OFF of the transport roller in ADU. | AR-D19 |
| BDD | Door open detection 1 | Detects upper door open. | AR-RB1 |
| BDD2 | Door open detection 2 | Detects left door open. | AR-RB1 |
| BES | Tray paper sensor | | AR-F13 |
| BGSOL | Gate solenoid | Switches straight or reverse paper exit. | AR-RB1 |
| BIM | Paper entry motor | Transports paper in the paper entry section. | AR-RB1 |
| BLUD | Belt lift-up upper limit detection | Detects if the transfer belt is lifted up or down. | Main machine |
| BLUM | Belt lift-up motor | Lifts the transfer belt unit. | Main machine |
| BPDF | Full sensor | Detects paper full on the tray. | AR-RB1 |
| BPOD | Paper exit sensor | Detects paper exit. | AR-RB1 |
| BPPD1 | Transport sensor 1 | Detects paper transport. | AR-RB1 |
| BPPD2 | Transport sensor 2 | Detects paper transport. | AR-RB1 |
| BPRD | Reverse section sensor | Detects paper presence in the reverse section. | AR-RB1 |
| BRM | Upper reverse motor | Transports paper in the upper section. | AR-RB1 |
| BTM | Transport belt motor | Drives the transfer belt. | Main machine |
| BTM | Lower reverse motor | Transports paper in the lower section. | AR-RB1 |
| BTNF | Belt waste toner detection | Detects belt waste toner full. | Main machine |
| C1SS1 | 1 cassette paper size detection 1 | Detects the paper size which is set by the paper size set block. | Main machine |
| C1SS2 | 1 cassette paper size detection 2 | Detects the paper size which is set by the paper size set block. | Main machine |
| C1SS3 | 1 cassette paper size detection 3 | Detects the paper size which is set by the paper size set block. | Main machine |
| C1SS4 | 1 cassette paper size detection 4 | Detects the paper size which is set by the paper size set block. | Main machine |
| CALS | Calibration plate open/close solenoid | Switches image density sensors. | Main machine |
| CPFC1 | Paper feed clutch | Transmits the paper feed motor power to each transport roller. (Controls ON/OFF.) | Main machine |
| DCSPSx | Paper remaining quantity sensor | Detects the remaining quantity of paper. | AR-D17/D18 |
| DCSSx | Paper size sensor | Detects the paper size. | AR-D17/D18/D19 |
| DDOPD | Door open sensor | Detects opening of the right door. | AR-D17/D18 |
| DEM | Reverse motor | Reverses or discharges documents. | AR-RF3 |
| DEOS | Paper exit open sensor | Detects opening of the paper exit cover. | AR-RF3 |
| DES | Paper exit sensor | Detects that a document has been transported to the paper exit sensor section. | AR-RF3 |
| DFM | Paper feed motor | Feeds a document from the tray. | AR-RF3 |
| DFOS | Paper feed open sensor | Detects opening of the paper feed cover. | AR-RF3 |
| DFSW | Paper feed open switch | Detects opening of the paper feed cover. | AR-RF3 |
| DH | Dehumidifier heater | Dehumidifier heater for the machine cassette. | Main machine |
| DH (Japan only) | Dehumidifier heater 1 | Dehumidifies the scanner section. | Main machine |
| DH (Japan only) | Dehumidifier heater 2 | Dehumidifies the lens section. | Main machine |
| DHSW (Japan only) | Dehumidifier heater switch | Turns ON/OFF the power line of the dehumidifier heaters provided in the scanner (reading) section and the paper feed section. | Main machine |
| DLMx | Lift motor | Drives the lift plate. | AR-D17/D18/D19 |
| DLS1 | Tray document length sensor 1 | Detects the document length on the tray. (Short) | AR-RF3 |
| DLS2 | Tray document length sensor 2 | Detects the document length on the tray. (Long) | AR-RF3 |
| DLUDx | Paper upper limit sensor | Detects the paper upper limit position. | AR-D17/D18/D19 |
| DM | Paper feed drive motor | Drives the paper feed section and the paper transport section. | AR-D17/D18/D19 |
| DM_C | Drum motor (C) | Drives the Cyan photoconductor unit. | Main machine |
| DM_K | Drum motor (K) | Drives the Black photoconductor unit. | Main machine |
| DM_M | Drum motor (M) | Drives the Magenta photoconductor unit. | Main machine |
| DM_Y | Drum motor (Y) | Drives the Yellow photoconductor unit. | Main machine |
| DPEDx | Paper empty sensor | Detects paper presence on the paper tray. | AR-D17/D18/D19 |
| DPFCx | Paper feed clutch | Controls ON/OFF of the paper feed roller. | AR-D17/D18/D19 |
| DPFSx | Pickup solenoid | Presses the paper pickup roller onto paper. | AR-D17/D18/D19 |
| DPPD1 | Paper transport sensor 1 | Detects paper transport. | AR-D17/D18/D19 |
| DPPD2 | Paper transport sensor 2 | Detects paper transport. | AR-D17/D18 |
| DPPD3 | Paper transport sensor 3 | Detects paper transport. | AR-D17/D18 |

| Signal name | Name | Function/Operation | Section |
|-------------|--|---|----------------|
| DRS | Reverse sensor | Detects that a document has been transported to the reverse sensor section. | AR-RF3 |
| DRSOL | Reverse solenoid | Switches the flapper in duplex operation. | AR-RF3 |
| DSWF | Front door open detection | Detects opening of the front door. | Main machine |
| DSWL | Paper exit door open detection | Detects opening of the paper exit door. | Main machine |
| DSWR | Paper feed door open detection | Detects opening of the paper feed door. | Main machine |
| DTM | Transport motor | Transports a document on the document glass, | AR-RF3 |
| DTRC | Transport clutch | Controls ON/OFF of the transport roller. | AR-D17/D18/D19 |
| DUSTPTR | Punch dust full sensor | Detects punch dust full. | AR-F13 |
| DWVR | Document width detection volume | Detects the document width on the tray. | AR-RF3 |
| EMPS | Empty sensor | Detects document presence on the paper feed tray. | AR-RF3 |
| ES | Entry port sensor | | AR-F13 |
| FAM | Bundle exit sensor | | AR-F13 |
| FDS | Front door sensor | | AR-F13 |
| FDSW | Front door switch | | AR-F13 |
| FE | Bookbinding clock sensor | | AR-F13 |
| FES | Bookbinding paper sensor | | AR-F13 |
| FFJM | Alignment motor (F) | | AR-F13 |
| FFM | Transport motor | | AR-F13 |
| FFSM | Stapler/Folding motor staple operation/ Paper folding operation | | AR-F13 |
| FHPS | Bookbinding HP sensor | | AR-F13 |
| FJHPS | Alignment HP sensor | | AR-F13 |
| FLM | Shift motor | | AR-F13 |
| FOS | ADF front open sensor | Detects opening of ADF. | AR-RF3 |
| FPM | Paddle motor oscillation guide drive, discharge to offset tray | | AR-F13 |
| FPNM | Punch motor | | AR-F13 |
| FPS | Bookbinding position sensor | | AR-F13 |
| FPSM | Puncher side registration motor | | AR-F13 |
| FRHPS | Bookbinding roller HP sensor | | AR-F13 |
| FRJM | Alignment motor (R) | | AR-F13 |
| FSM | Slide motor staple unit shift | | AR-F13 |
| FUSM | Fusing drive motor | Drives the fusing unit. | Main machine |
| GSS | Face up/down switch gate solenoid | Drives the face-up/down switch gate. | Main machine |
| HLTS1 | Upper heat roller thermostat | Detects an abnormally high temperature to turn off the heater lamp. | Main machine |
| HLTS2 | Lower heat roller thermostat | Detects an abnormally high temperature to turn off the heater lamp. | Main machine |
| HPOS | Offset home position sensor | Detects the offset home position. | Main machine |
| HUD | Humidity sensor | Detects the humidity. | Main machine |
| JS | Joint switch | | AR-F13 |
| LDD | Lower limit detector | | AR-LC5 |
| LE | Lift lock sensor | | AR-F13 |
| LEDONx | Paper size sensor | Detects the paper size. | AR-F13 |
| LLLS | Lift lower limit sensor | | AR-F13 |
| LLM | Lift-up motor | | AR-LC5 |
| LLSW | Upper limit lock switch | | AR-LC5 |
| LPED | Paper detector | | AR-LC5 |
| LPFC | Paper clutch | | AR-LC5 |
| LPFD | Transport detector | | AR-LC5 |
| LPFM | Paper feed and transport motor | | AR-LC5 |
| LPFS | Pick-up solenoid | | AR-LC5 |
| LRES | Encoder sensor | | AR-LC5 |
| LTOD | Copier connection detector | | AR-LC5 |
| LTRC | Paper feed clutch | | AR-LC5 |
| LUD | Upper limit detector | | AR-LC5 |
| LUD1 | 1 cassette lift-up upper limit detection | Detects the paper upper limit position. | Main machine |
| LUM1 | 1 cassette lift-up motor | Drives the lift plate. | Main machine |
| MHPS | Mirror home position sensor | Detects the scanner home position. | Main machine |
| MPED | Manual feed paper empty sensor | Detects paper presence on the paper tray. | Main machine |
| MPFC | Manual paper feed clutch | Controls ON/OFF of the paper feed roller. Presses the paper pickup roller onto paper. | Main machine |
| MPLD1 | Manual paper length detection 1 | Detects the paper length. | Main machine |
| MPLD2 | Manual paper length detection 2 | Detects the paper length. | Main machine |

| Signal name | Name | Function/Operation | Section |
|-------------|--|---|--------------|
| MPWS | Manual paper width detection | Detects the paper width. | Main machine |
| MSW | Main switch | Turns ON/OFF the main power. | Main machine |
| MTOP1 | Manual tray pull-out detection 1 | Detects the paper tray position. | Main machine |
| MTOP2 | Manual tray pull-out detection 2 | Detects the paper tray position. | Main machine |
| MTRC | Manual feed drive clutch | Transmits drive power to the manual paper feed unit. | Main machine |
| OBHPS | Paper exit belt HP sensor | | AR-F13 |
| OCSW | O/G open sensor | Detects opening of the document cover. (Generates the document size detection timing signal.) | Main machine |
| OSM | Offset motor (Slide motor) | Drives the paper offset. | Main machine |
| PCFM | Process cooling fan motor | Exhaust and cools the process section. | Main machine |
| PCS_C | Color toner concentration (process control) sensor | Detects the toner patch density (color toner) in image density correction. | Main machine |
| PE | Punch motor encoder | | AR-F13 |
| PED1 | 1 cassette paper empty detection | Detects paper presence on the paper tray. | Main machine |
| PFD1 | 1 cassette paper feed detection | Detects paper delivery from No. 1 paper tray. | Main machine |
| PFM | Paper feed motor | Drives the paper feed section and the paper transport section. | Main machine |
| PHPS | Paddle HP sensor | | AR-F13 |
| POD1 | Machine paper exit sensor 1 | Detects discharged paper. | Main machine |
| POD2 | Machine paper exit sensor 2 | Detects discharged paper. | Main machine |
| PPD1 | No. 1 paper transport sensor | Detects paper in front of the resist roller. | Main machine |
| PPD2 | PS front sensor | Detects paper in front of PS. | Main machine |
| PSFM | Power UN cooling fan motor | Cools the power unit. | Main machine |
| PSHPS | Punch side registration home position | | AR-F13 |
| PSM | PS motor | Drives the resist roller and controls ON/OFF. | Main machine |
| PUNCH | Punch home position | | AR-F13 |
| PWMFAN_ICU | Printer controller cooling fan motor | Cools the printer controller. | Main machine |
| REGS | Resist sensor | Detects that a document has been transported to the resist roller sensor section. | AR-RF3 |
| RJHPS | Alignment HP sensor R | | AR-F13 |
| SHPS | Slide HP sensor | | AR-F13 |
| SLS | Paper surface sensor | | AR-F13 |
| SM | Scanner motor | Drives the scanner unit. | Main machine |
| SPS | Staple sensor | Detects staple empty. | AR-F13 |
| SS | Staple cartridge sensor | Detects installation of a staple cartridge. | AR-F13 |
| SSS | Stapler safety switch | | AR-F13 |
| STHPS | Stapler HP sensor | | AR-F13 |
| TCS | Upper cover sensor | | AR-F13 |
| TES_C | Toner empty sensor (C) | Detects toner empty (C). | Main machine |
| TES_K | Toner empty sensor (K) | Detects toner empty (K). | Main machine |
| TES_M | Toner empty sensor (M) | Detects toner empty (M). | Main machine |
| TES_Y | Toner empty sensor (Y) | Detects toner empty (Y). | Main machine |
| TFD2 | Paper exit tray full detection | Detects face-down paper exit tray full. | Main machine |
| TFD2 | Face-up paper exit tray full detection | Detects face-up paper exit tray full. | Main machine |
| THSD | Lower heat roller thermistor | Detects the temperature on the heat roller surface. | Main machine |
| THSU | Upper heat roller thermistor | Detects the temperature on the heat roller surface. | Main machine |
| TIMS | Timing sensor | Detects that a document has been transported to the timing sensor section. | AR-RF3 |
| TRC | PS front clutch | Transmits the paper feed motor power to the manual transport roller. (Controls ON/OFF.) | Main machine |
| ULS | Lift upper limit sensor | | AR-F13 |
| VFMP | Exhaust fan motor 1 | Exhaust and cools the fusing section. | Main machine |
| VFMS | Exhaust fan motor 2 | Exhaust and cools the fusing section. | Main machine |


[14] OTHERS

1. Key operator program

A. Classification of set items

The set items of the key operator program are classified into the following three levels:

* Some items have further lower levels (set menus).



2. Special tools

| No | Name | Part code | Purpose | Note |
|----|--|--------------------------------------|---|--|
| 1 | SIT chart (CCD gamma adjustment chart) | UKOG-0280FCZZ | Used to correct CCD gamma characteristics. | |
| 2 | Service color test chart | UKOG-0283FCZZ | Used to check color copy quality. | |
| 3 | Gray scale chart | UKOG-0162FCZZ | Used to check copy density. | |
| 4 | Service color test chart for printer | UKOG-0305FCZZ | | New |
| 5 | Image density sensor adjustment jig | CPLTM6305FC01 | Used to adjust the image density sensor. (Plate with calibration sheet) | New |
| | | TLABZ4843FCZZ | Calibration sheet | New (for replacement) |
| 6 | Extension cable for measure high voltage | DHAI-3471FCZZ | Used to check the MC grid and DV bias voltage (Color) | New |
| 7 | | DHAI-3472FCZZ | Used to check the MC grid and DV bias voltage (Black) | New |
| 8 | Starting powder | UKOG-0123FCZZ | Used to reduce friction between the transfer belt and the transfer belt cleaning blade. | |
| 9 | Cleaning cloth | UKOG-0289FCZZ | Used to clean the optical system. Wash to reuse. | |
| 10 | Level converter | UKOG-0002QSZZ (with serial cable) | Used to download the FLASH ROM program from a PC to the FLASH ROM on the machine. | Commercially available serial cable can be used. |
| | | UKOG-0003QSZZ (without serial cable) | | |
| 11 | FLASH ROM download program file | Mainte_xxxx.exe | Download (upgrade) the FLASH ROM program for main body section | |
| 12 | | WDskxxx_d.pgm | Download (upgrade) the FLASH ROM program for Desk unit | |
| 13 | Spare FLASH ROM | | FLASH ROM (16Mbit x 2) 1pc | The type (capacity) of Flash ROM is determined depending on the kind of Flash ROM (in the PCU PWB, in the ICU PWB, Printer control PWB or in the operation control PWB). |
| 14 | | | FLASH ROM (16Mbit) 1pc | |
| 15 | | | FLASH ROM (8Mbit) 2pcs | |
| 16 | | | FLASH ROM (32Mbit x 2) 2pcs | |
| 17 | Magnifying glass | | Picture quality check (Mainly the color registration is checked.) | Purchase a commercially available one. (Magnification ratio:20 - 25) |

Memo

[illegible]

Memo

[illegible]

Memo

[illegible]

CAUTION FOR BATTERY REPLACEMENT

(Danish) ADVARSEL !

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Levér det brugte batteri tilbage til leverandoren.

(English) Caution !

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the manufacturer.

Dispose of used batteries according to manufacturer's instructions.

(Finnish) VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan
tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden
mukaisesti.

(French) ATTENTION

Il y a danger d'explosion s'il y a remplacement incorrect
de la batterie. Remplacer uniquement avec une batterie du
même type ou d'un type équivalent recommandé par
le constructeur.

Mettre au rebut les batteries usagées conformément aux
instructions du fabricant.

(Swedish) VARNING

Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens
instruktion.

(German) Achtung

Explosionsgefahr bei Verwendung inkorrektter Batterien.
Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder
vom Hersteller empfohlene Batterien verwendet werden.
Entsorgung der gebrauchten Batterien nur nach den vom
Hersteller angegebenen Anweisungen.

CAUTION FOR BATTERY DISPOSAL

(For USA, CANADA)

Contains lithium-ion battery. Must be disposed of properly.
Remove the battery from the product and contact
federal or state environmental
agencies for information on recycling and disposal options.



COPYRIGHT © 2003 BY SHARP CORPORATION

All rights reserved.

Printed in Japan.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic; mechanical; photocopying; recording or otherwise
without prior written permission of the publisher.

Trademark Acknowledgments

Microsoft Windows, MS-DOS, Windows NT, Windows 2000 are trademarks of Microsoft Corporation in the U. S. A. and other countries.

Macintosh, Power Macintosh, Mac OS, LaserWriter, and AppleTalk are registered trademarks of Apple Computer, Inc.

IBM, PC/ AT, and PowerPC are trademarks of International Business Machines Corporation.

Pentium is a registered trademark of Intel Corporation.

PCL is a trademark of the Hewlett- Packard Company.

PostScript® is a registered trademark of Adobe Systems Incorporated.


NetWare is a registered trademark of Novell, Inc.

All other trademarks and copyrights are the property of their respective owners.

SHARP CORPORATION
Digital Document System Group
Products Quality Assurance Department
Yamatokoriyama, Nara 639-1186, Japan
2003 March Printed in Japan

SHARP CIRCUIT DIAGRAM

CODE: 00ZARC260/C1/



DIGITAL FULL COLOR COPIER

デジタルフルカラー
複合機

MODEL AR-C260

CONTENTS


| | | | |
|--|-------|----------------------------|-------|
| [1] BLOCK DIAGRAM | 1-1 | [1] ブロックダイアグラム | 1-1 |
| [2] PWB LOCATION CHART | 2-1 | [2] 基板 (PWB) ローケーション | 2-1 |
| [3] ACTUAL WIRING CHART | 3-1 | [3] 実体配線図 | 3-1 |
| [4] CIRCUIT DIAGRAM AND PARTS LAYOUT ... | 4-1 | [4] 回路図と部品配置図 | 4-1 |
| A. PCU PWB | 4-1 | A. PCU PWB | 4-1 |
| B. ICU PWB | 4-21 | B. ICU PWB | 4-21 |
| C. MFPC2 PWB | 4-69 | C. MFPC2 PWB | 4-69 |
| D. SCANNER I/F PWB | 4-101 | D. スキャナIF PWB | 4-101 |
| E. OPE KEY PWB | 4-107 | E. オペキー PWB | 4-107 |
| F. PROCESS CONTROL PWB | 4-111 | F. プロセスコントロール PWB | 4-111 |
| G. LED-DL PWB | 4-113 | G. LED-DL PWB | 4-113 |
| H. LVDS/INV PWB | 4-115 | H. LVDS/INV PWB | 4-115 |
| I. DRIVER PWB | 4-118 | I. ドライバー PWB | 4-118 |
| J. HDD PWB | 4-123 | J. HDD PWB | 4-123 |
| K. PRINT CONTROL PWB | 4-130 | K. プリントコントローラ PWB | 4-130 |
| L. MDMC PWB | 4-179 | L. MDMC PWB | 4-179 |
| M. TEL/LIU PWB (JAPAN) | 4-207 | M. TEL LIU (JAPAN) | 4-207 |
| N. POWER SUPPLY PWB | 4-213 | N. 電源回路 | 4-213 |

Parts marked with “△” are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.



安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。

△印の商品は、安全上重要な部品です。交換をする時は、安全および性能維持のため必ず指定の部品をご使用下さい。

[1] BLOCK DIAGRAM / ブロックダイアグラム



[2] PWB LOCATION CHART / 基板 (PWB) ロケーション




| No. | パーツ | | 略称・信号名 | タイプ |
|-----|----------------|---|--------|-----|
| | 名 称 | 機 能・動 作 | | |
| 1 | CL インバータ基板 | キセノンランプを駆動する | | |
| 2 | MFP 基板 | CCD から出力されたイメージの各種補正、操作パネルのコントロール | | |
| 3 | フラッシュ基板 (OP) | OP 基板を動作させるプログラムが入った基板 | | |
| 4 | フラッシュ基板 (MFP) | MFP 基板を動作させるプログラムが入った基板 | | |
| 5 | 原稿検知発光基板 | 原稿サイズ検知 LED の発光 | | |
| 6 | CCD 基板 | 原稿イメージを電気信号に変換する | | |
| 7 | リフト UP 基板 | カセットサイズ検知、カセットリフトアップモータ信号中継 | | |
| 8 | 手差し VR 基板 | 手差し幅信号出力 | | |
| 9 | プロコン基板 (モノクロ用) | 転写ベルト上のモノクロトナー濃度を出力 | | |
| 10 | プロコン基板 (カラー用) | 転写ベルト上のカラートナー濃度を出力 | | |
| 11 | 原稿検知受光基板 | 原稿サイズ検知信号出力 | | |
| 12 | 操作基板 | キー操作信号を出力する | | |
| 13 | INV/LVDS 基板 | MFP 基板からの LCD、タッチパネル信号の中継、LCD バックライトの駆動 | | |
| 14 | フラッシュ基板 (ICU) | ICU 基板を動作させるプログラムが入った基板 | | |
| 15 | ICU 基板 | 画像処理、LED ヘッドのコントロール | | |
| 16 | PCU 基板 | エンジンセクションをコントロールする | | |
| 17 | DRIVER 基板 | DC 負荷電源の制御、モータ駆動 | | |
| 18 | AC 電源基板 | 1 次側の電源コントロール | | |
| 19 | LED DL 基板 | 感光体上の電荷を除電する | | |
| 20 | フラッシュ基板 (PCU) | PCU 基板を動作させるプログラムが入った基板 | | |
| 21 | 高圧 TC 基板 | 転写電圧を発生する | | |
| 22 | DC 電源基板 | 2 次側の電圧出力、HL コントロール | | |
| 23 | 高圧 MC 基板 | メインチャージャー用高圧と現像バイアス電圧を発生する | | |

英文リスト




[3] ACTUAL WIRING CHART / 実体配線図


(1) AC CIRCUIT SECTION (JAPAN) / AC回路部(JAPAN)




(1) AC CIRCUIT SECTION (EX100) / AC回路部 (EX100)




(1) AC CIRCUIT SECTION (EX200) / AC回路部(EX200)




(2) DRUM DRIVE/DSW SECTION / ドラムドライブ/DSW部




(3) PROCESS SECTION / プロセス部




(4) HIGH VOLTAGE UNIT / 高圧ユニット




(5) PCU-DRIVER SECTION / PCUドライバ部







(7) TRANSPORT SECTION / 搬送部




(8) TRANSPORT BELT UNIT / 搬送ベルトユニット




(9) FUSING UNIT (100V) / 定着ユニット(100V)




(9) FUSING UNIT (200V) / 定着ユニット(200V)




(10) DELIVERY SECTION / デリバリー部




(11) MANUAL PAPER FEEDING / 手差し給紙部




(12) LED-HEAD SECTION / LEDヘッド部




(13) OPTION UNIT / オプションユニット







(15) OPERATION UNIT / オペレーションユニット



(16) ICU SECTION / ICU部




WHALE
ICU
PWB



PRTC
PWB


[4] CIRCUIT DIAGRAM AND PARTS LAYOUT / 回路図と部品配置図


A. PCU PWB







PCU PWB (CPU Section)







PCU PWB (SRAM, EEPROM, Flash Memory, Mini-OP Section)







PCU PWB (I/O Gate Array Section)







PCU PWB (A/D,D/A Convert Section)







PCU PWB (Matrixed Sensing INPUT Section)








PCU PWB (Option UART & CRUM & Coin Vendor section)





PCU PWB (2003 & HV & Interface Section)





PCU PWB (Motor Driver Section)

The diagram illustrates the motor driver section of the PCU PWB, featuring three channels (A, B, and C) and their connection to the BTM and DMK boards.

Channel A:

- Inputs: $\langle 4 \rangle$ PMC3A, $\langle 4 \rangle$ PMC3B, $\langle 4 \rangle$ nPMC3A, $\langle 4 \rangle$ nPMC3B.
- Transformer: BR30 (47KJX4).
- Driver IC: IC28 (SLA7031M).
- Resistors: R153 (1KJ), R147 (220J), R139 (1J 2W), R138 (1J 2W), R160 (nm_2KJ).
- Capacitors: C95 (0.1uF), C88 (22000pF(1608/50V)).
- Motor: Q46 (nm_DTC114YUA).
- Currents: Normal : $i_o = 0.60A$ (1.0K/220), Slow : $i_o = 0.54A$ (1.0K/220/2KJ).

Channel B:

- Inputs: $\langle 4 \rangle$ PMC1A, $\langle 4 \rangle$ PMC1B, $\langle 4 \rangle$ nPMC1A, $\langle 4 \rangle$ nPMC1B.
- Transformer: BR37 (47KJX4).
- Driver IC: IC2 (SLA7032M).
- Resistors: R28 (2KJ), R27 (1KJ), R22 (1J 2W), R21 (1J 2W), R23 (0J), R18 (0J), R29 (nm_1.6KJ).
- Capacitors: C9 (0.1uF), C8 (0.1uF), C10 (0.02J), C12 (nm_2200pF).
- Motor: Q17 (nm_DTC114YUA).
- Currents: Normal : $i_o = 1.1A$ (2K/1K), Slow : $i_o = 0.78A$ (2K/1K/1.6K).

Channel C:

- Inputs: $\langle 4 \rangle$ PMC0A, $\langle 4 \rangle$ PMC0B, $\langle 4 \rangle$ nPMC0A, $\langle 4 \rangle$ nPMC0B.
- Transformer: BR39 (47KJX4).
- Driver IC: IC1 (SLA7031M).
- Resistors: R5 (1.6KJ), R7 (390J), R26 (1J 2W), R25 (1J 2W), R8 (nm_680J).
- Capacitors: C1 (0.1uF), C2 (22000pF(1608/50V)).
- Motor: Q6 (nm_DTA114YUA).
- Currents: Normal : $i_o = 0.65A$ (1.6K/390), Slow : $i_o = 0.44A$ (1.6K/390/680).

Connections:

- Channel A: PSM_A, PSM_AI, PSM_B, PSM_BI.
- Channel B: DMK_A, DMK_AI, DMK_B, DMK_BI.
- Channel C: BTM_A, BTM_AI, BTM_B, BTM_BI.

Additional Components:


- MTCON: Motor Thermal Control.
- MCONOUT: Motor Control Output.
- NEAR the MOTOR DRIVE LINE: 470uF/35V capacitor.




[PARTS SURFACE / 部品面]




AR-C260 CIRCUIT DIAGRAM AND PARTS LAYOUT / 回路図と部品配置図 4-21





ICU PWB (CPU)







ICU PWB (IOASIC)





ICU PWB (CPUBUS)











ICU PWB (MEM)

【標準画像FLASH】


【オプション画像FLASH】



【バックアップSRAM】





【EEPROM】



オン画像FLASH]


【プログラムFLASH】


[DOWNLOAD FLASH]









EEPCE (3)

ICU PWB (PCU I/F)









ICU PWB (BAT & RESET & RTC)






ICU PWB (RIC)






ICU PWB (POWER)



電源の行き先


| | |
|--------|----------|
| +24V | PRTC |
| +5V | ICU,PRTC |
| +5V | ICU,PRTC |
| +5VN | LED-HEAD |
| +3.3V | ICU,PRTC |
| +3.3V | ICU,PRTC |
| +3.3VN | LED-HEAD |
| GND | |
| GND | |
| GND | |

SH-3



,19,20,21,22,23)

ICUASIC



ICU PWB (ICU ASIC LED/MFP/PRTC)

(9)

(2,3,4,5,6,7,8,9,11,12,13,14,15,16,17,18,19,20,21,22,23)

(1,2,3,4,5,6,7,8,9,11,12,13,14,15,16,17,18,19,20,21,22,23)

(14) MFP_KD[3:0]

(14) MFP_CD[3:0]

(14) MFP_MD[3:0]

(14) MFP_YD[3:0]

(14) MFP_SEL

(14) MFP_LD_GT

(21) LEDC_HSYNCB

(17) LEDC_HSYNCB1

(17,21) LEDC_VSYNCB_K

(17,21) LEDC_VSYNCB_C

(17,21) LEDC_VSYNCB_M

(17,21) LEDC_VSYNCB_Y

(17) ICU_LEDDK[3:0]

(17) ICU_LEDDC[3:0]

(17) ICU_LEDDM[3:0]

(17) ICU_LEDDY[3:0]

(21) ECLK

(17) LEDCLK_ICU

IC33A

MFP_KD3 V3

MFP_KD2 W1

MFP_KD1 W2

MFP_KD0 W4

CD3 Y4

CD2 AA2

CD1 W3

CD0 Y2

MD3 AA3

MD2 AB2

MD1 Y3

MD0 AA1

YD3 AD2

YD2 AC2

YD1 AC1

YD0 AB1

SEL U1

LD_GT V2

P2CLK R440 1k 10J AD1

IC23E 74LCX14

IC23F 74LCX14

R190 1k 2 X 47J

R188 1k 2 0J

B24

C23

B23

B22

A23

XC LSUDK3 C21

XC LSUDK2 B21

XC LSUDK1 D20

XC LSUDK0 A22

XC LSUDC3 C20

XC LSUDC2 A20

XC LSUDC1 B20

XC LSUDC0 A21

XC LSUDM3 C19

XC LSUDM2 A19

XC LSUDM1 D18

XC LSUDM0 B19

XC LSUDY3 C18

XC LSUDY2 B17

XC LSUDY1 D18

XC LSUDY0 B18

XC LSULXU C22

XC LSULK A25

SOR3 N3

SOR2 P1

SOR1 P4

SOR0 P2

XC SOR3 1

XC SOR2 2

XC SOR1 3

XC SOR0 4

BR100 47Jk4

SOG3 T2

SOG2 R1

SOG1 P3

SOG0 R2

XC SOG3 1

XC SOG2 2

XC SOG1 3

XC SOG0 4

BR99 47Jk4

SOB3 U2

SOB2 R4

SOB1 T1

SOB0 R3

XC SOB3 1

XC SOB2 2

XC SOB1 3

XC SOB0 4

BR98 47Jk4

SOSEL M3

SOLD_GT T3

XC SOSEL R444 1k 2 47J

XC SOLD_GT R443 1k 2 47J

SOP2CLK Y1

R441 1k 2 10J

DS2CLK_ICU

XDSHSYNC G2

XC XDSHSYNC R445 1k 2 47J

XDSVSYNCK G1

XDSVSYNCC G3

XDSVSYNCM H2

XDSVSYNCA J4

XC XDSVSYNCK 1

XC XDSVSYNCC 2

XC XDSVSYNCM 3

XC XDSVSYNCA 4

BR105 47Jk4

PRT_KD[3:0]

PRT_CD[3:0]

PRT_MD[3:0]

PRT_YD[3:0]

PRT_KD3 J1

PRT_KD2 J2

PRT_KD1 H3

PRT_KD0 H1

PRT_CD3 K4

PRT_CD2 K1

PRT_CD1 J3

PRT_CD0 K2

PRT_MD3 M2

PRT_MD2 L1

PRT_MD1 K3

PRT_MD0 L2

PRT_YD3 M4

PRT_YD2 N2

PRT_YD1 L3

PRT_YD0 M1

DPCLK A3

R447 1k 2 10J

DPCLK_ICU

EFCLK V1

EFCLK B1

uPD85672S1-011-F6

LEDC

ECLKA

R302

X_J

R305

R303

10KJ

DGND

C138

X_150pF

DGND

クロックライン終端部

P2CLK

R439

X_J

R452

X_J

R451

X_J

DGND

C221

X_150pF

DGND

クロックライン終端部

DS2CLK_ICU

R453

X_J

R455

X_J

R454

X_J

DGND

C227

X_150pF

DGND

クロックライン終端部

DPCLK_ICU

R467

X_J

R464

X_J

R474

10KJ

DGND


C245


X_150pF






DGND

クロックライン終端部


ICU PWB (ICU ASIC SDRAM/JBIG/SH3)









ICU PWB (PM-2500)




PM-2500



ICU PWB (MFPIF & FPDLINK)









ICU PWB (PORT MFP)


CONNECTOR(MFP)


CONNECTC




CONNECTOR(MFP)










ICU PWB (DATA SELECT)







GATE1:GATE2
0:1 THROUGH MODE
1:0 ICU ASIC MODE




(1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,19,20,21,22,23)






CPUCLK: 29.4912MHz







ICU PWB (SDCLK/SYSCLK/JBIGCLK)




(SYSCLK/JBIGCLK
49.408MHz)




(JBIGCLK xxMHz)




CLK 66MHz


















ICU PWB (LEDASIC, SYSCLK, SSCI/F)







ICU PWB (LPH Connectors)




LEDヘッドのステイタスマニタ
LIGHT to Error



ICU PWB (PWM D/A, PCU I/F)







ICU PWB


PARTS LAYOUT / 部品配置図


[PARTS SURFACE / 部品面]







C. MFPC2 PWB







MFPC2 PWB (I/O)







MFPC2 PWB (I/O)







MFPC2 PWB (CCD A/D)






MFPC2 PWB (CCD A/D)







MFPC2 PWB (CCD A/D)




MFPC2 PWB (SCN-ASIC)







MFPC2 PWB (INPUT PROCESS ASIC, IPD-ASIC)




MFPC2 PWB (AREA SEPARATION ASIC)



















MFPC2 PWB (LVDS & FCRAM & NAND & CONNECTOR)







MFPC2 PWB (OPE CONTROL CPU)







MFPC2 PWB (FLASH & LCDC)










MFPC2 PWB (A/D & UART & OUTPUT)









MFPC2 PWB (OPE CONTROL CONNECTOR)





D. SCANNER I/F PWB / スキャナ I/F PWB





| | | | |
|---------|-----|------|---------|
| PCICLK | ○TP | TP26 | PCICLK |
| PCIINTN | ○TP | TP46 | PCIINTN |
| PCIRSTN | ○TP | TP61 | PCIRSTN |
| PCIREQN | ○TP | TP37 | PCIREQN |
| PCIGNTN | ○TP | TP49 | PCIGNTN |
| DEVSELN | ○TP | TP60 | DEVSELN |
| IDSEL | ○TP | TP54 | IDSEL |
| IRDYN | ○TP | TP33 | IRDYN |
| TRDYN | ○TP | TP55 | TRDYN |
| FRAMEN | ○TP | TP29 | FRAMEN |
| STOPN | ○TP | TP42 | STOPN |
| PERRN | ○TP | TP34 | PERRN |
| SERRN | ○TP | TP32 | SERRN |
| LOCKN | ○TP | TP65 | LOCKN |
| C_BE0N | ○TP | TP44 | C_BE0N |
| C_BE1N | ○TP | TP16 | C_BE1N |
| C_BE2N | ○TP | TP41 | C_BE2N |
| C_BE3N | ○TP | TP38 | C_BE3N |


| | | | |
|--------|-----|------|--------|
| PCIA00 | ○TP | TP71 | PCIA00 |
| PCIA01 | ○TP | TP4 | PCIA01 |
| PCIA02 | ○TP | TP70 | PCIA02 |
| PCIA03 | ○TP | TP3 | PCIA03 |
| PCIA04 | ○TP | TP69 | PCIA04 |
| PCIA05 | ○TP | TP2 | PCIA05 |
| PCIA06 | ○TP | TP68 | PCIA06 |
| PCIA07 | ○TP | TP1 | PCIA07 |


| | | | |
|--------|-----|------|--------|
| PCIA08 | ○TP | TP67 | PCIA08 |
| PCIA09 | ○TP | TP36 | PCIA09 |
| PCIA10 | ○TP | TP66 | PCIA10 |
| PCIA11 | ○TP | TP43 | PCIA11 |
| PCIA12 | ○TP | TP17 | PCIA12 |
| PCIA13 | ○TP | TP56 | PCIA13 |
| PCIA14 | ○TP | TP11 | PCIA14 |
| PCIA15 | ○TP | TP12 | PCIA15 |


| | | | |
|--------|-----|------|--------|
| PCIA16 | ○TP | TP64 | PCIA16 |
| PCIA17 | ○TP | TP53 | PCIA17 |
| PCIA18 | ○TP | TP39 | PCIA18 |
| PCIA19 | ○TP | TP40 | PCIA19 |
| PCIA20 | ○TP | TP63 | PCIA20 |
| PCIA21 | ○TP | TP52 | PCIA21 |
| PCIA22 | ○TP | TP62 | PCIA22 |
| PCIA23 | ○TP | TP30 | PCIA23 |

| | | | |
|--------|-----|------|--------|
| PCIA24 | ○TP | TP20 | PCIA24 |
| PCIA25 | ○TP | TP50 | PCIA25 |
| PCIA26 | ○TP | TP15 | PCIA26 |
| PCIA27 | ○TP | TP45 | PCIA27 |
| PCIA28 | ○TP | TP13 | PCIA28 |
| PCIA29 | ○TP | TP14 | PCIA29 |
| PCIA30 | ○TP | TP18 | PCIA30 |
| PCIA31 | ○TP | TP19 | PCIA31 |

| | | | |
|-------|-----|------|-------|
| SEL | ○TP | TP48 | SEL |
| LD_GT | ○TP | TP51 | LD_GT |
| SCLK | ○TP | TP27 | SCLK |
| SOB76 | ○TP | TP21 | SOR76 |
| SOR54 | ○TP | TP22 | SOR54 |
| SOR32 | ○TP | TP23 | SOR32 |
| SOR10 | ○TP | TP24 | SOR10 |
| SOG76 | ○TP | TP35 | SOG76 |
| SOG54 | ○TP | TP31 | SOG54 |
| SOG32 | ○TP | TP28 | SOG32 |
| SOG10 | ○TP | TP25 | SOG10 |
| SOB76 | ○TP | TP58 | SOB76 |
| SOB54 | ○TP | TP57 | SOB54 |
| SOB32 | ○TP | TP47 | SOB32 |
| SOB10 | ○TP | TP59 | SOB10 |









SCANNER I/F PWB


PARTS LAYOUT / 部品配置図

[PARTS SURFACE / 部品面]



E. OPE KEY PWB / オペキー PWB







OPE PWB / オペキーPWB

PARTS LAYOUT / 部品配置図

[PARTS SURFACE / 部品面]




[SOLDER SURFACE / 半田面]



F. PROCESS CONTROL PWB / プロセスコントロール PWB

PROCESS CONTROL PWB


1/1



PROCESS CONTROL PWB / プロセスコントロールPWB

PARTS LAYOUT / 部品配置図

[PARTS SURFACE / 部品面]






G. LED-DL PWB

LED-DL PWB

1/1

ハーネス直出し

| | |
|---|-----------|
| 1 | DL(BR) |
| 2 | DRINT(BL) |
| 3 | GND2(GY) |




部品面から見た図
[View from parts side]


LED-DL PWB


PARTS LAYOUT / 部品配置図

[PARTS SURFACE / 部品面]




H. LVDS/INV PWB







DRIVER PWB (DC POWER)







DRIVER PWB (MOTOR_DRIVE)








DRIVER PWB (CONNECTER)






3/3



to IC/LED




to OPTION
to AC
to DSWL




DRIVER PWB / ドライバーPWB

PARTS LAYOUT / 部品配置図


[PARTS SURFACE / 部品面]




J. HDD PWB









HDD PWB


5


4

3

2

1





PRINT CONTROL PWB (INFORMATION)


| | |
|--|--|
| PAGE01 : INFORMATION | |
| PAGE02 : SYSTEM CONFIGURATION | |
| PAGE03 : POWER | |
| PAGE04 : XPC785-1 | |
| PAGE05 : XPC785-2 / 60X BUS DUMP RES. | |
| PAGE06 : MPC107-1 (PCI60X) | |
| PAGE07 : MPC107-2(MEMORY INTERFACE / PLL) / JTAG | |
| PAGE08 : CAP(XPC785 / MPC107) | |
| PAGE09 : BOOT ROM / BUFFER | |
| PAGE10 : ON BOARD SDRAM | |
| PAGE11 : SDRAM DIMM SOCKET #0 / #1 | |
| PAGE12 : SDRAM CLKDRV / MEMORY DUMP RES. | |
| PAGE13 : POI SLOT #1 (NIC) #2(HDD)/SONIC SLOT | |
| PAGE14 : TEST PIN | |
| PAGE15 : ENGINE INTERFACE | |
| PAGE16 : D3032 | |
| PAGE17 : RTC / BATTERY / EEPROM | |
| PAGE18 : IEEE1284 IF | |
| PAGE19 : RESET/COOP ON | |
| PAGE20 : D8501A IO BUS BUFFER | |
| PAGE21 : USB INTERFACE (OK) | |
| PAGE22 : FLASH SDIMM | |
| PAGE23 : D8501A-1 | |
| PAGE24 : D8501A-2 | |




PRINT CONTROL PWB (SYSTEM CONFIGURATION)

[MP

[D8501A RESET OPTIONS]



[MPC107 RESET CONFIGURATION] (UM-Section 2.4)



ROM Data Width [MDL(0), FOE]

For ROM/FLASH chip select #0/1

| RCS0 | RCS1 | MDL0 | FOE | MCCR4-bit17 |
|-------|-------|------|-----|-------------|
| (bit) | (bit) | | | |

| | | | | |
|----|----|---|---|---|
| 64 | 64 | 1 | 0 | 0 |
| 64 | 8 | 1 | 0 | 1 |
| 8 | 64 | 1 | 1 | 0 |
| 8 | 8 | 1 | 1 | 1 |

Initial Address Map [SDBA0]

0 : The MPC107 is configured for address map A
(not supported when operating in PCI agent mode)

1 : The MPC107 is configured for address map B

Boot Memory Location [/RCS0]

0 : Indicates that boot ROM is located on the PCI bus

1 : Indicates that boot ROM is located on local processor/memory data bus

MPC107 Host Mode [SDMA10]

0 MPC107 is a PCI agent device

1 MPC107 is a PCI master (host) device

PCI Arbiter [SDMA9]

0 : PCI arbiter enabled

1 : PCI arbiter disabled

Driver capability for MDH[0:31], MDL[0:31], PAR[0:7], and RCS1 [SDMA8]

1 : 20-ohm data bus drive capability; when this is selected,
only 8-ohm or 13.3-ohm drive capability is allowed for SDMA7

0 : 40-ohm data bus drive capability; when this is selected,
only 20-ohm or 40-ohm drive capability is allowed for SDMA7

Driver capability for address signals (RAS/CS[0:7], CAS/DQM[0:7], WE, FOE, RCS0,

[SDMA8, SDMA7]

11 : 8-ohm drive capability

10 : 13.3-ohm drive capability

01 : 20-ohm drive capability

00 : 40-ohm drive capability

Driver capability for PCI and EPIC controller output signals [SDMA6]

0 : High drive capability on PCI signals (25 ohm)

1 : Medium drive capability on PCI signals (50 ohm)

Driver capability for SDA, SCL, CKO, QACK, and MCP as well as 60x output signals [SDMA5]

0 : High drive capability on CPU signals (20 ohm)

1 : Medium drive capability on CPU signals (40 ohm)

PCI output hold delay value (in nanoseconds) relative to PCI_SYNC_IN [SDMA4, SDMA3]

[SDMA4, SDMA3, 0] (UM-Section 4.3.2)

000 : Recommended for 66MHz PCI bus

100 : Recommended for 33MHz PCI bus

Clock flip disable [SDMA2]

(Section 2.3.3)

0 : Clock flip enabled

1 : No clock flip


DLL lock range extend [SDMA1]

0 : DLL lock range extended


1 : Standard DLL range

PRINT CONTROL PWB (POWER)


VCC-CPUIO = 3.3V for CPU I/O (max. 1A)



IVDD = 2.0V for CPU core (max. 3A)



VCCP5V = +5V_PRT from Engine I/F
VCC = +3.3V from Engine I/F



01


VCC

C33


0.1uF


The diagram shows a vacuum tube symbol labeled '302A' on the left. A horizontal line extends from the tube to a zigzag resistor symbol labeled 'R2' and '200'. To the right of the resistor is a vertical line labeled 'VCC'.

Imagine I/F



PRINT CONTROL PWB (XPC755-2 / 60X BUS DUMP RES.)







A vertical bar divided into four segments labeled 1, 2, 3, and 4 from bottom to top. An arrow points to the boundary between segments 2 and 3.




[illegible]








PRINT CONTROL PWB (CAP(XPC755 / MPC107))



CORE





PRINT CONTROL PWB (BOOT ROM / BUFFER)





PRINT CONTROL PWB (ON BOARD SDRAM)


256Mbit SDRAM x 4pcs




4pcs









PRINT CONTROL PWB (SDRAM CLKDRV / MEMORY DUMP RES.)





7 M_MDP(I




[illegible]









PRINT CONTROL PWB (ENGINE INTERFACE)







PRINT CONTROL PWB (D3032)










PRINT CONTROL PWB (IEEE1284 I/F)











PRINT CONTROL PWB (D8501A IO BUS BUFFER)






PRINT CONTROL PWB (USB INTERFACE (OKI))


4


3


2


1




















[PARTS SURFACE / 部品面]





MDMC PWB (CPU)

8 7 6 5


D


C

B


A


8 7 6 5







MDMC PWB (MODEM (AFE))







MDMC PWB (MODEM (DSP))










MDMC PWB (FAX G/A)







MDMC PWB (夜間FAX)







MDMC PWB (CPU ワークメモリ プログラム ROM)







MDMC PWB (MFP-I /F, H-UDI-I/F)






MDMC PWB (RESET, POWER)






MDMC PWB (SDRAM)





MDMC PWB (音声経路、TEL/LIU I/F)







C



A horizontal number line is shown, starting at 0 on the left and ending at 4 on the right. There are tick marks at 1, 2, and 3. An arrow points to the tick mark at 1.

MDMC PWB (3V-5V 変換)






MDMC PWB

PARTS LAYOUT / 部品配置図

[PARTS SURFACE / 部品面]



MDMC PWB


PARTS LAYOUT / 部品配置図


[SOLDER SURFACE / 半田面]



M. TEL/LIU PWB (JAPAN)


TEL/LIU PWB (JAPAN)





TEL/LIU PWB (JAPAN)

2/3



TEL/LIU PWB (JAPAN)

3/3

Japan Only

| MJ2 | MU46-RD315 |
|-----|------------|
| 1 | BT1 |
| 2 | LT1 |
| 3 | TEL1 |
| 4 | TEL2 |
| 5 | LT2 |
| 6 | BT2 |




| CN3 | SGB-XASK-1 |
|-----|------------|
| 1 | CIP |
| 2 | AG |
| 3 | /COUT |

| MJ1 | MU42-RD315 |
|-----|------------|
| 1 | L1 |
| 2 | L2 |


Japan Only

| CN1 | MD-S610-90 |
|-----|------------|
| 1 | TX+ |
| 2 | RX+ |
| 3 | RX- |
| 4 | TX- |
| 5 | /RHS |
| 6 | DG |


| CN2 | 30FE-BT-VK-N | | | |
|-----|--------------|----|----|----------|
| | DG | 1 | 2 | AG |
| | AG | 3 | 4 | SIGRX |
| | TELRX | 5 | 6 | SIGTX |
| | 12V | 7 | 8 | 12V |
| | /HS1 | 9 | 10 | /HS2 |
| | RHS | 11 | 12 | /EXHS |
| | /CI | 13 | 14 | /CON |
| | /MR | 15 | 16 | S |
| | /CML | 17 | 18 | /DP |
| | /RCWMUTE | 19 | 20 | /MICMUTE |
| | /VRSEL1 | 21 | 22 | /VRSEL2 |
| | /VRSEL3 | 23 | 24 | EC |
| | /CID | 25 | 26 | /FNETD |
| | 5V | 27 | 28 | 12VS |
| AGS | | 29 | 30 | DG |




TEL LIU PWB (JAPAN)
PARTS LAYOUT / 部品配置図
[PARTS SURFACE / 部品面]





TEL LIU PWB (JAPAN)
PARTS LAYOUT / 部品配置図
[SOLDER SURFACE / 半田面]





(2) DC CIRCUIT





CAUTION FOR BATTERY REPLACEMENT

(Danish)

ADVARSEL !

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Levér det brugte batteri tilbage til leverandoren.

(English)

Caution !

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the manufacturer.

"BATTERY DISPOSAL"

CONTAINS MANGANESE DIOXIDE LITHIUM BATTERY
MUST BE DISPOSED OF PROPERLY.
REMOVE THE BATTERY FROM THE PRODUCT AND
CONTACT FEDERAL OR STATE ENVIRONMENTAL
AGENCIES FOR INFORMATION ON RECYCLING
AND DISPOSAL OPTIONS.

"BATTERY DISPOSAL"

CONTAINS LITHIUM-ION BATTERY.
MUST BE DISPOSED OF PROPERLY.
REMOVE THE BATTERY FROM THE PRODUCT AND
CONTACT FEDERAL OR STATE ENVIRONMENTAL
AGENCIES FOR INFORMATION ON RECYCLING
AND DISPOSAL OPTIONS.

(Finnish)

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan
tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden
mukaisesti.

(French)

ATTENTION

Il y a danger d'explosion s' il y a remplacement incorrect
de la batterie. Remplacer uniquement avec une batterie du
même type ou d'un type équivalent recommandé par
le constructeur.
Mettre au rebut les batteries usagées conformément aux
instructions du fabricant.

(Swedish)

VARNING

Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens
instruktion.

(German)

Achtung

Explosionsgefahr bei Verwendung inkorrektter Batterien.
Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder
vom Hersteller empfohlene Batterien verwendet werden.
Entsorgung der gebrauchten Batterien nur nach den vom
Hersteller angegebenen Anweisungen.



COPYRIGHT © 2002 BY SHARP CORPORATION

All rights reserved.

Printed.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic; mechanical; photocopying; recording or otherwise
without prior written permission of the publisher.

Trademark Acknowledgments

Microsoft Windows, MS-DOS, Windows NT, Windows 2000 are trademarks of Microsoft Corporation in the U. S. A. and other countries.

Macintosh, Power Macintosh, Mac OS, LaserWriter, and AppleTalk are registered trademarks of Apple Computer, Inc.

IBM, PC/ AT, and PowerPC are trademarks of International Business Machines Corporation.

Pentium is a registered trademark of Intel Corporation.

PCL is a trademark of the Hewlett- Packard Company.

PostScript® is a registered trademark of Adobe Systems Incorporated.

NetWare is a registered trademark of Novell, Inc.


All other trademarks and copyrights are the property of their respective owners.

CODE:00ZARC260/P2/


デジタルフルカラー複合機

Digital Full Color Copier / Printer

Digital Full Color Multifunctional System



AR-C260
AR-C260M
AR-C260S



AR-C260F
AR-C260FP

AR-C260

[EXCEPT
JAPAN]

AR-C260M

AR-C260FP

[JAPAN
ONLY]

AR-C260S

[JAPAN
ONLY]

MODEL AR-C260F

[JAPAN
ONLY]

このパーツガイドに掲載されている表示価格ランクは消費税抜きです。

CONTENTS

- | | |
|--|---|
| 1 外装 1 (Exteriors 1) | 35 配線部 (Wiring section) |
| 2 外装 2 (Exteriors 2) | 36 梱包材 & 付属品 (Packing Material & Accessories) |
| 3 原稿検知ユニット (Document detect unit) | 37 FAX BOX unit [AR-C260F/C260FP] |
| 4 操作部 (Operation panel section) | 38 プリンターコントローラ部 (Printer controller section) |
| 5 オリジナルカバーユニット (Original cover unit) | [AR-C260M/C260FP] |
| [AR-C260S/AR-C260, | 39 RADF 外装部 (RADF Exteriors) [AR-C260F/C260FP] |
| AR-C260M(Except U.S.A,Europe,Australia,New Zealand)] | 40 RADF 給紙部 1 (RADF Paper feedig section 1) |
| 6 スキャナユニット 1 (Scanner unit 1) | [AR-C260F/C260FP] |
| 7 スキャナユニット 2 (Scanner unit 2) | 41 RADF 給紙部 2 (RADF Paper feedig section 2) |
| 8 ランプユニット (Lamp unit) | [AR-C260F/C260FP] |
| 9 スキャナ連結ユニット (Scanner joint unit) | 42 RADF 給紙駆動部 (RADF Paper feedig drive section) |
| 10 カセットユニット (Cassette unit) | [AR-C260F/C260FP] |
| 11 給紙ユニット (Paper feed unit) | 43 RADF 排紙部 1 (RADF Delivery section 1) |
| 12 給紙駆動ユニット (Paper feeding drive unit) | [AR-C260F/C260FP] |
| 13 マルチ手差しユニット 1 (Multi manual paper feeding unit 1) | 44 RADF 排紙部 2 (RADF Delivery section 2) |
| 14 マルチ手差しユニット 2 (Multi manual paper feeding unit 2) | [AR-C260F/C260FP] |
| 15 マルチ手差しユニット 3 (Multi manual paper feeding unit 3) | 45 RADF 搬送部 (RADF Transport section) |
| 16 縦搬送ガイドユニット (Vertical transport guide unit) | [AR-C260F/C260FP] |
| 17 カセットガイド R・縦搬送下ユニット | 46 RADF 搬送駆動部 (RADF Transport drive section) |
| (Cassette guide R / Vertical transport lower unit) | [AR-C260F/C260FP] |
| 18 PS ユニット (PS unit) | 47 RADF 台板ユニット (RADF Base plate unit) |
| 19 転写ベルトユニット 1 (Transfer belt unit 1) | [AR-C260F/C260FP] |
| 20 転写ベルトユニット 2 (Transfer belt unit 2) | 48 RADF 配線部 (RADF Wiring section) |
| 21 転写リフトアップユニット (Transfer lift-up unit) | [AR-C260F/C260FP] |
| 22 プロセスユニット (Process unit) | 49 モデムコントロール基板 (Modem control PWB) |
| 23 ドラム駆動ユニット (Drum drive unit) | [AR-C260F/AR-C260FP] |
| 24 定着ユニット 1 (Fusing unit 1) | 50 TEL/LIU 基板 (TEL/LIU PWB) |
| 25 定着ユニット 2 (Fusing unit 2) | [AR-C260F/AR-C260FP] |
| 26 定着駆動ユニット (Fusing drive unit) | 51 PCU 基板 (PCU PWB) |
| 27 左ドア (Left door) | 52 MFPC2 基板 (MFPC2 PWB) |
| 28 FD 排紙ユニット (FD delivery unit) | 53 ICU 基板 (ICU PWB) |
| 29 フレーム 1 (Frame 1) | 54 操作キー基板 (OPE KEY PWB) |
| 30 フレーム 2 (Frame 2) | 55 ドライバ基板 (DRIVER PWB) |
| 31 フレーム 3 (Frame 3) | 56 LVDS/INV 基板 (LVDS/INV PWB) |
| 32 転写挿入ガイド (Transfer insert guide) | 57 FAX 電源基板ユニット (FAX AC power supply unit) |
| 33 ダクトユニット (Duct unit) | [AR-C260F/C260FP] |
| 34 コントローラBOX (Control box) | 58 PRTC 基板 (PRTC PWB) [AR-C260M/AR-C260FP] |
| | ■ 索引 (Index) |

補修部品のランク付

市場における補修部品の在庫管理が、適正に運営出来る手助けとなることを、目的とします。

- Aランク：メンテナンスパーツ、メンテナンスパーツには入っていないがメンテナンスパーツに近い消耗パーツ。
 Bランク：性能・機能パーツ（センサー、クラッチ等の電気パーツ）、消耗パーツ。
 Eランク：基板含むユニットパーツ。
 Dランク：整備パーツ（外装、パッキング、同梱パーツ）。
 Cランク：上記ランク以外のパーツ（基板の子部品を除いたもの）。

DEFINITION

- Rank A : Maintenance parts, and consumable parts which are not included in but closely related to maintenance parts
 Rank B : Performance/function parts (sensors, clutches, and other electrical parts), consumable parts
 Rank E : Unit parts including PWB
 Rank D : Preparation parts (External fitting, packing, parts packed together)
 Rank C : Parts other than the above (excluding sub components of PWB)

安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。

△印の商品は、安全上重要な部品です。交換をする時は、安全及び性能維持のため必ず指定の部品をご使用下さい。

Because parts marked with "△" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

- 当モデルのサービス資料には、この資料以外にサービスマニュアル（回路図含む）があります。合わせてご利用下さい。
- Other than this Parts Guide, please refer to documents Service Manual(including Circuit Diagram) of this model.
- Please use the 13 digit code described in the right hand corner of front cover of the document, when you place an order.
- For U.S. only-Use order codes provided in advertising literature. Do not order from parts department.

* These parts are supplied by SMF


1 外装 1(Exteriors 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | GCAB-1018FCZ5 | BF | FG | N | D | Delivery tray cabinet right (100V Series) 排紙トレイキャビ 右 |
| | GCAB-1018FCZZ | AY | FQ | N | D | Delivery tray cabinet right (200V Series) 排紙トレイキャビ 右 |
| 2 | XJBSE40P12000 | AA | DD | N | C | Screw(4x12) ビス |
| 3 | GCAB-0988FCZ5 | BC | GJ | N | D | Delivery tray cabinet (100V Series) 排紙トレイキャビ |
| | GCAB-0988FCZZ | BE | GN | N | D | Delivery tray cabinet (200V Series) 排紙トレイキャビ |
| 4 | XEBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 6 | GCAB-0987FCZ5 | AV | FG | N | D | Left cabinet rear (100V Series) 左キャビ 後 |
| | GCAB-0987FCZZ | AU | EZ | N | D | Left cabinet rear (200V Series) 左キャビ 後 |
| 7 | PFTA-0141FCZ5 | AK | DX | N | D | Left cabinet rear cover (100V Series) 左キャビ 後蓋 |
| | PFTA-0141FCZZ | AH | DX | N | D | Left cabinet rear cover (200V Series) 左キャビ 後蓋 |
| 8 | GCAB-0993FCZZ | BA | FX | N | D | Rear cabinet 後キャビ |
| 9 | LPLTM6092FCZ1 | AM | EG | N | C | CONT back fixing plate (AR-C260/C260S/C260F) CONT 背面プレート |
| 10 | GCAB-0992FCZ5 | AT | EZ | N | D | Right cabinet rear (100V Series) 右キャビ 後 |
| | GCAB-0992FCZZ | AV | FG | N | D | Right cabinet rear (200V Series) 右キャビ 後 |
| 11 | PFTA-0142FCZZ | AE | DS | N | D | Right cabinet rear cover 右キャビ 後蓋 |
| 12 | PCOVP1703FCZ5 | AP | EQ | N | C | DC power supply CFM fixing cover (100V Series) DC 電源 CFM 取付けカバー |
| | PCOVP1703FCZZ | AP | EQ | N | C | DC power supply CFM fixing cover (200V Series) DC 電源 CFM 取付けカバー |
| 13 | GCAB-0991FCZ5 | AS | EQ | N | D | Right cabinet upper (100V Series) 右キャビ 上 |
| | GCAB-0991FCZZ | AR | EQ | N | D | Right cabinet upper (200V Series) 右キャビ 上 |
| 15 | GCAB-0990FCZ5 | AM | EG | N | D | Right cabinet lower (100V Series) 右キャビ 下 |
| | GCAB-0990FCZZ | AP | EQ | N | D | Right cabinet lower (200V Series) 右キャビ 下 |
| 16 | GCAB-0989FCZ5 | AT | EZ | N | D | Right cabinet front (100V Series) 右キャビ 前 |
| | GCAB-0989FCZZ | AR | EQ | N | D | Right cabinet front (200V Series) 右キャビ 前 |
| 17 | PMAGT0015FCZZ | AD | DJ | | C | Magnet catch(10P) MG キャッチ |
| 18 | GCAB-0980FCZ5 | BA | FX | N | D | Front frame cover 前フレームカバー |
| 19 | GCAB-0985FCZ5 | AP | EQ | N | D | Front cabinet lower (100V Series) 前キャビ 下 |
| | GCAB-0985FCZZ | AQ | EQ | N | D | Front cabinet lower (200V Series) 前キャビ 下 |
| 20 | CBDGD0043FC04 | AR | EQ | N | C | Front cabinet badge [AR-C260S] 前キャビ バッジ |
| | CBDGD0043FC05 | AQ | EQ | N | C | Front cabinet badge [AR-C260F] 前キャビ バッジ |
| | CBDGD0043FC03 | AQ | EQ | N | C | Front cabinet badge [AR-C260FP] 前キャビ バッジ |
| | CBDGD0043FC02 | AP | EQ | N | C | Front cabinet badge [AR-C260M] 前キャビ バッジ |
| | CBDGD0043FC01 | AQ | EQ | N | C | Front cabinet badge [AR-C260] 前キャビ バッジ |
| 21 | GCAB-0984FCZ5 | BM | HR | N | D | Front cabinet (100V Series) 前キャビ |
| | GCAB-0984FCZZ | BA | FX | N | D | Front cabinet (200V Series) 前キャビ |
| 22 | LPLTM5027FCZZ | AC | DJ | | C | Magnet catch plate S MG キャッチプレート S |
| 23 | LBNDZ0069FCZZ | AD | DJ | | C | Band バンド |
| 24 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 25 | XEBSE30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 26 | LPI N-0277FCZZ | AB | DJ | | C | Slide pin スライドピン |
| 27 | NFANP0070FCZZ | AZ | FX | N | B | PS cooling fan 電源冷却ファン |
| 28 | XEBSD40P30000 | AA | DD | | C | Screw(4x30) ビス |
| 29 | NFANP0071FCZZ | AZ | FX | N | B | Fan (AR-C260/C260S/C260F) ファン |
| 30 | LHLDZ1547FCZZ | AD | DJ | N | C | Fan holder (AR-C260/C260S/C260F) ファンホルダー |
| 31 | XHBSE30P06000 | AA | DD | | C | Screw(3x6) (AR-C260/C260S/C260F) ビス |
| 32 | LX-BZ0901FCZZ | AC | DD | | C | Screw (AR-C260/C260S/C260F) ビス |
| 33 | TLABZ4742FCZZ | AL | EB | N | C | Color mark label カラーマークラベル |

1 外装 1(Exteriors 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 34 | PCOVP1618FCZ1 | AH | DX | N | D | ROM cover ROM カバ ー |
| 35 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) ビ ス |
| 36 | PCOVP1623FCZ1 | AH | DX | N | D | FAX connector cover [Except AR-C260F/C260FP] FAX コネクターカバ ー |
| 37 | PMLT-1316FCZZ | AC | DJ | N | C | Sub ozone filter cushion サブ オゾ ンフィルタ ーモルト |
| 38 | PFILZ0296FCZZ | AQ | EQ | N | A | Sub ozone filter サブ オゾ ンフィルタ ー |
| 39 | PCOVP1706FCZ5 | AE | DJ | N | C | Sub ozone filter cover (100V Series) サブ オゾ ンフィルタ ーカバ ー |
| | PCOVP1706FCZZ | AE | DS | N | C | Sub ozone filter cover (200V Series) サブ オゾ ンフィルタ ーカバ ー |
| 40 | LX-NZ0088FCZZ | AC | DD | | C | Nut ナット |
| 41 | TLABZ4047FCZZ | AC | DJ | | C | Enagy star label (Japan,U.Kingdom, Australia,New Zealand,Germany) エナジ ースターラベ ル |
| 42 | TCAUA0770FCZZ | AB | DD | | C | Service cautions label (Except Japan) サービス注意ラベ ル |
| 43 | TLABF2705FCZZ | AB | DD | | C | FCC conformity label A,B (U.S.A,Canada) FCC 適合ラベ ル A,B |
| 45 | TLABH4186FCZZ | AE | DS | | C | Class A VCCI label (Japan only) クラス A VCCI ラベ ル |
| 47 | TLABS4306FCZZ | AC | DJ | | C | Noise label class A (U.S.A,Canada) ノイズ ラベ ルクラス A |
| 48 | TLABZ4694FCZZ | AF | DS | | C | Imagery label (U.S.A only) イメージ ャラベ ル |
| 49 | TLABZ4720FCZZ | AC | DJ | | C | Heater SW label (Japan only) ヒータースイッチラベ ル |
| 50 | TLABZ0059QSZZ | AE | DJ | | C | ECP label (Canada only) ECP ラベ ル |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

1 外装 1(Exteriors 1)




2 外装 2(Exteriors 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | GCAB-0995FCZ5 | AQ | EQ | N | D | Upper cabinet left (100V Series) 上キャビ 左 |
| | GCAB-0995FCZZ | AR | EQ | N | D | Upper cabinet left (200V Series) 上キャビ 左 |
| 2 | CFIX-0571FC01 | AY | FQ | N | D | Glass fixing left (Japan only) ガラス押え左 |
| | CFIX-0571FC02 | AN | EQ | N | D | Glass fixing left (Except Japan)(AB Series) ガラス押え左 |
| 3 | CFIX-0571FC03 | AN | EQ | N | D | Glass fixing left (Except Japan)(Inch Series) ガラス押え左 |
| | GCAB-0998FCZ5 | AP | EQ | N | D | Upper cabinet rear left (100V Series) 上キャビ 後左 |
| 4 | GCAB-0998FCZZ | AG | DX | N | D | Upper cabinet rear left (200V Series) 上キャビ 後左 |
| | LFIX-0572FCZ5 | AS | EQ | N | D | Glass fixing right (100V Series) ガラス押え右 |
| 5 | LFIX-0572FCZZ | AK | DX | N | D | Glass fixing right (200V Series) ガラス押え右 |
| | GCAB-0994FCZ5 | BA | FX | N | D | Upper cabinet right (100V Series) 上キャビ 右 |
| 6 | GCAB-0994FCZZ | AR | EQ | N | D | Upper cabinet right (200V Series) 上キャビ 右 |
| | GCAB-0996FCZ5 | AW | FG | N | D | Upper cabinet rear upper (100V Series) 上キャビ 後上 |
| 7 | GCAB-0996FCZZ | AW | FG | N | D | Upper cabinet rear upper (200V Series) 上キャビ 後上 |
| | GCAB-0997FCZ5 | AP | EQ | N | D | Upper cabinet rear lower (100V Series) 上キャビ 後下 |
| 8 | GCAB-0997FCZZ | AQ | EQ | N | D | Upper cabinet rear lower (200V Series) 上キャビ 後下 |
| | PFTA-0134FCZ1 | AE | DS | N | C | Connector cover W コネクター蓋 W |
| 9 | GCAB-0999FCZ5 | AG | DX | N | D | Upper cabinet rear right (100V Series) 上キャビ 後右 |
| | GCAB-0999FCZZ | AH | DX | N | D | Upper cabinet rear right (200V Series) 上キャビ 後右 |
| 10 | PCOVP1646FCZZ | AG | DX | N | D | Ozone filter cover オゾンフィルターカバー |
| 11 | GCAB-1023FCZ5 | BC | EQ | N | D | Rear joint cabinet (100V Series) 後連結キャビ |
| | GCAB-1023FCZZ | AT | EZ | N | D | Rear joint cabinet (200V Series) 後連結キャビ |
| 12 | PGLSP0003QSZ5 | BA | FX | | D | Table glass テーブルガラス |
| 13 | CGLSP0104DS51 | AT | EZ | N | E | Shading glass unit シェーディングガラスユニット |
| 15 | GCAB-1019FCZ5 | AV | FQ | N | D | Upper cabinet center (100V Series) 後キャビ 中 |
| | GCAB-1019FCZZ | AU | EZ | N | D | Upper cabinet center (200V Series) 後キャビ 中 |
| 16 | GCAB-1022FCZ5 | AQ | EZ | N | D | Right joint cabinet B (100V Series) 右連結キャビ B |
| | GCAB-1022FCZZ | AU | EZ | N | D | Right joint cabinet B (200V Series) 右連結キャビ B |
| 17 | GCAB-1020FCZ5 | AL | DX | N | D | Rear cabinet center (100V Series) 右キャビ 中 |
| | GCAB-1020FCZZ | AH | DX | N | D | Rear cabinet center (200V Series) 右キャビ 中 |
| 18 | GCAB-1025FCZ5 | AZ | EQ | N | D | Front cabinet upper (100V Series) 前キャビ 上 |
| | GCAB-1025FCZZ | AR | EQ | N | D | Front cabinet upper (200V Series) 前キャビ 上 |
| 19 | GCAB-0982FCZ5 | AU | FG | N | D | FD delivery enter cabinet (100V Series) FD 排紙口キャビ |
| | GCAB-0982FCZZ | AS | EQ | N | D | FD delivery enter cabinet (200V Series) FD 排紙口キャビ |
| 20 | GCAB-1024FCZ5 | AU | FQ | N | D | FD joint cabinet (100V Series) FD 連結キャビ |
| | GCAB-1024FCZZ | AX | FG | N | D | FD joint cabinet (200V Series) FD 連結キャビ |
| 21 | PFTA-0144FCZZ | AE | DJ | N | D | Card reader cover カードリーダー蓋 |
| 22 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 23 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 24 | XBTSE40P06000 | AA | DD | | C | Screw(4×6) ビス |
| 25 | XEBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 26 | TLABH4748FCZZ | AF | DS | N | C | Copy prohibition caution label (Japan only) コピー禁止注意ラベル |
| | TLABH4749FCZZ | AE | DJ | N | C | Copy prohibition caution label (Canada only) コピー禁止注意ラベル |
| 27 | XEBSD40P10000 | AA | DD | | C | Screw(4×10) ビス |
| 30 | PCOVP0911FCZ2 | AD | DJ | N | D | Upper exterior rear cover R 上キャビ 後カバー R (AR-C260F/C260FP/C260,C260M[U.S.A,CANADA,Australia,Europe]) |
| 31 | PCOVP0941FCZ2 | AD | DJ | N | D | Upper exterior rear cover L 上キャビ 後カバー L (AR-C260F/C260FP/C260,C260M[U.S.A,CANADA,Australia,Europe]) |
| 32 | LX-BZ0776FCZZ | AG | DS | | C | Screw (AR-C260F/C260FP) タンネジ R |


3 原稿検知ユニット (Document detect unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | NSFTZ1805FCZZ | AE | DS | | C | Original detection fulcrum shaft 原稿検知支点シャフト |
| 2 | XRESP30-06000 | AA | DD | | C | E type ring E-リング |
| 3 | MSPRT1563FCZZ | AC | DD | | C | Original detect spring 原稿検知スプリング |
| 4 | XBPSD30P06KS0 | AA | DD | | C | Screw(3×6KS) ビス |
| 5 | MARMP0148FCZ2 | AK | DX | | C | Original detector arm lower T 原稿検知アーム下 T |
| 6 | PSLDH0178FCZZ | AD | DJ | | C | Original detect shield plate 原稿検知遮光板 |
| 7 | CPWBF1453FCE1 | AX | FG | | E | ORS emission PWB 原稿検知発光基板 |
| 8 | LHLDZ1085FCZ2 | AD | DJ | | C | Holder ホルダー |
| 9 | LBSHZ1102CCZ2 | AC | DD | | C | Rubber roller bushing 1 ゴムローラー 1 プッシング |
| 10 | MARMP0147FCZ2 | AK | DX | | C | Original detector arm upper T 原稿検知アーム上 T |
| 11 | XEPSD30P05000 | AA | DD | | C | Screw(3×5) ビス |
| 12 | GCAB-0996FCZ5 | AW | FG | N | D | Upper cabinet rear upper (100V Series) 上キャビ 後上 |
| | GCAB-0996FCZZ | AW | FG | N | D | Upper cabinet rear upper (200V Series) 上キャビ 後上 |
| 13 | XEBSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 14 | CARMP0147DS51 | BA | FX | | E | Original detector luminescence unit 原稿検知発光ユニット |

2 外装 2(Exteriors 2)




3 原稿検知ユニット (Document detect unit)



4 操作部 (Operation panel section)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | LDAIU0646FCZ5 | BF | GN | N | C | Operation base (100V Series) 操作台板 |
| | LDAIU0646FCZZ | AX | FG | N | C | Operation base (200V Series) 操作台板 |
| 2 | XEBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 3 | CPWBF1525FCE1 | BD | GJ | N | E | Operation key PWB 操作キ基板 |
| 4 | XEPSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 5 | CPWBN1560FCE1 | BM | HR | N | E | LVDS/INV PWB LVDS/INV 基板 |
| 6 | LHLDZ1459FCZZ | AE | DS | | C | LCD holder B LCDホルダー-B |
| 7 | VVLLM065HB1-1 | CB | TX | | B | LCD(LLM065HB1) LCD |
| 8 | QCNW-0214FCZZ | AD | DJ | N | C | OP-LCD FFC OP-LCD FFC |
| 9 | LHLDZ1458FCZZ | AF | DS | | C | LCD holder A LCDホルダー-A |
| 10 | HPNLH0249FCZZ | BF | GN | | C | Touch panel N タッチパネル-N |
| 11 | CBTN-0253FC01 | AN | EG | | D | Change key 切り替えキー |
| 12 | CBTN-0252FC01 | AP | EQ | | D | Ten key テンキー |
| 13 | HPNLC0247FCZ5 | BD | GN | N | C | Operation panel A (100V Series) 操作パネル-A |
| | HPNLC0247FCZZ | AV | FG | N | C | Operation panel A (200V Series) 操作パネル-A |
| 14 | LPLTM2573FCZ1 | AD | DJ | | C | MG Plate MGプレート |
| 15 | XHSSE30P10000 | AA | DD | | C | Screw(3×10) ビス |
| 16 | CPNLC0248FC01 | AU | FG | N | D | Operation panel B (AR-C260S/C260M[JAPAN]) 操作パネル-B |
| | CPNLC0248FC03 | AU | GN | N | D | Operation panel B (AR-C260F/C260FP) 操作パネル-B |
| | CPNLC0248FC02 | AV | FG | N | D | Operation panel B (AR-C260/C260M[Except JAPAN]) 操作パネル-B |
| 17 | LPINS0014QSCZ | AF | DS | N | C | Pin ピン |
| 18 | LPINS0014QSBZ | AF | DS | N | C | Pin ピン |
| 19 | PSHEZ5065FCZZ | AQ | EQ | N | C | Copy key sheet W コピー用シートW |
| 20 | CBTN-0260FC01 | AE | DX | N | D | C key Cキー |
| 21 | CBTN-0261FC01 | AK | DJ | N | D | CA key CAキー |
| 22 | PFIW0294FCZZ | AE | DS | N | C | Copy key filter コピーキスモーク |
| 23 | CBTN-0256FC02 | AR | EQ | N | D | Color copy key カラーコピーキー |
| 24 | CBTN-0256FC03 | AN | EG | N | D | Monochrome copy key 白黒コピーキー |
| 25 | PSHEZ4906FCZZ | AC | DJ | | C | Touch panel sheet タッチパネルシート |
| 26 | MSPRP3009FCZZ | AD | DJ | | C | LCD earth spring LCD用アース板バネ |
| 27 | DHAI-3193FC11 | AC | DJ | N | C | Panel earth harness パネルアースハーネス |
| 28 | PSHEP5006FCZZ | AE | DS | N | C | Panel sheet パネルシート |
| 29 | DHAI-3419FCZZ | AE | DS | N | C | OP-PD harness OP-PDハーネス |

4 操作部 (Operation panel section)




FCP06314

5 オリジナルカバーユニット (Original cover unit)
[AR-C260S/AR-C260,AR-C260M(Except U.S.A,Europe,Australia,New Zealand)]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|-----------------------------------|
| | | Ex. | Ja. | | | |
| 1 | PSHEZ5059FCZZ | AU | EZ | | D | OC sheet OC マット |
| 2 | XJBSD40P12000 | AA | DD | | C | Screw(4×12) ビス |
| 3 | MHNG-0210FCZZ | AQ | EZ | | C | OC hinge L OC ヒンジ L |
| 4 | MHNG-0211FCZZ | AQ | EZ | | C | OC hinge R OC ヒンジ R |
| 5 | GCOVH0212FCZ2 | BB | GD | N | D | Original cover R オリジナルカバー R |
| 6 | PSTK-0015FCZ2 | AU | EZ | N | C | OR stocker OR ストッカー |
| 8 | MHNG-0170FCZ1 | AE | DS | | C | OC cover hinge OC カバーヒンジ |
| 9 | LPINS0280FCZZ | AD | DJ | | C | OC cover hinge pin OC カバーヒンジピン |
| 10 | XJBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 11 | GCOVH0211FCZ2 | BB | GD | N | D | Original cover F オリジナルカバー F |
| | (Unit) | | | | | |
| 901 | CCOVH0212FC34 | BN | HV | N | D | OC unit OC ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

5 オリジナルカバーユニット (Original cover unit)
[AR-C260S/AR-C260,AR-C260M(Except U.S.A,Europe,Australia,New Zealand)]




FCP06315

6 スキャナユニット 1(Scanner unit 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | CPLTM5995DS51 | CA | TV | N | E | Lens W unit レンズ W ユニット |
| 2 | XHBSD30P08KS0 | AB | DD | N | C | Screw(3×8KS) ビス |
| 3 | DHAi-3369FCZZ | AN | EG | N | C | MFP sensor harness MFP センサーハーネス |
| 4 | PCOVP1631FCZZ | AP | EQ | N | C | Dark box cover 暗箱カバー |
| 5 | XHBSD30P04000 | AA | DD | | C | Screw(3×4) ビス |
| 6 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) (Japan only) ビス |
| 7 | XHBSD30P06000 | AA | DD | | C | Screw(3×6) (Japan only) ビス |
| 8 | VHi28F161L01F | BA | FX | N | C | MFP FLASH ROM(28F161L01F) MFP フラッシュROM |
| 9 | LBSHC0355FCZZ | AF | DS | N | C | Bushing(LES-1017) ブッシング |
| 10 | VHi28F162L01F | BD | GN | N | C | OPE FLASH ROM(28F162L01F) OPE フラッシュROM |
| 11 | VHPGP3A38//--1 | AH | DX | | B | Photo sensor(GP3A38) フォトセンサー |
| 12 | XBBSD40P14000 | AA | DD | | C | Screw(4×14) ビス |
| 13 | LPLTM5989FCZZ | AQ | EQ | N | C | OC fixing plate OC 取付けプレート |
| 15 | VHPGP1A22LC-1 | AK | EB | | B | Photo sensor(GP1A22LC) フォトセンサー |
| 16 | XBBSD40P10000 | AA | DD | | C | Screw(4×10) ビス |
| 17 | LPLTM6096FCZZ | AF | DS | N | C | Connector fixing plate コネクタ取付けプレート |
| 18 | PSHEP5075FCZZ | AF | DS | N | C | Harness protect film N ハーネス保護フィルム N |
| 19 | LANGF1423FCZZ | AH | DX | N | C | Support angle R 補強アングル R |
| 20 | XHBSD30P06000 | AA | DD | | C | Screw(3×6) ビス |
| 21 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 22 | CPWBN1519DS52 | CX | ** | N | E | MFPC2 PWB MFPC2 基板 |
| 23 | LPLTM5991FCZZ | AW | FG | N | C | MPF support plate MPF 支持プレート |
| 24 | PCUSS0374FCZZ | AE | DS | N | C | Protection cushion ボウシクッション |
| 25 | CDAiU0618FC02 | BN | HV | N | C | Optical base 光学台板 |
| 26 | LRALM0201FCZZ | AN | EG | N | C | MFP rail MFP レール |
| 27 | PSHEZ4843FCZ1 | AC | DJ | | C | Harness fixing sheet 3 ハーネス押えシート 3 |
| 28 | PSHEP4932FCZ1 | AC | DJ | | C | Harness fixing sheet 4 ハーネス押えシート 4 |
| 29 | PMLT-1298FCZ1 | AE | DS | N | C | FFC cushion FFC モルト |
| 30 | PCOVP1632FCZZ | AM | EG | N | C | FFC cover FFC カバー |
| 31 | RHETP0099FCZZ | AV | EQ | N | C | Dry heater (Japan only) 除湿ヒーター |
| 33 | LBNDJ0002FCZZ | AA | DD | | C | Wire fixing band(HP-4N) (Japan only) バンド |
| 34 | LHLDW5031BCZZ | AA | DD | | C | Clamp (Japan only) ケーブルホルダー |
| 35 | PSHEZ4836FCZZ | AB | DJ | | C | Screw protect sheet ビス保護シート |
| 36 | QCNW-0197FCZZ | AL | EB | N | C | MFP-OP FFC MFP-OP FFC |
| 37 | QCNW-0213FCZZ | AH | DX | N | C | OP-KEY FFC OP-KEY FFC |
| (Unit) | | | | | | |
| 901 | DUNT-7248DSZZ | CM | UW | N | E | Scanner unit(Include Block 7) スキャナユニット (ブロック 7 含む) |


6 スキャナユニット 1(Scanner unit 1)



7 スキャナユニット 2(Scanner unit 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | PWIR-0199FCZZ | AR | EQ | N | C | MB wire FW MB ワイヤー FW |
| 2 | CHLDZ1446FC32 | BH | HC | N | E | 2nd.3rd mirror W unit 2.3 ミラー W ユニット |
| 3 | XBBS040P06000 | AA | DD | | C | Screw(4x6) ビス |
| 4 | LHLDZ1505FCZZ | AC | DJ | | C | Wire holder ワイヤーホルダー |
| 5 | PGIDM1890FCZZ | AC | DJ | | C | CL guide CL ガイド |
| 6 | CDAIU0619DS53 | BR | LX | N | E | Lamp unit ランプユニット |
| 7 | PWIR-0200FCZZ | AR | EQ | N | C | MB wire RW MB ワイヤー RW |
| 9 | LDAIU0610FCZZ | AE | DS | | C | Harness fixing base ハーネス押えベース |
| 10 | LFIX-0537FCZZ | AD | DJ | | C | Harness fixing plate ハーネス押え |
| 11 | LBSHC0356FCZZ | AC | DJ | N | C | Bushing(T1.6) ブッシング |
| 12 | LX-BZ0324FCZZ | AA | DD | | C | Screw 下クリナ用ビス |
| 13 | NPLYZ0013QSZZ | AL | EB | | C | Winding pulley PAN 巻取りプーリー PAN |
| 14 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 15 | LX-BZ0049FCZZ | AB | DD | | C | Screw(M4x6W) ミネビス |
| 16 | NSFTZ2694FCZZ | AP | EQ | N | C | Winder drive shaft 巻取り駆動軸 |
| 17 | CSFTZ2694FC31 | BA | FX | N | E | Winder drive shaft unit 巻取り駆動シャフトユニット |
| 18 | XHBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 19 | RMOTS0885FCZ1 | BE | GN | N | B | Scanner motor スキャナモーター |
| 20 | NBLTH0371FCZ1 | AF | DS | N | B | Winder drive belt 巻取り駆動ベルト |
| 21 | MSPRT3098FCZZ | AC | DJ | N | C | Belt tension spring ベルトテンションスプリング |
| 22 | LPLTM5992FCZZ | AK | DX | N | C | Mirror motor fixing plate ミラーモーター取付けプレート |
| 23 | LBNDJ0043FCZ1 | AA | DJ | | C | Band(SG-130) バンド |
| 24 | CDAIU0618FC02 | BN | HV | N | C | Optical base 光学台板 |
| 25 | PGUMS0283FCZ1 | AA | DJ | | C | Table glass rubber テーブルガラスゴム |
| 26 | NBRGY0466FCZZ | AK | EB | | C | Bearing(M8-M16) ベアリング |
| 28 | XEPSD40P06000 | AA | DD | | C | Screw(4x6) ビス |
| 29 | CPWBF1454FCE1 | BN | LE | | E | ORS PD PWB 原稿検知受光基板 |
| 30 | XHBSD40P06000 | AA | DD | | C | Screw(4x6) ビス |
| 31 | LHLDZ1381FCZZ | AL | EB | | C | ORS PWB holder 受光基板ホルダー |
| 32 | NPLYZ0005QSZZ | AG | DX | | C | Pulley 定フーリー |
| 33 | NPLYZ0006QSZZ | AD | DJ | | C | L pulley L フーリー |
| 34 | XRESP40-05000 | AA | DD | | C | E type ring E-リング |
| 35 | LRALM0184FCZZ | AG | DX | | C | MB-B rail R MB-B レール R |
| 36 | LRALM0183FCZZ | AG | DX | | C | MB-B rail F MB-B レール F |
| 37 | LX-BZ0004QSZZ | AB | DD | | C | Screw ビス |
| 38 | NPLYZ0401FCZZ | BB | GD | N | C | Pulley(50T) フーリー |
| 39 | TLABZ4335FCZZ | AB | DJ | | C | High voltage caution label 高圧注意ラベル |
| | (Unit) | | | | | |
| 901 | DUNT-7248DSZZ | CM | UW | N | E | Scanner unit(Include Block 6 Without No.39) スキャナユニット (ブロック6 含む。No.39 除く) |

7 スキャナユニット 2(Scanner unit 2)




FCP06317

⑧ ランプ° ユニット (Lamp unit)

[illegible]


8 ランプ° ユニット (Lamp unit)



9 スキャナ-連結ユニット (Scanner joint unit)

[illegible]


9 スキャナ-連結ユニット (Scanner joint unit)



10 カセットユニット (Casette unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | JHNDP0164FCZ3 | BL | HL | N | D | Tray Handle upper トレイ取手上 |
| 2 | XEBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 3 | PCOV1643FCZ1 | AU | EZ | N | D | Handle cover DSK upper 取手カバー - DSK 上 |
| 4 | TLABZ4047FCZZ | AC | DJ | | C | Enagv star label (U.S.A) エナジースターラベル |
| 5 | LPLTP5412FCZZ | AP | EQ | | C | Side plate R 側板 R |
| 6 | LPLTM5414FCZ1 | AR | EQ | | C | Rotation plate 回転プレート |
| 7 | PSHEZ3130FCZZ | AB | DD | | C | Rotation plate sheet 回転プレートシートラリーノ |
| 8 | LX-BZ0884FCZZ | AB | DD | | C | Pinion gear CGR ピニオンギヤ CGR |
| 9 | LPI NS7062SCZZ | AA | DD | | C | Pin(φ3-16) ピン |
| 10 | NGERH0193FCZZ | AB | DD | | C | Manual feed gear 手差しギヤ |
| 11 | PGIDH1833FCZ1 | AC | DJ | | C | Side plate guide 側板ガイド |
| 12 | PTPE-0243FCZ1 | AC | DJ | | C | Side plate tape N 側板両面テープ N |
| 13 | LPLTP5411FCZZ | AQ | EQ | | C | Side plate F 側板 F |
| 14 | MLEVP0755FCZ1 | AE | DJ | | C | Side plate F lever 側板 F レバ |
| 15 | MSPRC2631FCZZ | AC | DJ | | C | Side plate F lever spring 側板 F レバ スプリング |
| 16 | MLEVP0754FCZZ | AF | DS | | C | Rear plate lever copier 後端レバ - コピー |
| 17 | MSPRC2640FCZZ | AC | DJ | | C | Rear plate spring 後端板スプリング |
| 18 | LPLTP5413FCZZ | AF | DS | | C | Rear plate 後端板 |
| 21 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 22 | LX-BZ0833FCZZ | AC | DD | | C | Screw ビス |
| 23 | LSTPP0314FCZZ | AA | DJ | | C | Stopper ストップ |
| 24 | NSFTZ2467FCZZ | AF | DS | | C | Size detection rack shaft サイズ検知ラックシャフト |
| 25 | LDAIU0576FCZZ | AG | DX | | C | Size detection block サイズ検知ブロック |
| 26 | MSPRC2642FCZ1 | AB | DJ | | C | Tray earth spring カセットアーススプリング |
| 27 | NGERK1272FCZ1 | AF | DS | | C | Gear ギヤ |
| 29 | CSFTZ2553FC01 | AN | EG | | C | Lift shaft unit リフトシャフトユニット |
| 30 | NBRGP0626FCZZ | AC | DJ | | C | Bearing(M8) 軸受け |
| 31 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 32 | TLABZ4238FCZZ | AD | DJ | | C | Size display label (Japan only) サイズ表示ラベル |
| | TLABZ4239FCZZ | AD | DJ | | C | Size display label (Except Japan)[AB Series] サイズ表示ラベル |
| | TLABZ4240FCZZ | AD | DJ | | C | Size display label (Except Japan)[Inch Series] サイズ表示ラベル |
| 33 | MSPRC2669FCZZ | AB | DJ | | C | Tray right earth spring カセット右アーススプリング |
| 34 | LPLTM5416FCZZ | AH | DX | | C | Tray reinforce plate right カセット補強右プレート |
| 36 | LHLDZ1377FCZZ | AD | DJ | | C | Rear plate holder 後端プレートホルダー |
| 37 | LX-BZ0531FCZZ | AA | DD | | C | Screw(4×8) ビス |
| 39 | GCASP0173FCZ2 | BA | FX | | C | 550 sheets cassette 550 枚カセット |
| 40 | LHLDW1226FCZZ | AB | DJ | | C | Turn fastener ターンファスター |
| (Unit) | | | | | | |
| 901 | CCASP0173FC15 | BG | GT | | E | Casette unit (Japan only) カセットユニット |
| | CCASP0173FC16 | BG | GT | | E | Casette unit (Except Japan)[AB Series] カセットユニット |
| | CCASP0173FC17 | BF | GN | | E | Casette unit (Except Japan)[Inch Series] カセットユニット |


10 カセットユニット (Casette unit)



11 給紙ユニット (Paper feed unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | PCASZ0299FCZZ | AF | DS | N | C | Belt connector case ベルトコネクタケース |
| 2 | DHAI-3339FC11 | AV | FG | N | C | Paper feed harness 給紙ハーネス |
| 3 | XHBSE30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 4 | MARMP0293FCZ1 | AL | EB | N | C | Pick-up roller arm 呼び込みローラーアーム |
| 5 | MSPRD3084FCZZ | AD | DJ | N | C | Pick up roller arm spring 呼び込みローラーアームスプリング |
| 6 | MSPRC3074FCZZ | AC | DJ | N | C | Connector slide spring コネクタスライドスプリング |
| 7 | LX-BZ0850FCZZ | AC | DD | | C | Screw ビス |
| 8 | PCLC-0321FCZZ | AT | EZ | N | B | PF clutch W PFクラッチW |
| 9 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 10 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 11 | NBRGC0387FCZ1 | AC | DJ | | C | Bearing 軸受け |
| 12 | NSFTZ2700FCZZ | AQ | EQ | N | C | Paper feed roller shaft 給紙ローラシャフト |
| 13 | PGIDM1981FCZZ | AH | DX | N | C | Pick-up roller guide 呼び込みローラガイド |
| 14 | MSPRC3169FCZZ | AC | DJ | N | C | Pick-up spring 呼び込みスプリング |
| 15 | NPLYZ0409FCZZ | AL | EB | N | C | Paper feed roller pulley 給紙ローラプーリー |
| 16 | NCPL-0049FCBZ | AT | EZ | | C | MF separator coupling マルチ分離カップリング |
| 17 | NROLR1411FCZZ | AK | EB | N | B | Paper feed separator roller 給紙分離ローラ |
| 18 | NSFTZ2591FCZZ | AF | DS | | C | Pick-up roller shaft 呼び込みローラシャフト |
| 19 | NPLYZ0365FCZZ | AC | DJ | | C | Pick-up roller pulley 呼び込みローラプーリー |
| 20 | NBLTH0239FCZZ | AF | DX | | C | Belt(55MXL3.2) ベルト |
| 21 | NROLR1428FCZZ | AK | DX | N | B | Pick-up roller 呼び込みローラ |
| 22 | VHGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 23 | CFRM-1081FC01 | AU | FG | N | C | Paper feed frame 給紙フレーム |
| 24 | XEBSD40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 25 | PGIDM1983FCZZ | AS | EQ | N | C | PF upper front PG 給紙上前PG |
| 26 | MLEVP0695FCZZ | AC | DJ | | C | H Paper feeding lever H 給紙レバー |
| 27 | LHLDZ1517FCZZ | AE | DS | N | C | Belt connector holder ベルトコネクタホルダー |
| 28 | MSPRC3073FCZZ | AC | DJ | N | C | Belt connector spring ベルトコネクタスプリング |
| 29 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 30 | XHBSE30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 31 | XEBSD40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 32 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| | | | | | | (Unit) |
| 901 | CFRM-1081DS51 | BK | HG | N | E | Paper feed unit(Without No.29,30,31) 給紙ユニット(No.29,30,31 除く) |


11 給紙ユニット (Paper feed unit)



12 給紙駆動ユニット (Paper feeding drive unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|--------|---------------|------------|-----|----------|-----------|---|----------------------|
| | | Ex. | Ja. | | | | |
| 1 | CFRM-1063FC01 | AU | EZ | N | C | Paper feeding drive frame | 給紙駆動フレーム |
| 2 | NBRGY2122SCZZ | AB | DD | | C | Bearing | ベアリング |
| 3 | NSFTZ2688FCZZ | AL | EB | N | C | Multi output shaft | マルチ出力シャフト |
| 4 | LPINS0133FCZZ | AA | DD | | C | Pin(φ2-10) | ピン(φ2-10) |
| 5 | PCLC-0297FCZZ | AU | FG | | B | PS front clutch | PS 前クラッチ |
| 6 | CPLTM5983FC01 | AL | EB | N | C | Paper feed motor fixing plate | 給紙モータープレート |
| 7 | RMOTP0891FCZZ | BG | GT | N | B | Paper feed motor | 給紙モーター |
| 8 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) | ビス |
| 10 | NBRGC0651FCZZ | AD | DJ | | C | Bearing | 軸受け |
| 11 | XRESP70-08000 | AA | DD | | C | E type ring | E-リング |
| 12 | XRESP40-06000 | AA | DD | | C | E type ring | E-リング |
| 13 | PCLC-0298FCZZ | AT | EZ | | B | Paper feed clutch | 給紙クラッチ |
| 14 | NGERH1497FCZZ | AE | DS | N | B | PF gear(37T) | 給紙出力ギヤ |
| 15 | XRESP50-06000 | AA | DD | | C | E type ring | E-リング |
| 16 | NGERH1252FCZZ | AD | DJ | | C | Delivery change gear(21T) | 排紙変速ギヤ |
| 17 | NSFTZ2687FCZZ | AK | EB | N | C | Transfer output shaft | 搬送出力シャフト |
| 18 | QCNCM0999FCZZ | AC | DJ | | C | Connector(BU02P-TR-PH) | コネクター |
| 19 | QCNCM1000FCZZ | AC | DJ | | C | Connector(BU3P-TR-P-H) | コネクター |
| 20 | NGERH1496FCZZ | AE | DJ | N | C | PF reduction gear(65T) | 給紙減速ギヤ |
| 21 | NGERH0111FCWZ | AD | DJ | | C | Idle gear(24T) | アイドルギヤ |
| 22 | NGERH0867FCZZ | AC | DD | | C | Delivery gear(20T) | 排紙伝達ギヤ |
| 23 | NGERH0866FCZZ | AC | DD | | B | Gear(22T) | ギヤ |
| 24 | NGERH1510FCZZ | AD | DJ | N | B | PS drive gear(20T) | PS 駆動ギヤ |
| 25 | LBNDJ0043FCZ1 | AA | DJ | | C | Band(SG-130) | バンド |
| 26 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) | ビス |
| (Unit) | | | | | | | |
| 901 | CFRM-1063DS51 | BF | GN | N | E | Paper feeding drive unit(Without No.7,26) | 給紙駆動ユニット(No.7,26 除く) |


12 給紙駆動ユニット (Paper feeding drive unit)



13 マルチ手差しユニット 1(Multi manual paper feeding unit 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | LHLDZ1524FCZZ | AK | DX | N | C | Tray fulcrum holder R トレイ支点ホルダー-R |
| 2 | XEBSE40P10000 | AA | DD | | C | Screw(4x10) ビス |
| 3 | PCOVP1653FCZZ | AN | EQ | N | C | MF rear cover 250 手差し後カバー-250 |
| 4 | LSOU-0026QSCZ | BA | FX | N | C | Multi paper feed tray 2 upper 手差しトレイ2 上 |
| 5 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 6 | QSW-B0017QSZZ | AF | DS | N | B | Tray detect switch トレイ検知スイッチ |
| 7 | MLEVP0035QSE1 | AC | DJ | | C | Original detect actuator 原稿検知アクチュエーター |
| 8 | LSOU-0193FCZ5 | AN | EQ | N | C | Slide tray L (100V Series) スライドトレイ L |
| | LSOU-0193FCZZ | AP | EQ | N | C | Slide tray L (200V Series) スライドトレイ L |
| 9 | DHA1-3359FC11 | AQ | EQ | N | C | MF tray harness 手差しトレイハーネス |
| 10 | LSOU-0190FCZ5 | AV | FG | N | C | Multi paper feed tray 250 lower (100V Series) マルチトレイ250 下 |
| | LSOU-0190FCZZ | AT | EZ | N | C | Multi paper feed tray 250 lower (200V Series) マルチトレイ250 下 |
| 11 | PG1DW2015FCZZ | AG | DS | N | C | Support guide 補助ガイド |
| 13 | XEBSE30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 14 | LPLTP6020FCZZ | AF | DS | N | C | Width detector fixing plate 幅検知取付けプレート |
| 15 | CPWBF0106RS51 | AP | EQ | | E | Multi paper feed VR PWB ティン VR 基板ユニット |
| 16 | NGERP1385FCZZ | AF | DS | | C | Width detect pinion gear 幅検知ピニオンギヤ |
| 17 | XEPSD30P06X00 | AA | DD | | C | Screw(3x6X) ビス |
| 18 | NGERR1386FCZZ | AE | DJ | | C | Width detect rack gear 幅検知ラックギヤ |
| 19 | RDTCH0155FCZZ | AU | EZ | N | B | Hygrometer sensor 湿度センサーユニット |
| 20 | LHLDZ1521FCZZ | AE | DJ | N | C | Harness holder ハーネスホルダー |
| 21 | LSOU-0189FCZ5 | AT | EZ | N | C | Multi paper feed tray 250 upper (100V Series) マルチトレイ250 上 |
| | LSOU-0189FCZZ | AU | EZ | N | C | Multi paper feed tray 250 upper (200V Series) マルチトレイ250 上 |
| 22 | MSPRC2114FCZZ | AB | DJ | | C | Lock spring ロックスプリング |
| 23 | PTME-0271FCZZ | AD | DJ | | C | Tray lock pawl トレイロック爪 |
| 24 | PG1DM1987FCZZ | AG | DS | N | C | Size guide 250R サイズガイド 250R |
| 25 | PG1DM1986FCZZ | AF | DS | N | C | Size guide 250F サイズガイド 250F |
| 26 | PCOVP1652FCZZ | AN | EG | N | C | MF front cover 250 手差し前カバー-250 |
| 27 | LHLDZ1523FCZZ | AH | DX | N | C | Tray fulcrum holder F トレイ支点ホルダー-F |
| 28 | XEBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 29 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 30 | TLABZ4759FCZZ | AH | DX | N | C | MF size label (Japan only) ティンサイズラベル |
| (Unit) | | | | | | |
| 901 | DUNT-7187DSZZ | BV | RB | N | E | Multi paper feed unit(Include Block 14,15 Without No.29,30) (100V Series) マルチ給紙ユニット(ﾌﾞﾛｯｸ14,15 含む。No.29,30 含まない) |
| | DUNT-7187DS11 | BV | RB | N | E | Multi paper feed unit(Include Block 14,15 Without No.29,30) (200V Series) マルチ給紙ユニット(ﾌﾞﾛｯｸ14,15 含む。No.29,30 含まない) |

13 マルチ手差しユニット 1(Multi manual paper feeding unit 1)




FCP06323

14 マル手差しユニット 2(Multi manual paper feeding unit 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | PCOVP1639FCZ5 | AR | EQ | N | C | MF upper cover (100V Series) 手差し上カバー |
| | PCOVP1639FCZZ | AQ | EQ | N | C | MF upper cover (200V Series) 手差し上カバー |
| 2 | MSPRT3121FCZ1 | AC | DJ | N | C | Roller pressure spring ロータ加压スプリング |
| 3 | NSFTZ2707FCZZ | AH | DX | N | C | PS front follow roller shaft PS 前従動ローラシャフト |
| 4 | NRÖLP1060FCZZ | AF | DS | | C | U-turn roller Uターンローラ |
| 6 | PGiDM1974FCZ5 | AV | FG | N | C | MF upper PG (100V Series) 手差し上ペーパーガイド |
| | PGiDM1974FCZ1 | AV | FG | N | C | MF upper PG (200V Series) 手差し上ペーパーガイド |
| 7 | PSHEP5037FCZZ | AC | DJ | N | C | Upper PG sheet 上 PG シート |
| 8 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 9 | NBRGM0096FCZ1 | AC | DJ | | C | Bearing 軸受け |
| 10 | PCLC-0317FCZZ | AR | EQ | N | B | Pick-up start limiter 呼び込み起動リミッター |
| 11 | MSPRD3100FCZZ | AC | DJ | N | C | Stopper arm spring ストップアームスプリング |
| 12 | MLNKP0027FCZZ | AE | DJ | N | C | Pick-up link 呼び込みリンク |
| 13 | CPLTM6071FC01 | AK | DX | N | C | Stopper support plate ストップ支持プレート |
| 14 | PGiDM1985FCZZ | AF | DS | N | C | Support PG 補助ペーパーガイド |
| 15 | PSHEP5071FCZZ | AB | DJ | N | C | Paper guide sheet 用紙ガイドシート |
| 17 | PCOVP1658FCZ1 | AG | DX | N | C | Connected cover 運動カバー |
| 18 | PCOVP1642FCZ1 | AL | EB | N | C | Arm cover 250 アームカバー 250 |
| 19 | LSTPP0366FCZZ | AD | DJ | N | C | Stopper ストップ |
| 20 | MLEVP0871FCZZ | AD | DJ | N | C | Stopper release lever ストップ解除レバー |
| 21 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 22 | XEBSE40P10000 | AA | DD | | C | Screw(4×10) ビス |
| 23 | PSHEP5022FCZZ | AC | DJ | N | C | Pick-up guide sheet 呼び込みガイドシート |
| 24 | NSFTZ2701FCZZ | AK | DX | N | C | Pick-up roller shaft 呼び込みローラシャフト |
| 25 | NPLYZ0398FCZZ | AC | DJ | | C | Pick-up roller pulley(22T) 呼び込みローラプーリー |
| 26 | NBLTT7029XCZZ | AG | DS | | C | Drive belt 駆動ベルト |
| 27 | NRÖLR1428FCZZ | AK | DX | N | B | Pick-up roller 呼び込みローラ |
| 28 | NRÖLR1311FCZZ | AN | EG | | B | Paper feed separator roller 給紙分離ローラ |
| 29 | NCPL-0049FCZZ | AH | DX | | C | One-way coupling ワンウェイカップリング |
| 30 | NPLYZ0404FCZZ | AE | DJ | N | C | MF drive pulley 手差し駆動プーリー |
| 31 | MARMP0294FCZ1 | AM | EG | N | C | Pick-up arm 250 呼び込みアーム 250 |
| 32 | CSFTZ2698DS51 | AQ | EQ | N | E | Multi paper feed roller shaft 手差し給紙ローラシャフト |
| 33 | PSHEP5086FCZZ | AB | DJ | N | C | Wave prevention sheet 波打防止シート |
| 34 | NBRGC0280FCZZ | AB | DD | | C | Bearing 軸受け |
| 35 | PSHEP5119FCZZ | AB | DJ | | C | Harness guide sheet ハーネスガイドシート |
| (Unit) | | | | | | |
| 901 | DUNT-7187DSZZ | BV | RB | N | E | Multi paper feed unit(Include Block 13,15) (100V Series) マル手給紙ユニット (ブロック 13,15 含む) |
| | DUNT-7187DS11 | BV | RB | N | E | Multi paper feed unit(Include Block 13,15) (200V Series) マル手給紙ユニット (ブロック 13,15 含む) |

14 マル手差しユニット 2(Multi manual paper feeding unit 2)




FCP06324

15 マルチ手差しユニット 3(Multi manual paper feeding unit 3)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | NROLR1400FCZZ | AS | EZ | N | C | PS front roller PS 前ローラー |
| 2 | PSHEP4971FCZZ | AC | DJ | N | C | PF guide sheet mylar 給紙ガイドマイラー |
| 3 | PSHEZ4788FCZ1 | AD | DJ | | C | Manual feed sheet BE 手差しシート BE |
| 4 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 5 | NGERH0317FCZZ | AC | DJ | | C | DV gear(18T) DVギヤ |
| 6 | LPINS0155FCZZ | AA | DD | | C | Pin(φ3-10) ペイコピン |
| 7 | NBRGC0504FCZZ | AC | DJ | | C | Bearing 軸受け |
| 8 | NGERH1526FCZZ | AE | DJ | N | C | Reverse drive gear 逆転駆動ギヤ |
| 9 | MSPRC3122FCZZ | AD | DJ | N | C | Shaft earth spring シャフトアースプリング |
| 10 | NGERH1536FCZZ | AC | DJ | N | C | Idle gear(18T) アイドルギヤ |
| 11 | NGERH1511FCZZ | AE | DJ | N | C | Idle gear(21/24) アイドルギヤ |
| 12 | CFRM-1075FC01 | AN | EG | N | C | Multi paper feed drive frame 手差し駆動フレーム |
| 13 | XEBSE40P10000 | AA | DD | | C | Screw(4x10) ビス |
| 14 | LPINS0133FCZZ | AA | DD | | C | Pin(φ2-10) ペイコピン |
| 15 | NGERH1383FCZZ | AD | DJ | | C | Fusing drive gear(30T) 定着駆動ギヤ |
| 16 | NBRGM0096FCZ1 | AC | DJ | | C | Bearing 軸受け |
| 17 | PCLC-0298FCZZ | AT | EZ | | B | Paper feed clutch 給紙クラッチ |
| 18 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 19 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 20 | PCOVP1640FCZ5 | AL | EB | N | C | MF lower cover (100V Series) 手差し下カバー |
| 21 | PCOVP1640FCZ1 | AN | EQ | N | C | MF lower cover (200V Series) 手差し下カバー |
| 22 | MARMP0295FCZZ | AF | DS | N | C | Separator roller release arm 分離ローラー解除アーム |
| 23 | MLEVP0852FCZZ | AG | DS | N | C | PE actuator 250 PE アクチュエータ 250 |
| 24 | MSPRD3099FCZ1 | AC | DJ | N | C | RE actuator spring RE アクチュエータスプリング |
| 25 | PCOVP1641FCZZ | AG | DS | N | C | Maintenance cover メンテナンスカバー |
| 26 | MLNKP0029FCZZ | AD | DJ | N | C | RE actuator link RE アクチュエータリンク |
| 27 | VHGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 28 | MSPRC3066FCZZ | AC | DJ | N | C | Separator roller spring 分離ローラースプリング |
| 29 | LHLDZ1520FCZZ | AC | DJ | N | C | Separate roller shaft holder 分離ローラー軸ホルダー |
| 30 | CSFTZ2702DS51 | AP | EQ | N | E | Multi paper feed roller separate shaft 手差し分離ローラーシャフト |
| 31 | PCLC-0316FCZ1 | AR | EQ | N | B | Sparater roller torque limiter 分離ローラトルクリミッター |
| 32 | NROLR1311FCZZ | AN | EG | | B | Paper feed separator roller 給紙分離ローラー |
| 33 | PGIDM1973FCZ5 | AS | EQ | N | C | MF lower PG 250 (100V Series) 手差し下ペーパーガイド 250 |
| 34 | PGIDM1973FCZZ | AU | EZ | N | C | MF lower PG 250 (200V Series) 手差し下ペーパーガイド 250 |
| 35 | PSHEZ5088FCZZ | AF | DS | | C | Guide sheet ガイドシート |
| 36 | LSTYM0295FCZZ | AL | EB | N | C | Multi paper feed PG stay 手差し上 PG ステー |
| 37 | PSHEP4970FCZ2 | AE | DS | N | C | PS front guide mylar PS 前ガイドマイラー |
| 38 | PSHEP4993FCZ2 | AE | DS | N | C | PS front guide sheet B PS 前ガイドシート B |
| 39 | LX-WZ2011SCZZ | AA | DD | | C | Washer ホリスライダ |
| 40 | (Unit) | | | | | |
| 901 | DUNT-7187DSZZ | BV | RB | N | E | Multi paper feed unit(Include Block 13,14) マルチ給紙ユニット (ブロック 13,14 含む) (100V Series) |
| | DUNT-7187DS11 | BV | RB | N | E | Multi paper feed unit(Include Block 13,14) マルチ給紙ユニット (ブロック 13,14 含む) (200V Series) |


15 マルチ手差しユニット 3(Multi manual paper feeding unit 3)



16 縦搬送ガイドユニット (Vertical transport guide unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | PGiDM1977FCZZ | AN | EG | N | C | Vertical transfer guide R 縦搬送ガイド 右 |
| 2 | NROLP0896FCZZ | AC | DD | | C | Transport sub roller 搬送従動ローラ |
| 3 | NSFTZ2704FCZZ | AL | EB | N | C | Vertical transfer follow shaft 縦搬送従動シャフト |
| 4 | MSPRT3094FCZ1 | AC | DJ | N | C | Transfer spring 1 搬送スプリング 1 |
| 5 | XEBSE30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 6 | LPLTP6019FCZZ | AD | DJ | N | C | Release fulcrum plate 解除支点プレート |
| 7 | MLEVP0853FCZ1 | AF | DS | N | C | Guide lock release lever GID ロック解除レバー |
| 8 | PMLT-1305FCZZ | AC | DJ | N | C | Right door cushion upper 右ドアモット上 |
| 9 | MSPRD3093FCZ1 | AC | DJ | N | C | Look release spring ロック解除スプリング |
| 10 | PMLT-1304FCZZ | AC | DJ | N | C | Right door cushion FR 右ドアモット FR |
| 11 | GCAB-0983FCZ5 | AQ | EQ | N | C | Right door cabinet (100V Series) 右ドアキャビネット (100V Series) |
| | GCAB-0983FCZZ | AS | EQ | N | C | Right door cabinet (200V Series) 右ドアキャビネット (200V Series) |
| 12 | PMLT-1313FCZZ | AC | DJ | N | C | Right door cushion R 右ドアモット R |
| 13 | PCOVP1707FCZZ | AG | DX | N | D | LCC cover N LCC カバー N |
| 14 | XEBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 15 | LSTPP0275FCZZ | AE | DS | | C | Stopper ストッパー |
| 16 | LHLDZ1514FCZZ | AK | DX | N | C | Right door fulcrum holder F 右ドア支点ホルダー F |
| 17 | XHBSE40P12000 | AA | DD | | C | Screw(4×12) ビス |
| 19 | PMLT-1303FCZ1 | AD | DJ | N | C | Right door cushion lower 右ドアモット下 |
| 20 | PMLT-1317FCZZ | AH | DX | N | C | Right door cushion middle 右ドアモット中 |
| 21 | XRESP70-08000 | AA | DD | | C | E type ring (Except Japan) E-リング (Except Japan) |
| 22 | NGERH0111FCWZ | AD | DJ | | C | Idle gear(24T) アイドルギヤ (Except Japan) |
| 23 | MARMP0297FCZZ | AB | DJ | N | C | LCC transport roller gear arm (Except Japan) LCC 搬送ローラーギアアーム (Except Japan) |
| 24 | NBRGP0626FCZZ | AC | DJ | | C | Bearing(M8) 軸受け (Except Japan) |
| 25 | MSPRC2616FCZZ | AC | DJ | | C | DV drive spring (Except Japan) DVドライブスプリング (Except Japan) |
| 26 | LSTPP0274FCZZ | AA | DD | | C | Stopper ストッパー (Except Japan) |
| 27 | NROLR1406FCZZ | AM | EG | N | C | LCC transport roller (Except Japan) LCC 搬送ローラー (Except Japan) |
| 28 | NBRGC0188FCZZ | AB | DD | | C | Bearing (Except Japan) 軸受け (Except Japan) |
| 29 | XEBSE30P08000 | AA | DD | | C | Screw(3×8) ビス (Except Japan) |
| 30 | PGiDM1990FCZZ | AH | DX | N | C | LCC transport guide L (Except Japan) LCC 搬送ガイド L (Except Japan) |
| 31 | PGiDM1989FCZZ | AH | DX | N | C | LCC transport guide R (Except Japan) LCC 搬送ガイド R (Except Japan) |
| 32 | PCLR-0442FCZZ | AD | DJ | | C | Sub collar (Except Japan) 補助コリヤ (Except Japan) |
| 33 | NSFTZ2703FCZZ | AF | DS | N | C | LCC transport sub shaft (Except Japan) LCC 搬送従動シャフト (Except Japan) |
| 34 | MSPRT3092FCZZ | AC | DJ | N | C | LCC transport spring (Except Japan) LCC 搬送スプリング (Except Japan) |
| 35 | LPI NS0155FCZZ | AA | DD | | C | Pin(φ3-10) ヘイコピン (Except Japan) |
| 36 | PSHEP5115FCZZ | AC | DJ | N | C | Vertical transfer mayler 縦搬送マイラー |
| (Unit) | | | | | | |
| 901 | CGiDM1977DS51 | BA | FX | N | E | Vertical transfer guide unit(Without No.15,16,17) (Japan only) 縦搬送ガイドユニット (No.15,16,17 除く) (Japan only) |
| | CGiDM1977DS52 | BC | GJ | N | E | Vertical transfer guide unit(Without No.15,16,17) (Except Japan)[100V Series] 縦搬送ガイドユニット (No.15,16,17 除く) (Except Japan)[100V Series] |
| | CGiDM1977DS53 | BC | GJ | N | E | Vertical transfer guide unit(Without No.15,16,17) (Except Japan)[200V Series] 縦搬送ガイドユニット (No.15,16,17 除く) (Except Japan)[200V Series] |

16 縦搬送ガイドユニット (Vertical transport guide unit)




FCP06326

17 カセットガイド R・縦搬送下ユニット (Cassette guide R/Vertical transport lower unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | MLEVP0854FCZZ | AC | DJ | N | C | Transfer actuator 搬送アクチュエータ |
| 2 | MSPRD3067FCZZ | AC | DJ | N | C | Actuator spring アクチュエータ復帰スプリング |
| 3 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor (GP1A71L3) フォトセンサー |
| 4 | DHAI-3341FCZZ | AH | DX | N | C | PFD harness PFDハーネス |
| 5 | XEBSD30P16000 | AA | DD | | C | Screw (3x16) ビス |
| 6 | QSW-M0502FCZZ | AH | DX | | B | Door switch (AM51632C531) ドアスイッチ |
| 7 | NGERH1245FCZZ | AF | DS | | C | Transport drive gear (28T) 搬送駆動ギヤ |
| 8 | NGERH0111FCWZ | AD | DJ | | C | Idle gear (24T) アイドルギヤ |
| 9 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 10 | LSTPP0274FCZZ | AA | DD | | C | Stopper ストップバー |
| 11 | NBRGP0626FCZZ | AC | DJ | | C | Bearing (M8) 軸受け |
| 12 | LPINS0096FCZZ | AB | DD | | C | Pin (φ3-12) ピン |
| 13 | LPINS0155FCZZ | AA | DD | | C | Pin (φ3-10) ヘイコピン |
| 14 | NROLR1401FCZZ | AS | EQ | N | C | Vertical transfer roller 縦搬送ローラ |
| 15 | NBRGC0188FCZZ | AB | DD | | C | Bearing 軸受け |
| 16 | NROLR1429FCZZ | AS | EQ | N | C | Vertical transfer roller lower 縦搬送ローラ下 |
| 18 | PGIDM1802FCZZ | AK | DX | | C | Paper feed enter PG 給紙口ベアリングガイド |
| 19 | XEBSE40P08000 | AA | DD | | C | Screw (4x8) ビス |
| 20 | PGIDM1988FCZZ | AS | EZ | N | C | Vertical transfer lower PG 縦搬送下 PG |
| 21 | NROLP0896FCZZ | AC | DD | | C | Transport sub roller 搬送従動ローラ |
| 22 | LX-BZ0960FCZZ | AC | DD | | C | Screw ビス |
| 23 | MSPRT3094FCZ1 | AC | DJ | N | C | Transfer spring 1 搬送スプリング 1 |
| 24 | NSFTZ2704FCZZ | AL | EB | N | C | Vertical transfer follow shaft 縦搬送従動シャフト |
| 25 | PCOVP1509FCZZ | AH | DX | | D | Transport stay R cover 搬送ステー R カバー |
| 26 | XEBSD30P08000 | AA | DD | | C | Screw (3x8) ビス |
| 27 | LFIX-0524FCZZ | AC | DJ | | C | PG collar holder PG コロ押え |
| 28 | PCLR-0450FCZZ | AD | DJ | | C | PG collar PG コロ |
| 29 | NBLTH0376FCZZ | AF | DS | N | C | Sub roller belt 補助ローラベルト |
| 30 | NPLYZ0403FCZZ | AD | DJ | N | C | Sub roller pulley 補助ローラプーリー |
| 31 | PRNGP0081FCZZ | AA | DJ | | C | Ring (E4) リング |
| 32 | PSHEZ5007FCZZ | AF | DS | N | C | Sub belt sheet 補助ベルトシート |
| 33 | MSPRP3105FCZZ | AC | DJ | N | C | Transfer roller earth spring 搬送ローラース板バネ |
| 35 | PGIDM1978FCZZ | AW | FG | N | C | Cassette guide R カセットガイド R |
| 36 | PGIDM1984FCZZ | AF | DS | N | C | PF lower front PG 給紙下前ベアリングガイド |
| 37 | MSPRC3085FCZ1 | AC | DJ | N | C | Separator roller pressure spring 分離ローラ加圧スプリング |
| 40 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 41 | CSFTZ2706DS51 | AP | EQ | N | C | Separate roller shaft 分離ローラシャフト |
| 42 | NROLR1411FCZZ | AK | EB | N | B | Paper feed separator roller 給紙分離ローラ |
| 43 | PCLC-0316FCZ1 | AR | EQ | N | B | Separator roller torque limiter 分離ローラトルクリミッター |
| 44 | PGIDM1982FCZZ | AF | DS | N | C | Separator roller guide 分離ローラガイド |
| 45 | XHBSE40P08000 | AA | DD | | C | Screw (4x8) ビス |


17 カセットガイド R・縦搬送下ユニット (Cassette guide R/Vertical transport lower unit)



18 PSユニット (PS unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | NROLP1403FCZZ | AR | FQ | N | C | PS follow roller PS 従動ローラ |
| 2 | NBRGP0604FCZZ | AD | DJ | | C | Bearing 軸受け |
| 3 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 4 | NBLTH0373FCZZ | AF | DS | N | C | PS drive belt PS 駆動ベルト |
| 5 | NPLYZ0352FCZZ | AE | DJ | | C | PS drive pulley PS 駆動プーリー |
| 6 | NBRGP0682FCZZ | AC | DJ | N | C | Bearing 軸受け |
| 7 | LPINS0096FCZZ | AB | DD | | C | Pin(φ3-12) ピン |
| 8 | MSPRC2731FCZ1 | AC | DJ | | C | PS pressure spring PS 加圧スプリング |
| 9 | NBRGP0626FCZZ | AC | DJ | | C | Bearing(M8) 軸受け |
| 10 | NROLR1402FCZZ | AU | EZ | N | C | PS roller PS ロール |
| 11 | PSHEP4972FCZ1 | AE | DS | N | C | PS front sheet A PS 前シート A |
| 12 | PGIDM1979FCZZ | AH | DX | N | C | PS front PG PS 前ペーパーガイド |
| 13 | DHAi-3342FCZZ | AE | DS | N | C | PPD2 harness PPD2 ハarness |
| 14 | MLEVP0857FCZZ | AF | DJ | N | C | PS front actuator PS 前アクチュエータ |
| 15 | MSPRD3097FCZZ | AC | DJ | N | C | PS front actuator spring PS 前アクチュエータスプリング |
| 16 | LFRM-1076FCZZ | AN | EG | N | C | PS frame PS フレーム |
| 17 | XEBSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 18 | CPWBF0083RS51 | AU | EZ | | E | Sensor PWB センサ基板 |
| 19 | PSHEP4985FCZ1 | AE | DJ | N | C | PS front sheet B PS 前シート B |
| 20 | MSPRC3104FCZZ | AD | DJ | N | C | PS earth spring PS アーススプリング |
| (Unit) | | | | | | |
| 901 | CFRM-1076DS51 | BD | GN | N | C | PS unit(Without No.4) PS ユニット (No.4 除く) |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

18 PSユニット (PS unit)




FCP06328

19 転写ベルトユニット 1(Transfer belt unit 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | PSHEZ4973FCZZ | AH | DX | N | B | Electric discharge sheet W 除電シート W |
| 2 | NBRGP0677FCZZ | AC | DJ | N | B | Bearing 軸受け |
| 3 | NROLR1391FCZZ | AY | FQ | N | A | Transfer roller W 転写ローラ W |
| 4 | NBRGP0678FCZZ | AF | DS | N | B | Bearing 軸受け |
| 5 | NBRGP0675FCZZ | AH | DX | N | B | Bearing 軸受け |
| 6 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 7 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 8 | MSPRD3046FCZZ | AD | DJ | N | C | Transfer roller electrode C spring 転写ローラ電気 C スプリング |
| 9 | MSPRC3047FCZZ | AB | DJ | N | C | Transfer roller pressure spring 転写ローラ加圧スプリング |
| 10 | LFRM-1064FCZ1 | AT | EZ | N | C | Belt frame ベルトハウジング |
| 13 | LX-BZ0949FCZZ | AC | DD | N | C | Screw ビス |
| 14 | LPLTM5986FCZZ | AD | DJ | N | C | Housing fixing plate ハウジング取付けプレート |
| 16 | MSPRD3045FCZZ | AD | DJ | N | C | Transfer roller electrode k spring 転写ローラ電気 K スプリング |
| 17 | CROLM1390FC01 | AW | FG | N | B | Belt sub roller ベルト従動ローラ |
| 18 | NSFTZ2690FCZ1 | AL | EB | N | C | Belt sub roller shaft ベルト従動ローラシャフト |
| 19 | MSPRC3044FCZ1 | AD | DJ | N | C | Belt tension spring ベルトテンションスプリング |
| 20 | NBRGP0676FCZ1 | AC | DJ | N | C | Bearing 軸受け |
| 22 | QEARP0139FCZZ | AD | DJ | N | C | Belt earth plate J ベルトアース板 J |
| 23 | XEBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 24 | NSFTZ2689FCZZ | AR | EQ | N | C | Belt idle shaft ベルトアイドルシャフト |
| 25 | QEARP0138FCZZ | AE | DJ | N | C | Belt earth plate K ベルトアース板 K |
| 26 | LHLDZ1509FCZZ | AF | DS | N | C | Belt pressure holder ベルト加圧ホルダー |
| 27 | MSPRC3109FCZZ | AC | DJ | N | C | Belt pressure spring ベルト加圧スプリング |
| 28 | XHBSD30P10000 | AA | DD | | C | Screw(3x10) ビス |
| 29 | LHLDZ1539FCZZ | AD | DJ | N | C | Belt holder ベルトホルダー |
| 30 | XEBSD30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 32 | CROLM1404DS51 | BB | GD | N | E | Belt drive roller unit ベルト駆動ローラユニット |
| 34 | PBRSR0222FCZZ | AK | DX | N | B | Belt CL brush ベルト CL ブラシ |
| 35 | PBRSR0223FCZ1 | AL | EB | N | B | Roller CL brush ローラ CL ブラシ |
| 36 | PSHEP5087FCZZ | AC | DJ | N | C | Earth plate fixing sheet アースプレート押えシート |
| 37 | NBRGP0674FCZZ | AE | DJ | N | C | Bearing 軸受け |
| 38 | LPLTM5714FCZZ | AB | DJ | | C | M3 Plate M3 プレート |
| 39 | LX-BZ0965FCZZ | AE | DS | N | C | Screw ビス |
| 40 | PSHEZ5130FCZZ | AA | DJ | N | C | Plate fixing sheet プレート押えシート |
| (Unit) | | | | | | |
| 901 | DUNT-7188DS11 | CE | UF | N | A | Transfer belt unit(Include Block 20, Without No.39) 転写ベルトユニット (ブロック 20 含む。No.39 除く) (Japan) |
| 901 | DUNT-7188DS12 | CE | UF | N | A | Transfer belt unit(Include Block 20, Without No.39) 転写ベルトユニット (ブロック 20 含む。No.39 除く) (Except Japan) |

19 転写ベルトユニット 1(Transfer belt unit 1)



20 転写ベルトユニット 2(Transfer belt unit 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | VHGP2TC21//1 | BE | GN | | B | Pro con sensor(GP1A71L3) プ ロンセンサ |
| 2 | XBBS30P06000 | AA | DD | | C | Screw(3x6) ビ ス |
| 3 | DHAI-3414FC11 | AL | EB | N | C | PCS harness PCS ハーネス |
| 4 | CPWBF1529DS51 | AR | EQ | N | E | Pro con PWB プ ロン基板 |
| 5 | PSEL-0853FCZZ | AC | DJ | N | C | Belt waste toner seal B ベ ルト廃トナーシール B |
| 6 | UCLEZ0170FCZZ | AK | EB | N | A | Belt toner blade ベ ルトトナー受け |
| 7 | XBBS30P06000 | AA | DD | | C | Screw(3x6) ビ ス |
| 9 | LPLTM5987FCZZ | AG | DX | N | C | Belt CL plate ベ ルト CL プレート |
| 10 | PSHEP4968FCZZ | AD | DJ | N | C | Belt waste toner transfer sheet ベ ルト廃トナー搬送シート |
| 11 | XBBS30P08000 | AA | DD | | C | Screw(3x8) ビ ス |
| 12 | UCLEZ0169FCZZ | AQ | EQ | N | A | Transfer blade 転写ブレード |
| 13 | XHBSE30P08000 | AA | DD | | C | Screw(3x8) ビ ス |
| 14 | PSEL-0809FCZZ | AD | DJ | N | C | Waste toner cover seal 廃トナーカバーシール |
| 15 | PCOVP1649FCZZ | AN | EG | N | C | Belt waste toner cover ベ ルト廃トナーカバー |
| 16 | PCAPH0009YSZZ | AC | DJ | | C | TN cap TN キャップ |
| 17 | MLEVP0843FCZ1 | AC | DJ | N | C | Belt CL lever ベ ルト CL レバー |
| 18 | MSPRT3049FCZZ | AC | DJ | N | C | Belt CL roller spring ベ ルト CL ローラ スプリング |
| 19 | NROLR1392FCZZ | BA | FX | N | A | Belt CL roller ベ ルト CL ローラ |
| 20 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 21 | NGERH1500FCZZ | AD | DJ | N | B | Belt waste toner gear ベ ルト廃トナーギヤ |
| 22 | PCLC-0318FCZZ | AC | DJ | N | B | Waste toner detector clutch 排紙トナー検知クラッチ |
| 23 | MLEVP0865FCZZ | AC | DS | N | C | Delivery toner detector lever A 排紙トナー検知レバー A |
| 24 | MSPRT2414FCZZ | AC | DJ | | C | SW lower pawl spring SW 下爪スプリング |
| 25 | NBRGP0664FCZZ | AD | DJ | | C | Bearing 軸受け |
| 26 | DHAI-3350FC11 | AV | FG | N | C | Belt drawer harness ベ ルト ドrawerハーネス |
| 27 | PCASZ0298FCZZ | AQ | EQ | N | C | Belt waste toner transfer case ベ ルト廃トナー搬送ケース |
| 28 | PMLT-1288FCZ1 | AB | DJ | N | C | Belt waste toner cushion A ベ ルト排紙トナーモルト A |
| 30 | PMLT-1287FCZZ | AB | DJ | N | C | Waste toner auger cushion 廃トナーオーガモルト |
| 31 | NSFTZ2712FCZ1 | AN | EG | N | C | Belt waste toner transfer shaft ベ ルト廃トナー搬送シャフト |
| 32 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 33 | LHLDZ1519FCZZ | AW | FG | N | C | Process control sensor holder プ ロンセンサホルダー |
| 34 | XBBS30P04000 | AA | DD | | C | Screw(3x4) ビ ス |
| 35 | RPLU-0013QSZZ | AN | EG | | B | Transport solenoid 搬送ソレノイド |
| 36 | XBBS30P10000 | AA | DD | | C | Screw(3x10) ビ ス |
| 37 | LX-BZ0036GCZZ | AC | DD | | C | Screw ビ ス |
| 38 | RMOTS0881FCZZ | BC | GD | N | B | Belt drive motor PM ベ ルト駆動モータ PM |
| 39 | CPLTM6011FC02 | AS | EQ | N | C | Belt drive plate ベ ルト駆動プレート |
| 40 | XBBS40P08000 | AA | DD | | C | Screw(4x8) ビ ス |
| 41 | TLABH4747FCZ1 | AH | DX | N | C | Transfer belt caution label (Japan) テンジャベルト注意ラベル |
| | TLABH4747FCZZ | AE | DJ | N | C | Transfer belt caution label (Except Japan) テンジャベルト注意ラベル |
| 42 | XHBS30P06000 | AA | DD | | C | Screw(3x6) ビ ス |
| 43 | LDAIU0656FCZZ | AF | DS | N | C | Belt idle fixing base ベ ルトアイドル固定板 |
| 44 | NGERH1499FCZZ | AG | DX | N | B | Belt idle gear ベ ルトアイドルギヤ |
| 45 | LX-WZ2011SCZZ | AA | DD | | C | Washer ホリスライダ |
| 46 | PSHT-0094FCZZ | AD | DJ | N | C | Process control shutter プ ロンシャッター |
| 47 | PCOVP1648FCZ1 | AE | DJ | N | C | Belt gear cover ベ ルトギアカバー |
| 48 | MSPRT3165FCZZ | AC | DJ | N | C | Process control shutter spring プ ロンシャッタースプリング |
| 49 | QSW-B0017QSZZ | AF | DS | N | B | Tray detect switch カセット検知スイッチ |
| 50 | TLABZ4772FCZ1 | AF | DJ | N | B | Criterion label 基準ラベル |
| 51 | XEPSD30P08X00 | AA | DD | | C | Screw(3x8X) ビ ス |
| 52 | PSEL-0831FCZZ | AC | DJ | N | C | Belt waste toner seal A ベ ルト廃トナーシール A |
| 53 | PSEL-0832FCZZ | AC | DJ | N | C | Belt waste toner seal B ベ ルト廃トナーシール B |
| 54 | PSEL-0855FCZZ | AA | DJ | N | C | Belt waste toner seal D ベ ルト廃トナーシール D |
| 55 | PSEL-0854FCZZ | AA | DJ | N | C | Belt waste toner seal C ベ ルト廃トナーシール C |
| 56 | PSHEP5076FCZZ | AC | DJ | N | C | Harnes fixing sheet ハーネス押シート |
| 57 | PSHEZ4974FCZZ | AC | DJ | N | B | Belt cushion ベ ルトモケット |
| 60 | MSPRC3106FCZZ | AC | DJ | N | C | Waste toner detector clutch spring 廃トナー検知クラッチスプリング |
| 61 | LX-WZ0445FCZ1 | AC | DD | N | C | Washer ホリスライダ |
| 62 | TCADZ1595FCZZ | AC | DJ | N | C | Transfer belt fixing release manual 転写ベルト固定解除手順書 |
| 63 | PSHEZ5126FCZZ | AF | DS | N | C | Blade protect sheet プ レード 保護シート |
| 501 | CCASZ0298DS52 | BK | HG | N | A | Belt waste toner unit ベ ルト廃トナーユニット |
| | (Unit) | | | | | |
| 901 | DUNT-7188DS11 | CE | UF | N | A | Transfer belt unit(Include Block 19, Without No.62,63) (Japan) 転写ベルトユニット(ブロック 19 含む。No.62,63 除く) |
| 901 | DUNT-7188DS12 | CE | UF | N | A | Transfer belt unit(Include Block 19, Without No.62,63) (Except Japan) 転写ベルトユニット(ブロック 19 含む。No.62,63 除く) |


21 転写リフトアップユニット (Transfer lift-up unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | NSFTZ2691FCZZ | AU | EZ | N | C | Belt lift-up cam shaft ベ ルトリフトアップ カムシャフト |
| 2 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 3 | LPLTP6098FCZZ | AD | DJ | N | C | Belt lift-up detector plate ベ ルトリフトアップ 検知プレート |
| 4 | MCAMP0106FCZZ | AC | DJ | N | C | Belt lift-up cam ベ ルトリフトアップ カム |
| 5 | LPIINS0096FCZZ | AB | DD | | C | Pin(φ3-12) ピン |
| 6 | CFRM-1066FC02 | AK | EB | N | C | Belt lift up frame F ベ ルトリフトアップ フレーム F |
| 7 | NSFTZ2730FCZZ | AK | EB | N | C | Belt brake shaft ベ ルトブレーキシャフト |
| 8 | NGERH1525FCZZ | AD | DJ | N | C | Belt brake gear ベ ルトブレーキギヤ |
| 9 | LX-WZ0445FCZ1 | AC | DD | N | C | Washer(M16) ホリスライダ |
| 10 | MSPRC3077FCZ1 | AC | DJ | N | C | Belt lift-up spring ベ ルトリフトアップ スプリング |


21 転写リフトアップユニット (Transfer lift-up unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 11 | XWHS030-08100 | AA | DD | | C | Washer ヒラ ワッシャー |
| 12 | LX-BZ0916FCZZ | AA | DD | | C | Screw ビス |
| 13 | NBRGC0319FCZ1 | AC | DJ | | C | Bearing 軸受け |
| 14 | PCLR-0474FCZZ | AC | DJ | N | C | Belt lift-up collar ベルトリフトアップ カラー |
| 15 | XHBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 16 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 17 | NGERH1504FCZZ | AD | DJ | N | C | Waste toner idle gear(42T) 廃トナーアイドルギヤ |
| 18 | CARMM0286FC01 | AG | DX | N | C | Waste toner gear arm ハイトナーギヤアーム |
| 19 | NGERH1503FCZZ | AC | DJ | N | C | Lift-up gear(12/24T) リフトアップギヤ |
| 20 | MSPRT3050FCZZ | AC | DJ | N | C | Waste toner gear aem spring 廃トナーギヤアームスプリング |
| 21 | CFRM-1066FC01 | AQ | EQ | N | C | Belt lift up frame R ベルトリフトアップフレームR |
| 22 | NGERH1505FCZZ | AD | DJ | N | C | Waste toner idle gear(12/18T) 廃トナーアイドルギヤ |
| 23 | NGERH1502FCZZ | AD | DJ | N | C | Lift-up gear(16/36T) リフトアップギヤ |
| 24 | NGERH1501FCZZ | AK | EB | N | B | Belt lift-up gear(44T) ベルトリフトアップギヤ |
| 25 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 26 | DHAI-3344FCZZ | AF | DS | N | C | BLUD harness BLUDハーネス |
| 27 | PSHEP4986FCZZ | AC | DJ | N | C | Lift-up edge protect sheet リフトアップエッジ保護シート |
| 28 | LSTYM0293FCZZ | AP | EQ | N | C | Belt lift-UP stay ベルトリフトアップステー |
| 29 | RMOTS0882FCZZ | BA | FX | N | B | Belt lift up motor ベルトリフトアップモーター |

20 転写ベルトユニット 2(Transfer belt unit 2)




21 転写リフトアップユニット (Transfer lift-up unit)



22 フォームユニット (Process unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|--------|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | XBBS230P08000 | AA | DD | | C | Screw(3×8) ビス |
| 2 | CFRM-1084DS51 | AR | EQ | N | E | MC frame unit MC フレームユニット |
| 3 | TLABZ4766FCZ1 | AC | DJ | N | C | ARW-label-BK ARW ラベル BK |
| 4 | CCASZ0302DS51 | BB | GD | N | A | MC unit MC ユニット |
| 5 | PSHEP5062FCZZ | AB | DJ | N | C | RFL sheet RFL シート |
| 6 | PLNS-0076FCZZ | AL | EB | N | B | DCH Lens DCH レンズ |
| 7 | LPLTM5714FCZZ | AB | DJ | | C | M3 plate M3 プレート |
| 8 | PSHEZ5027FCZZ | AB | DJ | N | B | Cleaning sheet クリーニングシート |
| 9 | NGERH1529FCZZ | AC | DJ | N | C | WTN-gear-21T(21T) ギヤ |
| 10 | CFRM-1083DS72 | AQ | EQ | N | E | Process frame unit フォームフレームユニット |
| 11 | PSHEZ4997FCZ1 | AC | DJ | N | A | Side sheet F サイドシート F |
| 12 | PSHEZ4998FCZ1 | AB | DJ | N | A | Side sheet R サイドシート R |
| 13 | PSHEP5061FCZ1 | AD | DJ | N | C | BLC sheet BLC シート |
| 14 | UCLEZ0171FCZ2 | AX | FG | N | A | Cleaner blade クリーナーブレード |
| 15 | PSHEP5089FCZZ | AA | DJ | N | C | Blade side sheet ブレードサイドシート |
| 16 | CSFTZ2716DS51 | AP | EQ | N | C | Drum shaft ドラムシャフト |
| 17 | XEBSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 18 | UCLEZ0172FCZ1 | AQ | EQ | N | A | WTN cleaner seel WTN クリーナーシール |
| 19 | QEARP0140FCZZ | AD | DJ | N | C | GND earth CL GND-アース-CL |
| 20 | NBRGP0688FCZ1 | AD | DJ | N | C | Bearing 軸受け |
| 21 | LSTPP0011QSZZ | AC | DJ | | C | Stopper ストップバー |
| 22 | XEBSD40P10000 | AA | DD | | C | Screw(3×10) ビス |
| 23 | TLABZ4753FCZZ | AA | DJ | N | C | Color label Y カラーラベル Y |
| | TLABZ4754FCZZ | AA | DJ | N | C | Color label M カラーラベル M |
| | TLABZ4755FCZZ | AA | DJ | N | C | Color label C カラーラベル C |
| | TLABZ4756FCZZ | AB | DJ | N | C | Color label BK カラーラベル BK |
| 24 | JHNDP0167FCZ2 | AC | DJ | N | C | MC cleaner handle MC CLE ハンドル |
| 25 | NSFTZ2736FCZZ | AP | EQ | N | C | MC cleaner shaft MC クリーナーシャフト |
| 26 | PMLT-1312FCZZ | AB | DJ | N | C | Cleaner cushion クリーナーモット |
| 27 | LPLTM6112FCZZ | AH | DX | N | C | Process frame RFC フォームフレーム RFC |
| 28 | NBRGP0687FCZZ | AG | DS | N | C | Bearing 軸受け |
| 29 | PSEL-0829FCZ1 | AC | DJ | N | C | Blade seal ブレードシール |
| 30 | PSHEZ5099FCZ1 | AC | DJ | N | C | DCT sheet DCT シート |
| 31 | PSEL-0835FCZ1 | AC | DJ | N | C | Drop seal ドロップシール |
| 32 | PSEL-0864FCZZ | AD | DJ | N | C | Drop seal BRS ドロップシール BRS |
| 33 | PSEL-0830FCZZ | AA | DJ | N | C | STP seal PIP STP シール PIP |
| 34 | PSEL-0866FCZZ | AB | DJ | N | C | PIP seal TOP PIP シール TOP |
| 35 | PSHEP5121FCZZ | AA | DJ | N | C | RING sheet PIP RING シート PIP |
| (Unit) | | | | | | |
| 901 | CFRM-1083DS51 | BK | HC | N | E | Process unit(Without No.3,16,21,23) (U.S.A Other countries) フォームユニット (No.3,16,21,23 除く) |
| | CFRM-1083DS52 | BH | HC | N | E | Process unit(Without No.3,16,21,23) (Japan, Europe, Australia, New Zealand) フォームユニット (No.3,16,21,23 除く) |


22 フォームユニット (Process unit)



23 ドラム駆動ユニット (Drum drive unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|--------|---------------|------------|-----|----------|-----------|--------------------------------------|-------------------------|
| | | Ex. | Ja. | | | | |
| 1 | DHAI-3351FCZZ | AD | DJ | N | C | MC CMY harness | MC CMY ハーネス |
| 2 | DHAI-3349FCZZ | AD | DJ | N | C | Drive interface high voltage harness | 駆動間高圧ハーネス |
| 3 | XHBSD30P06000 | AA | DD | | C | Screw(3x6) | ビス |
| 4 | DHAI-3365FCZZ | AH | DX | N | C | TES harness | TES ハーネス |
| 5 | LFRM-1062FCZZ | AP | EQ | N | C | DR drive frame T | DR 駆動フレーム T |
| 6 | NBRGC0672FCZZ | AE | DJ | N | C | Bearing | 軸受け |
| 7 | XEBSD40P08000 | AA | DD | | C | Screw(4x8) | ビス |
| 8 | LHLDW1155FCZZ | AC | DJ | | C | Wire holder(LWS3S2W) | ホルダー |
| 9 | MSPRP3038FCZZ | AC | DJ | N | C | Drive shaft electrode spring | 駆動軸7-スプ リング |
| 10 | RMOTS0879FCZZ | BD | GN | N | B | Drum drive motor | ドラム駆動モータ |
| 11 | LANGT1411FCZZ | AD | DJ | N | C | Drive PWB fixing angle | ドライブ 基板取付けアングル |
| 12 | CFRM-1061DS71 | AV | FG | N | E | DR drive frame B sub | DR 駆動フレーム B サブ |
| 13 | PRNGP0110FCZZ | AA | DJ | N | C | Ring | リング |
| 14 | NCPL-0056FCZZ | AF | DS | N | B | Drum joint coupling | ドラム連結カップ リング |
| 15 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) | フォトセンサー |
| 16 | MLEVP0842FCZZ | AE | DS | N | C | Empty detector lever | 満杯検知レバ ー |
| 18 | XRESP80-08000 | AA | DD | | C | E type ring | E- リング |
| 19 | LPINS0096FCZZ | AB | DD | | C | Pin(φ3-12) | ピン |
| 21 | CSFTZ2686DS51 | AV | FG | N | E | DR drive shaft | DR 駆動シャフト |
| 22 | MSPRD3042FCZZ | AD | DJ | N | C | DV electrode spring | DV 接点スプ リング |
| 23 | MSPRD3041FCZZ | AD | DJ | N | C | GB electrode spring | GB 接点スプ リング |
| 24 | LPLTM6003FCZZ | AD | DJ | N | C | MC joint terminal plate | MC 接続端子 プレート |
| 25 | MSPRD3040FCZZ | AC | DJ | N | C | MC electrode spring | MC 接点スプ リング |
| 27 | CPWBF1526DS51 | AP | EQ | N | C | LED DL PWB | LED DL 基板 |
| 28 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) | ビス |
| 29 | RMOTS0879FCNA | BD | GN | N | B | Drum drive motor BK | ドラム駆動モータ BK |
| 30 | LHLDW1061FCZZ | AB | DD | | C | Holder(HL-18-0) | ホルダー |
| (Unit) | | | | | | | |
| 901 | DUNT-7251DSZZ | BZ | TF | N | E | Drum drive unit(Without No.4,11,28) | ドラム駆動ユニット(No.4,11,28除く) |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |


23 ドラム駆動ユニット (Drum drive unit)



FCP06333

24

24 定着ユニット 1(Fusing unit 1)




25 定着ユニット 2(Fusing unit 2)

[illegible]

26 定着駆動ユニット (Fusing drive unit)


[illegible]

25 定着ユニット 2(Fusing unit 2)



FCP06335

26 定着駆動ユニット (Fusing drive unit)




FCP06336

27 左ドア (Left door)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | MLEVP0863FCZZ | AE | EB | N | C | Full actuator FU 満杯アクチュエータ FU |
| 2 | PGIDM1970FCZZ | BB | EQ | N | C | Delivery guide upper 排紙ガイド上 |
| 3 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 4 | MSPRP3056FCZZ | AF | DS | N | C | Delivery roller spring 排紙コロ板バネ |
| 5 | PCLR-0475FCZZ | AA | DJ | N | C | Delivery collar 排紙コロ |
| 6 | XRESP70-08000 | AA | DD | | C | E type ring E-リング |
| 7 | LX-WZ0042FCZ1 | AA | DD | | C | Washer ヒラワッシャー |
| 8 | MSPRC2654FCZ1 | AB | DJ | | C | Separator pressure spring 離接加圧スプリング |
| 9 | CSTYM0294FC01 | AS | EQ | N | C | Delivery stay 排紙ステー |
| 10 | JKNBZ0144FCZZ | AE | DS | N | C | Roller knob グローブノブ |
| 11 | LX-BZ0944FCZ1 | AH | DS | N | C | Screw ビス |
| 12 | MSLi-0140FCZZ | BA | FX | N | C | Slide rail スライドレール |
| 13 | LFRM-1079FCZZ | AF | DS | N | C | Transfer slide FU 転写スライド FU |
| 14 | LFRM-1080FCZZ | AH | DX | N | C | Transfer slide PU 転写スライド PU |
| 15 | LSTYM0298FCZZ | AH | DX | N | C | Delivery stay lower 排紙ステー下 |
| 16 | MLEVP0781FCZZ | AD | DJ | | C | Left door release lever 左ドア解除レバー |
| 17 | PTME-0290FCZZ | AD | DJ | N | C | Delivery lock pawl 排紙ロック爪 |
| 18 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 19 | MSPRD3102FCZZ | AC | DJ | N | C | Lock spring F ロックスプリング F |
| 20 | NSFTZ2697FCZZ | AN | EQ | N | C | Delivery lock shaft 排紙ロックシャフト |
| 21 | MSPRD3103FCZZ | AD | DJ | N | C | Lock spring R ロックスプリング R |
| 22 | LFRM-1073FCZ1 | AS | EG | N | C | Delivery frame F 排紙フレーム F |
| 23 | LFRM-1074FCZZ | AS | EQ | N | C | Delivery frame R 排紙フレーム R |
| 24 | PGIDM1969FCZZ | AN | FQ | N | B | Reverse gate 反転ゲート |
| 25 | MSPRD3163FCZZ | AC | DJ | N | C | Gate earth spring ゲートアーススプリング |
| 26 | MARMP0298FCZZ | AC | DJ | N | C | Reverse gate arm 反転ゲートアーム |
| 27 | LSTYM0301FCZZ | AF | DS | N | C | Delivery stay upper 排紙ステー上 |
| 28 | GCAB-0981FCZ5 | AZ | FX | N | D | FU delivery cabinet (100V Series) FU 排紙キャビネット |
| | GCAB-0981FCZZ | BB | GD | N | D | FU delivery cabinet (200V Series) FU 排紙キャビネット |
| 29 | PCOVP1656FCZZ | AG | DX | N | D | FU delivery enter cover FU 排紙口カバー F |
| 30 | PBRSR0219FCZ1 | AG | DX | N | B | Discharge brush 除電ブラシ |
| 31 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 32 | LPINS0096FCZZ | AB | DD | | C | Pin(φ3-12) ピン |
| 33 | PSHEZ5074FCZZ | AC | DJ | N | C | Delivery edge protect sheet 排紙エッジ保護シート |
| 34 | LPINS0327FCZZ | AC | DJ | | C | Pin(φ2-10) ピン |
| 35 | LPINS0320FCZZ | AB | DJ | | C | Spring pin(φ2-8) スプリングピン |


27 左ドア (Left door)



28 FD 排紙ユニット (FD delivery unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | RMOTS0890FCZZ | BA | FX | N | B | Slide motor スライドモータ |
| 2 | XHBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 3 | CPLTM6017FC01 | AG | DX | N | C | Slide motor fixing plate スライドモータ取付けプレート |
| 4 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 5 | NGERH1531FCZZ | AD | DJ | N | C | Shifter gear(24/50) シフターギヤ |
| 6 | XRESP40-06000 | AA | DD | | C | E type ring E-リング |
| 7 | PGIDM1971FCZZ | AY | FQ | N | C | FD delivery guide IN FD 排紙ガイド IN |
| 8 | MSPRP3082FCZZ | AF | DS | N | C | FD earth plate spring B FD アース板 B スプリング |
| 9 | NPLYZ0402FCZZ | AD | DJ | N | C | Offset pulley(22T) オフセットプーリー |
| 10 | NBRGC0683FCZZ | AC | DJ | N | C | Bearing 軸受け |
| 11 | MSPRP3081FCZZ | AF | DS | N | C | FD earth plate spring A FD アース板 A スプリング |
| 12 | LPLTM6016FCZZ | AC | DJ | N | C | Pulley fulcrum plate プーリー支点プレート |
| 13 | XEBSE30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 14 | MLEVP0851FCZZ | AE | DS | N | C | FD empty actuator FD 満杯フケチュエータ |
| 15 | PGIDM1972FCZZ | AY | FQ | N | C | FD delivery PG FD 排紙ベールガイド |
| 16 | PBRSR0218FCZ1 | AH | DX | N | B | FD discharge brush FD 除電ブラシ |
| 17 | NROLP1432FCZZ | AE | DJ | N | C | Belt support lever roller FD 排紙従動ローラ |
| 18 | MSPRT3064FCZZ | AD | DJ | N | C | FD drive belt roller spring FD 排紙コイルスプリング |
| 19 | XRESP50-06000 | AA | DD | | C | E type ring E-リング |
| 20 | NBRGC0188FCZZ | AB | DD | | C | Bearing 軸受け |
| 21 | LPLNS0258FCZZ | AA | DD | | C | Spring pin(φ3-10) スプリングピン |
| 22 | NROLR1398FCZ1 | AR | EQ | N | C | FD delivery roller A FD 排紙ローラ A |
| 23 | PRNGP0077FCZZ | AA | DD | | C | Ring(E7) リング |
| 24 | NGERH0484FCZZ | AB | DD | | C | Gear(46T) ギヤ |
| 25 | NBLTH0374FCZZ | AE | DJ | N | C | FD delivery belt FD 排紙ベルト |
| 26 | NGERH0866FCZZ | AC | DD | | C | Gear(22T) ギヤ |
| 27 | NPLYZ0146FCZZ | AB | DD | | C | Pulley(22MXL) プーリー |
| 28 | LPLNS0165FCZZ | AB | DD | | C | Pin(φ2-8) ペイコピン |
| 29 | NROLR1399FCZ1 | AR | EQ | N | C | FD delivery roller B FD 排紙ローラ B |
| 30 | NSFTZ2713FCZZ | AK | DX | N | C | FD slide shaft FD スライドシャフト |
| 31 | PGIDM2007FCZZ | AP | EQ | N | C | FD delivery guide OUT FD 排紙ガイド OUT |
| 32 | LPLTM6073FCZZ | AC | DJ | N | C | FD fusing pressure plate FD 定着圧接プレート |
| 33 | MLEVP0850FCZZ | AG | DX | N | C | FD delivery actuator FD 排紙フケチュエータ |
| 34 | MSPRT3110FCZ1 | AC | DJ | N | C | FD Delivery actuator spring FD 排紙フケチュエータスプリング |
| 35 | XEBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 36 | PCLR-0479FCZZ | AC | DJ | N | C | FD slide collar FD スライドカラー |
| 37 | LX-BZ0840FCZZ | AC | DD | | C | Screw ラック固定ビス |
| 38 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビス |
| 39 | XEBSD30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 40 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| | (Unit) | | | | | |
| 901 | DUNT-7193DSZZ | BG | GX | N | E | FD delivery unit(Without No.1,2,3,5,6,38,39,40) FD 排紙ユニット (No.1,2,3,5,6,38,39,40 除く) |


28 FD 排紙ユニット (FD delivery unit)



29 フレーム 1(Frame 1)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | PCAPH0082FCZZ | AD | DJ | N | B | handle cap ハンドルキャップ |
| 2 | JHNDM0163FCZ1 | AG | DX | N | C | Handdle N ハンドルN |
| 3 | XEBSE30P06000 | AA | DD | | C | Screw(3×6) ビス |
| 4 | LPLTM6100FCZZ | AM | EG | N | C | Joint support plate 連結補強プレート |
| 5 | LPLTM6093FCZZ | AM | EG | N | C | Rear exterior fixing plate 後キャビ取付けプレート |
| 6 | LANGF1422FCZZ | AG | DS | N | C | Rear angle L 後端アングル L |
| 7 | LANGF1421FCZZ | AF | DS | N | C | Rear angle R 後端アングル R |
| 8 | LPLTM6097FCZZ | AD | DJ | N | C | MF fixing plate F 手差し取付け板 F |
| 14 | PCOVP1634FCZZ | AF | DS | N | C | MFP cover B MFPカバーB |
| 15 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 16 | CPLTM5974FC01 | AH | DX | N | C | Process guide plate K プロセスガイドプレートK |
| 17 | CPLTM5975FC01 | AL | EB | N | C | Process guide plate C プロセスガイドプレートC |
| 18 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 19 | LRALM0202FCZZ | AN | EG | N | C | Cassette rail L カセットレール左 |
| 20 | XHBSD40P06000 | AA | DD | | C | Screw(4×6) ビス |
| 21 | MSPRP3164FCZZ | AD | DJ | N | C | Earth spring アーススプリング |
| 22 | LHLDZ1546FCZZ | AC | DJ | N | C | Lock switch protect holder ロックスイッチ保護ホルダー |
| 23 | XEBSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

29 フレーム 1(Frame 1)




FCP06339

30 フレーム 2(Frame 2)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | QSW-C1390QCZZ | AN | EQ | | B | Power switch(LLN35C1) 電源スイッチ |
| 2 | XHBSD30P14000 | AA | DD | | C | Screw(3×14) ビス |
| 3 | QSW-M0502FCZZ | AH | DX | | B | Door switch(AM51632C531) ドアスイッチ |
| 4 | LHLDW1152FCZZ | AC | DJ | | C | Bushing(EH-14) ブッシュ |
| 5 | NGERH1530FCZ1 | AK | EB | N | C | DV drive gear(21T) 現像駆動ギヤ |
| 6 | LX-BZ0071FCZZ | AA | DD | | C | Screw ビス |
| 7 | TCAUH1035FCZZ | AC | DJ | | C | HT caution label (Japan only) コウチウイラベル |
| 8 | PCOVP1654FCZZ | AM | EG | | C | T heater cover (Japan only) Tヒーターカバー |
| 9 | LX-BZ0959FCZZ | AC | DD | N | C | Screw ビス |
| 10 | LPLTM6089FCZZ | AK | DX | N | C | Heater fixing plate (Japan only) ヒーターリツクハン |
| 11 | RHETP0084FCZZ | AS | EQ | | C | Dehumidify heater (Japan only) 除湿ヒーター |
| 12 | PGIDM1992FCZZ | AD | DJ | N | C | PS insert guide R PS 挿入ガイドR |
| 13 | PGIDM1991FCZZ | AE | DJ | N | C | PS insert guide F PS 挿入ガイドF |
| 14 | GLEGG0075FCZZ | AE | DJ | | C | Rubber foot ゴム足 |
| 15 | LX-BZ0898FCZZ | AC | DD | | C | Screw ビス |
| 16 | LBOSZ2114FCZZ | AK | EB | N | C | Process fulcrum boss プロセス位置決めボス |
| 17 | LX-BZ0855FCZZ | AC | DD | | C | Screw ビス |
| 18 | XHBSD30P06000 | AA | DD | | C | Screw(3×6) (Japan only) ビス |
| 19 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) (Japan only) ビス |
| 20 | NSFTZ2685FCZ1 | AL | EB | N | C | DV gear shaft 現像ギヤシャフト |
| 21 | XWHS40-08100 | AA | DD | | C | Washer ワッシャー |
| 22 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 23 | PCOVP1660FCZZ | AM | EG | N | C | Caseette cover R カセットカバー-R |
| 24 | PCLR-0441FCZZ | AK | DX | | C | collar コロ |
| 25 | LX-BZ0960FCZZ | AC | DD | | C | Screw ビス |
| 26 | PCOVP1659FCZZ | AK | DX | N | C | Caseette cover L カセットカバー-L |
| 27 | XBBS30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 28 | DUNT-7272DSZZ | CU | VZ | N | E | LED exposure unit LED 露光ユニット |
| 30 | PCOVP1700FCZZ | AG | DX | N | C | Connector cover コネクターカバー |
| 31 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| | | | | | | |
| | | | | | | |
| | | | | | | |

30 フレーム 2(Frame 2)




31 フレーム 3(Frame 3)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | QSW-M0502FCZZ | AH | DX | | B | Door switch(AM51632C531) ドアスイッチ |
| 2 | LDAIU0643FCZZ | AH | DX | N | C | Position block R 位置決めブロック R |
| 3 | XEBSD30P16000 | AA | DD | | C | Screw(3×16) ビス |
| 4 | LHLDZ1525FCZZ | AG | DJ | N | C | Full detector holder 満杯検知ホルダー |
| 5 | LSUPP0126FCZZ | AC | DJ | N | C | Supporter(SPLSN-4) サポート |
| 6 | CPWBF1546FCE1 | BB | GD | N | E | AC power supply PWB (Japan only) AC 電源基板 |
| | CPWBF1546FCE2 | BA | FX | N | E | AC power supply PWB (Except Japan)[100V series] AC 電源基板 |
| | CPWBF1546FCE4 | BA | FX | N | E | AC power supply PWB (Except Japan)[200V series] AC 電源基板 |
| 7 | LPLTM6027FCZZ | AH | DX | N | C | Driver PWB fixing plate ドライバ基板取付けプレート |
| 8 | CPWBN1545FCE1 | BQ | LP | N | E | Driver PWB ドライバ基板 |
| 9 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 15 | CPLTM6024DS51 | AU | EZ | N | E | Gate solenoid unit ゲートソレノイドユニット |
| 17 | DHAI-3362FCZZ | AY | FQ | N | C | AC control harness AC コントロールハーネス |
| 18 | XHBSE30P06000 | AA | DD | | C | Screw(3×6) ビス |
| 19 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 20 | LPLTM6079FCZZ | AD | DJ | N | C | Dask connector fixing plate デスクコネクタ取付けプレート |
| 21 | LPLTM5980FCZZ | AK | EB | N | C | Inlet fixing plate インレット取付けプレート |
| 22 | LHLDW1151FCZZ | AB | DJ | | C | Wire saddle(WWS-2) ワイヤサドル |
| 23 | LHLDW1152FCZZ | AC | DJ | | C | Bushing(EH-14) ブッシュ |
| 24 | DUNT-7289DSZZ | AK | DX | N | E | Inlet unit インレットユニット |
| 25 | XBPSD40P08K00 | AA | DD | | C | Screw(4×8K) ビス |
| 26 | VHI28F081L07F | AY | FQ | N | E | PCU FLASH ROM(28F081L07F) PCU フラッシュROM |
| 27 | DHAI-3412FCZZ | AC | DJ | N | C | DM drive earth harness DM 駆動アースハーネス |
| 28 | CPWBN1544DS51 | BR | LX | N | E | PCU PWB PCU 基板 |
| 29 | LPLTM5981FCZZ | AK | DX | N | C | Driver PWB fixing plate ドライバ基板取付けプレート |
| 30 | XBPSD30P08K00 | AA | DD | | C | Screw(3×8K) ビス |
| 31 | RDENC0020FCZ1 | BU | NE | N | E | AC/DC power supply PWB (100V Series) AC/DC 電源基板 |
| | RDENC0021FCZZ | BW | RJ | N | E | AC/DC power supply PWB (200V Series) AC/DC 電源基板 |
| 32 | VHPGP1A71L3-1 | AG | DS | N | B | Photo sensor(GP1A71L3) フォトセンサー |
| 33 | LPLTM5979FCZZ | AV | FG | N | C | Power supply fixing plate 電源取付けプレート |
| 34 | LHLDW1154FCZZ | AC | DJ | | C | Wire holder(LWS5S2W) ホルダー |
| 35 | LSUPP0126FCZZ | AC | DJ | N | C | Supporter(SPLSN-4) サポート |
| 36 | XHBSE30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 37 | RDENC0013FCZZ | BK | HG | N | E | High voltage TC power supply PWB コアックTC 電源基板 |
| 38 | QCNW-0190FCZZ | AD | DJ | N | C | MC-TC FFC MC-TC FFC |
| 39 | RDENC0012FCZZ | BR | LX | N | E | High voltage MC power supply PWB コアックMC 電源基板 |
| 40 | CDAIU0577FC31 | BE | GN | | E | Lift-up unit リフトアップユニット |
| 42 | NFANP0072FCZZ | BA | FX | N | B | Process exhaust fan プロセス排気ファン |
| 43 | XEPSD40P40000 | AC | DD | N | C | Screw(4×40) ビス |
| 44 | PDUC-0169FCZ1 | AE | DS | N | C | Inhalation of air duct fan fixing plate 吸気ダクトファン取付け板 |
| 45 | LPLTM6102FCZ1 | AN | EG | N | C | Inhalation of air duct fixing plate 吸気ダクト取付けプレート |
| 46 | MSPRD3125FCZZ | AD | DJ | N | C | PSM spring PSM スプリング |
| 47 | LX-BZ0833FCZZ | AC | DD | | C | Screw ビス |
| 48 | QSW-C9294QCZZ | AF | DS | | B | Dry heater switch(ALP SDDJE1) (Japan only) 除湿ヒータースイッチ |
| 49 | XEBSD30P08000 | AA | DD | | C | Screw(3×8) ビス |
| 50 | LX-LZ0022FCZZ | AB | DD | | C | Rivet(KGPS-5RF) リベット |
| 51 | LX-WZ0443FCZZ | AB | DD | | C | Washer ワasher |
| 52 | DHAI-3426FCZZ | AQ | EG | N | C | FAX AC harness (AR-C260F/C260FP) FAX AC ハーネス |
| 53 | LX-WZ0443FCZZ | AB | DD | | C | Washer (AR-C260F/C260FP) ワasher |
| 54 | XBPSD40P08K00 | AA | DD | | C | Screw(4×8K) (AR-C260F/C260FP) ビス |
| 55 | XHBSD30P08KS0 | AB | DD | N | C | Screw(3×8KS) ビス |
| 56 | RMOTS0883FCZZ | BA | FX | N | B | PS motor PS モーター |
| 58 | CPWBF1561DS51 | AZ | FQ | N | E | Reactor PWB (200V Series) リアクター基板 |

32 転写挿入ガイド (Transfer insert guide)


| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | PGIDM1967FCZZ | AR | EG | N | C | Belt insert guide R ベルト挿入ガイド R |
| 2 | MSPRP3030FCZZ | AD | DJ | N | C | Transfer electrode spring Y 転写接点 Y スプリング |
| 3 | MSPRP3031FCZZ | AF | DS | N | C | Transfer electrode spring M 転写接点 M スプリング |
| 4 | MSPRP3033FCZZ | AG | DX | N | C | Transfer electrode spring C 転写接点 C スプリング |
| 5 | MSPRP3034FCZZ | AG | DX | N | C | Transfer electrode spring K 転写接点 K スプリング |
| 6 | MSPRD3035FCZZ | AC | DJ | N | C | Transfer electrode spring 転写電極スプリング |
| 7 | MLEVP0841FCZZ | AG | DX | N | C | Belt support lever ベルト保持レバー |
| 8 | LDAIU0639FCZZ | AE | DS | N | C | Belt support block ベルト保持ブロック |
| 9 | MSPRC3029FCZZ | AC | DJ | N | C | Belt support spring ベルト保持スプリング |
| 10 | NROLP1408FCZZ | AD | DJ | N | C | Belt support lever roller ベルト補助レバーローラー |
| 11 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 12 | PGIDM1966FCZ1 | AP | EQ | N | C | Belt insert guide F ベルト挿入ガイド F |
| 13 | MLEVP0840FCZZ | AD | DJ | N | C | Belt protect lever ベルト保護レバー |
| 14 | LPLTM5976FCZZ | AL | DS | N | C | Belt protect plate ベルト保護プレート |
| 15 | MSPRP3032FCZZ | AC | DJ | N | C | Protect plate spring プロテクトプレートスプリング |
| 16 | PDUC-0167FCZ2 | AK | EB | N | C | Ozone duct A オゾンダクト A |
| 17 | DHAI-3367FCZZ | AT | EZ | N | C | CRUM harness CRUM ハーネス |
| 18 | XEBSD30P10000 | AA | DD | | C | Screw(3×10) ビス |
| 19 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |

31 フレーム 3(Frame 3)



FCP06341

32 転写挿入ガイド (Transfer insert guide)




FCP06342

33 ダクトユニット (Duct unit)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | LHLDZ1508FCZZ | AW | FG | N | C | Ozone filter holder オゾンフィルターホルダー |
| 2 | PFILZ0290FCZ1 | BA | FX | N | A | Ozone filter オゾンフィルター |
| 4 | NFANP0068FCZZ | BB | GD | N | B | Cooling fan 冷却ファン |
| 5 | XEBSD40P35000 | AC | DD | N | C | Screw(4×35) ビス |
| 6 | DHAi-3364FCZZ | AX | FG | N | C | HL AC supply harness (100V Series) HL AC 供給ハーネス |
| | DHAi-3402FC11 | AY | FQ | N | C | HL AC supply harness (200V Series) HL AC 供給ハーネス |
| 7 | XBPSD40P06K00 | AA | DD | | C | Screw(4×6K) ビス |
| 8 | XHBSE40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 9 | MSPRC2645FCZZ | AB | DJ | | C | MF reverse pressure spring 手差し逆転加圧スプリング |
| 10 | LX-BZ0850FCZZ | AC | DD | | C | Screw ビス |
| 11 | LX-WZ0443FCZZ | AB | DD | | C | Washer ワス用ヒラワッシャー |
| 13 | XEBSD40P08000 | AA | DD | | C | Screw(4×8) ビス |
| 15 | PDUC-0168FCZZ | AK | DX | N | C | Ozone duct B オゾンダクト B |
| 16 | LPLTM5973FCZZ | AQ | EQ | N | C | Fusing separate plate 定着仕切りプレート |
| 17 | PDUC-0166FCZZ | AX | EZ | N | C | Fan duct ファンダクト |
| 20 | PSHEP5111FCZZ | AA | DJ | N | C | Process guide sheet フォレカイドシート |
| | | | | | | |
| | | | | | | |
| | | | | | | |


33 ダクトユニット (Duct unit)



34 コントローラBOX(Control box)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | CPWBN1549DS54 | CU | VW | N | E | ICU PWB (AR-C260S/C260M)[JAPAN] ICU 基板 |
| | CPWBN1549DS55 | CV | VZ | N | E | ICU PWB (AR-C260F/C260FP)[JAPAN] ICU 基板 |
| | CPWBN1549DS57 | CU | VW | N | E | ICU PWB (AR-C260/C260M)[Except JAPAN] ICU 基板 |
| 2 | PCOVP1699FCZ1 | AN | EQ | N | C | Box cover R ボックスカバー R |
| 3 | LPLTM6025FCZZ | AE | DS | N | C | FFC shield plate FFCシールドプレート |
| 4 | PBOX-0131FCZZ | AU | EZ | N | C | Controller BOX コントローラBOX |
| 5 | MSPRP3164FCZZ | AD | DJ | N | C | Earth spring アースリング |
| 6 | XHBSE30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 7 | PCOVP1697FCZZ | AG | DX | N | C | Box cover F ボックスカバー F |
| 9 | PHOG-0385FCZZ | AB | DD | | C | Harness clamp ハネスクランプ |
| 10 | PCOVP1698FCZZ | AN | EQ | N | C | Box cover C ボックスカバー C |
| 11 | MSPRP3037FCZZ | AD | DJ | N | C | Controller spring B コントローラ接地スプリング B |
| 12 | LSUPP1001ACZZ | AB | DD | | C | Supporter(KGPS-4S) スーパー |
| 13 | LPLTM6090FCZZ | AE | DJ | N | C | OP connector fixing plate OPコネクタ取付けプレート |
| 14 | PGIDH2016FCZZ | AC | DJ | N | C | Controller guide コントローラガイド |
| 15 | LHLDW1006FCZZ | AA | DD | | C | Mini clamp(UAMS-09-0) ミニクランプ |
| 16 | LHLDW0429FCZZ | AB | DD | | C | Wire saddle(WS-2NS) ワイヤサドル |
| 17 | QCNW-0215FCZZ | AZ | FQ | N | C | FAX I/F cable (AR-C260F/C260FP) FAX I/F ケーブル |
| 18 | MSPRP3036FCZZ | AE | DJ | N | C | FAX harness spring (AR-C260F/C260FP) FAX ハネス接地スプリング |
| 19 | XHBSE30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 20 | XHBSE30P04000 | AA | DD | | C | Screw(3x4) ビス |
| 21 | DHA1-3465FCZZ | AV | FG | N | C | PRTCFM harness (AR-C260/C260S/C260F) PRTCFM ハネス |
| 22 | VH128F322L23F | BH | HC | N | C | ICU FLASH ROM(28F322L23F) (AR-C260F/C260FP) ICU フラッシュROM |
| | VH128F322L22F | BH | HC | N | C | ICU FLASH ROM(28F322L22F) (Other Model) ICU フラッシュROM |


34 コントローラBOX(Control box)



35 配線部 (Wiring section)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | DHA i-3424FC12 | AV | FG | N | C | LED head harness LED ヘッドハーネス |
| 2 | DHA i-3419FCZZ | AE | DS | N | C | OP-PD harness OP-PD ハーネス |
| 3 | QCNW-0197FCZZ | AL | EB | N | C | MFP-OP FFC MFP-OP FFC |
| 4 | QCNW-0213FCZZ | AH | DX | N | C | OP-KEY FFC OP-KEY FFC |
| 5 | DHA i-3413FCZZ | AN | EG | N | C | OSM harness OSM ハーネス |
| 6 | DHA i-3345FC11 | AY | FQ | N | C | Delivery harness 排紙ハーネス |
| 7 | DHA i-3361FCZZ | AT | EZ | N | C | MSW harness (100V Series) MSW ハーネス |
| | DHA i-3400FCZZ | AU | EZ | N | C | MSW harness (200V Series) MSW ハーネス |
| 8 | DHA i-3443FC12 | AY | FQ | N | C | MFP-ICU harness MFP-ICU ハーネス |
| 9 | DHA i-3416FCZZ | AN | EQ | N | C | Driver PWB harness 駆動基板ハーネス |
| 10 | DHA i-3404FCZZ | AR | EQ | N | C | DHSW harness (Japan only) DHSW ハーネス |
| 11 | DHA i-3405FCZZ | AG | DX | N | C | DH harness (Japan only) DH ハーネス |
| 12 | DHA i-3410FCZZ | AL | EB | N | C | BLU interface harness BLU 中継ハーネス |
| 13 | DHA i-3360FCZZ | AU | EZ | N | C | Cassette guide harness カセットガイドハーネス |
| 14 | DHA i-3348FCZZ | AR | EQ | N | C | Multi interface harness 手差し中継ハーネス |
| 15 | QCNW-0211FCZZ | AF | DS | N | C | PCU interface FFC PCU 間 FFC |
| 16 | DHA i-3363FCZZ | AT | EZ | N | C | DC harness DC ハーネス |
| 17 | LHLDW1223FCZZ | AA | DJ | N | C | Wire lock holder(White) オメガロック |
| 18 | LHLDW1545FCZZ | AB | DJ | N | C | Wire lock holder(Black) オメガロック |
| 19 | LBNDJ0043FCZ1 | AA | DJ | N | C | Band バンド |
| 20 | DHA i-3426FCZZ | AQ | EG | N | C | FAX AC harness (AR-C260F/C260FP) FAX AC ハーネス |

35 配線部 (Wiring section)



36 梱包材&付属品 (Packing Material & Accessories)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | SPAKC6335DSZZ | BB | GD | N | D | Packing case [Japan](AR-C260S) ハンギングケース |
| | SPAKC6383DSZZ | AZ | FQ | N | D | Packing case [Japan](AR-C260F) ハンギングケース |
| | SPAKC6383DS11 | BF | GN | N | D | Packing case [Japan](AR-C260FP) ハンギングケース |
| | SPAKC6334DS12 | BU | NN | N | D | Packing case [SRS/SRSSC,Indonesia,STCL](AR-C260) ハンギングケース |
| | SPAKC6334DS11 | BE | GN | N | D | Packing case [U.S.A Other countries](AR-C260) ハンギングケース |
| | SPAKC6335DS11 | BE | GN | N | D | Packing case [Japan](AR-C260M) ハンギングケース |
| | SPAKC6334DS15 | BU | NN | N | D | Packing case [SRS/SRSSC,Indonesia,STCL](AR-C260M) ハンギングケース |
| 2 | SPAKC6334DS14 | BE | GN | N | D | Packing case [U.S.A Other countries](AR-C260M) ハンギングケース |
| | SPAKA6338FCZZ | AL | EB | N | D | Top packing cushion L [Japan](AR-C260S/C260M) テン7ド L |
| | SPAKA6384FCZZ | AL | EB | N | D | Top packing cushion L [Japan](AR-C260F/C260FP) テン7ド L |
| 3 | SPAKA6336FCZZ | AK | EB | N | D | Top packing cushion L [Except Japan] テン7ド L |
| | SPAKA6339FCZZ | AN | EQ | N | D | Top packing cushion R [Japan](AR-C260S/C260M) テン7ド R |
| | SPAKA6385FCZZ | AP | EQ | N | D | Top packing cushion R [Japan](AR-C260F/C260FP) テン7ド R |
| | SPAKA6337FCZZ | AN | EG | N | D | Top packing cushion R [Except Japan] テン7ド R |
| 4 | SSAKZ0018FCZZ | AN | EG | | D | Vinyl bag ホリブ加 |
| 5 | CPAKA6340FC01 | AW | FG | N | D | Bottom packing case unit 底ケースユニット |
| 7 | SPAKA0581YSZZ | AE | DS | N | C | DRCA sleeve DRCA スリーブ |
| 8 | SSAKA3640QCZZ | AB | DD | | C | Vinyl bag(320x690mm) ホリブ加 |
| 9 | DUNT-7255DSZZ | AZ | FQ | N | E | Delivery tray unit (Japan only) 排紙トレイユニット |
| 10 | TINSJ2329FCZZ | BB | GD | N | D | Operation manual(COPY) (Japan only) 取扱説明書(コピー) |
| | TINSJ2330FCZZ | BA | FX | | D | Operation manual(FAX) (Japan only)[AR-C260F/C260FP] 取扱説明書(FAX) |
| | TINSJ2331FCZZ | AV | FG | N | D | Operation manual(KEY) (Japan only) 取扱説明書(キー) |
| | TINSJ2362FCZZ | AK | EB | N | D | Operation manual(COLOR) (Japan only)[AR-C260M/C260FP] 取扱説明書(カラー) |
| | TINSJ2378FCZZ | AS | EQ | N | D | Operation manual(MFP install) (Japan only)[AR-C260M/C260FP] 取扱説明書(MFPインストール) |
| | TINSJ2444FCZZ | AM | EG | N | D | Operation manual(S11) (English)[U.S.A] 取扱説明書(S11) |
| | TINSE2332FCZZ | BA | FX | N | D | Operation manual(COPY) (English)[U.S.A] 取扱説明書(コピー) |
| | TINSE2347FCZZ | AP | EQ | N | D | Operation manual(KEY) (English)[U.S.A] 取扱説明書(キー) |
| | TINSE2363FCZZ | AM | EG | N | D | Operation manual(COLOR) (English)[U.S.A][AR-C260M] 取扱説明書(カラー) |
| | TINSE2379FCZZ | AN | EQ | N | D | Operation manual(MFP install) (English)[U.S.A][AR-C260M] 取扱説明書(MFPインストール) |
| | TINSE2445FCZZ | AM | EG | N | D | Operation manual(S11) (English)[U.S.A] 取扱説明書(S11) |
| | TINSE2336FCZZ | BA | FX | N | D | Operation manual(COPY) (French)[CANADA] 取扱説明書(コピー) |
| | TINSE2351FCZZ | AP | EQ | N | D | Operation manual(KEY) (French)[CANADA] 取扱説明書(キー) |
| | TINSE2367FCZZ | AM | EG | N | D | Operation manual(COLOR) (French)[CANADA][AR-C260M] 取扱説明書(カラー) |
| | TINSE2383FCZZ | AN | EQ | N | D | Operation manual(MFP install) (French)[CANADA][AR-C260M] 取扱説明書(MFPインストール) |
| | TINSE2449FCZZ | AM | EG | N | D | Operation manual(S11) (French)[CANADA] 取扱説明書(S11) |
| | TINSE2334FCZZ | BB | GD | N | D | Operation manual(COPY) (English)[Other countries] 取扱説明書(コピー) |
| | TINSE2349FCZZ | AQ | EQ | N | D | Operation manual(KEY) (English)[Other countries] 取扱説明書(キー) |
| | TINSE2365FCZZ | AM | EG | N | D | Operation manual(COLOR) (English)[Other countries][AR-C260M] 取扱説明書(カラー) |
| | TINSE2381FCZZ | AN | EQ | N | D | Operation manual(MFP install) (English)[Other countries][AR-C260M] 取扱説明書(MFPインストール) |
| | TINSE2447FCZZ | AM | EG | N | D | Operation manual(S11) (English)[Other countries] 取扱説明書(S11) |
| | TINSE2333GHZZ | * | * | N | D | Operation manual(COPY) (English)[U.Kingdom] 取扱説明書(コピー) |
| | TINSE2348GHZZ | * | * | N | D | Operation manual(KEY) (English)[U.Kingdom] 取扱説明書(キー) |
| | TINSE2364GHZZ | * | * | N | D | Operation manual(COLOR) (English)[U.Kingdom][AR-C260M] 取扱説明書(カラー) |
| | TINSE2380GHZZ | * | * | N | D | Operation manual(MFP install) (English)[U.Kingdom][AR-C260M] 取扱説明書(MFPインストール) |
| | TINSE2446GHZZ | * | * | N | D | Operation manual(S11) (English)[U.Kingdom] 取扱説明書(S11) |
| | TINSE2334GHZZ | * | * | N | D | Operation manual(COPY) (English)[Europe] 取扱説明書(コピー) |
| | TINSE2349GHZZ | * | * | N | D | Operation manual(KEY) (English)[Europe] 取扱説明書(キー) |
| | TINSE2365GHZZ | * | * | N | D | Operation manual(COLOR) (English)[Europe][AR-C260M] 取扱説明書(カラー) |
| | TINSE2381GHZZ | * | * | N | D | Operation manual(MFP install) (English)[Europe][AR-C260M] 取扱説明書(MFPインストール) |
| | TINSE2447GHZZ | * | * | N | D | Operation manual(S11) (German) 取扱説明書(S11) |
| | TINSG2341GHZZ | * | * | N | D | Operation manual(COPY) (German) 取扱説明書(コピー) |
| | TINSG2356GHZZ | * | * | N | D | Operation manual(KEY) (German) 取扱説明書(キー) |
| | TINSG2372GHZZ | * | * | N | D | Operation manual(COLOR) (German)[AR-C260M] 取扱説明書(カラー) |
| | TINSG2388GHZZ | * | * | N | D | Operation manual(MFP install) (German)[AR-C260M] 取扱説明書(MFPインストール) |
| | TINSG2454GHZZ | * | * | N | D | Operation manual(S11) (French) 取扱説明書(S11) |
| | TINSG2336GHZZ | * | * | N | D | Operation manual(COPY) (French) 取扱説明書(コピー) |
| | TINSG2351GHZZ | * | * | N | D | Operation manual(KEY) (French) 取扱説明書(キー) |
| | TINSG2367GHZZ | * | * | N | D | Operation manual(COLOR) (French)[AR-C260M] 取扱説明書(カラー) |
| | TINSG2383GHZZ | * | * | N | D | Operation manual(MFP install) (French)[AR-C260M] 取扱説明書(MFPインストール) |
| | TINSG2449GHZZ | * | * | N | D | Operation manual(S11) (Spanish) 取扱説明書(S11) |
| | TINSG2337GHZZ | * | * | N | D | Operation manual(COPY) (Spanish) 取扱説明書(コピー) |
| | TINSG2352GHZZ | * | * | N | D | Operation manual(KEY) (Spanish) 取扱説明書(キー) |
| | TINSG2368GHZZ | * | * | N | D | Operation manual(COLOR) (Spanish)[AR-C260M] 取扱説明書(カラー) |
| | TINSG2384GHZZ | * | * | N | D | Operation manual(MFP install) (Spanish)[AR-C260M] 取扱説明書(MFPインストール) |
| | TINSG2450GHZZ | * | * | N | D | Operation manual(S11) (Italian) 取扱説明書(S11) |
| | TINSG2338GHZZ | * | * | N | D | Operation manual(COPY) (Italian) 取扱説明書(コピー) |
| | TINSG2353GHZZ | * | * | N | D | Operation manual(KEY) (Italian) 取扱説明書(キー) |
| | TINSG2369GHZZ | * | * | N | D | Operation manual(COLOR) (Italian)[AR-C260M] 取扱説明書(カラー) |
| | TINSG2385GHZZ | * | * | N | D | Operation manual(MFP install) (Italian)[AR-C260M] 取扱説明書(MFPインストール) |


36 梱包材&付属品 (Packing Material & Accessories)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 10 | TINSI2451GHZZ | * | * | N | D | Operation manual(S11) (Italian) 取扱説明書 (S11) |
| | TINSH2339GHZZ | * | * | N | D | Operation manual(COPY) (Dutch) 取扱説明書 (コピー) |
| | TINSH2354GHZZ | * | * | N | D | Operation manual(KEY) (Dutch) 取扱説明書 (キー) |
| | TINSH2370GHZZ | * | * | N | D | Operation manual(COLOR) (Dutch)[AR-C260M] 取扱説明書 (カラー) |
| | TINSH2386GHZZ | * | * | N | D | Operation manual(MFP install) (Dutch)[AR-C260M] 取扱説明書 (MFP インストール) |
| | TINSH2452GHZZ | * | * | N | D | Operation manual(S11) (Dutch) 取扱説明書 (S11) |
| | TINSW2340GHZZ | * | * | N | D | Operation manual(COPY) (Swedish) 取扱説明書 (コピー) |
| | TINSW2355GHZZ | * | * | N | D | Operation manual(KEY) (Swedish) 取扱説明書 (キー) |
| | TINSW2371GHZZ | * | * | N | D | Operation manual(COLOR) (Swedish)[AR-C260M] 取扱説明書 (カラー) |
| | TINSW2387GHZZ | * | * | N | D | Operation manual(MFP install) (Swedish)[AR-C260M] 取扱説明書 (MFP インストール) |
| | TINSW2453GHZZ | * | * | N | D | Operation manual(S11) (Swedish) 取扱説明書 (S11) |
| | TINSZ2342GHZZ | * | * | N | D | Operation manual(COPY) (Norwegian) 取扱説明書 (コピー) |
| | TINSZ2357GHZZ | * | * | N | D | Operation manual(KEY) (Norwegian) 取扱説明書 (キー) |
| | TINSZ2373GHZZ | * | * | N | D | Operation manual(COLOR) (Norwegian)[AR-C260M] 取扱説明書 (カラー) |
| | TINSZ2389GHZZ | * | * | N | D | Operation manual(MFP install) (Norwegian)[AR-C260M] 取扱説明書 (MFP インストール) |
| | TINSZ2455GHZZ | * | * | N | D | Operation manual(S11) (Norwegian) 取扱説明書 (S11) |
| | TINSZ2343GHZZ | * | * | N | D | Operation manual(COPY) (Finnish) 取扱説明書 (コピー) |
| | TINSZ2358GHZZ | * | * | N | D | Operation manual(KEY) (Finnish) 取扱説明書 (キー) |
| | TINSZ2374GHZZ | * | * | N | D | Operation manual(COLOR) (Finnish)[AR-C260M] 取扱説明書 (カラー) |
| | TINSZ2390GHZZ | * | * | N | D | Operation manual(MFP install) (Finnish)[AR-C260M] 取扱説明書 (MFP インストール) |
| | TINSZ2456GHZZ | * | * | N | D | Operation manual(S11) (Finnish) 取扱説明書 (S11) |
| | TINSD2344GHZZ | * | * | N | D | Operation manual(COPY) (Danish) 取扱説明書 (コピー) |
| | TINSD2359GHZZ | * | * | N | D | Operation manual(KEY) (Danish) 取扱説明書 (キー) |
| | TINSD2375GHZZ | * | * | N | D | Operation manual(COLOR) (Danish)[AR-C260M] 取扱説明書 (カラー) |
| | TINSD2391GHZZ | * | * | N | D | Operation manual(MFP install) (Danish)[AR-C260M] 取扱説明書 (MFP インストール) |
| | TINSD2457GHZZ | * | * | N | D | Operation manual(S11) (Danish) 取扱説明書 (S11) |
| | CCADZ1561FC01 | AK | DX | | D | Maintenance card (Japan) マンテナンスカード |
| | CCADZ1518FC01 | AB | DJ | | D | Maintenance card (Except Japan) マンテナンスカード |
| | TCADZ6017FCZZ | AF | DS | N | D | MSDS card (U.S.A,Canada) MSDS カード |
| | TCADZ6017GHZZ | * | * | N | D | MSDS card (English)[Europe] MSDS カード |
| | PSHEP5013FCZ1 | * | * | N | D | Key sheet (French) キーシート |
| | PSHEP5013FCZZ | * | * | N | D | Key sheet (German) キーシート |
| | PSHEP5013FCZ2 | * | * | N | D | Key sheet (Spanish) キーシート |
| | PSHEP5013FCZ3 | * | * | N | D | Key sheet (Italian) キーシート |
| | PSHEP5013FCZ4 | * | * | N | D | Key sheet (Dutch) キーシート |
| | PSHEP5013FCZ5 | * | * | N | D | Key sheet (Swedish) キーシート |
| | PSHEP5013FCZ6 | * | * | N | D | Key sheet (Norwegian) キーシート |
| | PSHEP5013FCZ7 | * | * | N | D | Key sheet (Finnish) キーシート |
| | PSHEP5013FCZ8 | * | * | N | D | Key sheet (Danish) キーシート |
| | TCADS1512FCZZ | AB | DJ | | D | Supply set up card (Australia,New Zealand) 納入設置報告書 |
| | TCADS1511FCZZ | AC | DJ | | D | Supply set up card (Europe) 納入設置報告書 |
| | CDSKA0014FC31 | AT | EZ | N | D | CD-ROM (AR-C260M/C260FP)[Japan] CD-ROM |
| | CDSKA0014FC32 | AT | EZ | N | D | CD-ROM (AR-C260M)[U.S.A other countries] CD-ROM |
| | CDSKA0014GH35 | * | * | N | D | CD-ROM (AR-C260M)[Europe] CD-ROM |
| | CDSKA0014FC35 | AT | EZ | N | D | CD-ROM (AR-C260M)[Yenen,Saudi Arabia, Oman,Qatar,Bahrain,Kuwait,UAE] CD-ROM |
| | CDSKA0002QS33 | AP | EQ | N | D | NIC CD-ROM (AR-C260M/C260FP)[Except Europe] NIC CD-ROM |
| | CDSKA0002TS33 | * | * | N | D | NIC CD-ROM (AR-C260M)[Europe] NIC CD-ROM |
| | UKOG-0304FCZZ | AQ | EQ | N | D | Color chart (AR-C260M/C260FP) カラーチャート |
| 11 | QACCJ6912QCPZ | AV | FG | N | B | AC cord (Japan,Philippines) AC コード |
| | QACCD7912QCPZ | AS | EQ | N | B | AC cord (U.S.A,Canada) AC コード |
| | QACCL7922QCPZ | AN | EQ | N | B | AC cord (Australia,New Zealand) AC コード |
| | QACCB7626QCPZ | * | * | N | B | AC cord (U.Kingdom) AC コード |
| | QACCE6922QCPZ | AQ | EQ | N | B | AC cord (SEEG,STCL) AC コード |
| | DHAi-3332DSZZ | BB | GD | N | B | AC cord (SRS/SRSSC,Indonesia) AC コード |
| | DHAi-3332DS11 | BB | GD | N | B | AC cord (India) AC コード |
| | QACCB7623QCZZ | BB | GD | N | B | AC cord (Other countries) AC コード |
| 12 | SPAKA6346FCZZ | AD | DJ | N | D | Accessories spacer (Japan only) 付属品スペーサー |
| 13 | SSAKA2440QCZZ | AB | DD | | D | Vinyl bag(280×410mm) ホリッポ |
| 14 | LX-BZ0555FCZZ | AB | DD | | D | Screw DVS 取付けビス |
| 15 | TCADZ1178FCZZ | AB | DJ | | D | Screw remove caution tag ビス開梱注意カード |
| 16 | LX-WZ0326FCZZ | AA | DD | | D | MB cushion B9 MB クッション B9 |
| 17 | SPAKA6302FCZ1 | AD | DJ | N | D | Packing add 転写固定材 |
| 18 | SPAKA4693FCZZ | AE | DS | | D | Packing add OC [Japan](AR-C260S) OC 保護材 |
| 21 | SSAKA5003CCZZ | AA | DD | | C | Vinyl bag(140×260mm) ホリッポ |
| 22 | SPAKA6075FCZZ | AE | DJ | N | D | RSPF protect sheet [Japan](AR-C260F/C260FP) RSPF 保護シート |
| | SPAKA6450FCZZ | AD | DJ | N | D | OC protect sheet (Other Model) OC 保護シート |
| 24 | TCADZ1275FCZZ | AB | DJ | | D | Cassette rotation plate caution tag カセット回転板注意カード |
| 25 | LHLDW1226FCZZ | AB | DJ | | C | Turn fastener ターンファスター |
| 26 | SPAKA6345FCZZ | AE | DJ | N | D | Scanner reinforce add スキャナー補強材 |
| 27 | QCNW-7197XCZZ | AH | DX | | C | Line cable [Japan](AR-C260F/C260FP) ラインケーブル |
| 28 | RCORF0046FCZZ | AH | DX | N | C | Ferrite core [Japan](AR-C260F/C260FP) フェライトコア |
| 29 | SSAKH3013CCZZ | AA | DD | | C | Vinyl bag(120×220mm) [Japan](AR-C260F/C260FP) ホリッポ |
| 30 | SSAKA0006UCZZ | AA | DD | | C | Vinyl bag(50×60mm) ホリッポ |

36 梱包材&付属品 (Packing Material & Accessories)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 31 | XBBSE40P06000 | AA | DD | | C | Screw(4x6) [Japan]([AR-C260F/C260FP) ビス |
| 32 | MLEVP0864FCZZ | AD | DJ | N | C | Full actuator FU 満杯7カチュータ FU |
| 101 | TCADZ6015FCZZ | AC | DJ | N | D | Set up card 設置手順書 |
| 102 | SPAKA6440FCZZ | AL | EB | N | D | Scanner reinforce sleeve (AR-C260F/C260FP) スキャナ補強スリーブ |
| 103 | SPAKA6386FCZZ | AL | EB | N | D | ADF spacer (AR-C260F/C260FP) ADFスペーサー |
| 104 | SPAKA6235DSZZ | AH | DX | N | D | Joint C (AR-C260F/C260FP) ジョイント C |
| 105 | TCADZ1593FCZZ | AC | DJ | N | D | Process insert inst card フォトリソ挿入手順書 |
| 106 | GCÖVZ0237FCZZ | AZ | FQ | N | D | Dust cover (Yemen,Saudi Arabia, Oman,Qatar,Bahrain,Kuwait,UAE) タストカバー |
| | | | | | | |
| | | | | | | |
| | | | | | | |

36 梱包材&付属品 (Packing Material & Accessories)




FCP06346

37 FAX BOX unit(AR-C260F/AR-C260FP)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | PCOVP1564FCZZ | AF | DS | | D | FAX ROM cover FAX ROM カバ- |
| 2 | GCAB-0947FCZZ | AT | EZ | | D | FAX rear cabinet FAX 後枠ビ- |
| 3 | LHLDZ1494FCZZ | AF | DS | | C | FAX AC cord holder B FAX AC コード ホルダ-B |
| 4 | LFIX-0567FCZZ | AD | DJ | | C | FAX holder cord fixing plate FAX ホルダ-コード 押え |
| 5 | DHAI-3441FCZZ | AV | FG | N | C | FAX power supply harness FAX 電源ハ-ス |
| 6 | LHLDZ1493FCZZ | AF | DS | | C | FAX AC cord holder C FAX AC コード ホルダ-C |
| 7 | XEBSE30P12000 | AA | DD | | C | Screw(3x12) ビ-ス |
| 8 | XEBSE30P10000 | AA | DD | | C | Screw(3x10) ビ-ス |
| 9 | XBPSD40P06K00 | AA | DD | | C | Screw(4x6K) ビ-ス |
| 10 | XBPSD40P40XS0 | AA | DD | | C | Screw(4x40XS) ビ-ス |
| 11 | RDENC0004FCZZ | BV | RB | | E | FAX AC power supply unit FAX AC 電源基板 |
| 12 | LSHZ1001ACZZ | AB | DD | | C | Edge saddle エッジ サドル |
| 13 | XHBSE30P06000 | AA | DD | | C | Screw(3x6) ビ-ス |
| 14 | LPLTM5788FCZZ | AP | EQ | | C | FAX power supply fixing plate FAX 電源取付板 |
| 15 | QSW-C9295QCZZ | AL | EB | | B | FAX power supply switch(ALP SDDJF3) FAX 電源スイッチ |
| 16 | LSHZ2050SCZZ | AB | DD | | C | Edge saddle(EDS-1208U) エッジ サドル |
| 17 | LX-WZ0443FCZZ | AB | DD | | C | Washer ア-ス用ヒラワッシャ |
| 18 | LSUPP0118FCZZ | AB | DJ | | C | PWB supporter(SPLSN6) 基板サ-ター |
| 19 | LHLDW1499FCZZ | AC | DJ | | C | Wire saddle(WS-2U) ワイヤ-サドル |
| 20 | LSUPP0076FCZZ | AA | DD | | C | PWB supporter(SPSN6U) 基板サ-ター |
| 21 | XBPSD30P08KS0 | AA | DD | | C | Screw(3x8KS) ビ-ス |
| 22 | LPLTM5892FCZZ | AD | DJ | | C | FAX separate plate FAX 仕切り板 |
| 23 | LFIX-0560FCZZ | AF | DS | | C | FAX AC cord fixing plate FAX AC コード 押え |
| 24 | PSHEZ4933FCZZ | AD | DJ | | C | FAX MD cover sheet FAX MD カバ-シート |
| 25 | DHAI-3207FC11 | AG | DX | N | C | FAX switch harness FAX スイッチハ-ス |
| 26 | DHAI-3204FC11 | AM | EG | N | C | FAX BOX harness FAX BOX ハ-ス |
| 27 | GCAB-0946FCZZ | AZ | FQ | | D | FAX front cabinet B FAX 前枠ビ- B |
| 28 | LPLTM6075FCZ1 | AS | EQ | N | C | FAX fixing plate N FAX 取付板 N |
| 29 | LPLTM6108FCZZ | AF | DS | N | C | FAX fixing plate B FAX 取付板 B |
| 30 | LPLTM5789FCZZ | AF | DS | | C | Speaker fixing plate スピーカ 取付板 |
| 31 | DUNT-7136FCA1 | AN | EQ | N | E | FAX speaker unit FAX スピーカ-ユニット |
| 32 | XHBSE40P05000 | AB | DD | | C | Screw(4x5) ビ-ス |
| 33 | PSHEZ4879FCZZ | AH | DX | | C | FAX front sheet FAX 前シート |
| 34 | CPWBN1491FCE1 | CA | TV | | E | TEL/LIU PWB TEL/LIU 基板 |
| 35 | LPLTM5787FCZZ | AQ | EQ | | C | FAX PWB fixing plate FAX 基板取付板 |
| 36 | CPWBN1472FCE4 | CG | UM | | E | Modem control PWB モデムコントロール基板 |
| 37 | QCNW-0210FCZZ | AE | DJ | | C | FAX interface FFC FAX 中継 FFC |
| 38 | VHI28F082L06S | BF | GN | N | E | FAX FLASH ROM(28F082L06S) FAX フラッシュROM |
| 39 | DHAI-3206FC11 | AG | DX | N | C | CIP interface harness CIP チュケイハ-ス |
| 40 | LX-BZ0962FCZ1 | AF | DS | N | C | Screw ビ-ス |
| 41 | LHLDW2087SCZZ | AA | DD | N | C | Mini clamp ミニクランプ |
| 42 | XBPSD26P08000 | AA | DD | | C | Screw(2.6x8) ビ-ス |
| 43 | LX-BZ0938FCZZ | AC | DD | | C | Screw ビ-ス |
| 44 | XWHSE30-05080 | AA | DD | | C | Washer ヒラ ワッシャ |
| 45 | NSFTZ2738FCZZ | AD | DJ | N | C | FAX fixing shaft FAX 取付シャフト |
| 46 | XHBSE40P08000 | AA | DD | | C | Screw(4x8) ビ-ス |
| 47 | XHBSE40P10000 | AA | DD | | C | Screw(4x10) ビ-ス |
| 501 | CPLTM5788FCE4 | BS | MW | N | E | FAX power supply unit FAX 電源ユニット |


37 FAX BOX unit(AR-C260F/AR-C260FP)



38 プリンタコントローラ部 (Printer controller section)[AR-C260M/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | XHBSD30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 2 | MSPRP3168FCZZ | AC | DJ | N | C | HDD spring HDD スプリング |
| 3 | LX-BZ1022LCZZ | AB | DD | | C | Screw ビス |
| 4 | XBPSE30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 5 | DUNT-7269FCZZ | CD | UD | | E | HDD HDD |
| 6 | LPLTM6028FCZZ | AL | EB | N | C | HDD fixing plate HDD 取付けプレート |
| 7 | DHAI-3454FCZZ | AK | DX | N | C | HDD P/S harness HDD 電源ハーネス |
| 8 | DHAI-3453FCZZ | AV | FG | N | C | HDD IDE harness HDD IDE ハーネス |
| 9 | CPWBN1534DS52 | BP | LP | N | E | HDD PWB HDD 基板 |
| 10 | XHBSD30P05000 | AA | DD | | C | Screw(3x5) ビス |
| 11 | LBNDJ0016FCZZ | AA | DD | | C | Band バンド |
| 12 | CPWBN1521DS51 | BM | HR | N | E | SCN IF PWB SCN IF PWB |
| 14 | LX-BZ0963FCZZ | AF | DS | N | C | Screw ビス |
| 15 | XHBSD30P08000 | AA | DD | | C | Screw(3x8) ビス |
| 16 | CPWBN1518DS55 | EB | ZZ | N | E | Printer controller PWB プリンタコントローラ基板 |
| 17 | LPLTM5977FCZZ | AS | EQ | N | C | Controller PWB fixing plate コントローラ基板取付け板 |
| 19 | LX-BZ0855FCZZ | AC | DD | | C | Tension spring screw テンションスプリング 段ビス |
| 22 | VHI28F322L33F | BM | HR | N | E | Flash ROM KANJI [Japan only] フラッシュ ROM 漢字 |
| 23 | VHI28F322L32F | BG | GT | N | E | Flash ROM PCL フラッシュ ROM PCL |
| 24 | VHI28F081L11F | AY | FQ | N | E | Flash ROM BOOT フラッシュ ROM BOOT |
| 25 | NFANP0071FCZZ | AZ | FX | N | B | Fan ファン |
| 26 | LHLDZ1547FCZZ | AD | DJ | N | C | Fan holder ファンホルダー |
| 27 | XHBSE30P06000 | AA | DD | | C | Screw(3x6) ビス |
| 28 | LX-BZ0901FCZZ | AC | DD | | C | Screw ビス |


38 プリンタコントローラ部 (Printer controller section)[AR-C260M/AR-C260FP]



39 RADF 外装部 (RADF Exteriors)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P068// | AK | DX | N | C | Tray guide F トレイガイド F |
| 3 | 0CW040100FNIT | AB | DJ | N | C | Screw(M4IT) ビス |
| 4 | 0CW2269P004// | BB | GD | N | C | Paper feeding tray 給紙トレイ |
| 5 | 0CW2268P084// | AF | DS | N | C | Tray rack gear トレイラックギヤ |
| 6 | 0CW2269P069// | AK | DX | N | C | Tray guide R トレイガイド R |
| 7 | 0CW2269P077// | AL | EB | N | C | Tray sensor lever トレイセンサーレバー |
| 8 | 0CWE314000619 | AH | DX | | B | Photo interrupter フォトインタラプター |
| 9 | 0CW660580// | AA | DD | | C | Nut ナット |
| 10 | 0CW2268P085// | AE | DJ | N | C | Tray pinion gear トレイピニオンギヤ |
| 11 | 0CW2268P170// | AE | DS | N | C | Tray spring トレイタバネ |
| 12 | 0CW2269K032// | CB | TZ | N | E | Paper feeding unit 給紙ユニット |
| 13 | 0CW2214P128B/ | AK | DX | N | C | Slide switch bracket スライドスイッチブラケット |
| 14 | 0CW2185P357A/ | AA | DJ | | C | Screw(M3×8) ビス |
| 15 | 0CW2269K232// | AY | FQ | N | B | Harness ハーネス |
| 16 | 0CW2269P003// | BA | FX | N | C | Rrar cover リヤカバー |
| 17 | 0CW040080FNB/ | AA | DD | | C | Screw ビス |
| 18 | 0CW2269P009// | AP | EQ | N | C | Rear sub cover リヤサブカバー |
| 19 | 0CW2158P322A/ | AC | DJ | N | C | Screw ビス |
| 20 | 0CW2269P365// | AV | FG | N | C | Rrar cover sound proof cushion 1 リヤカバー防音スポンジ 1 |
| 21 | 0CW2269P366// | AS | EQ | N | C | Rrar cover sound proof cushion 2 リヤカバー防音スポンジ 2 |
| 23 | 0CW2269P002// | AX | FQ | N | C | Front cover フロントカバー |
| 24 | 0CW2269P381// | AL | EB | N | C | LED label LEDラベル |
| 25 | 0CW2269K207// | AH | DX | N | E | LED PWB LED基板 |
| 26 | 0CW4054P220D/ | AB | DJ | | C | Screw ビス |
| 27 | 0CW040080FZTP | AA | DD | | C | Screw(M4×8) ビス |
| 28 | 0CW2269K066// | BY | TF | N | D | Reverse unit 反転ユニット |
| 29 | 0CW030060FZWS | AA | DD | | C | Screw ビス |
| 501 | 0CW2269K064// | BG | GT | N | D | Tray unit トレイユニット |


39 RADF 外装部 (RADF Exteriors)[AR-C260F/AR-C260FP]



40 RADF 給紙部 1 (RADF Paper feeding section 1)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P133// | AG | DX | N | C | Paper feeding bracket R 給紙シテンプラケット R |
| 2 | 0CW2254P494A/ | AB | DJ | N | C | Screw(M4x8) ビス |
| 3 | 0CW2268P057// | AE | DJ | N | C | Resist arm R レジアーム R |
| 4 | 0CW2269P368// | AF | DS | N | C | Reverse cover seal cushion F 反転カバーシールスポンジ F |
| 5 | 0CW2269P362// | AD | DJ | N | C | Stopper cushion ビックストップパースポンジ |
| 6 | 0CW2269P054D/ | AE | DS | N | C | Shutter シャッター |
| 7 | 0CW2269P350// | AD | DJ | N | C | Shutter cushion シャッタースポンジ |
| 8 | 0CW2269P139// | AE | DS | N | C | Bracket ブラケット |
| 10 | 0CW2269P364// | AF | DS | N | C | Paper feeding cover seal cushion 給紙カバーシールスポンジ |
| 11 | 0CW2268P056// | AE | DJ | N | C | Resist arm F レジアーム F |
| 12 | 0CW2269P132// | AE | DS | N | C | Paper feeding bracket F 給紙シテンプラケット F |
| 13 | 0CW2269P007// | AZ | FQ | N | D | Paper feeding opening/closing cover 給紙開閉カバー |
| 14 | 0CW2269P301// | AV | FG | N | B | Paper feeding roller 給紙ローラー |
| 15 | 0CW2269P361// | AD | DJ | N | C | Ring 5 ビアスリング 5 |
| 16 | 0CW2252P620C// | AD | DJ | N | C | Clip 4 クリップ 4 |
| 18 | 0CW2269P052// | AD | DJ | N | C | Shutter stopper シャッターストップバー |
| 19 | 0CW2225P312A/ | AD | DJ | N | C | Bearing ジョウゲ |
| 20 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| 21 | 0CW2269P341B/ | AF | DS | N | C | Arm F sheet ビックアーム F マイラー |
| 23 | 0CW2269P300// | AN | EQ | N | B | Roller ビックローラー |
| 24 | 0CWNSBLT00056 | AN | EG | N | C | Timing belt タイミングベルト |
| 25 | 0CW2261P055A/ | AC | DJ | N | C | Pulley プーリー |
| 26 | 0CWHP02010SCH | AC | DJ | N | C | Pin(2x10) ペイコウピン |
| 27 | 0CW2261P023E/ | AD | DJ | N | C | Arbor アーバー |
| 28 | 0CW2269P316// | AH | DX | N | C | Spring clutch ビックバネクラッチ |
| 29 | 0CW2269P206// | AQ | EQ | N | C | Roller shaft フィードローシャフト |
| 30 | 0CW2269P061E/ | AG | DX | N | C | Arm F ビックアーム F |
| 31 | 0CW2269K061// | AL | EB | N | C | Roller shaft unit ビックローラーシャフトユニット |
| 33 | 0CWER040SKP// | AB | DD | N | C | E-ring 4 E リング 4 |
| 36 | 0CW2269P062// | AN | EG | N | C | Arm R ビックアーム R |
| 37 | 0CW2166P034B/ | AC | DJ | N | C | Clip 5 クリップ 5 |
| 42 | 0CW2269P318// | AH | DX | N | C | Gear spring clutch ビックギヤバネクラッチ |
| 43 | 0CW2260P002A/ | AE | DJ | N | C | Gear ギヤ |
| 45 | 0CW2269K062B/ | AU | EZ | N | E | Paper feeding upper guide unit 給紙上ガイドユニット |
| 48 | 0CW2269P344D/ | AG | DS | N | C | Paper feeding sheet 給紙マイラー |
| 49 | 0CW2269P053// | AE | DS | N | C | Sensor lever センサティエンガーレバー |
| 50 | 0CW2269P071D/ | AH | DX | N | C | Paper feeding maintenance cover 給紙メンテナンスカバー |
| 51 | 0CW2268P076B/ | AD | DJ | N | C | Flange フランジ |
| 52 | 0CW2269P355A/ | AH | DX | N | C | Cushion スポンジ |
| 53 | 0CW2269P356A/ | AF | DS | N | C | Cushion スポンジ |
| 60 | 0CW2269P459// | AG | DS | N | C | Mylar R マイラー R |
| 61 | 0CW2269P460// | AE | DS | N | C | Pick-up arm F mylar 2 ビックアップアーム F マイラー 2 |


40 RADF 給紙部 1 (RADF Paper feeding section 1)[AR-C260F/AR-C260FP]



41 RADF 給紙部 2 (RADF Paper feeding section 2)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P010// | AS | EQ | N | C | Transport guide 搬送ガイド |
| 2 | 0CW2269P011// | AQ | EQ | N | C | Resist guide U レジガイド U |
| 3 | 0CW2269K094C// | AZ | FX | N | B | Separation pad unit 分離パッドユニット |
| 4 | 0CW2269P065// | AE | DS | N | C | Separation spring cover 分離バネカバー |
| 5 | 0CW2269P349B// | AD | DJ | N | C | Separation spring 分離バネ |
| 6 | 0CW2185P357A// | AA | DJ | | C | Screw(M3×8) ビス |
| 7 | 0CW2269P066// | AF | DS | N | C | Separation spring holder 分離バネホルダー |
| 8 | 0CW2268P071// | AE | DJ | N | C | Collar ティゲンコ |
| 9 | 0CW2269K047// | AR | EQ | N | B | Front plate rubber + cover マシバキゴム+カバー |
| 10 | 0CW2269P320// | AE | DS | N | B | Lower cushion ビック下ホシジ |
| 11 | 0CW2269P311// | AG | DX | N | B | Lower moquette ビック下セケット |
| 12 | 0CW030080FNWS | AA | DJ | | C | Screw(M3×8) ビス |
| 13 | 0CW2268K041A// | AG | DX | N | C | Fulcrum bracket unit R シテンブラケットカンメユニット R |
| 14 | 0CW2164P330A// | AB | DJ | | C | Screw(M3×6) ビス |
| 15 | 0CW2247P326A// | AF | DS | N | C | Bearing MF ジクケ MF |
| 16 | 0CW2268P354// | AG | DX | N | C | Resist spring レジストスプリング |
| 17 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| 18 | 0CWNSBRG00019 | AQ | EQ | N | C | Bearing(φ8) ベアリング |
| 19 | 0CW2252P620C// | AD | DJ | N | C | Clip 4 クリップ 4 |
| 20 | 0CWER070SKP// | AA | DD | N | C | E-ring 7 E リング 7 |
| 21 | 0CW2268P073// | AD | DJ | N | C | Grar ギヤ |
| 22 | 0CW2254P494A// | AB | DJ | N | C | Screw(M4×8) ビス |
| 23 | 0CW2214P455C// | AE | DS | N | C | Plate spring ロックイタバネ |
| 24 | 0CW030060FZTP | AA | DD | | C | Screw(M3×6) ビス |
| 25 | 0CW2269P324// | AE | DS | N | C | Empty earth sheet エンプティアースシート |
| 26 | 0CW2269P334// | AY | FQ | N | B | Resist roller レジストローラー |
| 27 | 0CW2240P835A// | AT | EZ | N | B | Reverse sensor 反射センサー |
| 28 | 0CW030080FZWS | AA | DD | | C | Screw ビス |
| 29 | 0CW040060FNBB | AB | DJ | | C | Screw(M4×6) ビス |
| 30 | 0CW2269P115// | AL | EB | N | C | Resist sensor bracket レジストセンサーブラケット |
| 31 | 0CW2269P149// | AE | DJ | N | C | Sensor bracket エンブティセンサーブラケット |
| 32 | 0CWE314000619 | AH | DX | | B | Photo interrupter フォトインタラプター |
| 33 | 0CW2269P109// | AT | EZ | N | C | Resist guide L レジガイド L |
| 35 | 0CW2269P332// | AR | EQ | N | C | Discharge brush R 給紙除電ブラシ R |
| 37 | 0CW2269K042B// | AG | DX | N | C | Sensor seal unit 反射センサーシールユニット |
| 39 | 0CW2269P331// | AT | EZ | N | C | Discharge brush F 給紙除電ブラシ F |
| 40 | 0CWPW080025// | AB | DJ | N | C | Poly slider ポリスライダー |
| 41 | 0CW2269P315// | AD | DJ | N | C | Spring レジローラストバネ |
| 42 | 0CW2268K040B// | AG | DX | N | C | Fulcrum bracket unit F 支点ブラケットカンメユニット F |
| 43 | 0CW2254P058A// | AE | DJ | N | C | Sensor lever オープンセンサーレバー |
| 44 | 0CW2254P338A// | AC | DJ | N | C | Spring holder SP バネホルダー SP |
| 45 | 0CW030060FZSW | AA | DD | | C | Screw ビス |
| 46 | 0CW2269P038// | AE | DS | N | C | Sensor holder オープンセンサーホルダー |
| 47 | 0CW2268P336// | AD | DJ | N | C | Resist guide sheet レジスト案内ミラー |
| 48 | 0CW2268P303// | BA | FX | N | C | Resist assist roller レジ従動ローラー |
| 50 | 0CW2268P401// | AG | DS | N | C | Harness guide 1 ハネスガイド 1 |
| 52 | 0CW2269P451A// | AF | DS | N | C | Separation sheet 分離ミラー |
| 53 | 0CW2269P453A// | AE | DJ | N | C | Separation sheet 分離ミラー |
| 54 | 0CW2269P455A// | AQ | EQ | N | C | Sub pad サブパッド |
| 55 | 0CW2269P012A// | AM | EG | N | C | Lower frame 下フレーム |
| 56 | 0CW030060FZWS | AA | DD | | C | Screw ビス |


41 RADF 給紙部 2 (RADF Paper feeding section 2)[AR-C260F/AR-C260FP]



42 RADF 給紙駆動部 (RADF Paper feeding drive section)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P055// | AE | DS | N | C | Sensor lever オープンセンサーレバー |
| 2 | 0CWE314000619 | AH | DX | | B | Photo interrupter フォトインタラプター |
| 3 | 0CW030080FZWS | AA | DD | | C | Screw ビス |
| 4 | 0CW2268P083// | AF | DS | N | C | Sensor holder オープンセンサーホルダー |
| 5 | 0CW2164P340A/ | AA | DD | | C | Screw(M4×7) ビス |
| 6 | 0CW040080FZTP | AA | DD | | C | Screw(M4×8) ビス |
| 8 | 0CW2269K013// | AU | EZ | N | C | Paper feeding motor bracket unit 給紙モーターブラケットユニット |
| 9 | 0CWNSBRG00016 | AT | EZ | | C | Braring(φ6) ベアリング |
| 11 | 0CW040080FZWS | AA | DD | | C | Screw ビス |
| 12 | 0CW2269K241B/ | BL | HL | N | B | Paper feeding motor 給紙モーター |
| 13 | 0CW2269P171// | AL | EB | N | C | Switch spring スイッチタイパネ |
| 14 | 0CWE120001648 | AP | EQ | N | B | Microswitch マイクロスイッチ |
| 15 | 0CW023100FZWS | AB | DJ | N | C | Screw(M2.3×10) ビス |
| 17 | 0CW2268P064// | AG | DX | N | C | Pulley プーリー |
| 18 | 0CW2268P065// | AG | DX | N | C | Gear ギヤ |
| 19 | 0CWER070SKP// | AA | DD | N | C | E-ring 7 E リング 7 |
| 20 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| 21 | 0CW2268P217// | AK | EB | N | C | Paper feeding gear shaft 給紙ギヤシャフト |
| 22 | 0CWNSBLT00277 | AP | EQ | N | C | Timing belt タイミングベルト |
| 23 | 0CW2269P057// | AE | DS | N | C | Pulley プーリー |
| 24 | 0CW2268P344// | AP | EQ | N | C | Clutch 連結フッククラッチ |
| 25 | 0CW2268P066// | AH | DX | N | C | Gear ギヤ |
| 26 | 0CWHP02010SCH | AC | DJ | N | C | Pin(2×10) ペイコピン |
| 30 | 0CW2269P056// | AD | DJ | N | C | Paper feeding tension collar 給紙テンションコル |
| 31 | 0CW2078P023B/ | AC | DJ | | C | Screw(M3) ビス |
| 32 | 0CW2269K011// | AH | DX | N | C | Paper feeding tension bracket unit 給紙テンションブラケットユニット |
| 33 | 0CW2268P335// | AD | DJ | N | C | Paper feeding tension spring 給紙テンションバネ |


42 RADF 給紙駆動部 (RADF Paper feeding drive section)[AR-C260F/AR-C260FP]



43 RADF 排紙部 1 (RADF Delivery section 1)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P354// | AL | EB | N | C | Sound proof cushion 反転防音スポンジ |
| 2 | 0CW2269P306// | AQ | EQ | N | C | Discharge brush 反転ベルト口除電ブラシ |
| 4 | 0CW2269P336// | AG | DX | N | C | Fixing sheet 押エミヤ |
| 6 | 0CWE450001139 | AC | DJ | N | C | Clamp クランプ |
| 8 | 0CWE450001128 | AC | DJ | | C | Tielap タイラップ |
| 9 | 0CWE314000619 | AH | DX | | B | Photo interrupter フォトインタラプター |
| 10 | 0CW2269P017// | AE | DJ | N | C | Reverse lever 反転レバー |
| 11 | 0CW4062Q304B/ | AC | DJ | N | C | Screw(M3) ビス |
| 12 | 0CW2164P330A/ | AB | DJ | | C | Screw(M3×6) ビス |
| 13 | 0CW2214P455C/ | AE | DS | N | C | Plate spring ロックイタパネ |
| 14 | 0CW030080FZBi | AA | DJ | | C | Screw(M3×8) ビス |
| 15 | 0CWNSBRG00019 | AQ | EQ | N | C | Bearing(φ8) ベアリング |
| 16 | 0CW2268P352// | AD | DJ | N | C | Reverse spring 反転スラストパネ |
| 17 | 0CW2268P078// | AE | DS | N | C | Pulley プーリー |
| 18 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| 19 | 0CW2269P333// | BB | GD | N | B | Reverse roller 反転ローラー |
| 20 | 0CW3085P334A/ | AC | DJ | N | C | Screw(M3×4) ビス |
| 21 | 0CW2269P105// | AH | DX | N | C | Reverse sensor earth 反転センサーアース |
| 22 | 0CW2269P106// | AF | DS | N | C | Reverse earth 反転アース |
| 23 | 0CW2269P015// | AG | DS | N | C | Reverse roller guide cover 反転ローラーガイドカバー |
| 24 | 0CW2269P304// | AD | DJ | N | C | Reverse sensor sheet 反転センサーマイラー |
| 25 | 0CW2240P835A/ | AT | EZ | N | B | Reverse sensor 反射センサー |
| 26 | 0CW2269P014C/ | AW | FG | N | C | Reverse roller guide 反転ローラーガイド |
| 27 | 0CW2078P086B/ | AB | DD | | C | Screw(M3) ビス |
| 28 | 0CW2269P340// | AF | DS | N | C | Reverse sensor harness sheet 反転センサーハーネスマイラー |
| 29 | 0CW2269P359// | AN | EG | N | C | Reverse exit sheet 反転出口マイラー |
| 30 | 0CW2269P358// | AD | DJ | N | C | Sheet スライドマイラー |
| 31 | 0CW030060FZTP | AA | DD | | C | Screw(M3×6) ビス |
| 32 | 0CW2129P188A/ | AD | DJ | N | C | Clip 3 クリップ 3 |
| 33 | 0CW2269P107// | AK | DX | N | C | Reverse roller guide bracket 反転ローラーガイドブラケット |
| 34 | 0CW2269P016// | AD | DJ | N | C | Delivery lever 排紙レバー |
| 35 | 0CW2269P207// | AF | DS | N | C | Delivery sensor lever shaft 排紙センサーレバーシャフト |
| 37 | 0CW2078P652B/ | AE | DS | N | C | Bearing 8 ジグザク 8 |
| 38 | 0CWER070SKP// | AA | DD | N | C | E-ring 7 E リング 7 |
| 39 | 0CW2269P059// | AE | DJ | N | C | Reverse solenoid lever 反転ソレノイドレバー |
| 40 | 0CW2252P620C/ | AD | DJ | N | C | Clip 4 クリップ 4 |
| 41 | 0CW2269P308// | AD | DJ | N | C | Solenoid spring ソレノイドパネ |
| 44 | 0CW2269P142// | AF | DS | N | C | Solenoid bracket 反転ソレノイドブラケット |
| 45 | 0CW030040FZWS | AA | DD | | C | Screw(M3×4) ビス |
| 47 | 0CW2269P339// | AD | DJ | N | C | Solenoid lever cushion ソレノイドレバースポンジ |
| 49 | 0CW2185P357A/ | AA | DJ | | C | Screw(M3×8) ビス |
| 50 | 0CW2269P389// | AD | DJ | N | C | Revers sensor cushion 反転センサーオアシススポンジ |
| 51 | 0CW2269P440// | AT | EZ | N | C | Solenoid + Harness ソレノイド + ハーネス |
| 52 | 0CW2269P013// | AQ | EQ | N | C | Reverse guide 反転ガイド |

43 RADF 排紙部 1 (RADF Delivery section 1)[AR-C260F/AR-C260FP]




FCP06232

44 RADF 排紙部 2 (RADF Delivery section 2)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | 0CW4048P300A/ | AC | DJ | N | C | Screw(M4x5) ビス |
| 2 | 0CW2269P111// | AN | EG | N | C | Reverse motor bracket 反転モーターブラケット |
| 3 | 0CW2268P360// | AD | DJ | N | C | Reverse tension spring 反転テンションバネ |
| 4 | 0CW2269P160A/ | AG | DX | N | C | Reverse motor adjust bracket 反転モーター調整ブラケット |
| 5 | 0CW040060FZWS | AA | DD | | C | Screw(M4x6) ビス |
| 6 | 0CW2268K522A/ | BL | HL | N | B | Motor モーター |
| 7 | 0CW2269P305// | AQ | EQ | N | C | Discharge brush 排紙口除電ブラシ |
| 8 | 0CW2269P006// | AW | FG | N | C | Reverse cover 反転カバー |
| 9 | 0CW2269P369// | AE | DS | N | C | Reverse cover seal cushion R 反転カバーシールスポンジ R |
| 10 | 0CW2269P368// | AF | DS | N | C | Reverse cover seal cushion F 反転カバーシールスポンジ F |
| 11 | 0CW2269P338// | AD | DJ | N | C | Reverse sensor cover seal 反射センサーシール |
| 12 | 0CW2269P005// | AP | EQ | N | C | Reverse upper guide 反転上ガイド |
| 13 | 0CW2269P335// | AD | DJ | N | C | Reverse collar front sheet 反転コロ前マイラー |
| 14 | 0CW2269P128// | AE | DS | N | C | Reverse plate spring U 反転イタバネU |
| 15 | 0CW2268P005A/ | AD | DJ | N | C | Reverse collar 反転コロ |
| 16 | 0CW2185P357A/ | AA | DJ | | C | Screw(M3x8) ビス |
| 17 | 0CW2269P303// | AY | FQ | N | C | Reverse flapper 反転フラッパー |
| 18 | 0CW2269P104// | AF | DS | N | C | Reverse bracket R 反転シテンブラケット R |
| 19 | 0CW2254P494A/ | AB | DJ | N | C | Screw(M4x8) ビス |
| 20 | 0CW2269P112// | AF | DS | N | C | Reverse bracket F 反転シテンブラケット F |
| 21 | 0CW2269P060// | AE | DJ | N | C | Reverse flapper lever 反転フラッパーレバー |
| 22 | 0CWER040SKP// | AB | DD | N | C | E-ring 4 Eリング 4 |
| 24 | 0CW2269P110// | AP | EQ | N | C | Discharge bracket 排紙ブラケット |
| 25 | 0CW030060FZTP | AA | DD | | C | Screw(M3x6) ビス |
| 26 | 0CW2269P018// | AQ | EQ | N | C | Discharge guide 排紙ガイド |
| 27 | 0CW2269P309// | AC | DJ | N | C | Discharge collar spring 排紙コロボネ |
| 28 | 0CW2269P211// | AG | DX | N | C | Discharge collar shaft 排紙コロシャフト |
| 29 | 0CW2269P357// | AG | DX | N | C | Discharge collar 排紙コロ |
| 30 | 0CW2269P351// | AC | DJ | N | C | Flapper cushion フラッパースポンジ |
| 31 | 0CW2269P337// | AE | DJ | N | C | Discharge collar front sheet 排紙コロ前マイラー |
| 32 | 0CW2269P307// | AN | EQ | N | C | Sheet スキイデマイラー |
| 33 | 0CW2269K016// | AF | DS | N | C | Paper feeding bracket R unit 給紙シテンブラケットRユニット |
| 34 | 0CW3085P334A/ | AC | DJ | N | C | Screw(M3x4) ビス |
| 35 | 0CW040060FZBP | AB | DJ | | C | Screw ビス |
| 36 | 0CWNSBLT00278 | AL | EB | N | C | Timing belt タイミングベルト |
| 37 | 0CW2269P399A/ | AE | DS | N | C | Sheet マイラー |
| 40 | 0CW2260P457// | AP | EQ | N | C | Discharge mylar S 除電マイラー S |
| 41 | 0CW2260P458// | AN | EQ | N | C | Discharge mylar C 除電マイラー C |


44 RADF 排紙部 2 (RADF Delivery section 2)[AR-C260F/AR-C260FP]



45 RADF 搬送部 (RADF Transport section)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|----------------------------|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269P327// | BA | FX | N | C | Belt roller L |
| 2 | 0CW2164P142A/ | AE | DS | | C | Belt roller spring holder |
| 3 | 0CW2205P360A/ | AD | DJ | N | C | Roller spring |
| 4 | 0CW2269P029// | AG | DS | N | C | Roller holder F |
| 5 | 0CW2269P025// | AG | DS | N | C | Roller holder R |
| 6 | 0CW030060FZBP | AA | DD | | C | Screw |
| 7 | 0CW2269P343// | AZ | FQ | N | C | Roller |
| 8 | 0CWNSBRG00019 | AQ | EQ | N | C | Bearing(φ8) |
| 9 | 0CW2269P099A/ | AD | DJ | N | C | Pulley |
| 10 | 0CWER070SKP// | AA | DD | N | C | E-ring 7 |
| 11 | 0CW2269P120// | AP | EQ | N | C | DF side plate R |
| 12 | 0CW2269P119// | AQ | EQ | N | C | DF side plate F |
| 13 | 0CW040080FNB i | AA | DD | | C | Screw |
| 14 | 0CW2198P374A/ | AC | DJ | N | C | Washer(M4) |
| 15 | 0CW2214P044A/ | AF | DS | N | C | Belt guide |
| 16 | 0CW2205P147A/ | AG | DX | N | C | Roller plate spring |
| 17 | 0CW2205P025A/ | AD | DJ | N | C | Spacer |
| 18 | 0CW2268P059// | AE | DJ | N | C | Fixing holder |
| 19 | 0CW2205P351A/ | AU | EZ | N | C | Belt roller |
| 20 | 0CW2269P123// | AH | DX | N | C | Belt tension bracket F |
| 21 | 0CW2078P023B/ | AC | DJ | | C | Screw(M3) |
| 22 | 0CW040060FNB i | AA | DD | | C | Screw(M4×6) |
| 23 | 0CW2269P026// | AF | DS | N | C | Roller holder 1-F |
| 24 | 0CW2269P022// | AF | DS | N | C | Roller holder 1-R |
| 25 | 0CW2268P110// | AH | DX | N | C | Transport tension bracket |
| 26 | 0CW2269P382// | AD | DJ | N | C | DF unit regulation cushion |
| 27 | 0CW2269P326// | AZ | FQ | N | C | Belt roller R |
| 28 | 0CW2214P520B/ | AU | EZ | N | C | Fixing holder |
| 29 | 0CW2078P086B/ | AB | DD | | C | Screw(M3) |
| 30 | 0CW030060FZWS | AA | DD | | C | Screw |
| 31 | 0CW2268P146// | AP | EQ | N | C | Transport unit stay |
| 33 | 0CW2269P176// | AE | DS | N | C | Collar plate spring |
| 35 | 0CW2198P305B/ | AH | DX | N | C | Collar H |
| 36 | 0CW2214P157B/ | AK | DX | N | C | Collar plate spring L |
| 37 | 0CW2214P575A/ | BR | LP | N | A | DF belt CGR |
| 38 | 0CW030080FZWS | AA | DD | | C | Screw |


45 RADF 搬送部 (RADF Transport section)[AR-C260F/AR-C260FP]



46 RADF 搬送駆動部 (RADF Transport drive section)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | 0CW040080FZWS | AA | DD | | C | Screw ビス |
| 2 | 0CW2268P402// | AK | DX | N | C | Harness guide 2 ハーネスガイド 2 |
| 3 | 0CW040080FZSW | AA | DD | | C | Screw ビス |
| 4 | 0CW2269K242B/ | BM | HV | N | B | Motor モーター |
| 5 | 0CW2269P363// | AD | DJ | N | C | Transport tension spring 搬送テンションバネ |
| 7 | 0CW040060FZTP | AA | DD | | C | Screw(M4x6) ビス |
| 8 | 0CW2269P114// | AQ | EQ | N | C | Transport motor bracket 搬送モーターブラケット |
| 9 | 0CW4054P220D/ | AB | DJ | | C | Screw ビス |
| 10 | 0CW2269K012// | AG | DX | N | C | Transport tension bracket unit 搬送テンションブラケットユニット |
| 11 | 0CW2268P069// | AD | DJ | N | C | Tension collar テンションコル |
| 12 | 0CW2268P076// | AD | DJ | N | C | Flange フランジ |
| 13 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| | | | | | | |
| | | | | | | |
| | | | | | | |

46 RADF 搬送駆動部 (RADF Transport drive section)[AR-C260F/AR-C260FP]




FCP06235

47 RADF 台板ユニット (RADF Base plate unit)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | 0CW2214P116B/ | AE | DJ | N | C | DF fixing plate DF コネクティングプレート |
| 2 | 0CW2269P001// | BP | LP | N | D | Base ベース |
| 3 | 0CW2269K202// | BZ | TF | N | E | Main PWB メイン基板 |
| 4 | 0CW2269K240// | AX | FG | N | B | ROM (IC) ROM (IC) |
| 5 | 0CW040120FZIT | AB | DJ | N | C | Screw(M4×12) ビス |
| 6 | 0CWE450000070 | AB | DJ | | C | Clamp クランプ |
| 7 | 0CWE450001139 | AC | DJ | N | C | Clamp クランプ |
| 8 | 0CW2164P340A1 | AB | DJ | N | C | Screw(M4×7) ビス |
| 9 | 0CW2185P357A/ | AA | DJ | | C | Screw(M3×8) ビス |
| 10 | 0CW2269P159// | AF | DS | N | C | Switch bracket オープンスイッチブラケット |
| 11 | 0CW2269P172// | AK | DX | N | C | Switch plate spring 2 スイッチイタパネ 2 |
| 12 | 0CWE120001648 | AP | EQ | N | B | Microswitch マイクロスイッチ |
| 13 | 0CW023100FZWS | AB | DJ | N | C | Screw(M2.3×10) ビス |
| 14 | 0CW2269P146// | AN | EG | N | C | Base stay R ベースステー R |
| 15 | 0CW2269P108// | AH | DX | N | C | Base F bracket ベース F ブラケット |
| 16 | 0CW4054P143B1 | AB | DJ | N | C | Screw(M4×12) ビス |
| 17 | 0CW2269K026G/ | BD | GN | N | C | Hinge R unit ヒンジ R ユニット |
| 18 | 0CW2269P147// | AF | DS | N | C | Switch lever オープンスイッチレバー |
| 19 | 0CW030060FZWS | AA | DD | | C | Screw ビス |
| 21 | 0CW040060FZTP | AA | DD | | C | Screw(M4×6) ビス |
| 22 | 0CW2269K001// | AH | DX | N | C | Transport unit fulcrum bracket R 搬送ユニットシジブラケット R |
| 23 | 0CW2268P145// | AG | DS | N | C | Transport unit earth spring 搬送ユニットアースイタパネ |
| 24 | 0CW030060FZTP | AA | DD | | C | Screw(M3×6) ビス |
| 25 | 0CW2269P116// | AH | DX | N | C | Magnet bracket マグネットブラケット |
| 26 | 0CW030040FZWS | AA | DD | | C | Screw(M3×4) ビス |
| 27 | 0CW2214P393A/ | AG | DX | N | C | Magnet catch(13N) マグネットキャッチ |
| 28 | 0CW030060FZSW | AA | DD | | C | Screw ビス |
| 29 | 0CW2269K025F/ | BD | GJ | N | C | Hinge L unit ヒンジ L ユニット |
| 31 | 0CW2269K008// | AK | EB | N | C | Transport unit fulcrum bracket L 搬送ユニットシジブラケット L |
| 32 | 0CWER050SKP// | AA | DD | N | C | E-ring 5 E リング 5 |
| 33 | 0CWNSBRG00016 | AT | EZ | | C | Braring(φ6) ベアリング |
| 34 | 0CW2269P221// | AH | DX | N | C | Transport drive shaft 搬送駆動シャフト |
| 35 | 0CWNSBLT00282 | AR | EQ | N | C | Belt ベルト |
| 36 | 0CW2269P020// | AD | DJ | N | C | Belt drive pulley ベルト駆動アイドラープーリー |
| 37 | 0CW2268P076// | AD | DJ | N | C | Flange フランジ |
| 38 | 0CW2269P393A1 | AG | DX | N | C | Magnet catch(13N) マグネットキャッチ |
| 40 | 0CW2269P145// | AW | FG | N | C | Base stay L ベースステー L |
| 41 | 0CWNSBLT00281 | AQ | EQ | N | C | Timing belt タイミングベルト |


47 RADF 台板ユニット (RADF Base plate unit)[AR-C260F/AR-C260FP]



48 RADF 配線部 (RADF Wiring section)[AR-C260F/AR-C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|-------------|
| | | Ex. | Ja. | | | |
| 1 | 0CW2269K225B/ | AP | EQ | N | C | Harness |
| 2 | 0CW2269K223B/ | AL | EB | N | C | Harness |
| 3 | 0CW2269K221// | AM | EG | N | C | Harness |
| 6 | 0CW2269K230// | AK | EB | N | C | Harness |
| 7 | 0CW2269K234B/ | AY | FQ | N | C | Harness |
| 8 | 0CW2269K243// | BL | HL | N | C | Harness |
| 9 | 0CW2269K222B/ | AG | DX | N | C | Harness |
| 10 | 0CW2269K231// | AK | DX | N | C | Harness |
| 11 | 0CW2269K224// | AL | EB | N | C | Harness |
| | | | | | | |
| | | | | | | |
| | | | | | | |

48 RADF 配線部 (RADF Wiring section)[AR-C260F/AR-C260FP]



FCP06237

49 モデムコントロール基板 (Modem control PWB)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | QCNCM1069ACZZ | AD | DD | | C | Connector(6pin) [CN108] コネクター |
| 2 | QCNCM7014SC0B | AD | DJ | | C | Connector(2pin) [CN104] コネクター |
| 3 | QCNCM7014SC0C | AA | DD | | C | Connector(3pin) [CN105] コネクター |
| 4 | QCNCW1155FCZZ | AE | DJ | | C | Connector(30pin) [CN107] コネクター |
| 5 | QSOCN0082FCZZ | AP | EQ | | C | Connector(26pin) [CN101] コネクター |
| 6 | QSOCZ0073FCZZ | AL | EB | | C | Connector(72pin) [CN106] コネクター |
| 7 | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C117,118,119,120,122,123] コンデンサー |
| | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C124,125,149,151,153,155] コンデンサー |
| | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C156,165,175,180,231,250] コンデンサー |
| | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C267,282] コンデンサー |
| 8 | RCRSP0068FCZZ | AG | DS | | B | Crystal(12.500MHZ) [X101] クリスタル |
| 9 | RCRSP0069FCZZ | AG | DS | | B | Crystal(14.7456MHZ) [X103] クリスタル |
| 10 | RCRUA0010FCZZ | AQ | EQ | | B | Crystal(24.576MHZ) [X104] クリスタル |
| 12 | RFILN0047FCZZ | AC | DJ | | C | EMI filter(MMZ1608S121) [NF101,102] EMIフィルター |
| 13 | RFILZ1042LCZZ | AC | DJ | | C | Filter(ZJSR5101102) [NF103] フィルター |
| 14 | VCCCCZ1EH221J | AB | DD | | C | Capacitor(25WV 220pF) [C177] コンデンサー |
| 15 | VCCCCZ1HH100D | AA | DD | | C | Capacitor(50WV 10pF) [C141,143,197,233] コンデンサー |
| 16 | VCCCCZ1HH150J | AA | DD | | C | Capacitor(50WV 15pF) [C292] コンデンサー |
| 17 | VCEAPS1CC106M | AC | DD | | C | Capacitor(16WV 10μF) [C130,131,224,257] コンデンサー |
| 18 | VCEAPS1HC475M | AC | DJ | | C | Capacitor(50WV 4.7μF) [C161,181,182] コンデンサー |
| 19 | VCEAPZ1EW107M | AD | DJ | | C | Capacitor(25WV 100μF) [C249,268,273,281] コンデンサー |
| 20 | VCEAPZ1EW476M | AE | DJ | | C | Capacitor(25WV 47μF) [C176,192,232,245,246] コンデンサー |
| | VCEAPZ1EW476M | AE | DJ | | C | Capacitor(25WV 47μF) [C248,287,288] コンデンサー |
| 21 | VCFYDA1HA104J | AC | DD | | C | Capacitor(50WV 0.1μF) [C179,185,186] コンデンサー |
| 22 | VCFYDA1HA105J | AE | DJ | | C | Capacitor(50WV 1μF) [C178,190] コンデンサー |
| 23 | VCFYDA1HA333J | AC | DD | | C | Capacitor(50WV 0.033μF) [C184] コンデンサー |
| 24 | VCFYDA1HA474J | AD | DJ | | C | Capacitor(50WV 0.47μF) [C157] コンデンサー |
| 25 | VCKYCZ1AF224Z | AC | DD | | C | Capacitor(10WV 0.22μF) [C216-221,251,252,253] コンデンサー |
| | VCKYCZ1AF224Z | AC | DD | | C | Capacitor(10WV 0.22μF) [C269,271,275-279] コンデンサー |
| 26 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C101,102,105,106,107] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C121,132,133,134,135,136] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C139,140,142,144] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C145,146,147] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C148,163,166,168-174] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C189,191,198-208] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C222,223] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C229,230,234-237,239,247] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C254,255,256,264-266,270] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C272,274,280,285,286,289] コンデンサー |
| 27 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.10μF) [C290,291,293,294] コンデンサー |
| | VCKYCZ1EB472K | AA | DD | | C | Capacitor(25WV 4700pF) [C154,187,104] コンデンサー |
| 28 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C152,162,188,193,194,196] コンデンサー |
| 29 | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) [C137,138] コンデンサー |
| 31 | VHDBR751V40-1 | AD | DJ | | B | Diode(RB751V40) [D103,105] ダイオード |
| 32 | VHD1SS133/-1 | AA | DD | | B | Diode(1SS133) [D104] ダイオード |
| 33 | VHERD5.1EB2-1 | AA | DD | | B | Zener diode(RD5.1EB2) [ZD101] ヴェナダーダイオード |
| 34 | VHIEES02L400P | AG | DX | | B | IC(EES02L400P) [IC110] IC |
| 35 | RH-IX0002FCZZ | AQ | EQ | | B | IC(74LCX16652M) [IC123] IC |
| 36 | VHILCX244SJ-1 | AG | DX | | B | IC(LCX244SJ) [IC124,128,129] IC |
| 37 | VHILM111718-1 | AH | DX | | B | IC(LM111718) [U101] IC |
| 38 | VHIMAX3225E-1 | AT | EZ | | B | IC(MAX3225E) [IC108,109] IC |
| 39 | VH129F04-01FC | AX | FG | | B | Modem flash unit(29F04) [IC132] モデムフラッシュユニット |
| 40 | VHIMN195004-1 | BN | HZ | | B | IC(MN195004) [IC131] IC |
| 42 | VHINJM2113M-1 | AG | DS | | B | IC(NJM2113M) [IC114] IC |
| 43 | VHINJM4558MF1 | AE | DJ | | B | IC(NJM4558MF1) [IC112,113,115] IC |
| 44 | VHINU4051M-1 | AG | DX | | B | IC(NJU4051M) [IC502] IC |
| 45 | VHINU4052BMF | AG | DS | | B | IC(NJU4052BMF) [IC503,504] IC |
| 46 | VHINU4053BMF | AG | DS | | B | IC(NJU4053BMF) [IC501] IC |
| 47 | VHIPST591CMT1 | AE | DS | | B | IC(PST591CMT1) [IC107] IC |
| 48 | VHIPST591IM-1 | AG | DS | | B | IC(PST591IM) [IC106] IC |
| 49 | VHIPST994C+-1 | AG | DS | | B | IC(PST994C) [IC120] IC |
| 50 | VHISD4M16L1-1 | AZ | FX | | B | IC(SD4M16L1) [IC119] IC |
| 51 | VHISH770910-1 | BH | GX | | B | IC(SH770910) [IC111] IC |
| 52 | VHISR1024L15J | AU | FG | | B | IC(SR1024L15J) [IC121,122] IC |
| 53 | RH-IX0004FCZZ | AS | EQ | | B | IC(61C1024-15J) [IC130] IC |
| 54 | VHITD62503F/- | AG | DX | | B | IC(TD62503F) [IC101] IC |
| 55 | VHITR88017S-1 | BA | FX | | B | IC(TR88017S) [IC126] IC |
| 56 | VHIUPD65946-1 | BB | GD | | B | IC(UPD65946) [IC127] IC |
| 57 | VHI74HC132M-1 | AF | DS | | B | IC(74HC132M) [IC118,133] IC |
| 58 | VHI74HC74AM-1 | AE | DJ | | B | IC(74HC74AM) [IC117] IC |
| 59 | VHI74LCX04M-1 | AE | DJ | | B | IC(74LCX04M) [IC103,116] IC |
| 60 | VHI74LVX08M-1 | AE | DJ | | B | IC(74LVX08M) [IC105] IC |
| 61 | VHI74LVX14M-1 | AE | DJ | | B | IC(74LVX14M) [IC102] IC |
| 62 | VHP1LHEE-002A | AC | DJ | | B | LED (Red)(1LHEE) [LED104,105] LED 赤 |
| 63 | VRD-HT2EY751J | AA | DD | | C | Resistor(1/4W 750Ω ±5%) [R160,231,232] 抵抗 |
| 64 | VRD-HT2HY471J | AA | DD | | C | Resistor(1/2W 470Ω ±5%) [R233] 抵抗 |
| 65 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R101,120-126,128,129,130] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R131,201,225,226,255] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R268-282,328-333,376] 抵抗 |
| 67 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R285-298,315-327] 抵抗 |

49 モデムコントロール基板 (Modem control PWB)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 67 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R344-359] 抵抗 |
| 68 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1.0KΩ ±5%) [R342] 抵抗 |
| 69 | VRS-CZ1JD103F | AA | DD | | C | Resistor(1/16W 10KΩ ±1%) [R170,210,213,227] 抵抗 |
| 70 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R106,117,132,176,177,178] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R179,180,183,192,193,197] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R198,199,229,237-252] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R264,265,266,283] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R284,310,311] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R312,313,314,334,335,336] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R337,338,343,367] 抵抗 |
| 71 | VRS-CZ1JD104J | AA | DD | | C | Resistor(1/16W 100KΩ ±5%) [R187,191] 抵抗 |
| 72 | VRS-CZ1JD123J | AA | DD | | C | Resistor(1/16W 12KΩ ±5%) [R174] 抵抗 |
| 73 | VRS-CZ1JD133F | AA | DD | | C | Resistor(1/16W 13KΩ ±1%) [R184,185] 抵抗 |
| 74 | VRS-CZ1JD152J | AA | DD | | C | Resistor(1/16W 1.5KΩ ±5%) [R234] 抵抗 |
| 75 | VRS-CZ1JD153F | AB | DD | | C | Resistor(1/16W 15KΩ ±1%) [R166,167,168,169] 抵抗 |
| 76 | VRS-CZ1JD183J | AA | DD | | C | Resistor(1/16W 18KΩ ±5%) [R215,228] 抵抗 |
| 77 | VRS-CZ1JD203J | AA | DD | | C | Resistor(1/16W 20KΩ ±5%) [R186] 抵抗 |
| 78 | VRS-CZ1JD222J | AA | DD | | C | Resistor(1/16W 2.2KΩ ±5%) [R230] 抵抗 |
| 79 | VRS-CZ1JD273F | AA | DD | | C | Resistor(1/16W 27KΩ ±1%) [R214] 抵抗 |
| 80 | VRS-CZ1JD273J | AA | DD | | C | Resistor(1/16W 27KΩ ±5%) [R195,366,378,204] 抵抗 |
| 81 | VRS-CZ1JD302J | AA | DD | | C | Resistor(1/16W 3KΩ ±5%) [R173] 抵抗 |
| 82 | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R104,134,267,300-309] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R361,368-371,373-375] 抵抗 |
| 83 | VRS-CZ1JD333J | AA | DD | | C | Resistor(1/16W 33KΩ ±5%) [R211,212,224] 抵抗 |
| 84 | VRS-CZ1JD363J | AA | DD | | C | Resistor(1/16W 36KΩ ±5%) [R189] 抵抗 |
| 85 | VRS-CZ1JD393F | AA | DD | | C | Resistor(1/16W 39KΩ ±1%) [R171] 抵抗 |
| 86 | VRS-CZ1JD393J | AA | DD | | C | Resistor(1/16W 39KΩ ±5%) [R216] 抵抗 |
| 87 | VRS-CZ1JD471J | AA | DD | | C | Resistor(1/16W 470Ω ±5%) [R116,340] 抵抗 |
| 88 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R103,105,114,133] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R135,139-142] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R144,145,148] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R161,163,164,165,202] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R205,206,207] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R208,209,260] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R261,262,263,299,360] 抵抗 |
| 89 | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R235] 抵抗 |
| 90 | VRS-CZ1JD513J | AA | DD | | C | Resistor(1/16W 51KΩ ±5%) [R182] 抵抗 |
| 91 | VRS-CZ1JD560J | AA | DD | | C | Resistor(1/16W 56Ω ±5%) [R143,236] 抵抗 |
| 92 | VRS-CZ1JD682J | AA | DD | | C | Resistor(1/16W 6.8KΩ ±5%) [R172,190] 抵抗 |
| 93 | VRS-CZ1JD683J | AA | DD | | C | Resistor(1/16W 68KΩ ±5%) [R188] 抵抗 |
| 94 | VRS-CZ1JD753J | AA | DD | | C | Resistor(1/16W 75KΩ ±5%) [R200] 抵抗 |
| 95 | VRS-CZ1JD912J | AA | DD | | C | Resistor(1/16W 9.1KΩ ±5%) [R217] 抵抗 |
| 96 | VRS-CZ1JD913J | AA | DD | | C | Resistor(1/16W 91KΩ ±5%) [R220] 抵抗 |
| 97 | VSDTA114EUA-1 | AC | DJ | | B | Transistor(DTA114EUA) [TR118] トランジスタ |
| 98 | VSDTC114EUA-1 | AC | DJ | | B | Transistor(DTC114EUA) [TR101,111,117] トランジスタ |
| 99 | VSDTC363EU+-1 | AC | DJ | | B | Transistor(DTC363EU) [TR102,103,104,105,109,110] トランジスタ |
| | VSDTC363EU+-1 | AC | DJ | | B | Transistor(DTC363EU) [TR112,113,114,115,116] トランジスタ |
| | VSDTC363EU+-1 | AC | DJ | | B | Transistor(DTC363EU) [TR120,121,122,123,124] トランジスタ |
| 100 | VS2SD592A/-1 | AE | DJ | | B | Transistor(2SD592A) [TR119] トランジスタ |
| 101 | PCAPH0010GCZZ | AD | DJ | | C | Cap(JM-2W-96) [JP104] キャップ |
| 102 | QPIN-0003GCZZ | AC | DJ | | C | Pin(T3B-SQ) [JP104] ピン |
| 103 | VCKYCZ1CB103K | AA | DD | | C | Capacitor(16WV 0.010μF) [C295] コンデンサ |
| | (Unit) | | | | | |
| 901 | CPWBN1472FCE4 | CG | UM | N | E | Modem control PWB unit モデムコントロール基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

50 TEL/LIU 基板ユニット (TEL/LIU PWB)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | QCNCW1155FCZZ | AE | DJ | | C | Connector(30pin) [CN2] コネクタ |
| 2 | QJAKT0001FCZZ | AD | DJ | | C | Moduler connector(2pin) [MJ1] モジュラコネクタ |
| 3 | QJAKT0002FCZZ | AE | DJ | | C | Moduler connector(6pin) [MJ2] モジュラコネクタ |
| 4 | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C5,33,34,43,45,53] コンデンサ |
| | RC-KZ0008QCZZ | AB | DD | | C | Capacitor(50WV 0.1μF) [C17,27,35,47] コンデンサ |
| 6 | RCILZ0089FCZZ | AG | DX | | C | Coil(ST110AV) [L8] コイル |
| 7 | RFILN0047FCZZ | AC | DJ | | C | EMI filter(MMZ1608S121) [NF1] EMI フィルタ |
| 8 | RFILN2011SCZZ | AC | DJ | | C | Coil(SBT-0260) [L1,2,6,7] コイル |
| | RFILN2011SCZZ | AC | DJ | | C | Coil(SBT-0260) [L3,4,5] コイル |
| 9 | RR-WZ0418FCZZ | AF | DS | | B | Relay(HPC1/2W) [R30] リレー |
| 10 | RRLYD1211QCZZ | AH | DX | | B | Relay(OUAZSH112LZ) [RY2] リレー |
| | RRLYD1211QCZZ | AH | DX | | B | Relay(OUAZSH112LZ) [RY1] リレー |
| 11 | RRLYD1411QCZZ | AM | EG | | B | Relay(RSH-12-U) [RY3,4] リレー |
| 14 | VCCCCZ1EH221J | AB | DD | | C | Capacitor(25WV 220pF) [C50] コンデンサ |
| | VCCCCZ1EH221J | AB | DD | | C | Capacitor(25WV 220pF) [C20,32] コンデンサ |
| 15 | VCCCCZ1HH101J | AA | DD | | C | Capacitor(50WV 100pF) [C44] コンデンサ |
| 16 | VCEAZA1EW476M | AC | DD | | C | Capacitor(25WV 47μF) [C14,51] コンデンサ |
| 17 | VCEAZA1HW105M | AB | DD | | C | Capacitor(50WV 1.0μF) [C52] コンデンサ |

50 TEL/LIU 基板ユニット (TEL/LIU PWB)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 17 | VCEAZA1HW105M | AB | DD | | C | Capacitor(50WV 1.0μF) [C36] コンデンサー |
| 18 | VCEAZA1HW226M | AC | DD | | C | Capacitor(50WV 22μF) [C1] コンデンサー |
| 19 | VCEAZA1HW334M | AB | DD | | C | Capacitor(50WV 0.33μF) [C10] コンデンサー |
| 20 | VCEAZA1HW475M | AB | DD | | C | Capacitor(50WV 4.7μF) [C4,11,42,48,49] コンデンサー |
| 21 | VCE9EA1CW106M | AC | DD | | C | Capacitor(16WV 10μF) [C30,31] コンデンサー |
| 22 | VCE9GA1CW476M | AD | DD | | C | Capacitor(16WV 47μF) [C8] コンデンサー |
| 23 | VCFYJU2EA105K | AE | DS | | C | Capacitor(250WV 1μF) [C6] コンデンサー |
| 25 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C9] コンデンサー |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C2,18,19,21,28] コンデンサー |
| 26 | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) [C39] コンデンサー |
| 27 | VHD0R5G4B42-1 | AF | DS | | B | Diode(0R5G4B42) [REC1,2] ダイオード |
| 28 | VHD1SS133//--1 | AA | DD | | B | Diode(1SS133) [D7,8,9] ダイオード |
| | VHD1SS133//--1 | AA | DD | | B | Diode(1SS133) [D1,3,4,5,6,10] ダイオード |
| 29 | VHD10DDA40+-1 | AB | DD | | B | Diode(10DDA40) [D2] ダイオード |
| 30 | VHEHVS2C1//--1 | AB | DJ | | B | Zener diode(HZS2C1) [ZD2,3] ユニバーサルダイオード |
| 31 | VHEMTZJ33B+-1 | AC | DJ | | B | Zener diode(MTZJ33B) [ZD1,6] ユニバーサルダイオード |
| 32 | VHEMTZJ4R7B-1 | AC | DJ | | B | Zener diode(MTZJ4R7B) [ZD4,5,8,9] ユニバーサルダイオード |
| 33 | VHEMTZJ8.2B-1 | AB | DJ | | B | Zener diode(MTZJ8.2B) [ZD7] ユニバーサルダイオード |
| 34 | VHIBU4066BCF1 | AD | DJ | | B | IC(BU4066BCF1) [IC103,104] IC |
| 35 | VHINJM4558MF1 | AE | DJ | | B | IC(NJM4558MF1) [IC102,105,107,108] IC |
| 36 | VHITA31076F-1 | AH | DX | | B | IC(TA31076F) [IC101] IC |
| 37 | VHPPC814X1+-1 | AD | DJ | | B | Photo coupler(PC814X1) [PC3] フォトカプラー |
| 38 | VHPPC817D//--1 | AD | DJ | | B | Photo coupler(PC817D) [PC1,4] フォトカプラー |
| 39 | VHPTLP624-1BV | AG | DX | | B | Photo coupler(TLP624) [PC2] フォトカプラー |
| 40 | VHVDSS-401M// | AH | DX | | B | Arrestor(DSS) [SA2] アレスター |
| 41 | VHVTNR5V471K/ | AD | DJ | | B | Varistor(TNR5V471K) [SA1] バリスター |
| 42 | VHVTN07G101-1 | AB | DJ | | B | Varistor(TN07G101) [VA2] バリスター |
| 43 | VRD-HT2EY100J | AA | DD | | C | Resistor(1/4W 10Ω ±5%) [R11,53] 抵抗 |
| 44 | VRD-HT2EY104J | AA | DD | | C | Resistor(1/4W 100KΩ ±5%) [R20] 抵抗 |
| 45 | VRD-HT2EY124J | AA | DD | | C | Resistor(1/4W 120KΩ ±5%) [R21] 抵抗 |
| 46 | VRD-HT2EY164J | AA | DD | | C | Resistor(1/4W 160KΩ ±5%) [R4] 抵抗 |
| 47 | VRD-HT2EY183J | AA | DD | | C | Resistor(1/4W 18KΩ ±5%) [R39] 抵抗 |
| 48 | VRD-HT2EY204J | AA | DD | | C | Resistor(1/4W 200KΩ ±5%) [R3] 抵抗 |
| 49 | VRD-HT2EY224J | AA | DD | | C | Resistor(1/4W 220KΩ ±5%) [R19] 抵抗 |
| 50 | VRD-HT2EY300J | AA | DD | | C | Resistor(1/4W 30Ω ±5%) [R18] 抵抗 |
| 52 | VRD-HT2EY303J | AA | DD | | C | Resistor(1/4W 30KΩ ±5%) [R38] 抵抗 |
| 53 | VRD-HT2EY471J | AA | DD | | C | Resistor(1/4W 470Ω ±5%) [R7] 抵抗 |
| 55 | VRD-HT2EY682J | AA | DD | | C | Resistor(1/4W 6.8KΩ ±5%) [R5] 抵抗 |
| 56 | VRD-HT2EY910J | AA | DD | | C | Resistor(1/4W 91Ω ±5%) [R10] 抵抗 |
| 57 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R1,2,6] 抵抗 |
| 58 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1.0KΩ ±5%) [R15,23,26,28,29] 抵抗 |
| 59 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R14,25,56,75,76] 抵抗 |
| 60 | VRS-CZ1JD113J | AA | DD | | C | Resistor(1/16W 11KΩ ±5%) [R43,79,81] 抵抗 |
| 61 | VRS-CZ1JD153J | AA | DD | | C | Resistor(1/16W 15KΩ ±5%) [R74] 抵抗 |
| 62 | VRS-CZ1JD183J | AA | DD | | C | Resistor(1/16W 18KΩ ±5%) [R78] 抵抗 |
| 63 | VRS-CZ1JD203J | AA | DD | | C | Resistor(1/16W 20KΩ ±5%) [R41,54] 抵抗 |
| 64 | VRS-CZ1JD223J | AA | DD | | C | Resistor(1/16W 22KΩ ±5%) [R8,33,48,49,50] 抵抗 |
| | VRS-CZ1JD223J | AA | DD | | C | Resistor(1/16W 22KΩ ±5%) [R65,66,68,71] 抵抗 |
| | VRS-CZ1JD223J | AA | DD | | C | Resistor(1/16W 22KΩ ±5%) [R51,52,59,60] 抵抗 |
| 65 | VRS-CZ1JD243J | AA | DD | | C | Resistor(1/16W 24KΩ ±5%) [R55] 抵抗 |
| | VRS-CZ1JD243J | AA | DD | | C | Resistor(1/16W 24KΩ ±5%) [R82] 抵抗 |
| 66 | VRS-CZ1JD272J | AA | DD | | C | Resistor(1/16W 2.7KΩ ±5%) [R40] 抵抗 |
| 67 | VRS-CZ1JD273J | AA | DD | | C | Resistor(1/16W 27KΩ ±5%) [R58,77,84] 抵抗 |
| 68 | VRS-CZ1JD332J | AA | DD | | C | Resistor(1/16W 3.3KΩ ±5%) [R44] 抵抗 |
| 70 | VRS-CZ1JD512J | AA | DD | | C | Resistor(1/16W 5.1KΩ ±5%) [R73] 抵抗 |
| 71 | VRS-CZ1JD513J | AA | DD | | C | Resistor(1/16W 51KΩ ±5%) [R72] 抵抗 |
| 72 | VRS-CZ1JD621J | AA | DD | | C | Resistor(1/16W 681KΩ ±5%) [R67,69] 抵抗 |
| 74 | VRS-RA3AA202J | AB | DD | | C | Resistor(1W 2KΩ ±5%) [R13] 抵抗 |
| 75 | VSDTC143ZKA-1 | AC | DJ | | B | Transistor(DTC143ZKA) [Q104,117,118,119,121,122] トランジスタ |
| | VSDTC143ZKA-1 | AC | DJ | | B | Transistor(DTC143ZKA) [Q101,102,105,106,111,112] トランジスタ |
| | VSDTC143ZKA-1 | AC | DJ | | B | Transistor(DTC143ZKA) [Q113,115,116,120,123] トランジスタ |
| 76 | VS2SA1807-P-1 | AE | DS | | B | Transistor(2SA1807) [Q110] トランジスタ |
| 77 | VS2SC2412KS-1 | AB | DD | | B | Transistor(2SC2412KS) [Q108,109] トランジスタ |
| 78 | VS2SC3415-P-1 | AP | EQ | | B | Transistor(2SC3415) [Q11] トランジスタ |
| 79 | VS2SD1266A0-1 | AF | DS | | B | Transistor(2SD1266A0) [Q2] トランジスタ |
| 80 | VS2SD592A-S-1 | AK | DX | | B | Transistor(2SD592A) [Q3] トランジスタ |
| 81 | QCNCM1156FCZZ | AD | DJ | | C | Connector(3pin) [CN3] コネクタ |
| 82 | QSODC0081FCZZ | AL | EB | | C | Connector(6pin) [CN1] コネクタ |
| 83 | RC-KZ0009QCZZ | AB | DD | | C | Capacitor(50WV 0.01μF) [C24] コンデンサー |
| 84 | RRLYD3211QCZZ | AM | EG | | B | Relay(G6E134PUS) [RY5] リレー |
| 85 | RTRNP0534FCZZ | AT | EZ | | B | Transformer(CIT1414EP-A) [T3] トランス |
| 86 | RTRNP2105SCZZ | AP | EQ | | B | Transformer(2105) [T1] トランス |
| 87 | VCEAZA1HW225M | AB | DD | | C | Capacitor(50WV 2.2μF) [C16,22,26,29] コンデンサー |
| 88 | VCFYDA1HA105J | AE | DJ | | C | Capacitor(50WV 1μF) [C13] コンデンサー |
| 89 | VCFYJU2AA824K | AF | DS | | C | Capacitor(100WV 0.82μF) [C23] コンデンサー |
| 90 | VCFYJU2GA473K | AC | DD | | C | Capacitor(400WV 0.047μF) [C7] コンデンサー |
| 91 | VCKYCZ1AB333K | AB | DD | | C | Capacitor(10WV 0.033μF) [C38,54] コンデンサー |
| 92 | VCKYCZ1HB222K | AA | DD | | C | Capacitor(50WV 2200pF) [C3] コンデンサー |
| 93 | VQYNU1HM223K | AA | DD | | C | Capacitor(50WV 0.023μF) [C15] コンデンサー |
| 95 | VHIH8D3063+-1 | AW | FG | | B | IC(H8D3063) [IC1] IC |

50 TEL/LIU 基板ユニット (TEL/LIU PWB)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--------------------------------------|
| | | Ex. | Ja. | | | |
| 97 | VH1THS56F/-1 | AS | EZ | | B | IC(THS56F) [IC2] IC |
| 98 | VRD-HT2EY472J | AA | DD | | C | Resistor(1/4W 4.7KΩ ±5%) [R22] 抵抗 |
| 99 | VRS-CZ1JD151J | AA | DD | | C | Resistor(1/16W 150Ω ±1%) [R46] 抵抗 |
| 100 | VRS-CZ1JD222J | AA | DD | | C | Resistor(1/16W 2.2KΩ ±5%) [R45] 抵抗 |
| 101 | VRS-CZ1JD331J | AA | DD | | C | Resistor(1/16W 330Ω ±5%) [R16] 抵抗 |
| 102 | VRS-CZ1JD363J | AA | DD | | C | Resistor(1/16W 36KΩ ±5%) [R57] 抵抗 |
| 103 | VRS-CZ1JD393J | AA | DD | | C | Resistor(1/16W 39KΩ ±5%) [R31] 抵抗 |
| 104 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R9] 抵抗 |
| 105 | VRS-CZ1JD683J | AA | DD | | C | Resistor(1/16W 68KΩ ±5%) [R27,42] 抵抗 |
| 106 | VRS-CZ1JD821J | AA | DD | | C | Resistor(1/16W 820Ω ±5%) [R64] 抵抗 |
| 107 | VRS-CZ1JD822J | AA | DD | | C | Resistor(1/16W 8.2KΩ ±5%) [R32] 抵抗 |
| 108 | VRS-RA3AA472J | AB | DD | | C | Resistor(1W 4.7KΩ ±5%) [R83] 抵抗 |
| | (Unit) | | | | | |
| 901 | CPWBN1491FCE1 | CA | TV | | E | TEL/LIU PWB unit TEL/LIU 基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

51 PCU 基板 (PCU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | QCNCM0879FCZZ | AF | DS | | C | Connector(28Pin) [CN17] コネクタ |
| 2 | QCNCM0923FC10 | AE | DJ | | C | Connector(10pin) [CN6,CN14] コネクタ |
| 3 | QCNCM0923FC12 | AE | DJ | | C | Connector(12pin) [CN10] コネクタ |
| 4 | QCNCM0923FC16 | AF | DS | | C | Connector(16pin) [CN19] コネクタ |
| 5 | QCNCM0923FC22 | AF | DS | | C | Connector(22pin) [CN20] コネクタ |
| 6 | QCNCM0923FC24 | AF | DS | | C | Connector(24pin) [CN9] コネクタ |
| 7 | QCNCM0923FC32 | AG | DS | | C | Connector(32Pin) [CN7] コネクタ |
| 8 | QCNCM0923FC3D | AF | DS | | C | Connector(B34B-PHDSS)(34pin) [CN11,CN12] コネクタ |
| 9 | QCNCM7014SC0C | AA | DD | | C | Connector(3pin) [CN1,CN3,CN5,CN8] コネクタ |
| 10 | QCNCM7014SC0F | AB | DD | | C | Connector(6pin) [CN13,CN2] コネクタ |
| 11 | QCNCW0885FCZZ | AG | DX | | C | Connector(1-171825-2) [CN4] コネクタ |
| 13 | QCNCW1170FCZZ | AG | DS | | C | Connector(28FMZ-BT) [CN16] コネクタ |
| 14 | QSOCZ0073FCZZ | AL | EB | | C | Connector(72pin) [SOCKET1] コネクタ |
| 15 | QSOCZ6428ACZZ | AE | DS | | C | IC socket(28pin) [IC22] IC ソケット |
| 16 | RCRSP0071FCZZ | AH | DX | N | B | Crystal(AT-51(20.00MHz)) [X1] クリスタル |
| 17 | RCRSZ0001QSZZ | AG | DS | | B | Crystal(AT-51(19.6608MHz)) [X2] クリスタル |
| 18 | RFILZ0004QSZZ | AM | EG | | C | Filter(ZJSR5101-223) [NF5,NF4] フィルタ |
| 19 | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300OpF) [NF1,NF2,NF3] フィルタ |
| 20 | RH-IX0003QSZZ | AQ | EQ | | B | IC(SRAM)(IS61LV256-12J) [IC25,IC24] IC(SRAM) |
| 21 | RMP TW4101QCJJ | AB | DD | | B | Block resistor(100Ω×4) [BR15,BR19] プ ロックレ ザ ー |
| 22 | RMP TW4102QCJJ | AB | DD | | B | Block resistor(1.0KΩ×4) [BR26,BR29] プ ロックレ ザ ー |
| | RMP TW4102QCJJ | AB | DD | | B | Block resistor(1.0KΩ×4) [BR31,BR34,BR35,BR36,BR38] プ ロックレ ザ ー |
| 23 | RMP TW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR21,BR24,BR41,BR42,BR43] プ ロックレ ザ ー |
| | RMP TW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR44,BR45,BR46,BR17] プ ロックレ ザ ー |
| 24 | RMP TW4330QCJJ | AB | DD | | B | Resistor array(33Ω×4 1/32W ±5%) [BR8,BR9] テ ィ コウ ア レ ー |
| | RMP TW4330QCJJ | AB | DD | | B | Resistor array(33Ω×4 1/32W ±5%) [BR10,BR11] テ ィ コウ ア レ ー |
| | RMP TW4330QCJJ | AB | DD | | B | Resistor array(33Ω×4 1/32W ±5%) [BR12,BR16,BR20] テ ィ コウ ア レ ー |
| | RMP TW4330QCJJ | AB | DD | | B | Resistor array(33Ω×4 1/32W ±5%) [BR23,BR47] テ ィ コウ ア レ ー |
| 26 | RMP TW4472QCJJ | AB | DD | | B | Resistor array(4.7kΩ×4 ±5%) [BR1,BR4,BR5,BR6,BR13] テ ィ コウ ア レ ー |
| | RMP TW4472QCJJ | AB | DD | | B | Resistor array(4.7kΩ×4 ±5%) [BR14,BR27,BR28] テ ィ コウ ア レ ー |
| | RMP TW4472QCJJ | AB | DD | | B | Resistor array(4.7kΩ×4 ±5%) [BR32,BR33] テ ィ コウ ア レ ー |
| | RMP TW4472QCJJ | AB | DD | | B | Resistor array(4.7kΩ×4 ±5%) [BR40] テ ィ コウ ア レ ー |
| 27 | RMP TW4473QCJJ | AB | DD | | B | Resistor array(47kΩ×4 ±5%) [BR30,BR37,BR39] テ ィ コウ ア レ ー |
| 29 | VCCCCZ1HH180J | AA | DD | | C | Capacitor(50WV 18pF)(GRM36CH180J50PT) [C82,C89] コ ン デ ン サ ー |
| 30 | VCCCCZ1HH220J | AA | DD | | C | Capacitor(50WV 22pF) [C84,C83] コ ン デ ン サ ー |
| 31 | VCCUCY1AJ105Z | AC | DD | | C | Capacitor(10WV 1.0μF) [C105] コ ン デ ン サ ー |
| 32 | VCEAGA0JW107M | AC | DD | | C | Capacitor(6.3WV 100μF) [C110] コ ン デ ン サ ー |
| 33 | VCEAGA1AW108M | AC | ZT | | C | Capacitor(10WV 1000μF) [C44] コ ン デ ン サ ー |
| 34 | VCEAGA1AW477M | AB | DD | | C | Capacitor(10WV 470μF) [C55] コ ン デ ン サ ー |
| 35 | VCEAZU1VW106M | AB | DD | | C | Capacitor(10μF/35V)(SMG35VB-10M) [C15,C35,C40] コ ン デ ン サ ー |
| | VCEAZU1VW106M | AB | DD | | C | Capacitor(10μF/35V)(SMG35VB-10M) [CC48,C56] コ ン デ ン サ ー |
| | VCEAZU1VW106M | AB | DD | | C | Capacitor(10μF/35V)(SMG35VB-10M) [C58,C68,C77] コ ン デ ン サ ー |
| 36 | VCEAZU0JW338M | AE | DJ | | C | Capacitor(3300μF/6.3V)(UVR0J332MPA1TD) [C60] コ ン デ ン サ ー |
| 37 | VCEAZU1VW477M | AD | DJ | | C | Capacitor(35WV 470μF) [C3] コ ン デ ン サ ー |
| 38 | VCKYCY1HB223K | AC | DD | | C | Capacitor(50WV 0.022μF) [C2,C4,C5,C6,C7] コ ン デ ン サ ー |
| | VCKYCY1HB223K | AC | DD | | C | Capacitor(50WV 0.022μF) [C13,C14,C88] コ ン デ ン サ ー |
| 39 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C1,C8,C9,C11,C16] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C17,C20,C23,C30,C33] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C34,C36,C37,C38,C39] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C42,C43,C45,C46,C47] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C49,C50,C52,C53,C54] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C57,C59,C61,C62,C63] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C64,C65,C66,C70] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C81,C85,C86,C87,C90] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C91,C95,C96,C97,C101] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C104,C107,C109] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C111,C112,C113,C114,C115] コ ン デ ン サ ー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C116,C118,C123,C124,C125] コ ン デ ン サ ー |

51 PCU 基板 (PCU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|-----------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 39 | VCKY CZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C126,C127,C139] コンデンサー |
| 40 | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C18,C19,C21,C22,C24] コンデンサー |
| | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C25,C26,C27,C28,C29] コンデンサー |
| | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C31,C32,C69,C71,C72] コンデンサー |
| | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C73,C74,C75,C76,C78] コンデンサー |
| | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C79] コンデンサー |
| | VCKY CZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C106,C108,C117] コンデンサー |
| 41 | VHDDAN202U/-1 | AB | DD | | B | Diode(DAN202U) [D2,D7,D8,D9] ダイオード |
| | VHDDAN202U/-1 | AB | DD | | B | Diode(DAN202U) [D21,D22] ダイオード |
| 42 | VHDDAP202U/-1 | AB | DD | | B | Diode(DAP202U) [D10,D23] ダイオード |
| 43 | VHDDSS133// -1 | AA | DD | | B | Diode(1SS133) [D1,D5,D11,D12,D13,D20] ダイオード |
| 44 | VHDMA704A// -1 | AC | DJ | | B | Diode(MA704A) [D15,D16] ダイオード |
| 45 | VH DRA13++++ -1 | AD | DJ | | B | Diode(RA13) [D14] ダイオード |
| 46 | VHERD22FB// -1 | AD | DJ | | B | Zener diode(RD22FB) [D4] ヲエナゲダイオード |
| 47 | VHH103AT-2// -1 | AG | DS | | B | Thermistor(103AT-2) [TH1] サミスター |
| 48 | VHHMSMDC014-1 | AF | DS | | B | Thermistor(miniSMDC014) [R71] ホリスイッチ |
| 49 | VHi65946P110C | BB | GD | | B | I/O ASIC(uPD65946GN-P11-LMU) [IC27] IC |
| 50 | VHi74VHC32MTC | AD | DJ | | B | IC(74VHC32MTC) [IC9] IC |
| 52 | VHiH8S2320+-1 | AY | FQ | | B | IC(H8S/2320) [IC23] IC |
| 53 | VHiHC151MTC-1 | AE | DJ | | B | LOGIC(74HC151MTCX) [IC13,IC14,IC15,IC20] IC |
| 54 | VHiHN58V65A-1 | AW | FG | | B | EEPROM(HN58V65AP) [IC22] EEPROM |
| 55 | VHiLM324D+-1 | AE | DJ | | B | OP-AMP(LM324DR) [IC19] IC |
| 56 | VHiLM339D+-1 | AE | DJ | | B | IC(LM339DT) [IC17] コンパレータ |
| 57 | VHiM51957BFP1 | AH | DX | | B | IC(M51957BFP1) [IC35,IC34] IC |
| 59 | VHiSLA7031M-1 | AQ | EQ | | B | IC(SLA7031M) [IC1,IC28] IC |
| 60 | VHiSLA7032M-1 | AR | EQ | | B | IC(SLA7032M) [IC2] IC |
| 61 | VHiTA7291AS-1 | AG | DX | | B | IC(TA7291AS) [IC12] IC |
| 62 | VHiTD62003AF/ | AE | DS | | B | IC(TD62003AF) [IC3,IC4,IC5,IC6,IC7] IC |
| | VHiTD62003AF/ | AE | DS | | B | IC(TD62003AF) [IC8,IC33] IC |
| 63 | VHiVC4051MT-1 | AF | DS | | B | LOGIC(74VHC4051MTCX) [IC36] IC |
| 64 | VHiVHC14MTC-1 | AD | DJ | | B | LOGIC(74VHC14AMTCX) [IC10,IC16,IC18,IC32] IC |
| 65 | VHiVHCT14AM-1 | AE | DJ | | B | LOGIC(74VHCT14AMTCX) [IC29] IC |
| 67 | VHiVT574MTC-1 | AF | DS | | B | LOGIC(74VHCT574AMTCX) [IC11] IC |
| 69 | VRS-CY1JD270J | AA | DD | | C | Resistor(1/16W 27Ω ±5%) [R51,R38] 抵抗 |
| 70 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R18,R19,R20,R23,R46] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R97,R212,R140,R142] 抵抗 |
| 71 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R69,R90,R91,R110] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R124,R172,R185] 抵抗 |
| 72 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R13,R14,R27,R31,R32] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R33,R34,R35,R39,R52] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R57,R60,R63,R66,R67] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R75,R93,R111] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R113,R153,R154] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R161,R169,R195,R196,R197] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R202,R206,R207,R209,R210] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R213,R214] 抵抗 |
| 73 | VRS-CZ1JD103F | AA | DD | | C | Resistor(1/16W 10KΩ ±1%) [R199] 抵抗 |
| 74 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R47,R78,R125,R149,R150] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R151,R152,R170,R175] 抵抗 |
| 75 | VRS-CZ1JD104F | AA | DD | | C | Resistor(1/16W 100KΩ ±1%) [R130,R131,R198] 抵抗 |
| 76 | VRS-CZ1JD104J | AA | DD | | C | Resistor(1/16W 100KΩ ±5%) [R42,R54,R56,R61,R70] 抵抗 |
| | VRS-CZ1JD104J | AA | DD | | C | Resistor(1/16W 100KΩ ±5%) [R101,R116,R117] 抵抗 |
| | VRS-CZ1JD104J | AA | DD | | C | Resistor(1/16W 100KΩ ±5%) [R145,R146] 抵抗 |
| 77 | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R81,R89,R92,R102,R103] 抵抗 |
| | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R144] 抵抗 |
| 78 | VRS-CZ1JD113F | AA | DD | | C | Resistor(1/16W 11KΩ ±1%) [R168] 抵抗 |
| 79 | VRS-CZ1JD162J | AA | DD | | C | Resistor(1.6KJ)(MCR01MZSJ162) [R5,R106] 抵抗 |
| 80 | VRS-CZ1JD201J | AA | DD | | C | Resistor(1/16W 200Ω ±5%) [R109] 抵抗 |
| 81 | VRS-CZ1JD202J | AA | DD | | C | Resistor(1/16W 2.0KΩ ±5%) [R28] 抵抗 |
| 82 | VRS-CZ1JD221J | AA | DD | | C | Resistor(1/16W 220Ω ±5%) [R147] 抵抗 |
| 84 | VRS-CZ1JD272J | AA | DD | | C | Resistor(1/16W 2.7KΩ ±5%) [R99] 抵抗 |
| 85 | VRS-CZ1JD273F | AA | DD | | C | Resistor(1/16W 27KΩ ±1%)(MCR01MZSF272) [R177] 抵抗 |
| 86 | VRS-CZ1JD303J | AA | DD | | C | Resistor(1/16W 30KΩ ±5%)(MCR01MZSJ303) [R11,R16] 抵抗 |
| | VRS-CZ1JD303J | AA | DD | | C | Resistor(1/16W 30KΩ ±5%)(MCR01MZSJ303) [R77] 抵抗 |
| | VRS-CZ1JD303J | AA | DD | | C | Resistor(1/16W 30KΩ ±5%)(MCR01MZSJ303) [R119,R134] 抵抗 |
| | VRS-CZ1JD303J | AA | DD | | C | Resistor(1/16W 30KΩ ±5%)(MCR01MZSJ303) [R165,R184] 抵抗 |
| 87 | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R50,R76,R82,R85,R95] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R98,R104,R136,R137,R143] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R155,R156,R157,R188,R191] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R193,R43,R64,R68,R41] 抵抗 |
| 88 | VRS-CZ1JD391J | AA | DD | | C | Resistor(1/16W 390Ω ±5%)(MCR01MZSJ391) [R7,R108] 抵抗 |
| 89 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R1,R2,R3,R10,R12] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R17,R24,R30,R36,R37] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R40,R44,R45,R49,R53] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R55,R58,R59,R62,R65] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R72,R73,R80,R83,R87] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R88,R112,R114,R118,R121] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R122,R128,R133] 抵抗 |

51 PCU 基板 (PCU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 89 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R148,R158] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R162,R171,R174] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R176,R186] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R187,R194,R201] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R203,R204] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R205,R208,R211] 抵抗 |
| 90 | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R86,R129,R189,R190] 抵抗 |
| 91 | VRS-CZ1JD622J | AA | DD | | C | Resistor(1/16W 6.2KΩ ±5%)(MCR01MZSJ622) [R74] 抵抗 |
| 93 | VRS-CZ1JD821J | AA | DD | | C | Resistor(1/16W 820Ω ±5%)(MCR01MZSJ821) [R107] 抵抗 |
| 94 | VRS-TP2BD1R0J | AA | DD | | C | Resistor(1/8W 1.0Ω ±5%) [R178,R179,R180,R181,R182] 抵抗 |
| | VRS-TP2BD1R0J | AA | DD | | C | Resistor(1/8W 1.0Ω ±5%) [R183] 抵抗 |
| 96 | VS2SA1576A/-1 | AB | DJ | | B | Transistor(2SA1576A) [Q3,Q4,Q5,Q8] トランジスタ |
| 97 | VS2SC2412K/-1 | AB | DD | | B | Transistor(2SC2412K) [Q39,Q35] トランジスタ |
| 98 | VSDTA114YUA-1 | AC | DJ | | B | Transistor(DTA114YUA) [Q30,Q31,Q36,Q40,Q53,Q58] トランジスタ |
| 99 | VSDTA144EUA-1 | AC | DJ | | B | Transistor(DTA144EUA) [Q49] トランジスタ |
| 100 | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q2,Q9,Q10,Q11,Q12] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q13,Q14,Q15,Q16,Q18] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q19,Q20,Q21,Q22,Q23] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q24,Q25,Q26,Q27,Q28] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q33,Q34,Q37,Q38] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q45,Q47] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q48,Q50,Q51,Q52,Q54] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q55,Q56,Q57,Q59] トランジスタ |
| | (Unit) | | | | | |
| 901 | CPWBN1544DS51 | BR | LX | N | E | PCU PWB UNIT PCU 基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

52 MFPC2 基板 (MFPC2 PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | QCNCM0923FC10 | AE | DJ | | C | Connector(10pin) [CN9] コネクタ |
| 2 | QCNCM0923FC14 | AE | DJ | | C | Connector(14pin) [CN10] コネクタ |
| 3 | QCNCM0923FC16 | AF | DS | | C | Connector(16pin) [CN11] コネクタ |
| 4 | QCNCM0923FC24 | AF | DS | | C | Connector(24pin) [CN12] コネクタ |
| 5 | QCNCM0991FCZZ | AG | DX | | C | Connector(30FMZ-BT) [CN3,CN13] コネクタ |
| 6 | QCNCM1069AC1J | AD | DJ | | C | Connector(10pin) [CN7] コネクタ |
| 7 | QCNCM7014SC0F | AB | DD | | C | Connector(6pin) [CN6] コネクタ |
| 8 | QCNCW1157FCZZ | AB | DJ | | C | Connector(IMS-9604S-05C) [CN8] コネクタ |
| 9 | QCNCW1169FCZZ | AG | DS | | C | Connector(26FMZ-BT) [CN5] コネクタ |
| 10 | QCNCW5380NCZZ | AC | DJ | | C | Connector(B4B-PH-K-S) [CN14] コネクタ |
| 11 | QSOCZ0071FCZZ | AP | EQ | | C | Socket(MM20-72B1-1) [SOCKET1,SOCKET2] ソケット |
| 12 | QSOCZ6428ACZZ | AE | DS | | C | IC socket(28pin) [IC51] IC ソケット |
| 13 | RCRSQ0072FCZZ | AF | DS | | B | Crystal(22.1184MHz)(AT-51) [X1] クリスタル |
| 14 | RCRSQ0073FCZZ | AF | DS | | B | Crystal(21.4772MHz)(AT-51) [X3] クリスタル |
| 15 | RCRSQ0074FCZZ | AF | DS | | B | Crystal(25.69930MHz)(AT-51) [X4] クリスタル |
| 16 | RCRSZ0001QSZZ | AG | DS | | B | Crystal(AT-51(19.6608MHz)) [X2] クリスタル |
| 17 | RFILN0046FCZZ | AH | DX | | C | Noise filter(ZJSC-R47121) [NF20] ノイズフィルタ |
| 18 | RFILZ1042LCZZ | AC | DJ | | C | Filter(1000pF) [NF3,NF10,NF11,NF13,NF15] フィルタ |
| | RFILZ1042LCZZ | AC | DJ | | C | Filter(1000pF) [NF16] フィルタ |
| 19 | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300pF) [NF5,NF6,NF8,NF9,NF17] フィルタ |
| | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300pF) [NF18,NF19,NF21,NF22] フィルタ |
| | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300pF) [NF23,NF24,NF25,NF26,NF27] フィルタ |
| | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300pF) [NF28,NF34,NF36,NF37,NF38] フィルタ |
| | RFILZ1043LCZZ | AC | DJ | | C | Filter(3300pF) [NF39] フィルタ |
| 20 | RH-IX0003QSZZ | AQ | EQ | | B | IC(SRAM)(IS61LV256-12J) [IC41,IC33] IC(SRAM) |
| 21 | RH-IX3103YAZZ | AG | DS | | B | REGURATOR(L1087MPX_ADJ) [IC1,IC12,IC18,IC43,IC57] IC |
| 22 | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR52,BR53,BR54,BR55,BR67] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR68,BR69,BR73,BR74,BR75] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR79,BR80,BR81,BR82,BR83] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR84,BR95,BR98,BR99,BR101] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR102,BR103,BR105,BR107] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR109,BR111,BR113,BR117] ブロック抵抗 |
| | RMPTC4103QCJJ | AC | DD | | B | Block resistor(10KΩ×4) [BR118,BR120,BR122,BR124] ブロック抵抗 |
| 23 | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR1,BR2,BR3,BR4,BR5,BR6] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR7,BR8,BR9,BR10,BR20] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR21,BR22,BR23,BR24,BR25] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR26,BR27,BR28,BR29,BR30] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR31,BR32,BR33,BR38,BR39] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR40,BR41,BR42,BR43,BR44] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR45,BR46,BR47,BR48,BR49] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR50,BR51,BR56,BR57,BR58] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR59,BR60,BR61,BR62,BR63] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR65,BR66,BR70,BR71,BR72] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR76,BR77,BR78,BR85,BR86] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR87,BR88,BR89,BR90,BR91] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR92,BR93,BR94,BR96,BR97] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR100,BR104,BR106,BR108] ブロック抵抗 |

52 MFPC2 基板 (MFPC2 PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 23 | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR110, BR112, BR114, BR115] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR116, BR119, BR121, BR123] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR125, BR127, BR128, BR129] ブロック抵抗 |
| | RMPTC4330QCJJ | AC | DD | | B | Block resistor(33Ω×4) [BR130, BR131, BR132, BR133] ブロック抵抗 |
| 24 | RMPTC4473QCJJ | AC | DD | | B | Block resistor(47KΩ×4) [BR15, BR16, BR17, BR18, BR19] ブロック抵抗 |
| | RMPTC4473QCJJ | AC | DD | | B | Block resistor(47KΩ×4) [BR34, BR35, BR36, BR37, BR64] ブロック抵抗 |
| | RMPTC4473QCJJ | AC | DD | | B | Block resistor(47KΩ×4) [BR126] ブロック抵抗 |
| | RMPTC4473QCJJ | AC | DD | | B | Block resistor(47KΩ×4) [BR126] ブロック抵抗 |
| 25 | VCCCCZ1HH150J | AA | DD | | C | Capacitor(50WV 15pF) [C315, C316] コンデンサ |
| 26 | VCCCCZ1HH220J | AA | DD | | C | Capacitor(50WV 22pF) [C260, C262, C391] コンデンサ |
| | VCCCCZ1HH220J | AA | DD | | C | Capacitor(50WV 22pF) [C421, C454, C455] コンデンサ |
| 27 | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C10, C14, C30, C33, C59, C60] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C70, C71, C187, C191, C194] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C195, C268, C285, C289, C294] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C296, C299, C300, C314, C325] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C334, C361, C371, C379, C380] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C401, C405, C409, C444, C447] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C451, C574] コンデンサ |
| | VCEAEA0JW107M | AA | DD | | C | Capacitor(6.3WV 100μF) [C451, C574] コンデンサ |
| 28 | VCEAGA1AW476M | AA | DD | | C | Capacitor(10WV 47μF) [C224, C393, C425, C461, C462] コンデンサ |
| | VCEAGA1AW476M | AA | DD | | C | Capacitor(10WV 47μF) [C463, C464, C465, C466] コンデンサ |
| 29 | VCEAGA1AW477M | AB | DD | | C | Capacitor(10WV 470μF) [C4, C5, C62, C64, C220, C222] コンデンサ |
| | VCEAGA1AW477M | AB | DD | | C | Capacitor(10WV 470μF) [C305, C307, C395, C429, C474] コンデンサ |
| 30 | VCEAGA1CW106M | AA | DD | | C | Capacitor(16WV 10μF) [C6, C61, C150, C225, C426] コンデンサ |
| | VCEAGA1CW106M | AA | DD | | C | Capacitor(16WV 10μF) [C572, C573] コンデンサ |
| 31 | VCEAGA1CW107M | AC | DD | | C | Capacitor(100μF/16V) [C411, C446] コンデンサ |
| 32 | VCEAGA1HW224M | AA | DD | | C | Capacitor(50WV 0.22μF) [C357, C399] コンデンサ |
| 33 | VCEAGA1VW107M | AB | DD | | C | Capacitor(35WV 100μF) [C410, C570] コンデンサ |
| 34 | VCEAGA1VW227M | AB | DD | | C | Capacitor(35WV 220μF) [C352, C398, C404, C438, C478] コンデンサ |
| | VCEAGA1VW227M | AB | DD | | C | Capacitor(35WV 220μF) [C569] コンデンサ |
| 35 | VCKYCY1HF223Z | AA | DD | | C | Capacitor(50WV 0.022μF) [C212, C400, C427, C483, C364] コンデンサ |
| 36 | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C3, C7, C8, C9, C11, C12, C13] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C15, C16, C17, C18, C19, C20] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C21, C22, C23, C24, C25, C26] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C27, C28, C29, C34, C35, C36] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C37, C38, C39, C40, C41, C42] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C43, C44, C45, C46, C47, C48] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C49, C50, C51, C52, C53, C54] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C55, C56, C57, C58, C63, C65] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C72, C73, C74, C75, C76, C77] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C78, C79, C80, C81, C82, C83] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C84, C85, C86, C87, C88, C89] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C90, C91, C92, C93, C94, C95] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C97, C99, C100, C102, C103] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C104, C105, C106, C107, C108] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C109, C111, C112, C113, C114] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C115, C116, C117, C118, C119] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C120, C121, C122, C123, C124] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C125, C126, C127, C128, C129] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C130, C131, C132, C133, C134] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C135, C136, C137, C138, C139] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C140, C141, C142, C149, C151] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C152, C153, C154, C155, C156] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C157, C158, C159, C160, C161] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C162, C163, C164, C165, C166] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C167, C168, C169, C171, C172] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C173, C174, C175, C176, C182] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C183, C184, C185, C186, C188] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C189, C190, C192, C193, C197] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C198, C199, C200, C201, C202] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C203, C205, C206, C207, C208] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C209, C210, C211, C216, C218] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C221, C223, C228, C230, C231] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C234, C236, C237, C244, C246] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C248, C249, C250, C252] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C254, C261, C263, C267] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C269, C270, C271, C275, C277] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C278, C279, C280, C281, C282] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C283, C284, C286, C287, C288] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C290, C291, C292, C293, C295] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C297, C298, C304, C306] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C313, C318, C319, C320, C321] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C322, C324, C327, C328, C329] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C333, C335, C336, C337, C339] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C340, C341, C342, C343, C344] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C345, C346, C347, C348, C350] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C351, C358, C359, C360, C362] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C363, C366, C367, C368, C369] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C370, C373, C375, C381, C382] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C383, C384, C385, C386, C387] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C388, C389, C390, C392, C394] コンデンサ |
| | VCKYCY1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C396, C397, C402, C403, C407] コンデンサ |

52 MFPC2 基板 (MFPC2 PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 36 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C408,C412,C413,C414,C415] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C416,C417,C419,C420,C423] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C424,C428,C430,C431,C432] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C439,C440,C445,C448,C449] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C450,C452,C453,C458,C460] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C467,C468,C475,C479,C482] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C485,C487,C488,C490,C491] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C492,C493,C494,C496,C497] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C498,C499,C500,C501,C503] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C505,C506,C507,C509,C510] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C513,C514,C515,C516,C517] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C518,C520,C521,C522,C523] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C524,C525,C527,C529,C530] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C531,C533,C534,C537,C538] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C539,C540,C541,C542,C544] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C545,C546,C547,C548,C549] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C551,C553,C554,C555,C557] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C558,C560,C579,C580] コンデンサ |
| 37 | VCKYCZ1EB472K | AA | DD | | C | Capacitor(25WV 4700p(1005)) [C470] コンデンサ |
| 38 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C110,C144,C145,C146,C170] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C196,C204,C213,C214,C215] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C217,C219,C238,C247,C251] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C253,C255,C256,C257,C259] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C301,C302,C303,C323] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C326,C331,C338,C353,C354] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C355,C356,C372,C374] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C406,C418,C433,C434,C435] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C436,C441,C442,C471,C473] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C476,C477,C486,C504,C528] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C552,C561,C562,C563,C564] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C565,C566,C567,C568] コンデンサ |
| 39 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C1,C2,C66,C67,C68] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C308,C365] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C143,C147,C148,C226,C227] コンデンサ |
| 40 | VCKYTQ0JF106Z | AD | DJ | | C | Capacitor(0.01μF/50V) [C229,C232,C233,C235,C312] コンデンサ |
| | VCKYTQ0JF106Z | AD | DJ | | C | Capacitor(0.01μF/50V) [C349,C437,C443,C480,C571] コンデンサ |
| | VCKYTQ0JF106Z | AD | DJ | | C | Capacitor(6.3WV 10μF) [C484,C489,C495,C502,C508] コンデンサ |
| 41 | VHDDAN202U/-1 | AB | DD | | B | Capacitor(6.3WV 10μF) [C512,C519,C526,C532,C536] コンデンサ |
| | VHDDAN202U/-1 | AB | DD | | B | Capacitor(6.3WV 10μF) [C543,C550,C556] コンデンサ |
| | VHDDAN202U/-1 | AB | DD | | B | Diode(DAN202U) [D1,D2,D7,D8,D11,D15,D18] ダイオード |
| 42 | VHDDAP202U/-1 | AB | DD | | B | Diode(DAN202U) [D21,D23,D31,D34,D36,D38] ダイオード |
| | VHDDAP202U/-1 | AB | DD | | B | Diode(DAP202U) [D39,D40,D42,D55,D56,D57] ダイオード |
| | VHDDAP202U/-1 | AB | DD | | B | Diode(DAP202U) [D3,D4,D9,D10,D12,D14,D17] ダイオード |
| 43 | VHDDSS133/-1 | AA | DD | | B | Diode(DAP202U) [D20,D22,D30,D32,D35,D37] ダイオード |
| | VHDDSS133/-1 | AA | DD | | B | Diode(DAP202U) [D41,D43,D44,D45,D52,D53] ダイオード |
| | VHDDSS133/-1 | AA | DD | | B | Diode(DAP202U) [D54] ダイオード |
| 44 | VHDM1FS4///-1 | AD | DJ | | B | Diode(1SS133) [D5,D6,D13,D25,D26,D27] ダイオード |
| | VHDM1FS4///-1 | AD | DJ | | B | Diode(1SS133) [D28,D29,D33,D60] ダイオード |
| | VHDM1FS4///-1 | AD | DJ | | B | Diode(M1FS4) [D46,D47,D48,D49,D50,D51] ダイオード |
| 45 | VHDM704A/-1 | AC | DJ | | B | Diode(M1FS4) [D58,D59] ダイオード |
| 46 | VHDM704A/-1 | AC | DJ | | B | Diode(MA704A) [D16] ダイオード |
| 47 | VHDM704A/-1 | AD | DJ | | B | Diode(RA13) [D24] ダイオード |
| 48 | VHEH3S3B1/-1 | AC | DJ | | B | Diode(RA13) [D24] ダイオード |
| 49 | VH161622FH1C | BA | FX | | B | Zener diode(HZS3B1) [ZD1] ヲホダ イオード |
| 50 | VH161622FH1C | BA | FX | | B | FCRAM(MB81E161622) [IC3,IC5,IC13] FCRAM |
| 51 | VH161LV6416-1 | AX | FG | | B | SRAM(IS61LV6416(TSOP)) [IC50] SRAM |
| 52 | VH174LCX08MTC | AE | DJ | | B | IC(74LCX08MTC) [IC49] IC |
| 53 | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) [IC11,IC17,IC22] IC |
| 54 | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) [IC32,IC39,IC48] IC |
| 55 | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) [IC14,IC25,IC27,IC34,IC35] IC |
| 56 | VH174LCX245MT | AM | DX | | B | IC(74LCX245MT) [IC42] IC |
| 57 | VH174VHC08/-1 | AE | DS | | B | IC(74VHC08) [IC26] IC |
| 58 | VH190C363A+-1 | AU | FG | | B | LVDS(DS90C363AMTD) [IC19] IC |
| 59 | VH1H8S2320+-1 | AY | FQ | | B | IC(H8S/2320) [IC31,IC23] IC |
| 60 | VH1HG73C095-1 | AY | FQ | | B | CCDC(HG73C095TE) [IC45] IC |
| 61 | VH1HN58V65A-1 | AW | FG | | B | EEPROM(HN58V65AP) [IC51] EEPROM |
| 62 | VH1LM358DR+-1 | AF | DS | | B | IC(LM358D) [IC16,IC38] IC |
| 63 | VH1LM98513+-1 | AY | FQ | | B | A/D CONVERTER(LM98513) [IC54,IC55,IC56] IC |
| 64 | VH1M51957BFP1 | AH | DX | | B | IC(M51957BFP1) [IC21,IC40] IC |
| 65 | VH1M87J8310-1 | BQ | LP | | B | CPT-ASIC(208 QFP)(208 QFP) [IC15] IC |
| 66 | VH1M87L4240-1 | BG | GT | | B | ASIC-A(MB87L4240PMT-G-BND(208QFP)) [IC10] IC |
| 67 | VH1M87M12901 | BZ | TF | | B | ASIC-B(MB87M1290PFVS-G-BND(304QFP)) [IC6] IC |
| 68 | VH1MBLV064N-1 | BA | FX | | B | ROM(NAND (MBM30LV0064-PFTN)) [IC2] 色補正 ROM |
| 69 | VH1MTD2007F-1 | AU | EZ | | B | IC(MTD2007F) [IC53] IC |
| 70 | VH1SD8M16L1-1 | BB | GD | | B | SDRAM(HY57V281620HCT-P) [IC37] SDRAM |
| 71 | VH1TD62003AF/- | AE | DS | | B | IC(TD62003AF) [IC44] IC |
| 72 | VH1TD62503F/- | AG | DX | | B | IC(TD62503F) [IC28,IC29] IC |
| 73 | VH1UPD85632-1 | BM | HV | | B | SCN-ASIC(240 QFP)(240 QFP) [IC36] IC |
| 74 | VH1UPD85658-1 | BV | RB | | B | ASIC-C(240 QFP)(UPD85658GN-011-LMU)) [IC9] IC |
| 75 | VHPLT1F67AF-1 | AC | DJ | | B | LED(LT1F67AF) [LED1,LED2] LED |
| 76 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R48,R57,R62,R110] 抵抗 |

52 MFPC2 基板 (MFPC2 PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 76 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R88,R144,R170] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R171,R180,R198,R199,R200] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R201,R202,R223,R229,R233] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R248,R249,R251,R256,R262] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R263,R265,R270,R276,R277] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R279,R284,R130] 抵抗 |
| 77 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R131] 抵抗 |
| 78 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1,R2,R4,R15,R16,R25,R90] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R91,R92,R124,R125,R126] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R127,R184,R186,R235] 抵抗 |
| 79 | VRS-CZ1JD103F | AA | DD | | C | Resistor(1/16W 10KΩ ±1%) [R43] 抵抗 |
| 80 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R12,R26,R27,R28,R45,R51] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R58,R65,R69,R85] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R87,R95,R102] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R111,R113,R115,R128] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R129,R132,R133,R136,R137] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R138,R140,R156,R157,R158] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R191,R193,R195,R196,R243] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R244,R245,R257,R271,R285] 抵抗 |
| 81 | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R288,R289,R291] 抵抗 |
| 83 | VRS-CZ1JD122J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R121,R179,R222] 抵抗 |
| | VRS-CZ1JD122J | AA | DD | | C | Resistor(1/16W 1.2KΩ ±5%) [R30,R31,R32] 抵抗 |
| | VRS-CZ1JD122J | AA | DD | | C | Resistor(1/16W 1.2KΩ ±5%) [R33,R41,R154] 抵抗 |
| | VRS-CZ1JD122J | AA | DD | | C | Resistor(1/16W 1.2KΩ ±5%) [R155] 抵抗 |
| 84 | VRS-CZ1JD123J | AA | DD | | C | Resistor(1/16W 12KΩ ±5%) [R42] 抵抗 |
| 85 | VRS-CZ1JD133J | AA | DD | | C | Resistor(1/16W 13KΩ ±5%) [R231] 抵抗 |
| 86 | VRS-CZ1JD152J | AA | DD | | C | Resistor(1/16W 1.5KΩ ±5%) [R17,R22,R40] 抵抗 |
| 88 | VRS-CZ1JD203F | AA | DD | | C | Resistor(1/16W 20KΩ ±1%) [R44] 抵抗 |
| 89 | VRS-CZ1JD203J | AA | DD | | C | Resistor(1/16W 20KΩ ±5%) [R183,R185,R234] 抵抗 |
| 90 | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R162,R166,R167,R168,R206] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R209,R211,R212] 抵抗 |
| 91 | VRS-CZ1JD221J | AA | DD | | C | Resistor(1/16W 220Ω ±5%) [R78,R292,R293] 抵抗 |
| 92 | VRS-CZ1JD242J | AA | DD | | C | Resistor(1/16W 2.4KΩ ±5%) [R29,R230,R232] 抵抗 |
| 93 | VRS-CZ1JD303J | AA | DD | | C | Resistor(1/16W 30KΩ ±5%) [R89] 抵抗 |
| 94 | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R134,R135,R139,R141] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R187,R189] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R319,R320,R321,R322,R323] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R324,R62,R110] 抵抗 |
| 95 | VRS-CZ1JD331J | AA | DD | | C | Resistor(1/16W 330Ω ±5%) [R123,R150,R221] 抵抗 |
| 96 | VRS-CZ1JD332F | AA | DD | | C | Resistor(1/16W 3.3KΩ ±1%) [R120,R119] 抵抗 |
| 97 | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R294,R295,R296] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R297,R298] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R299,R300,R301] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R302,R304] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R305,R306,R307] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R308,R309] 抵抗 |
| | VRS-CZ1JD362J | AA | DD | | C | Resistor(1/16W 3.6KΩ ±5%) [R310,R311,R312] 抵抗 |
| 98 | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R3,R5,R6,R18,R20,R21,R36] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R37,R38,R39,R49,R80,R83] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R84,R86,R116,R142,R159] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R192,R194,R204,R205,R214] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R220,R226,R227] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R325,R326] 抵抗 |
| 99 | VRS-CZ1JD471J | AA | DD | | C | Resistor(1/16W 470Ω ±5%) [R203,R213,R225,R259,R273] 抵抗 |
| | VRS-CZ1JD471J | AA | DD | | C | Resistor(1/16W 470Ω ±5%) [R287] 抵抗 |
| 100 | VRS-CZ1JD472F | AA | DD | | C | Resistor(1/16W 4.7kΩ ±1%)(MCR01MZSF472) [R122,R118] 抵抗 |
| 101 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R53,R54,R55] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R93,R94,R105] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R107,R112,R188] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R190,R239] 抵抗 |
| | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R240,R241,R242] 抵抗 |
| 102 | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R19,R59,R60,R61,R81,R114] 抵抗 |
| | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R117,R145,R147,R149,R160] 抵抗 |
| | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R161,R164,R165,R169] 抵抗 |
| 105 | VRS-HT3DAR51J | AC | DD | | C | Resistor(2W 0.51Ω ±5%) [R153,R152] 抵抗 |
| 106 | VS2SB1197/-1 | AC | DJ | | B | Transistor(2SB1197) [Q22,Q24,Q26] トランジスタ |
| 107 | VSDTA114EUA-1 | AC | DJ | | B | Transistor(DTA114EUA) [Q16,Q21,Q28,Q29,Q37] トランジスタ |
| 108 | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q1,Q2,Q3,Q4,Q5,Q6,Q8,Q9] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q10,Q11,Q12,Q13,Q14,Q15] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q19,Q20,Q23,Q25,Q27,Q30] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q31,Q33,Q34,Q35,Q17] トランジスタ |
| | (Unit) | | | | | |
| 901 | CPWBN1519DS52 | CX | ** | N | E | MFPC2 PWB UNIT MPFC2 基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | PCAPH0010GCZZ | AD | DJ | | C | Cap(JM-2W-96) [PIN1,PIN2] キャップ |
| 2 | PCOV1468FCZZ | AD | DJ | | D | FAX battery cover FAX テンチカバー |
| 3 | QCNCM0923FC14 | AE | DJ | | C | Connector(14pin) [CN10] コネクター |
| 4 | QCNCM0923FC22 | AF | DS | | C | Connector(22pin) [CN4,CN5,CN6,CN9] コネクター |
| 5 | QCNCM0923FC24 | AF | DS | | C | Connector(24pin) [CN13] コネクター |
| 6 | QCNCM1069AC1J | AD | DJ | | C | Connector(10pin) [CN11] コネクター |
| 7 | QCNCM1187FCZZ | AM | EG | N | C | Connector(F_BM30B-SRDS-G-TF) (AR-C260F/C260FP) [CN12] コネクター |
| 8 | QCNCM7014SC0C | AA | DD | | C | Connector(3pin) [CN20] コネクター |
| 9 | QCNCM7014SC0G | AB | DD | | C | Connector(7pin) (Japan Only) [CN14] コネクター |
| 10 | QCNCW0948FCZ6 | AC | DJ | | C | Connector(B06B-XASK-1) [CN1,CN2,CN3,CN7] コネクター |
| 11 | QCNCW1047FCZZ | AH | DX | | C | Connector(TSC7658-01-201) [CN18] コネクター |
| 12 | QCNCW1170FCZZ | AG | DS | | C | Connector(28FMZ-BT) [CN16] コネクター |
| 13 | QCNCW1186FCZZ | AF | DS | | C | Connector(TX25-100P-LT-H1) [CN17] コネクター |
| 14 | QPIN-0003GCZZ | AC | DJ | | C | Pin(T3B-SQ) [PIN1,PIN2] ピン |
| 15 | QSOCZ0001QSZZ | AL | EB | | C | Socket(DMM168-FLAA2-3A133) [DIMM2,DIMM1] ソケット |
| 16 | QSOCZ0073FCZZ | AL | EB | | C | Connector(72pin) [SOCKET2,SOCKET3] コネクター |
| 17 | QSOCZ0073FCZZ | AL | EB | | C | Connector(72pin) (AR-C260F/C260FP)[SOCKET1] コネクター |
| 18 | QSOCZ6428ACZZ | AE | DS | | C | IC socket(28pin) [IC50] IC ソケット |
| 19 | RCRSP0069FCZZ | AG | DS | | B | Crystal(14.7456MHz)(AT-51) [X3] クリスタル |
| 20 | RCRSP0077FCZZ | AF | DS | | B | Crystal(16.667MHz)(AT-51) [X5] クリスタル |
| 21 | RCRSP0079FCZZ | AF | DS | | B | Crystal(12.352MHz)(AT-51) [X6] クリスタル |
| 22 | RCRSP6676RCZZ | AG | DX | | B | Crystal(32.768KHz) [X9] クリスタル |
| 23 | RCRSQ0073FCZZ | AF | DS | | B | Crystal(21.47727MHz)(AT-51) [X1] クリスタル |
| 23 | RFILN5022NCZZ | AC | DJ | | C | EMI filter(BLM11A12PT) [L1,L2,L5,L7,L9,L11,L13] EMI フィルター |
| | RFILN5022NCZZ | AC | DJ | | C | EMI filter(BLM11A12PT) [L15,L16,L20,L22,L24,L26] EMI フィルター |
| | RFILN5022NCZZ | AC | DJ | | C | EMI filter(BLM11A12PT) [L27,L29,L32,L35,L36,L37] EMI フィルター |
| 24 | RFILZ1043LCZZ | AC | DJ | | C | Filter(33000pF) [NF2,NF3,NF4,NF5,NF6,NF8] フィルター |
| | RFILZ1043LCZZ | AC | DJ | | C | Filter(33000pF) [NF9] フィルター |
| 25 | RH-IX3103YAZZ | AG | DS | | B | REGULATOR(L1087MPX_ADJ) [IC51,IC31] IC |
| 26 | RMEMM0001FCZZ | BZ | TF | | B | SDRAM-Module-PWB(256MB-DIMM) [DIMM2] SDRAM-Module-PWB |
| 27 | RMPTW4100QCJJ | AA | DD | | B | Block resistor(10Ω×4) [BR42,BR58,BR61,BR66] ブロック抵抗 |
| 28 | RMPTW4101QCJJ | AB | DD | | B | Block resistor(100Ω×4) [BR1,BR2,BR3,BR4,BR5,BR6] ブロック抵抗 |
| | RMPTW4101QCJJ | AB | DD | | B | Block resistor(100Ω×4) [BR26,BR40] ブロック抵抗 |
| 29 | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR7,BR8,BR9,BR10,BR11] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR12,BR13,BR14,BR15,BR18] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR25,BR27,BR28,BR39,BR41] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR57,BR62,BR63,BR64,BR65] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR84,BR85,BR104,BR108] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR109,BR110,BR111,BR114] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR115,BR116,BR117,BR122] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR124,BR132,BR137,BR142] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR146,BR150,BR152,BR154] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR156,BR158,BR160,BR162] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR164,BR167,BR169,BR177] ブロック抵抗 |
| | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR179,BR205,BR206] ブロック抵抗 |
| 30 | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR19,BR20,BR21] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR22,BR23] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR24,BR37,BR38] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR43,BR44] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR45,BR46,BR47] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR48,BR49] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR50,BR51,BR52] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR55,BR56] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR59,BR60,BR67] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR69,BR71] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR73,BR75,BR77] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR78,BR81] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR82,BR86,BR87] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR88,BR89] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR91,BR97] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR98,BR99] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR100,BR105] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR106,BR107] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR118,BR125] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR126,BR127] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR128,BR129] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR130,BR131] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR133,BR136] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR138,BR141] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR143,BR145] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR147,BR149] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR151,BR153] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR155,BR157] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR159,BR161] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR163,BR165] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR170,BR171] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR172,BR173] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR174,BR175] ブロック抵抗 |
| | RMPTW4470QCJJ | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR176] ブロック抵抗 |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 30 | RMP T W 4 4 7 0 Q C J J | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR180,BR181] ブロック抵抗 |
| | RMP T W 4 4 7 0 Q C J J | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR182,BR183] ブロック抵抗 |
| | RMP T W 4 4 7 0 Q C J J | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR184,BR200] ブロック抵抗 |
| | RMP T W 4 4 7 0 Q C J J | AB | DD | | B | Block resistor(47Ω×4 1/32W ±5%) [BR201,BR202,BR203] ブロック抵抗 |
| 31 | U B A T 1 0 0 1 4 F C Z Z | AN | EQ | | B | Battery(CR2477-H01) (AR-C260F/C260FP)[BT1] バッテリー |
| 32 | V C C C C Z 1 H H 1 5 1 J | AC | DD | | C | Capacitor(150pF/50V)(GRM36CH151J50PT) [C64,C65,C66] コンデンサ |
| | V C C C C Z 1 H H 1 5 1 J | AC | DD | | C | Capacitor(150pF/50V)(GRM36CH151J50PT) [C67,C103] コンデンサ |
| | V C C C C Z 1 H H 1 5 1 J | AC | DD | | C | Capacitor(150pF/50V)(GRM36CH151J50PT) [C104,C118,C119] コンデンサ |
| 33 | V C C C C Z 1 H H 2 2 0 J | AA | DD | | C | Capacitor(50WV 22pF) [C33,C34] コンデンサ |
| 34 | V C C C C Z 1 H H 2 7 0 J | AA | DD | | C | Capacitor(27P 50V 1005) [C148,C150,C151] コンデンサ |
| | V C C C C Z 1 H H 2 7 0 J | AA | DD | | C | Capacitor(27P 50V 1005) [C153] コンデンサ |
| | V C C C C Z 1 H H 2 7 0 J | AA | DD | | C | Capacitor(27P 50V 1005) [C60,C62] コンデンサ |
| 35 | V C E A G A 1 A W 1 0 7 M | AB | DD | | C | Capacitor(10WV 100μF) [C46,C81,C112,C117,C154] コンデンサ |
| | V C E A G A 1 A W 1 0 7 M | AB | DD | | C | Capacitor(10WV 100μF) [C155,C182,C233,C241,C254] コンデンサ |
| | V C E A G A 1 A W 1 0 7 M | AB | DD | | C | Capacitor(10WV 100μF) [C272,C273,C295,C316] コンデンサ |
| 36 | V C E A G A 1 A W 4 7 6 M | AA | DD | | C | Capacitor(10WV 47μF) [C1,C6,C13,C30,C83,C94] コンデンサ |
| | V C E A G A 1 A W 4 7 6 M | AA | DD | | C | Capacitor(10WV 47μF) [C218,C219] コンデンサ |
| | V C E A G A 1 A W 4 7 6 M | AA | DD | | C | Capacitor(10WV 47μF) (AR-C260F/C260FP)[C361,C367] コンデンサ |
| 37 | V C E A G A 1 A W 4 7 6 M | AA | DD | | C | Capacitor(10WV 47μF) [C1025,C1035] コンデンサ |
| | V C E A Z A 1 A W 4 7 7 M | AC | DD | | C | Capacitor(10WV 470μF) [C5,C8,C12,C56,C157,C177] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (Japan only) [C287,C288] コンデンサ |
| 38 | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (Japan only) [C292,C307,C308] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) [C53] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (AR-C260F/C260FP) [C196,C197,C205] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (AR-C260F/C260FP) [C217,C220] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (AR-C260F/C260FP) [C225,C226,C229] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (AR-C260F/C260FP) [C232,C244] コンデンサ |
| | V C K Y C Y 1 E B 1 0 4 K | AG | DX | | C | Capacitor(25WV 0.1μF(1608:B)) (AR-C260F/C260FP) [C232,C244] コンデンサ |
| 39 | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C10,C11,C29,C37,C38,C40] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C41,C50,C57,C59,C61,C63] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C68,C70,C71,C72,C73,C74] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C75,C76,C77,C78,C80,C82] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C84,C89,C90,C91,C93,C96] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C99,C100,C101,C102,C105] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C106,C107,C108,C109,C113] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C114,C116,C120,C121,C122] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C124,C125,C128,C129,C130] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C131,C132,C133,C134,C136] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C137,C140,C141,C142,C143] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C144,C147,C149,C152,C156] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C158,C159,C160,C161,C162] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C163,C164,C167,C168,C169] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C171,C172,C173,C175,C176] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C178,C180,C181,C183,C184] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C188,C189,C190,C192,C193] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C194,C195,C198,C199,C200] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C201,C202,C206,C207,C208] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C209,C210,C211,C212,C213] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C214,C215,C222,C223,C234] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C235,C236,C237,C238,C239] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C240,C248,C251,C252,C253] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C257,C258,C259,C260,C261] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C262,C264,C265,C266,C267] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C268,C269,C270,C274,C275] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C276,C277,C278,C281,C282] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C284,C285,C286,C289,C290] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C291,C294,C296,C297,C298] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C299,C300,C301,C302,C303] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C304,C309,C310,C317,C318] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C319,C320,C323,C324,C325] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C329,C333,C334,C335,C336] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C344,C347,C348,C351] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C355,C356,C357,C364,C368] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C1022,C1026,C1027,C1028] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C1029,C1030,C1031,C1032] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C1033,C1034,C1047,C1050] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C1051,C1052,C1053] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) (AR-C260F/C260FP) [C92,C135,C165] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) (AR-C260F/C260FP)[C216,C224] コンデンサ |
| | V C K Y C Z 1 C F 1 0 4 Z | AB | DD | | C | Capacitor(16WV 0.1μF) (AR-C260F/C260FP) [C250,C279,C280] コンデンサ |
| 40 | V C K Y C Z 1 E B 1 0 3 K | AB | DD | | C | Capacitor(0.01μF 25V 1005) [C15,C19,C23,C98] コンデンサ |
| 41 | V C K Y C Z 1 H B 1 0 2 K | AA | DD | | C | Capacitor(50WV 1000pF) [C17,C21,C25,C36,C79,C110] コンデンサ |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION | |
|-----|----------------|------------|-----|----------|-----------|----------------------------------|---|
| | | Ex. | Ja. | | | | |
| 41 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | [C174,C293,C312,C313,C322] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | [C327,C332,C337,C338,C339] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | [C352,C353,C354,C358,C359] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | [C360,C365,C1024,C1036] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | [C1037,C1056] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) | (AR-C260F/C260FP) [C203,C230] コンデンサ |
| 42 | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) | (AR-C260F/C260FP)[C231] コンデンサ |
| | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) | [C14,C18,C22,C95,C314] コンデンサ |
| 43 | VHD1SS355//--1 | AB | DJ | | B | Diode(1SS355) | [C315] コンデンサ |
| | VHD1SS355//--1 | AB | DJ | | B | Diode(1SS355) | [D100,D101] ダイオード |
| 44 | VHDDAN202U/--1 | AB | DD | | B | Diode(DAN202U) | (AR-C260F/C260FP)[D37,D40] ダイオード |
| | VHDDAN202U/--1 | AB | DD | | B | Diode(DAN202U) | [D9,D12,D16,D17,D18,D28] ダイオード |
| | VHDDAN202U/--1 | AB | DD | | B | Diode(DAN202U) | [D29,D30,D31,D32,D33,D34] ダイオード |
| | VHDDAN202U/--1 | AB | DD | | B | Diode(DAN202U) | [D35,D36,D41,D42,D43,D45] ダイオード |
| 45 | VHDDAP202U/--1 | AB | DD | | B | Diode(DAP202U) | (AR-C260F/C260FP)[D4] ダイオード |
| | VHDDAP202U/--1 | AB | DD | | B | Diode(DAP202U) | [D8,D11,D13,D14,D15,D19] ダイオード |
| | VHDDAP202U/--1 | AB | DD | | B | Diode(DAP202U) | [D20,D21,D22,D23,D24,D25] ダイオード |
| | VHDDAP202U/--1 | AB | DD | | B | Diode(DAP202U) | [D26,D27,D38,D39,D44,D46] ダイオード |
| 46 | VHDBR451F//--1 | AD | DS | | B | Diode(RB451F) | (AR-C260F/C260FP)[D3] ダイオード |
| 47 | VH123S09SC+-1 | AV | FG | | B | ZDBUFFER(CY23S09SC-1) | [IC34] IC |
| 48 | VH158C256AP-1 | BB | GD | | B | EEPROM(HN58V256AP-10) | [IC50] EEPROM |
| 50 | VH165949P03-1 | BE | GN | | B | ASIC(uPD65949GD-P03-LML)(IOASIC) | [IC56] IC |
| 51 | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) | [IC21,IC23,IC29,IC66,IC67] IC |
| | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) | [IC68] IC |
| | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) | (AR-C260F/C260FP)[IC43] IC |
| 52 | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC2,IC3,IC4,IC7,IC8,IC13] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC17,IC18,IC26,IC27,IC35] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC53,IC69,IC72,IC73] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC74,IC75,IC76,IC102] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC103,IC104,IC105,IC106] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) | [IC107,IC108] IC |
| 53 | VH174LCX245MT | AM | DX | | B | IC(74LCX245MT) | [IC57,IC58,IC59,IC60,IC61] IC |
| 54 | VH185672011-1 | BV | RB | | B | ASIC(uPD85672S1-011-F6)(ICUASIC) | [IC33] IC |
| 55 | VH190CF364A-1 | AU | FG | | B | LVDISIC(DS90CF364AMTD) | [IC32] IC |
| 56 | VH1CY25811S-1 | AN | EG | | B | SSIC(CY25811SC) | [IC12] IC |
| 58 | VH1CY25814S-1 | AN | EG | | B | SSIC(CY25814SC) | [IC39,IC37] IC |
| 59 | VH1H1207ECB-1 | AN | EQ | | B | RS232CDRIVER(HIN207ECB) | (Japan only) [IC52] IC |
| 60 | VH1LCX574MT-1 | AF | DS | | B | LOGIC(74LCX574) | [IC28] IC |
| 61 | VH1LCX74MTC-1 | AE | DJ | | B | LOGIC(74LCX74) | [IC1] IC |
| 62 | VH1LHF80J01-1 | AX | FG | | B | FLASH ROM(F_LH28F800BJE-PTTL90) | (AR-C260F/C260FP) [IC30,IC42] FLASH ROM |
| 63 | VH1LM393D+-1 | AE | DJ | | B | COMPARATOR(LM393D) | [IC78] IC |
| 64 | VH1M3032ATC-1 | AT | EZ | N | B | CPLD(EPM3032ATC44-10) | [IC109] IC |
| 65 | VH1M51957BFP1 | AH | DX | | B | IC(M51957BFP1) | [IC22] IC |
| 66 | VH1MAX3225E-1 | AT | EZ | | B | IC(MAX3225E) | (AR-C260F/C260FP)[IC45,IC44] IC |
| 67 | VH1NJU6356E-1 | AK | DX | | B | IC(NJU6356E) | [IC63] IC |
| 68 | VH1PM2500+-1 | BP | LP | | B | ASIC(PM-2500) | [IC48] IC |
| 69 | VH1SD8M16L1-1 | BB | GD | | B | SDRAM(128x16SDRAM) | [IC55] SDRAM |
| 70 | VH1SH770910-1 | BH | GX | | B | IC(SH770910) | [IC54] IC |
| 71 | VH1SR1024-7LL | AU | EZ | | B | SRAM(F_UT62L1024LC-70LL) | (AR-C260F/C260FP) [IC65,IC64] SRAM |
| 72 | VHPLT1F67AF-1 | AC | DJ | | B | LED(LT1F67AF) | [SLED1,SLED2] LED |
| | VHPLT1F67AF-1 | AC | DJ | | B | LED(LT1F67AF) | [SLED3] LED |
| 73 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R3,R6,R9,R13,R37,R40,R64] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R85,R104,R105,R118,R155] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R156,R162,R163,R175,R178] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R188,R192,R246,R272,R306] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R307,R308,R309,R311,R312] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R317,R318,R321,R330,R331] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R343,R344,R353,R356,R357] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R367,R371,R384,R420,R424] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R457,R458,R460,R461,R478] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R557,R558,R571,R602,R678] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R687,R704,R902,R903] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R905,R907,R1016] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R1022,R1040,R1051,R1062] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R1085,R1092,R1096,R1098] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | [R1100,R1102,R1104,R1111] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | (AR-C260F/C260FP) [R191,R423,R431] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | (AR-C260F/C260FP) [R432,R436] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | (AR-C260F/C260FP) [R437,R449,R450] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) | (AR-C260F/C260FP) [R462,R463] 抵抗 |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 73 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) (AR-C260F/C260FP) [R488,R489,R523] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) (AR-C260F/C260FP) [R790,R1010] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R2,R5,R8,R221] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) (Except Japan) [R1083] 抵抗 |
| 74 | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R136,R137,R149,R150,R227] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R228,R253,R257,R258,R287] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R288,R293,R296,R301,R316] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R375,R440,R441,R447] 抵抗 |
| 75 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R10,R12,R32,R34,R38,R41] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R42,R43,R44,R45,R68,R70] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R97,R108,R110,R119,R120] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R121,R122,R132,R176,R213] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R214,R215,R216,R220,R222] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R266,R267,R268,R271,R276] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R279,R313,R319,R320,R332] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R334,R349,R364,R368,R388] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R389,R390,R391,R392,R393] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R1012,R1013,R1015] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R1052,R1053,R1077,R1078] 抵抗 |
| | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R1081] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R145,R166] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R232,R247,R295,R335] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R339,R348,R528,R595,R611] 抵抗 |
| 76 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R618,R643,R644,R648,R649] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R676,R684,R685,R686,R689] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R690,R708,R726,R727,R730] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R731,R732,R742,R744,R752] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R753,R754,R755,R756,R758] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R759,R760,R767,R768] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R802,R803,R804,R1005] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1006,R1008,R1023] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1028,R1029,R1030,R1031] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1036,R1074,R1082,R1109] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1115,R1116,R1117,R1121] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R124] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) (AR-C260F/C260FP) [R421,R471,R472] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) (AR-C260F/C260FP) [R795,R1009] 抵抗 |
| 77 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R11,R28,R29,R33,R35,R46] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R116,R168,R169,R170,R172] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R174,R180,R233,R235,R238] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R241,R265,R280,R286,R290] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R291,R303,R314,R333,R350] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R362,R363,R373,R387,R394] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R415,R419,R428,R434,R435] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R442,R446,R448,R456,R468] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R474,R475,R476,R477,R480] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R481,R482,R483,R496,R497] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R498,R499,R500,R501,R546] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R567,R568,R579,R580,R586] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R587,R594,R614,R615,R616] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R617,R621,R622,R623,R624] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R627,R628,R629,R636,R637] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R638,R639,R645,R673,R679] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R680,R681,R688,R696] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260/C260S/C260M) [R703] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260F/C260FP) [R702] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R705,R706,R707,R710,R714] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R735,R736,R737,R738,R739] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260/C260S/C260M) [R740] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260F/C260FP) [R741,R1087] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R743,R745,R746,R747] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R748,R749,R750,R751,R785] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R796,R800,R801] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1014,R1032,R1033,R1034] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1035,R1037,R1055,R1056] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1063,R1064,R1066,R1067] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1068,R1069,R1070,R1071] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1072,R1075,R1076] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1089,R1112,R1113,R1114] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R1119] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260F/C260FP) [R422,R433,R438] 抵抗 |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 77 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260F/C260FP) [R466,R473] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (AR-C260F/C260FP) [R484,R485,R494] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) (Except Japan) [R1073,R1079,R1080] 抵抗 |
| 78 | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R79,R125,R336] 抵抗 |
| | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R340,R1054] 抵抗 |
| 79 | VRS-CZ1JD121J | AA | DD | | C | Resistor(1/16W 120Ω ±5%) [R325,R326,R590] 抵抗 |
| 80 | VRS-CZ1JD151J | AA | DD | | C | Resistor(1/16W 150Ω ±5%) [R694] 抵抗 |
| | VRS-CZ1JD152J | AA | DD | | C | Resistor(1/16W 1.5KΩ ±5%) [R83,R560] 抵抗 |
| 81 | VRS-CZ1JD152J | AA | DD | | C | Resistor(1/16W 1.5KΩ ±5%) [R563,R574,R575,R786] 抵抗 |
| 82 | VRS-CZ1JD182J | AA | DD | | C | Resistor(1/16W 1.8KΩ ±5%) [R77] 抵抗 |
| 83 | VRS-CZ1JD202J | AA | DD | | C | Resistor(1/16W 2.0KΩ ±5%) [R682] 抵抗 |
| | VRS-CZ1JD271J | AA | DD | | C | Resistor(1/16W 270Ω ±5%) [R591] 抵抗 |
| 84 | VRS-CZ1JD271J | AA | DD | | C | Resistor(1/16W 270JΩ ±5%) [R78] 抵抗 |
| 85 | VRS-CZ1JD272J | AA | DD | | C | Resistor(1/16W 2.7KΩ ±5%) [R82] 抵抗 |
| 86 | VRS-CZ1JD333J | AA | DD | | C | Resistor(1/16W 33KΩ ±5%) (AR-C260F/C260FP)[R791] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R54,R55,R56,R59,R60,R61] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R73,R74,R75,R128,R129] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R130,R131,R159,R160,R161] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R181,R182,R183,R195,R197] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R199,R200,R201,R203,R204] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R217,R218,R219,R223,R239] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R242,R248,R262,R263,R264] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R270,R275,R277,R278,R304] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R310,R328,R346,R360,R361] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R372,R379,R383,R385,R395] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R396,R397,R398,R399,R406] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R416,R418,R429,R443,R444] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R445,R469,R503,R504,R505] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R506,R507,R508,R509,R510] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R511,R512,R513,R518,R519] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R520,R521,R537,R538,R539] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R540,R541,R542,R543,R544] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R545,R547,R548,R549,R550] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R551,R552,R553,R554,R565] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R566,R569,R570,R577,R578] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R581,R585,R593,R599,R600] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R603,R606,R607,R608,R609] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R612,R625,R631,R633,R634] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R641,R642,R650,R653,R654] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R655,R656,R657,R659,R660] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R661,R662,R667,R668,R669] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R670,R671,R674,R691,R692] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R693,R695,R709,R711,R712] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R713,R715,R716,R717,R718] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R719,R720,R721,R722,R723] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R724,R725,R728,R729,R733] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R765,R772,R773,R774,R775] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R776,R778,R780,R781,R782] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R783,R784,R1018,R1019] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R1020,R1021,R1038,R1039] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R1057,R1058,R1059,R1060] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R1065,R1090,R1091,R1093] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R1094,R1106,R1108] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) (AR-C260F/C260FP) [R514,R515,R516] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) (AR-C260F/C260FP) [R517,R588] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) (AR-C260F/C260FP) [R596,R597,R604] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) (AR-C260F/C260FP) [R658,R663] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) (AR-C260F/C260FP) [R664,R665,R666] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R404] 抵抗 |
| 88 | VRS-CZ1JD471J | AA | DD | | C | Resistor(1/16W 470Ω ±5%) [R797] 抵抗 |
| | VRS-CZ1JD471J | AA | DD | | C | Resistor(1/16W 470Ω ±5%) [R798,R799] 抵抗 |
| 89 | VRS-CZ1JD472J | AA | DD | | C | Resistor(1/16W 4.7KΩ ±5%) [R788] 抵抗 |
| 90 | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R1084] 抵抗 |
| 91 | VRS-CZ1JD680J | AA | DD | | C | Resistor(1/16W 68JΩ ±5%) [R133,R140,R146,R153,R224] 抵抗 |
| | VRS-CZ1JD680J | AA | DD | | C | Resistor(1/16W 68JΩ ±5%) [R231,R254,R261] 抵抗 |
| 92 | VS2SB1198K/-1 | AC | DJ | | B | Transistor(2SB1198K) (AR-C260F/C260FP)[Q35] トランジスタ |
| 93 | VS2SC2412K/-1 | AB | DD | | B | Transistor(2SC2412K) (AR-C260F/C260FP)[Q36] トランジスタ |
| 94 | VS2SJ243///-1 | AD | DJ | | B | Transistor(2SJ243) [FET2] トランジスタ |
| | VS2SJ243///-1 | AD | DJ | | B | Transistor(2SJ243) (AR-C260F/C260FP)[FET4] トランジスタ |
| 95 | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q6,Q8,Q9,Q10] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q11,Q12,Q13,Q14,Q15,Q16] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q18,Q20,Q22,Q23,Q24,Q25] トランジスタ |

53 ICU 基板 (ICU PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 95 | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q26,Q27,Q28,Q29,Q30,Q32] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q33,Q34,Q100,Q103,Q104] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q105,Q106,Q107,Q108,Q109] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) [Q110] トランジスタ |
| | VSDTC114YUA-1 | AB | DJ | | B | Transistor(DTC114YUA) (AR-C260F/C260FP)[Q7] トランジスタ |
| 96 | QCNCM0923FC10 | AE | DS | | C | Connector(10Pin) (Except Japan) [CN19] コネクタ |
| | (Unit) | | | | | (Unit) |
| 901 | CPWBN1549DS54 | CU | VW | N | E | ICU PWB UNIT (AR-C260S/C260M)[Japan] ICU 基板 |
| | CPWBN1549DS55 | CV | VZ | N | E | ICU PWB UNIT (AR-C260F/C260FP)[Japan] ICU 基板 |
| | CPWBN1549DS57 | CU | VW | N | E | ICU PWB UNIT (AR-C260/C260M)[Except Japan] ICU 基板 |
| | | | | | | |
| | | | | | | |
| | | | | | | |

54 操作キー基板 (OPE KEY PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | QCNCM1171FCZZ | AE | DS | | C | Connector(B6B-PH-SM3-TB) [CN2] コネクタ |
| 3 | QSW-P0005QSZZ | AC | DJ | | B | Tact switch(B3F-6102) [SW1,SW2,SW3,SW4,SW5] タクトスイッチ |
| | QSW-P0005QSZZ | AC | DJ | | B | Tact switch(B3F-6102) [SW6,SW7,SW9,SW10,SW11] タクトスイッチ |
| | QSW-P0005QSZZ | AC | DJ | | B | Tact switch(B3F-6102) [SW12,SW17,SW18,SW19,SW20] タクトスイッチ |
| | QSW-P0005QSZZ | AC | DJ | | B | Tact switch(B3F-6102) [SW21] タクトスイッチ |
| 4 | QSW-P0469FCZZ | AD | DS | | B | Push switch(SKHWAC) [SW8,SW13,SW14,SW15,SW16] プッシュスイッチ |
| 5 | RALMB1002LCZZ | AE | DS | | B | Alarm(PKM13EPY-4000-TF01) [BZ1] アラーム |
| 6 | VCEAJU1CW476M | AB | DD | | C | Capacitor(16WV 47μF) [C1] コンデンサ |
| 7 | VCKYPU1EB223Z | AB | DD | | C | Capacitor(25WV 0.022μF) [C2] コンデンサ |
| 8 | VHDDSS133/-1 | AA | DD | | B | Diode(1SS133) [D1,D2] ダイオード |
| 9 | VHP1LHLE-002A | AC | DJ | | B | LED(Green)(LTL-1LHLE-002A) [LED1,LED2,LED3] LEDミッドリ |
| | VHP1LHLE-002A | AC | DJ | | B | LED(Green)(LTL-1LHLE-002A) [LED4,LED5] LEDミッドリ |
| | VHP1LHLE-002A | AC | DJ | | B | LED(Green)(LTL-1LHLE-002A) [LED6,LED7,LED8] LEDミッドリ |
| 10 | VHPLT9400E/-1 | AK | EB | | B | LED(LT9400E) [LED9,LED10] LED |
| 11 | VRD-HT2EY102J | AA | DD | | C | Resistor(1/4W 1.0KΩ ±5%) [R17] 抵抗 |
| 12 | VRD-HT2EY111J | AA | DD | | C | Resistor(1/4W 110Ω ±5%) [R3] 抵抗 |
| 13 | VRD-HT2EY151J | AA | DD | | C | Resistor(1/4W 150Ω ±5%) [R4,R6,R7,R8,R9] 抵抗 |
| | VRD-HT2EY151J | AA | DD | | C | Resistor(1/4W 150Ω ±5%) [R10,R11,R12,R13,R14] 抵抗 |
| | VRD-HT2EY151J | AA | DD | | C | Resistor(1/4W 150Ω ±5%) [R15,R16] 抵抗 |
| 14 | VRD-HT2EY302J | AA | DD | | C | Resistor(1/4W 3.0KΩ ±5%) [R5] 抵抗 |
| 15 | VRD-HT2EY473J | AA | DD | | C | Resistor(1/4W 47KΩ ±5%) [R18,R19,R20,R21,R22] 抵抗 |
| 16 | VRD-HT2EY682J | AA | DD | | C | Resistor(1/4W 6.8KΩ ±5%) [R2] 抵抗 |
| 17 | VRD-HT2EY911J | AA | DD | | C | Resistor(1/4W 910Ω ±5%) [R1] 抵抗 |
| 18 | VS2SC1740SR-1 | AB | DD | | B | Transistor(2SC1740SR) [Q1] トランジスタ |
| | (Unit) | | | | | |
| 901 | CPWBF1525FCE1 | BD | GJ | N | E | OPE KEY PWB UNIT 操作キー基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

55 トライバ-基板 (DRIVER PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | QCNCM0672FCZZ | AB | DD | | C | Connector(2pin) [CN9] コネクタ |
| 2 | QCNCM0923FC12 | AE | DJ | | C | Connector(12pin) [CN3] コネクタ |
| 3 | QCNCM0923FC3D | AF | DS | | C | Connector(B34B-PHDSS)(34pin) [CN2] コネクタ |
| 4 | QCNCM0931FCZZ | AF | DS | | C | Connector(20pin) [CN8] コネクタ |
| 5 | QCNCM1069AC0H | AE | DJ | | C | Connector(8pin) [CN6] コネクタ |
| 6 | QCNCM1069AC1J | AD | DJ | | C | Connector(10pin) [CN5] コネクタ |
| 7 | QCNCM7014SC0F | AB | DD | | C | Connector(6pin) [CN1,CN4] コネクタ |
| 8 | QCNCW0864FCZZ | AG | DX | | C | Connector(12pin) [CN7] コネクタ |
| 9 | QFS-D1327QCZZ | AE | DS | | A | Fuse(1.25A 250V) [F1] ヒューズ |
| 10 | QFSHB0028FCZZ | AC | DJ | | C | Fuse holder(TP00351-31) [F1] ヒューズホルダ |
| 11 | RC-KZ1054CCN2 | AB | DD | | C | Capacitor(RPE132-906) [C7,C17,C23,C29,C32,C33] コンデンサ |
| 12 | RMPTW4103QCJJ | AB | DD | | B | Block resistor(10KΩ×4) [BR3] ブロック抵抗 |
| 13 | RMPTW4473QCJJ | AB | DD | | B | Resistor array(47kΩ×4 ±5%) [BR1,BR2] ティコタリ |
| 14 | VCEAGA1AW476M | AA | DD | | C | Capacitor(10WV 47μF) [C30] コンデンサ |
| 15 | VCEAGA1CW106M | AA | DD | | C | Capacitor(16WV 10μF) [C5,C6,C16,C22,C28,C44] コンデンサ |
| 16 | VCEAGU1VW108M | AE | DX | | C | Capacitor(35WV 1000μF) [C31] コンデンサ |
| 17 | VCEAZA1VW476M | AC | DD | | C | Capacitor(35WV 47μF) [C1,C2] コンデンサ |
| 18 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C8,C9,C10,C11,C12] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C13,C14,C15] コンデンサ |
| 19 | VCKYCZ1HB222K | AA | DD | | C | Capacitor(50WV 2200pF) [C18,C19,C24,C25,C34,C35] コンデンサ |
| 20 | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) [C20,C21,C26,C27,C36,C37] コンデンサ |
| 21 | VHDDSM1D1/-1 | AB | DJ | | B | Diode(DSM1D1) [D1,D3,D5,D8] ダイオード |
| 22 | VHDDSS133/-1 | AA | DD | | B | Diode(1SS133) [D2,D4,D6,D7,D9] ダイオード |
| 23 | VHDRA13++++-1 | AD | DJ | | B | Diode(RA13) [D10] ダイオード |
| 24 | VHISLA7024MT/- | AS | EQ | | B | IC(SLA7024MT) [IC4,IC5,IC6] IC |
| 25 | VHISLA7031M-1 | AQ | EQ | | B | IC(SLA7031M) [IC2] IC |
| 26 | VHIVHCT244T-1 | AK | DX | | B | IC(74VHCT244MTC) [IC1,IC3] IC |

55 ドライバ基板 (DRIVER PWB)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 27 | VRD-HT2EY242J | AA | DD | | C | Resistor(1/4W 2.4KΩ ±5%) [R1,R3,R6,R40] 抵抗 |
| 28 | VRD-HT2EY104J | AA | DD | | C | Resistor(1/4W 100KΩ ±5%) [R5] 抵抗 |
| 29 | VRD-HT2EY562J | AA | DD | | C | Resistor(1/4W 5.6KΩ ±5%) [R2,R4] 抵抗 |
| 30 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R7,R14,R23,R32] 抵抗 |
| 32 | VRS-CZ1JD242J | AA | DD | | C | Resistor(1/16W 2.4KΩ ±5%) [R16,R17,R25,R26,R34,R35] 抵抗 |
| 33 | VRS-CZ1JD271J | AA | DD | | C | Resistor(1/16W 270Ω ±5%) [R20,R29,R38] 抵抗 |
| 34 | VRS-CZ1JD473J | AA | DD | | C | Resistor(1/16W 47KΩ ±5%) [R12,R13,R21,R22,R30,R31] 抵抗 |
| 35 | VRS-HT3DA1R0J | AB | DD | | C | Resistor(1/16W 2W 1.0Ω ±5%) [R9,R10,R15,R18,R24] 抵抗 |
| 35 | VRS-HT3DA1R0J | AB | DD | | C | Resistor(2W 1.0Ω ±5%) [R27,R33,R36] 抵抗 |
| 38 | VRD-HT2EY473J | AA | DD | | C | Resistor(1/4W 47KΩ ±5%) [R39] 抵抗 |
| | (Unit) | | | | | |
| 901 | CPWBN1545FCE1 | BQ | LP | N | E | DRIVER PWB ドライバ基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

56 LVDS/INV 基板 (LVDS/INV PWB UNIT)

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|----------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | QCNCM0991FCZZ | AG | DX | | C | Connector(30FMZ-BT) [CN1] コネクター |
| 2 | QCNCM1172FCZZ | AL | EB | N | C | Connector(S02(8.0)B-BHS-L) [CN3] コネクター |
| 3 | QCNCW1164FCZZ | AE | DJ | N | C | Connector(04FM-1.0BT) [CN2] コネクター |
| 4 | QCNCW1165FCZZ | AG | DX | N | C | Connector(20FLS-SM1-TB) [CN4] コネクター |
| 5 | QFS-E1111QCZZ | AF | DS | | A | Fuse(217.200(200mA/250V)) [F1] ヒューズ |
| 6 | QFSHB0028FCZZ | AC | DJ | | C | Fuse holder(TP00351-31) ヒューズ 継ぎ |
| 7 | RCILF0068FCZZ | AF | DS | | C | Coil(C-15389) [L1] コイル |
| 8 | RTRNZ0511FCZZ | AQ | EQ | | B | Transformer(C-15099) [T1] トランス |
| 9 | VCIFYJU2JA103K | AC | DD | | C | Capacitor(630WV 0.010μF) [C3] コンデンサー |
| 10 | VCKYCZ1EF223Z | AA | DD | | C | Capacitor(0.022μF/50V(1005)) [C1,C2] コンデンサー |
| 11 | VCKYCZ1HB471K | AA | DD | | C | Capacitor(50WV 470pF) [C6] コンデンサー |
| 12 | VCKYPU3SD150K | AC | DD | | C | Capacitor(15pF/3KV)(CC45SL3FD150KYAN) [C4] コンデンサー |
| 13 | VHH103AT-2/-1 | AG | DS | | B | Thermistor(103AT-2) [TH1] サーミスタ |
| 15 | VRD-RC2EY103J | AA | DD | | C | Resistor(1/4W 10KΩ ±5%) [R9,R10] 抵抗 |
| 16 | VRS-CZ1JD101J | AA | DD | | C | Resistor(1/16W 100Ω ±5%) [R1-R8] 抵抗 |
| 17 | VS2SD1857A+-1 | AB | DJ | | B | Transistor(2SD1857ATV2) [Q1,Q2] トランジスタ |
| | (Unit) | | | | | |
| 901 | CPWBN1560FCE1 | BM | HR | N | E | LVDS/INV PWB UNIT LVDS/INV 基板ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

57 FAX 電源基板ユニット (FAX AC power supply unit)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 1 | 0FT23040224// | AD | DJ | | C | Angle(TC-92 30X36X1T) [1] 金具 |
| 2 | 0FT23042251// | AP | EQ | | C | Fin(AL1 30X30) [2] フィン |
| 3 | 0FT23075095// | AP | EQ | | C | Connector(B6P-VH) [CN1] コネクター |
| 4 | 0FT23194310// | AU | EZ | | B | Thermistor(NTH11D8R0LA) [TH1] サーミスタ |
| 5 | 0FT23314081// | AU | EZ | | B | IC(UPC393C) [Z6] IC |
| 7 | 0FT23423816// | AC | DJ | | C | Screw(M3X8 S NP3 W・SW) [5] 小ワッシャ W セムスネジ |
| 8 | 0FT23432963// | AC | DJ | | C | Screw(M3X10 S NP3 W・SW) [6] 小ワッシャ W セムスネジ |
| 9 | 0FT23485706// | AK | DX | | C | Connector(B2B-PH-K-S) [CN4] コネクター |
| 10 | 0FT23559467// | AR | EQ | | B | Transistor(2SC3588 HFE=L:K) [Q11] トランジスタ |
| 11 | 0FT23562328// | AD | DJ | | C | Resistor(RSMF2SL 68KΩJ) [R2] 酸化金属被膜抵抗器 |
| 12 | 0FT23562379// | AD | DJ | | C | Resistor(RSMF12SL 1ΩJ) [R20] 酸化金属被膜抵抗器 |
| 13 | 0FT23562379// | AD | DJ | | C | Resistor(RSMF12SL 1ΩJ) [R83] 酸化金属被膜抵抗器 |
| 14 | 0FT23562549// | AD | DJ | | C | Resistor(RSMF12SL 330ΩJ) [R62] 酸化金属被膜抵抗器 |
| 15 | 0FT23562700// | AD | DJ | | C | Resistor(RSMF12SL 47KΩJ) [R13] 酸化金属被膜抵抗器 |
| 16 | 0FT23562700// | AD | DJ | | C | Resistor(RSMF12SL 47KΩJ) [R14] 酸化金属被膜抵抗器 |
| 17 | 0FT23562727// | AD | DJ | | C | Resistor(RSMF12SL 100KΩJ) [R54] 酸化金属被膜抵抗器 |
| 18 | 0FT23562816// | AC | DJ | | C | Resistor(RSMF1SL 2.2ΩJ) [R11] 酸化金属被膜抵抗器 |
| 19 | 0FT23562816// | AC | DJ | | C | Resistor(RSMF1SL 2.2ΩJ) [R12] 酸化金属被膜抵抗器 |
| 20 | 0FT23562859// | AD | DJ | | C | Resistor(RSMF1SL 10ΩJ) [R18] 酸化金属被膜抵抗器 |
| 21 | 0FT23563103// | AD | DJ | | C | Resistor(RSMF1SL 47KΩJ) [R4] 酸化金属被膜抵抗器 |
| 22 | 0FT23563103// | AD | DJ | | C | Resistor(RSMF1SL 47KΩJ) [R5] 酸化金属被膜抵抗器 |
| 23 | 0FT23563324// | AC | DJ | | C | Resistor(RSMF2SL 100ΩJ) [R10] 酸化金属被膜抵抗器 |
| 24 | 0FT23563324// | AC | DJ | | C | Resistor(RSMF2SL 100ΩJ) [R19] 酸化金属被膜抵抗器 |
| 25 | 0FT23598977// | AK | DX | | C | Connector(B3B-PH-K-S) [CN2] コネクター |
| 26 | 0FT23611329// | AK | DX | | C | Capacitor(MMC-104K400) [C6] フィルコンデンサ |
| 27 | 0FT23642925// | AK | DX | | B | Reactor(TG0113MADS SK) [L4] リアクトル |
| 28 | 0FT23644634// | AK | DX | | B | Variable resistor(EVM-4LGA00B13) [RV1] 可変抵抗器 |
| 29 | 0FT23665429// | AU | EZ | | B | IC(UPC78M24AHF) [Z2] IC |
| 30 | 0FT23671666// | AU | EZ | | B | IC(UPC78M12AHF) [Z1] IC |
| 31 | 0FT23697355// | AU | EZ | | B | Absorber(ERZV10D471) [NR1] サージアブソーバ |
| 32 | 0FT23736903// | AX | FG | | B | Rectifier(SF10SC4) [RC2] 整流器 |
| 33 | 0FT23462226// | AD | DJ | | C | Resistor(RK73K2ATD 470ΩJ) [R34] チップ抵抗器 |
| 34 | 0FT23462226// | AD | DJ | | C | Resistor(RK73K2ATD 470ΩJ) [R65] チップ抵抗器 |
| 35 | 0FT23462234// | AD | DJ | | C | Resistor(RK73K2ATD 1KΩJ) [R30] チップ抵抗器 |

57 FAX 電源基板ユニット (FAX AC power supply unit)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 36 | 0FT23462234// | AD | DJ | | C | Resistor(RK73K2ATD 1KΩJ) [R35] チップ 抵抗器 |
| 37 | 0FT23462234// | AD | DJ | | C | Resistor(RK73K2ATD 1KΩJ) [R41] チップ 抵抗器 |
| 38 | 0FT23462234// | AD | DJ | | C | Resistor(RK73K2ATD 1KΩJ) [R44] チップ 抵抗器 |
| 39 | 0FT23462250// | AD | DJ | | C | Resistor(RK73K2ATD 2.2KΩJ) [R38] チップ 抵抗器 |
| 40 | 0FT23462250// | AD | DJ | | C | Resistor(RK73K2ATD 2.2KΩJ) [R39] チップ 抵抗器 |
| 41 | 0FT23462250// | AD | DJ | | C | Resistor(RK73K2ATD 2.2KΩJ) [R52] チップ 抵抗器 |
| 42 | 0FT23462250// | AD | DJ | | C | Resistor(RK73K2ATD 2.2KΩJ) [R66] チップ 抵抗器 |
| 43 | 0FT23462250// | AD | DJ | | C | Resistor(RK73K2ATD 2.2KΩJ) [R68] チップ 抵抗器 |
| 44 | 0FT23462269// | AD | DJ | | C | Resistor(RK73K2ATD 10KΩJ) [R8] チップ 抵抗器 |
| 45 | 0FT23462269// | AD | DJ | | C | Resistor(RK73K2ATD 10KΩJ) [R17] チップ 抵抗器 |
| 46 | 0FT23462269// | AD | DJ | | C | Resistor(RK73K2ATD 10KΩJ) [R48] チップ 抵抗器 |
| 47 | 0FT23462293// | AD | DJ | | C | Resistor(RK73K2ATD 560ΩJ) [R31] チップ 抵抗器 |
| 48 | 0FT23463362// | AD | DJ | | C | Resistor(RK73K2ATD 180ΩJ) [R42] チップ 抵抗器 |
| 49 | 0FT23536106// | AD | DJ | | C | Resistor(RK73K2ATD 1.5KΩJ) [RX2] チップ 抵抗器 |
| 50 | 0FT23536106// | AD | DJ | | C | Resistor(RK73K2ATD 1.5KΩJ) [R22] チップ 抵抗器 |
| 51 | 0FT23536106// | AD | DJ | | C | Resistor(RK73K2ATD 1.5KΩJ) [R59] チップ 抵抗器 |
| 52 | 0FT23538850// | AD | DJ | | C | Resistor(RK73K2ATD 4.7KΩJ) [R46] チップ 抵抗器 |
| 53 | 0FT23538850// | AD | DJ | | C | Resistor(RK73K2ATD 4.7KΩJ) [R67] チップ 抵抗器 |
| 54 | 0FT23538850// | AD | DJ | | C | Resistor(RK73K2ATD 100ΩJ) [R69] チップ 抵抗器 |
| 55 | 0FT23538915// | AD | DJ | | C | Resistor(RK73K2ATD 5.6KΩJ) [R71] チップ 抵抗器 |
| 56 | 0FT23538923// | AD | DJ | | C | Resistor(RK73K2ATD 3.9KΩJ) [R37] チップ 抵抗器 |
| 57 | 0FT23538974// | AD | DJ | | C | Resistor(RK73K2ATD 2.7KΩJ) [R7] チップ 抵抗器 |
| 58 | 0FT23538982// | AD | DJ | | C | Resistor(RK73K2ATD 47ΩJ) [R23] チップ 抵抗器 |
| 59 | 0FT23541509// | AK | DX | | B | Zener diode(RD8.2M-B2) [D11] チップ ユニーク イート |
| 60 | 0FT23546047// | AD | DJ | | C | Resistor(RK73K2ATD 100KΩJ) [R57] チップ 抵抗器 |
| 61 | 0FT23546047// | AD | DJ | | C | Resistor(RK73K2ATD 100KΩJ) [R63] チップ 抵抗器 |
| 62 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C10] チップ セラミックコンデンサ |
| 63 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C13] チップ セラミックコンデンサ |
| 64 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C14] チップ セラミックコンデンサ |
| 65 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C39] チップ セラミックコンデンサ |
| 66 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C50] チップ セラミックコンデンサ |
| 67 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C54] チップ セラミックコンデンサ |
| 68 | 0FT23549119// | AF | DS | | C | Capacitor(GRM40R103K25PT) [C55] チップ セラミックコンデンサ |
| 69 | 0FT23551148// | AK | DX | | B | Zener diode(RD12M-B2-T1) [D5] チップ ユニーク イート |
| 70 | 0FT23551377// | AK | DX | | B | Diode(SFPM-52VL) [D62] チップ ダイオード |
| 71 | 0FT23557111// | AD | DJ | | C | Resistor(RK73K2ATD 220ΩJ) [R21] チップ 抵抗器 |
| 72 | 0FT23565505// | AD | DJ | | C | Resistor(RK73K2ATD 220KΩJ) [R56] チップ 抵抗器 |
| 73 | 0FT23578194// | AD | DJ | | C | Resistor(RK73K2ATD 22ΩJ) [R43] チップ 抵抗器 |
| 74 | 0FT23578194// | AD | DJ | | C | Resistor(RK73K2ATD 22ΩJ) [R51] チップ 抵抗器 |
| 75 | 0FT23581330// | AD | DJ | | C | Capacitor(GRM40R104K25PT) [CX1] チップ セラミックコンデンサ |
| 76 | 0FT23581330// | AD | DJ | | C | Capacitor(GRM40R104K25PT) [CX2] チップ セラミックコンデンサ |
| 77 | 0FT23581330// | AD | DJ | | C | Capacitor(GRM40R104K25PT) [C36] チップ セラミックコンデンサ |
| 78 | 0FT23583309// | AG | DX | | B | Zener diode(RD5.6M-B2-T1) [D42] チップ ユニーク イート |
| 79 | 0FT23598470// | AG | DX | | B | Zener diode(RD10M-B2-T1) [D46] チップ ユニーク イート |
| 80 | 0FT23624293// | AD | DJ | | C | Resistor(RK73K2ATD 27KΩJ) [R16] チップ 抵抗器 |
| 81 | 0FT23625591// | AD | DJ | | C | Resistor(RK73K2ATD 1.8KΩJ) [R36] チップ 抵抗器 |
| 82 | 0FT23625591// | AD | DJ | | C | Resistor(RK73K2ATD 1.8KΩJ) [R40] チップ 抵抗器 |
| 83 | 0FT23663914// | AD | DJ | | C | Resistor(RK73K2ATD 5.1KΩJ) [R33] チップ 抵抗器 |
| 84 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D6] チップ ダイオード |
| 85 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D10] チップ ダイオード |
| 86 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D12] チップ ダイオード |
| 87 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D44] チップ ダイオード |
| 88 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D45] チップ ダイオード |
| 89 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D47] チップ ダイオード |
| 90 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D54] チップ ダイオード |
| 91 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D55] チップ ダイオード |
| 92 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D61] チップ ダイオード |
| 93 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D63] チップ ダイオード |
| 94 | 0FT33122675// | AF | DS | | B | Diode(KDS184RTK) [D66] チップ ダイオード |
| 95 | 0FT33189184// | AD | DJ | | C | Capacitor(GRM40-034R104K50PT) [C24] チップ セラミックコンデンサ |
| 96 | 0FT23095657// | AF | DS | | B | Transister(2SC1815-Y:GR TPE2) [Q2] トランジスタ |
| 97 | 0FT23095657// | AF | DS | | B | Transister(2SC1815-Y:GR TPE2) [Q7] トランジスタ |
| 98 | 0FT23095657// | AF | DS | | B | Transister(2SC1815-Y:GR TPE2) [Q9] トランジスタ |
| 99 | 0FT23095657// | AF | DS | | B | Transister(2SC1815-Y:GR TPE2) [Q12] トランジスタ |
| 100 | 0FT23124819// | AK | DX | | C | Capacitor(KME25VB-220 TC-04) [C27] 電解コンデンサ |
| 101 | 0FT23124827// | AF | DS | | C | Capacitor(KME25VB-47 TC-04) [C29] 電解コンデンサ |
| 102 | 0FT23204782// | AP | EQ | | C | Capacitor(KME35VB-220 TC-04) [C23] 電解コンデンサ |
| 103 | 0FT23204790// | AP | EQ | | C | Capacitor(KME35VB-100 TC-04) [C17] 電解コンデンサ |
| 104 | 0FT23204790// | AP | EQ | | C | Capacitor(KME35VB-100 TC-04) [C25] 電解コンデンサ |
| 105 | 0FT23241823// | AP | EQ | | B | Diode(EG01ZV0) [D36] ダイオード |
| 106 | 0FT23259382// | AP | EQ | | C | Capacitor(KME10VB-470 TC-04) [C37] 電解コンデンサ |
| 107 | 0FT23259420// | AP | EQ | | C | Capacitor(KME35VB-470 TC-04) [C20] 電解コンデンサ |
| 108 | 0FT23259447// | AK | DX | | C | Capacitor(KME50VB-1 TC-04) [C34] 電解コンデンサ |
| 109 | 0FT23259498// | AK | DX | | C | Capacitor(KME50VB-10 TC-04) [C15] 電解コンデンサ |
| 110 | 0FT23259498// | AK | DX | | C | Capacitor(KME50VB-10 TC-04) [C35] 電解コンデンサ |
| 111 | 0FT23259498// | AK | DX | | C | Capacitor(KME50VB-10 TC-04) [C56] 電解コンデンサ |
| 112 | 0FT23287629// | AK | DX | | B | Transister(2SA1015-Y TPE2) [Q6] トランジスタ |
| 113 | 0FT23287637// | AP | EQ | | B | Transister(2SA1020-O:Y TPE6) [Q4] トランジスタ |
| 114 | 0FT23287696// | AP | EQ | | B | Transister(2SC3225 TPE6) [Q3] トランジスタ |
| 115 | 0FT23287823// | AK | DX | | C | Capacitor(KME50VB-22 TC-04) [C21] 電解コンデンサ |

57 FAX 電源基板ユニット (FAX AC power supply unit)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 116 | 0FT23319431// | AF | DS | | B | Diode(1SS119-14 TD) [D64] ダイオード |
| 117 | 0FT23319431// | AF | DS | | B | Diode(1SS119-14 TD) [D65] ダイオード |
| 118 | 0FT23326101// | AU | EZ | | C | Capacitor(KME200VB-22 TC-04) [C48] 電解コンデンサ |
| 119 | 0FT23329089// | AK | DX | | C | Capacitor(KME50VB-47 TC-04) [C18] 電解コンデンサ |
| 120 | 0FT23329089// | AK | DX | | C | Capacitor(KME50VB-47 TC-04) [C42] 電解コンデンサ |
| 121 | 0FT23379450// | AU | EZ | | B | IC(AN1431T-TA) [Z7] IC |
| 122 | 0FT23379450// | AU | EZ | | B | IC(AN1431T-TA) [Z8] IC |
| 123 | 0FT23394395// | AU | EZ | | C | Capacitor(KME10VB-3300 TC-03) [C32] 電解コンデンサ |
| 124 | 0FT23414892// | AF | DS | | C | Resistor(RDF14 TS 820ΩJ) [R9] カーボン抵抗器 |
| 125 | 0FT23415341// | AF | DS | | C | Resistor(RDMF14 TS 22ΩJ) [R60] カーボン抵抗器 |
| 126 | 0FT23415430// | AF | DS | | C | Resistor(RDMF14 TS 100ΩJ) [R82] カーボン抵抗器 |
| 127 | 0FT23415570// | AF | DS | | C | Resistor(RDMF14 TS 1KΩJ) [RX1] カーボン抵抗器 |
| 128 | 0FT23415570// | AF | DS | | C | Resistor(RDMF14 TS 1KΩJ) [RX5] カーボン抵抗器 |
| 129 | 0FT23415570// | AF | DS | | C | Resistor(RDMF14 TS 1KΩJ) [RX6] カーボン抵抗器 |
| 130 | 0FT23415600// | AF | DS | | C | Resistor(RDMF14 TS 1.8KΩJ) [R89] カーボン抵抗器 |
| 131 | 0FT23415643// | AF | DS | | C | Resistor(RDMF14 TS 3.9KΩJ) [R58] カーボン抵抗器 |
| 132 | 0FT23415651// | AF | DS | | C | Resistor(RDMF14 TS 4.7KΩJ) [R49] カーボン抵抗器 |
| 133 | 0FT23415716// | AF | DS | | C | Resistor(RDMF14 TS 10KΩJ) [R53] カーボン抵抗器 |
| 134 | 0FT23415740// | AF | DS | | C | Resistor(RDMF14 TS 15KΩJ) [R45] カーボン抵抗器 |
| 135 | 0FT23415899// | AF | DS | | C | Resistor(RDMF14 TS 100KΩJ) [R55] カーボン抵抗器 |
| 136 | 0FT23429199// | AK | DX | | B | Diode(AK04V0) [D14] ダイオード |
| 137 | 0FT23484661// | AD | DJ | | C | Resistor(RSMF12TS 0.22ΩJ) [R84] 酸化金属被膜抵抗器 |
| 138 | 0FT23486796// | AK | DX | | C | Capacitor(DE0905-979R471K2K) [C11] セラミックコンデンサ |
| 139 | 0FT23486850// | AK | DX | | C | Capacitor(ECQ-B1H473KF4) [C12] フィルムコンデンサ |
| 140 | 0FT23486850// | AK | DX | | C | Capacitor(ECQ-B1H473KF4) [C16] フィルムコンデンサ |
| 141 | 0FT23543641// | AK | DX | | C | Fuse holder(EYF-52BCZ) [F1] フューズホルダー |
| 142 | 0FT23605507// | AK | DX | | B | Diode(1GU42 TPA3) [D7] ダイオード |
| 143 | 0FT23605507// | AK | DX | | B | Diode(1GU42 TPA3) [D9] ダイオード |
| 144 | 0FT23605507// | AK | DX | | B | Diode(1GU42 TPA3) [D13] ダイオード |
| 145 | 0FT23605507// | AK | DX | | B | Diode(1GU42 TPA3) [D43] ダイオード |
| 146 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D1] ダイオード |
| 147 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D3] ダイオード |
| 148 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D8] ダイオード |
| 149 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D20] ダイオード |
| 150 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D21] ダイオード |
| 151 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D22] ダイオード |
| 152 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D23] ダイオード |
| 153 | 0FT23610810// | AK | DX | | B | Diode(S5688GTPA3) [D48] ダイオード |
| 154 | 0FT23624285// | AK | DX | | B | Diode(EG01CV0) [D52] ダイオード |
| 155 | 0FT23690482// | AD | DJ | | C | Resistor(RSMF12TS 10ΩJ) [R32] 酸化金属被膜抵抗器 |
| 156 | 0FT23752267// | AD | DJ | | C | Resistor(RSMF12TS 2.2ΩJ) [R50] 酸化金属被膜抵抗器 |
| 157 | 0FT23752267// | AD | DJ | | C | Resistor(RSMF12TS 2.2ΩJ) [R86] 酸化金属被膜抵抗器 |
| 158 | 0FT33005385// | AD | DJ | | C | Resistor(RSMF12TS 4.7KΩJ) [R87] 酸化金属被膜抵抗器 |
| 159 | 0FT33036442// | AD | DJ | | C | Resistor(RSMF12TS 180ΩJ) [R61] 酸化金属被膜抵抗器 |
| 160 | 0FT33055277// | AK | DX | | C | Terminal(TP00448-41) [4] 端子 |
| 161 | 0FT33186711// | AR | EQ | | B | Transister(2SA1625-T HFE=M:L) [Q8] トランジスタ |
| 162 | 0FT33213786// | AK | DX | | C | Capacitor(DE1007-486E222M-KH) [C2] セラミックコンデンサ |
| 163 | 0FT33213786// | AK | DX | | C | Capacitor(DE1007-486E222M-KH) [C3] セラミックコンデンサ |
| 164 | 0FT33295049// | AK | DX | | C | Capacitor(DE0605-979SL470J2K) [C7] セラミックコンデンサ |
| 165 | 0FT33388799// | AP | EQ | | C | Capacitor(DE1207-486E332M-KH) [C8] セラミックコンデンサ |
| 166 | 0FT33552203// | AD | DJ | | C | Resistor(RSPF12TS 470KΩJ) [R1] 電力形被膜抵抗器 |
| 167 | 0FT33570120// | AD | DJ | | C | Resistor(RSPF12TS 150KΩJ) [R90] 電力形被膜抵抗器 |
| 168 | 0FT33008015// | AW | FG | | B | Rectifier(D2SB60) [RC1] 整流器 |
| 169 | 0FT33035349// | AK | DX | | B | Diode(RL2Z LF-A1) [D38] ダイオード |
| 170 | 0FT33085427// | AU | EZ | | B | Transister(2SA1400 HFE=K) [Q10] トランジスタ |
| 171 | 0FT33146922// | AK | DX | | A | Fuse(51S040L AC125V 4A) [F1] ガラス管フューズ |
| 172 | 0FT33173377// | BA | FX | | B | Reactle(LF-4D-E822) [L1] リクトル |
| 173 | 0FT33197209// | BA | FX | | B | Photocoupler(TLP747J(D4) 0884) [PC2] フォトカプラー |
| 174 | 0FT33199031// | AW | FG | | B | Transister(2SC4130-O.Y) [Q1] トランジスタ |
| 175 | 0FT33213581// | AP | EQ | | C | Fin(ST-S 20G PT1 15X35X10) [9] フィン |
| 176 | 0FT33262132// | AP | EQ | | B | Photocoupler(PC123FY2) [PC1] フォトカプラー |
| 177 | 0FT33262132// | AP | EQ | | B | Photocoupler(PC123FY2) [PC3] フォトカプラー |
| 178 | 0FT33293976// | AF | DS | | C | Capacitor(DD104-63CH470J50) [C38] セラミックコンデンサ |
| 179 | 0FT33331673// | AZ | FQ | | B | Regurator(UPC29M33HF) [Z4] IC レギュレータ |
| 180 | 0FT33441622// | AL | EB | | C | Capacitor(ECQU2A104ML P=15.0MM) [C4] フィルムコンデンサ |
| 181 | 0FT33441630// | AP | EQ | | C | Capacitor(ECQU2A224ML P=15.0MM) [C1] フィルムコンデンサ |
| 182 | 0FT33478232// | AZ | FQ | | C | Capacitor(HU4 2D 331MRXS3SS DIA22X30L) [C5] 電解コンデンサ |
| 183 | 0FT33509685// | AP | EQ | | C | Connector(B04B-XASK-1-A) [CN3] コネクタ |
| 184 | 0FT33529090// | AP | EQ | | C | Terminal(85163 #250) [L] ファストン端子 |
| 185 | 0FT33529090// | AP | EQ | | C | Terminal(85163 #250) [L1F] ファストン端子 |
| 186 | 0FT33529090// | AP | EQ | | C | Terminal(85163 #250) [N] ファストン端子 |
| 187 | 0FT33529090// | AP | EQ | | C | Terminal(85163 #250) [N1F] ファストン端子 |
| 188 | 0FT33568266// | BA | FX | | B | Relay(SDT-S-112LMR) [RL3] リレー |
| 189 | 0FT33570163// | AF | DS | | C | Resistor(RSPF1B 150KΩJ) [R24] 電力形被膜抵抗器 |
| 190 | 0FT33570163// | AF | DS | | C | Resistor(RSPF1B 150KΩJ) [R25] 電力形被膜抵抗器 |
| 191 | 0FT33603762// | BB | GD | | B | IC(PQ12RF1) [Z3] IC |
| 192 | 0FT33603789// | BF | GN | | B | Transformer(CXM41100-505) [T1] 変圧器 |
| 193 | 0FT33638361// | BC | GJ | | B | Relay(G2R-1A-E-TV8-ASI DC12V) [RL1] リレー |
| 194 | 0FT33638361// | BC | GJ | | B | Relay(G2R-1A-E-TV8-ASI DC12V) [RL2] リレー |
| 195 | 0FT35863281// | BF | GN | | B | Transformer(EXT43420-635C) [T2] 変圧器 |

57 FAX 電源基板ユニット (FAX AC power supply unit)[AR-C260F/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| | (Unit) | | | | | |
| 901 | RDENC0004FCZZ | BV | RB | | E | FAX AC power supply unit FAX AC 電源ユニット |
| | | | | | | |
| | | | | | | |
| | | | | | | |

58 PRTC 基板 (PRTC PWB)[AR-C260M/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 1 | PCAPH0010GCZZ | AD | DJ | | C | Cap(JM-2W-96) [JP1,JP3,JP7] キャップ |
| 2 | PCÖVP1468FCZZ | AD | DJ | | D | FAX battery cover [BT1] FAX テンチカバー |
| 3 | PRDAR0057FCZ1 | AF | DS | N | C | Heat sink(C16UG16-30) [IC12] 熱伝導パッド |
| 4 | PRDAF0089FCZZ | AU | EZ | | C | Heat Sink(MI-MBA25101-23W/2.54BU) [IC26] 熱伝導パッド |
| 5 | PSHEZ4684FCZZ | AC | DJ | | C | Sheet(2067B) [IC12] ケールシート |
| 6 | QCNCM1182FCZZ | AM | EG | | C | Connector (Board to Board) (100pin PCI CN)(100P9.2-JXKS-GB) [CN12,CN8] コネクタ |
| 7 | QCNCM1183FCZZ | AM | EG | | C | Connector (Board to Board) (100pin PCI CN)(100P15.2-JXKS-GB) [CN9] コネクタ |
| 8 | QCNCP0340QCZZ | AC | DJ | | C | Connector(3pin) [CN14] コネクタ |
| 9 | QSÖCN0002ESZZ | AH | DX | | C | Socket(RBE42-36K11) [CN15] ソケット |
| 10 | QCNCW1190FCZZ | AN | EG | | C | Connector (Board to Board)(TX24-100R-LT-H1) [CN1] コネクタ |
| 11 | QPIN-0003GCZZ | AC | DJ | | C | Pin(T3B-SQ) [JP1,JP3,JP7] ピン |
| 12 | QSÖCN0005ESZZ | AE | DS | | C | Socket(UBR234K2200) [CN13] ソケット |
| 13 | QSÖCZ0001QSZZ | AL | EB | | C | Socket(DMM168-FLAA2-3A133) [CN10,CN11] ソケット |
| 14 | QSÖCZ0002QSZZ | AD | DJ | | C | IC socket [IC20] IC ソケット |
| 15 | QSÖCZ0073FCNA | AL | EB | | C | DIMM Socket(72pin Flash DIMM)(DMM2-SD72A-113) [CN3,CN4,CN6,CN7] DIMM ソケット |
| 16 | RCILZ0353AFZZ | AH | DX | | C | Chock coil(PLP3216S121SL2)(Typ120Ω) [L8] コモンモード チョークコイル |
| 17 | RCÖRF1057ACZZ | AB | DJ | | C | Ferrite beads(BLM21P221SG) [L6,L9,L11] フェライトビーズ |
| 18 | RCRSP0080FCZZ | AF | DS | | B | Crystal(16.345MHz)(AT-51,16.345MHz) [Y3] クリスタル |
| 20 | RCRSP6676RCZZ | AG | DX | | B | Crystal(32.768KHz) [Y1] クリスタル |
| 21 | RFILN0048FCZZ | AC | DJ | | C | Chip Inductor(BLM10B121SBPTM) [L3,L4] インダクター |
| 22 | RH-iX1013ACZZ | BK | HC | | B | SDRAM (256Mb)(W982516BH-75) [IC27,IC32,IC39,IC46] SDRAM (256Mb) |
| 23 | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR22,BR23,BR24,BR25,BR26] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR27,BR28,BR29,BR30,BR31] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR32,BR33,BR34,BR35,BR36] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR40,BR41,BR42,BR43,BR47] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR48,BR50,BR53,BR55,BR58] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR60,BR80,BR83,BR84,BR85] ブロック抵抗 |
| | RMPTR4100ACZZ | AB | DD | | B | Block resistor(10Ω×4) [BR86,BR87,BR88,BR89,BR90] ブロック抵抗 |
| 24 | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR92,BR93,BR94,BR95,BR96,BR97] ブロック抵抗 |
| | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR1,BR2,BR3,BR4,BR5] ブロック抵抗 |
| | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR6,BR7,BR8,BR9,BR10] ブロック抵抗 |
| | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR11,BR12,BR21,BR49,BR51] ブロック抵抗 |
| | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR54,BR57,BR61,BR62,BR64] ブロック抵抗 |
| | RMPTR4103ACZZ | AB | DD | | B | Block resistor(10KΩ×4) [BR65,BR66,BR68,BR69,BR70] ブロック抵抗 |
| 25 | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR71,BR73,BR78,BR81,BR82,BR91] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR13, BR14,BR15,BR16,BR17] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR18,BR19,BR20,BR37,BR38] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR39,BR44,BR45,BR46,BR52] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR56,BR59,BR63,BR67,BR72] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR74,BR75,BR76,BR77,BR79] ブロック抵抗 |
| | RMPTR4330ACZZ | AB | DD | | B | Block resistor(33Ω×4) [BR98,BR99,BR100,BR101,BR102] ブロック抵抗 |
| 26 | UBATL2033SCZZ | AK | EB | | B | Block resistor(33Ω×4) [BR103,BR104,BR105,BR106] ブロック抵抗 |
| | UBATL2033SCZZ | AK | EB | | B | Battery(CR2032-H03) [BT1] バッテリー |
| | VCAAPF0JJ107M | AF | DS | | C | Capacitor(PXA 100μF/6.3V)(PXA6.3VC100MF60) [C53,C106,C327] コンデンサー |
| | VCCCCZ1HH101J | AA | DD | | C | Capacitor(50WV 100pF) [C293,C294,C295,C296,C297] コンデンサー |
| 28 | VCCCCZ1HH101J | AA | DD | | C | Capacitor(50WV 100pF) [C298,C299,C300,C301,C302] コンデンサー |
| | VCCCCZ1HH101J | AA | DD | | C | Capacitor(50WV 100pF) [C303,C304,C305,C306,C307] コンデンサー |
| | VCCCCZ1HH101J | AA | DD | | C | Capacitor(50WV 100pF) [C308,C309] コンデンサー |
| 29 | VCCCCZ1HH220J | AA | DD | | C | Capacitor(50WV 22pF) [C153,C176,C286,C290,C329,C330] コンデンサー |
| 30 | VCEAPH1VC225M | AC | DD | | C | Capacitor(2.2μF/35V) [C146,C147,C148,C149,C193] コンデンサー |
| | VCEAPH1VC225M | AC | DD | | C | Capacitor(2.2μF/35V) [C199,C256,C257] コンデンサー |
| 31 | VCEAPS1AC227M | AD | DJ | | C | Capacitor(220μF/10V (MVY)) [C2,C44,C45,C276,C277] コンデンサー |
| 32 | VCEAPS1CC106M | AC | DD | | C | Capacitor(16WV 10μF) [C21,C38,C271,C272] コンデンサー |
| 33 | VCEAPS1CC226M | AC | DJ | | C | Capacitor(22μF/16V) [C57,C102,C279,C314] コンデンサー |
| 34 | VCEAPS1CC476M | AC | DJ | | C | Capacitor(47μF/16V) [C31,C39,C52,C118,C139] コンデンサー |
| | VCEAPS1CC476M | AC | DJ | | C | Capacitor(47μF/16V) [C194,C260] コンデンサー |
| 35 | VCEAPZ1EW107M | AD | DJ | | C | Capacitor(25WV 100μF) [C20] コンデンサー |
| 37 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C3,C4,C5,C6,C10] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C12,C23,C24,C25,C26] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C28,C29,C30,C32,C33] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C35,C36,C37,C40,C41] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C42,C46,C51,C54,C55] コンデンサー |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C56,C58,C59,C61,C62] コンデンサー |

58 PRTC 基板 (PRTC PWB)[AR-C260M/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|---|
| | | Ex. | Ja. | | | |
| 37 | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C67,C68,C70,C71,C72] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C74,C75,C77,C78,C79] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C80,C81,C88,C89,C91] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C92,C93,C94,C95,C96] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C97,C101,C103,C107,C108] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C110,C112,C113,C114,C117] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C119,C120,C121,C122,C127] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C128,C129,C130,C131,C132] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C134,C136,C138,C140,C143] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C144,C145,C155,C160,C161] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C166,C167,C169,C174,C175] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C177,C180,C182,C185,C189] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C190,C191,C192,C196,C200] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C201,C203,C204,C205,C217] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C218,C219,C220,C223,C224] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C225,C226,C230,C231,C232] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C234,C235,C236,C238,C240] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C241,C242,C243,C245,C247] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C248,C250,C251,C252,C253] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C254,C255,C258,C259,C261] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C263,C264,C265,C266,C267] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C268,C274,C278,C280,C281] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C282,C283,C284,C285,C287] コンデンサ |
| | VCKYCZ1CF104Z | AB | DD | | C | Capacitor(16WV 0.1μF) [C292,C315,C316,C322,C323] コンデンサ |
| 38 | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C69,C84,C87,C90,C111] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C116,C123,C142,C163,C164] コンデンサ |
| | VCKYCZ1HB102K | AA | DD | | C | Capacitor(50WV 1000pF) [C195,C202,C273,C331] コンデンサ |
| 39 | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C9,C11,C47,C48,C49] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C50,C60,C63,C64,C65] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C66,C73,C76,C82,C83] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C86,C98,C99,C100,C104] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C105,C109,C115,C124,C133] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C135,C137,C162,C165,C181] コンデンサ |
| | VCKYCZ1HF103Z | AA | DD | | C | Capacitor(0.01μF/50V) [C221,C229,C237,C239,C249] コンデンサ |
| 40 | VHDBR051L40-1 | AE | DS | | B | Diode(RB051L40) [D5] ダイオード |
| | VHDBR451F/-1 | AD | DS | | B | Diode(RB451F) [D3,D4,D6,D8,D9] ダイオード |
| 42 | VH1107AP66C-1 | BX | TF | | B | Microcontroller(XPC107APX66LC) [IC40] IC |
| 43 | VH11085CZAD-1 | AH | DX | | B | Voltage Regulator(PJ1085CZ) [IC12] IC |
| 44 | VH12309SC1H-1 | AT | EZ | | B | Zero Delay Buffer(CY2309SC-1H) [IC29] IC |
| 45 | VH160852ATB-1 | AX | FG | | B | USB Controller(ML60852ATB) [IC45] IC |
| 46 | VH174LCX08MTC | AE | DJ | | B | IC(74LCX08MTC) [IC28,IC1] IC |
| 47 | VH174LCX14MTC | AE | DJ | | B | IC(74LCX14MTC) [IC2,IC8,IC36] IC |
| 48 | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) [IC3,IC4,IC6,IC7,IC9] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) [IC10,IC18,IC19,IC21,IC23] IC |
| | VH174LCX244MT | AM | DX | | B | IC(74LCX244MT) [IC24,IC25] IC |
| 49 | VH174LCX245MT | AM | DX | | B | IC(74LCX245MT) [IC14,IC15,IC16,IC17,IC52] IC |
| 50 | VH174LVX16128 | AP | EQ | | B | IC(74LVX16128) [IC48] ドライバ IC |
| 51 | VH1755B300E-1 | BZ | TF | | B | CPU(XPC755BPX300LE) [IC26] IC |
| 52 | VH17SZ125M5-1 | AE | DS | | B | LOGIC(NC7SZ125M5X) [IC44] IC |
| 55 | VH1D3032+++-1 | AX | FG | N | B | ASIC(D3032) [IC31] IC |
| 56 | VH1D8501A++-1 | BS | MW | N | B | ASIC(D8501A) [IC22] IC |
| 57 | VH1EES04L400P | AG | DX | | B | EEPROM(CAT24WC04P) [IC20] EEPROM |
| 60 | VH1NJM2903M/- | AD | DJ | | B | IC(NJM2903M) [IC37] IC |
| 61 | VH1NJU6356E-1 | AK | DX | | B | IC(NJU6356E) [IC38] IC |
| 62 | VH1PST598DN-1 | AF | DS | | B | Reset IC(PST598DNR) [IC34] IC |
| 63 | VH1PST5981N-1 | AF | DS | | B | IC(PST5981) [IC33] IC |
| 64 | VH1R1117D25-1 | AG | DS | | B | Voltage Regulator(RC1117D25X) [IC49] IC |
| 67 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R6,R12,R13,R14,R15] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R19,R21,R23,R24,R25] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R26,R27,R28,R29,R30] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R33,R34,R35,R36,R37] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R38,R39,R41,R52,R54] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R55,R56,R57,R58,R59] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R60,R66,R82,R83,R105] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R109,R118,R122,R124,R146] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R148,R150,R151,R152,R156] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R157,R158,R159,R160,R166] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R171,R173,R175,R201,R229] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R238,R241,R245,R250,R254] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R267,R268,R269,R270,R271] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R273,R280,R294,R296,R300] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R306,R307,R313,R314,R315] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R316,R321,R325,R333,R345] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R348,R369,R371,R373,R383] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R384,R396,R397,R398,R399] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R400,R409,R410,R421,R443] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R445,R468,R493,R521,R532] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R537,R540,R548,R549,R555] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R556,R557,R558,R566,R574] 抵抗 |

58 PRTC 基板 (PRTC PWB)[AR-C260M/C260FP]

| NO. | PARTS CODE | PRICE RANK | | NEW MARK | PART RANK | DESCRIPTION |
|-----|---------------|------------|-----|----------|-----------|--|
| | | Ex. | Ja. | | | |
| 67 | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R604,R607,R608,R611,R612] 抵抗 |
| | VRS-CZ1JD000J | AA | DD | | C | Resistor(1/16W 0Ω ±5%) [R615,R618,R620] 抵抗 |
| 68 | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R169,R178,R179,R180,R181] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R182,R184,R185,R187,R188] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R189,R190,R191,R194,R195] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R196,R200,R203,R206,R208] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R210,R213,R217,R218,R222] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R223,R224,R225,R227,R228] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R236,R243,R248,R259,R260] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R261,R264,R266,R299,R308] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R317,R318,R319,R320,R322] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R323,R324,R337,R352,R353] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R388,R389,R391,R392,R411] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R412,R413,R414,R415,R434] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R455,R465,R467,R490,R499] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R501,R504,R507,R513,R545] 抵抗 |
| | VRS-CZ1JD100J | AA | DD | | C | Resistor(1/16W 10Ω ±5%) [R634,R635] 抵抗 |
| 69 | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R1,R3,R7,R8,R11] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R20,R42,R45,R62,R64] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R68,R94,R100,R102,R107] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R117,R255,R338,R366,R380] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R405,R422,R423,R424,R436] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R437,R452,R562,R595,R596] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R597,R598,R599,R600,R601] 抵抗 |
| | VRS-CZ1JD102J | AA | DD | | C | Resistor(1/16W 1KΩ ±5%) [R605,R614,R616] 抵抗 |
| 70 | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R5,R61,R63,R71,R80] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R90,R99,R103,R108,R141] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R142,R143,R144,R161,R162] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R167,R183,R186,R192,R197] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R198,R199,R207,R211,R214] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R215,R216,R221,R226,R230] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R231,R232,R239,R240,R242] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R244,R246,R247,R249,R262] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R263,R272,R278,R282,R283] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R284,R285,R286,R288,R290] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R301,R302,R304,R305,R310] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R311,R312,R350,R351,R354] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R355,R356,R357,R359,R364] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R365,R367,R385,R390,R406] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R420,R429,R435,R438,R440] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R446,R454,R469,R470,R471] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R475,R476,R484,R495,R496] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R497,R503,R506,R509,R512] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R514,R516,R517,R519,R520] 抵抗 |
| | VRS-CZ1JD103J | AA | DD | | C | Resistor(1/16W 10KΩ ±5%) [R523,R526,R527,R530,R534] 抵抗 |
| 71 | VRS-CZ1JD105J | AA | DD | | C | Resistor(1/16W 1.0MΩ ±5%) [R542,R543,R559,R561,R563,R564] 抵抗 |
| | VRS-CZ1JD152J | AA | DD | | C | Resistor(1/16W 1.5KΩ ±5%) [R485,R539] 抵抗 |
| 73 | VRS-CZ1JD201J | AA | DD | | C | Resistor(1/16W 200Ω ±5%) [R550] 抵抗 |
| | VRS-CZ1JD201J | AA | DD | | C | Resistor(1/16W 200Ω ±5%) [R2,R4,R174,R293,R339] 抵抗 |
| 74 | VRS-CZ1JD201J | AA | DD | | C | Resistor(1/16W 200Ω ±5%) [R340,R602] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R40,R69,R73,R78,R79] 抵抗 |
| 75 | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R81,R139,R341,R343,R360] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R361,R362,R363,R378,R379] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R393,R394,R401,R402,R408] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R426,R427,R428,R449,R451] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R498,R544,R546,R576,R577] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R578,R579,R580,R581,R582] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R583,R584,R585,R586,R587] 抵抗 |
| | VRS-CZ1JD220J | AA | DD | | C | Resistor(1/16W 22Ω ±5%) [R588,R589,R590,R591,R592] 抵抗 |
| 76 | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R89,R91,R92,R95,R96] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R97,R98,R104,R110,R111] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R125,R136,R137,R138,R140] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R202,R205,R419,R425,R536] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R624,R625,R626,R628,R629] 抵抗 |
| | VRS-CZ1JD330J | AA | DD | | C | Resistor(1/16W 33Ω ±5%) [R630,R631,R632,R633] 抵抗 |
| 77 | VRS-CZ1JD332J | AA | DD | | C | Resistor(1/16W 3.3KΩ ±5%) [R547] 抵抗 |
| 78 | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R472,R473,R483,R487,R488] 抵抗 |
| | VRS-CZ1JD470J | AA | DD | | C | Resistor(1/16W 47Ω ±5%) [R500,R510,R538,R627] 抵抗 |
| 79 | VRS-CZ1JD823J | AA | DD | | C | Resistor(1/16W 82KΩ ±5%)(MCR01MZSJ823) [R466] 抵抗 |
| 80 | VSDTC114EK/-1 | AB | DD | | B | Transistor(DTC114EK) [Q5] トランジスタ |
| 81 | VSDTC114YK/-1 | AC | ZZ | | B | Transistor(DTC114YK) [Q1,Q3,Q4,Q13] トランジスタ |
| 82 | XBBSD30P06000 | AA | DD | | C | Screw(3×6) [IC12] ビス |
| | (Unit) | | | | | |
| 901 | CPWBN1518DS55 | EB | ** | | E | PRTC PWB PRTC 基板 |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

■ 索引 (Index)

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 【C】 | | | | | | |
| CARMM0286FC01 | 572 240 0472 | 21- 18 | AG | DX | N | C |
| CARMP0147DS51 | 572 240 0445 | 3- 14 | BA | FX | | E |
| CBDGD0043FC01 | 572 150 0033 | 1- 20 | AQ | EQ | N | C |
| CBDGD0043FC02 | 572 150 0034 | 1- 20 | AP | EQ | N | C |
| CBDGD0043FC03 | 572 150 0035 | 1- 20 | AQ | EQ | N | C |
| CBDGD0043FC04 | 572 150 0031 | 1- 20 | AR | EQ | N | C |
| CBDGD0043FC05 | 572 150 0032 | 1- 20 | AQ | EQ | N | C |
| CBTN-0252FC01 | 572 170 0507 | 4- 12 | AP | EQ | | D |
| CBTN-0253FC01 | 572 170 0508 | 4- 11 | AN | EG | | D |
| CBTN-0256FC02 | 572 170 0511 | 4- 23 | AR | EQ | N | D |
| CBTN-0256FC03 | 572 170 0512 | 4- 24 | AN | EG | N | D |
| CBTN-0260FC01 | 572 170 0513 | 4- 20 | AE | DX | N | D |
| CBTN-0261FC01 | 572 170 0514 | 4- 21 | AK | DJ | N | D |
| CCADZ1518FC01 | 572 913 0954 | 36- 10 | AB | DJ | | D |
| CCADZ1561FC01 | 572 913 0986 | 36- 10 | AK | DX | | D |
| CCASP0173FC15 | 572 108 1287 | 10-901 | BG | GT | | E |
| CCASP0173FC16 | 572 108 1288 | 10-901 | BG | GT | | E |
| CCASP0173FC17 | 572 108 1284 | 10-901 | BF | GN | | E |
| CCASZ0298DS52 | 572 108 1316 | 20-501 | BK | HG | N | A |
| CCASZ0302DS51 | 572 108 1312 | 22- 4 | BB | GD | N | A |
| CCOVH0212FC34 | 572 110 1296 | 5-901 | BN | HV | N | D |
| CDAiU0577FC31 | 572 210 1041 | 31- 40 | BE | GN | | E |
| CDAiU0618FC02 | 572 210 1218 | 6- 25 | BN | HV | N | C |
| 〃 | 572 210 1218 | 7- 24 | BN | HV | N | C |
| CDAiU0619DS53 | 572 210 1217 | 7- 6 | BR | LX | N | E |
| 〃 | 572 210 1217 | 8-901 | BR | LX | N | E |
| CDSKA0002QS33 | 578 966 0079 | 36- 10 | AP | EQ | N | D |
| CDSKA0002TS33 | | 36- 10 | * | * | N | D |
| CDSKA0014FC31 | | 36- 10 | AT | EZ | N | D |
| CDSKA0014FC32 | | 36- 10 | AT | EZ | N | D |
| CDSKA0014FC35 | | 36- 10 | AT | EZ | N | D |
| CDSKA0014GH35 | | 36- 10 | * | * | N | D |
| CFiX-0571FC01 | 572 211 0755 | 2- 2 | AY | FQ | N | D |
| CFiX-0571FC02 | 572 211 0782 | 2- 2 | AN | EQ | N | D |
| CFiX-0571FC03 | 572 211 0783 | 2- 2 | AN | EQ | N | D |
| CFRM-1061DS71 | 572 213 2223 | 23- 12 | AV | FG | N | E |
| CFRM-1063DS51 | 572 213 2224 | 12-901 | BF | GN | N | E |
| CFRM-1063FC01 | 572 213 2230 | 12- 1 | AU | EZ | N | C |
| CFRM-1066FC01 | 572 213 2231 | 21- 21 | AQ | EQ | N | C |
| CFRM-1066FC02 | 572 213 2232 | 21- 6 | AK | EB | N | C |
| CFRM-1070FC01 | 572 213 2233 | 24- 32 | AP | EQ | N | C |
| CFRM-1071FC01 | 572 213 2234 | 25- 23 | AL | EB | N | C |
| CFRM-1072FC01 | 572 213 2235 | 25- 25 | AL | EB | N | C |
| CFRM-1075FC01 | 572 213 2236 | 15- 12 | AN | EG | N | C |
| CFRM-1076DS51 | 572 213 2225 | 18-901 | BD | GN | N | C |
| CFRM-1081DS51 | 572 213 2226 | 11-901 | BK | HG | N | E |
| CFRM-1081FC01 | 572 213 2237 | 11- 23 | AU | FG | N | C |
| CFRM-1083DS51 | 572 213 2249 | 22-901 | BK | HC | N | E |
| CFRM-1083DS52 | 572 213 2227 | 22-901 | BH | HC | N | E |
| CFRM-1083DS72 | 572 213 2248 | 22- 10 | AQ | EQ | N | E |
| CFRM-1084DS51 | 572 213 2228 | 22- 2 | AR | EQ | N | E |
| CGiDM1977DS51 | 572 345 3902 | 16-901 | BA | FX | N | E |
| CGiDM1977DS52 | 572 345 3938 | 16-901 | BC | GJ | N | E |
| CGiDM1977DS53 | 572 345 3986 | 16-901 | BE | GN | N | E |
| CGLSP0104DS51 | 572 348 0157 | 2- 13 | AT | EZ | N | E |
| CHLDZ1446FC32 | 572 214 2328 | 7- 2 | BH | HC | N | E |
| CPAKA6340FC01 | 572 902 1717 | 36- 5 | AW | FG | N | D |
| CPLTM5788FCE4 | 572 221 8193 | 37-501 | BS | MW | N | E |
| CPLTM5974FC01 | 572 221 8202 | 29- 16 | AH | DX | N | C |
| CPLTM5975FC01 | 572 221 8203 | 29- 17 | AL | EB | N | C |
| CPLTM5983FC01 | 572 221 8134 | 12- 6 | AL | EB | N | C |
| CPLTM5995DS51 | 572 221 8125 | 6- 1 | CA | TV | N | E |
| CPLTM5997FC01 | 572 221 8135 | 25- 17 | AL | EB | N | C |
| CPLTM5999FC01 | 572 221 8136 | 26- 1 | AL | EB | N | C |
| CPLTM6000FC01 | 572 221 8137 | 26- 8 | AK | EB | N | C |
| CPLTM6011FC02 | 572 221 8138 | 20- 39 | AS | EQ | N | C |
| CPLTM6017FC01 | 572 221 8139 | 28- 3 | AG | DX | N | C |
| CPLTM6024DS51 | 572 221 8126 | 31- 15 | AU | EZ | N | E |
| CPLTM6071FC01 | 572 221 8140 | 14- 13 | AK | DX | N | C |
| CPLTM6109DS51 | 572 221 8194 | 24- 52 | AP | EQ | | E |
| CPNLC0248FC01 | 572 158 0779 | 4- 16 | AU | FG | N | D |
| CPNLC0248FC02 | 572 158 0782 | 4- 16 | AV | FG | N | D |
| CPNLC0248FC03 | 572 158 0780 | 4- 16 | AU | GN | N | D |
| CPWBF0083RS51 | 578 684 0931 | 18- 18 | AU | EZ | | E |
| CPWBF0106RS51 | 572 684 4048 | 13- 15 | AP | EQ | | E |
| CPWBF1453FCE1 | 572 684 3826 | 3- 7 | AX | FG | | E |
| CPWBF1454FCE1 | 572 684 3827 | 7- 29 | BN | LE | | E |
| CPWBF1523FC32 | 572 684 4034 | 8- 14 | BF | GN | N | E |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| CPWBF1525FCE1 | 572 684 4035 | 4- 3 | BD | GJ | N | E |
| " | 572 684 4035 | 54-901 | BD | GJ | N | E |
| CPWBF1526DS51 | 572 684 4016 | 23- 27 | AP | EQ | N | C |
| CPWBF1529DS51 | 572 684 4017 | 20- 4 | AR | EQ | N | E |
| CPWBF1546FCE1 | 572 684 4036 | 31- 6 | BB | GD | N | E |
| CPWBF1546FCE2 | 572 684 4078 | 31- 6 | BA | FX | N | E |
| CPWBF1546FCE4 | 572 684 4079 | 31- 6 | BA | FX | N | E |
| CPWBF1561DS51 | | 31- 58 | AZ | FQ | N | E |
| CPWBN1472FCE4 | 572 684 4049 | 37- 36 | CG | UM | N | E |
| " | 572 684 4049 | 49-901 | CG | UM | N | E |
| CPWBN1491FCE1 | 572 684 3845 | 37- 34 | CA | TV | | E |
| " | 572 684 3845 | 50-901 | CA | TV | | E |
| CPWBN1518DS55 | 572 684 4042 | 38- 16 | EB | ZZ | N | E |
| " | 572 684 4042 | 58-901 | EB | ZZ | N | E |
| CPWBN1519DS52 | 572 684 4039 | 52-901 | CX | ** | N | E |
| " | 572 684 4039 | 6- 22 | CX | ** | N | E |
| CPWBN1521DS51 | 572 684 4043 | 38- 12 | BM | HR | N | E |
| CPWBN1534DS52 | 572 684 4044 | 38- 9 | BP | LP | N | E |
| CPWBN1544DS51 | 572 684 4040 | 31- 28 | BR | LX | N | E |
| " | 572 684 4040 | 51-901 | BR | LX | N | E |
| CPWBN1545FCE1 | 572 684 4037 | 31- 8 | BQ | LP | N | E |
| " | 572 684 4037 | 55-901 | BQ | LP | N | E |
| CPWBN1549DS54 | 572 684 4041 | 34- 1 | CU | VW | N | E |
| " | 572 684 4041 | 53-901 | CU | VW | N | E |
| CPWBN1549DS55 | 572 684 4045 | 34- 1 | CV | VZ | N | E |
| " | 572 684 4045 | 53-901 | CV | VZ | N | E |
| CPWBN1549DS57 | 572 684 4059 | 34- 1 | CU | VW | N | E |
| " | 572 684 4059 | 53-901 | CU | VW | N | E |
| CPWBN1560FCE1 | 572 684 4038 | 4- 5 | BM | HR | N | E |
| " | 572 684 4038 | 56-901 | BM | HR | N | E |
| CRöLM1390FC01 | 572 287 2390 | 19- 17 | AW | FG | N | B |
| CRöLM1404DS51 | 572 287 2374 | 19- 32 | BB | GD | N | E |
| CSFTZ2553FC01 | 572 290 2487 | 10- 29 | AN | EG | | C |
| CSFTZ2686DS51 | 572 290 2894 | 23- 21 | AV | FG | N | E |
| CSFTZ2694FC31 | 572 290 2900 | 7- 17 | BA | FX | N | E |
| CSFTZ2698DS51 | 572 290 2895 | 14- 32 | AQ | EQ | N | E |
| CSFTZ2702DS51 | 572 290 2896 | 15- 33 | AP | EQ | N | E |
| CSFTZ2706DS51 | 572 290 2897 | 17- 41 | AP | EQ | N | C |
| CSFTZ2716DS51 | 572 290 2898 | 22- 16 | AP | EQ | N | C |
| CSTYM0294FC01 | 572 231 0594 | 27- 9 | AS | EQ | N | C |
| CTHM-0011FC01 | 578 644 0001 | 24- 27 | AK | EB | | B |
| 【D】 | | | | | | |
| DHAi-3193FC11 | 572 542 2266 | 4- 27 | AC | DJ | N | C |
| DHAi-3204FC11 | 572 542 2267 | 37- 26 | AM | EG | N | C |
| DHAi-3206FC11 | 572 542 2269 | 37- 39 | AG | DX | N | C |
| DHAi-3207FC11 | 572 542 2270 | 37- 25 | AG | DX | N | C |
| DHAi-3332DS11 | 572 542 2026 | 36- 11 | BB | GD | N | B |
| DHAi-3332DSZZ | 572 542 2025 | 36- 11 | BB | GD | N | B |
| DHAi-3339FC11 | 572 542 2326 | 11- 2 | AV | FG | N | C |
| DHAi-3341FCZZ | 572 542 2272 | 17- 4 | AH | DX | N | C |
| DHAi-3342FCZZ | 572 542 2273 | 18- 13 | AE | DS | N | C |
| DHAi-3344FCZZ | 572 542 2274 | 21- 26 | AF | DS | N | C |
| DHAi-3345FC11 | 572 542 2275 | 35- 6 | AY | FQ | N | C |
| DHAi-3348FCZZ | 572 542 2276 | 35- 14 | AR | EQ | N | C |
| DHAi-3349FCZZ | 572 542 2277 | 23- 2 | AD | DJ | N | C |
| DHAi-3350FC11 | 572 542 2327 | 20- 26 | AV | FG | N | C |
| DHAi-3351FCZZ | 572 542 2279 | 23- 1 | AD | DJ | N | C |
| DHAi-3353FCZZ | 572 542 2280 | 24- 13 | AY | FQ | N | C |
| DHAi-3354FC11 | 572 542 2328 | 25- 41 | AH | DX | N | C |
| DHAi-3359FC11 | 572 542 2329 | 13- 9 | AQ | EQ | N | C |
| DHAi-3360FCZZ | 572 542 2283 | 35- 13 | AU | EZ | N | C |
| DHAi-3361FCZZ | 572 542 2284 | 35- 7 | AT | EZ | N | C |
| DHAi-3362FCZZ | 572 542 2285 | 31- 17 | AY | FQ | N | C |
| DHAi-3363FCZZ | 572 542 2286 | 35- 16 | AT | EZ | N | C |
| DHAi-3364FCZZ | 572 542 2287 | 33- 6 | AX | FG | N | C |
| DHAi-3365FCZZ | 572 542 2288 | 23- 4 | AH | DX | N | C |
| DHAi-3367FCZZ | 572 542 2289 | 32- 17 | AT | EZ | N | C |
| DHAi-3369FCZZ | 572 542 2290 | 6- 3 | AN | EG | N | C |
| DHAi-3399FCZZ | 572 542 2291 | 24- 13 | AY | FQ | N | C |
| DHAi-3400FCZZ | 572 542 2324 | 35- 7 | AU | EZ | N | C |
| DHAi-3402FC11 | | 33- 6 | AY | FQ | N | C |
| DHAi-3404FCZZ | 572 542 2294 | 35- 10 | AR | EQ | N | C |
| DHAi-3405FCZZ | 572 542 2295 | 35- 11 | AG | DX | N | C |
| DHAi-3410FCZZ | 572 542 2298 | 35- 12 | AL | EB | N | C |
| DHAi-3412FCZZ | 572 542 2300 | 31- 27 | AC | DJ | N | C |
| DHAi-3413FCZZ | 572 542 2301 | 35- 5 | AN | EG | N | C |
| DHAi-3414FC11 | 572 542 2331 | 20- 3 | AL | EB | N | C |
| DHAi-3416FCZZ | 572 542 2303 | 35- 9 | AN | EQ | N | C |
| DHAi-3419FCZZ | 572 542 2304 | 35- 2 | AE | DS | N | C |
| " | 572 542 2304 | 4- 29 | AE | DS | N | C |
| DHAi-3424FC12 | 572 542 2417 | 35- 1 | AV | FG | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|------------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| DHA i - 3426FCZZ | 572 542 2306 | 31- 52 | AQ | EG | N | C |
| " | 572 542 2306 | 35- 20 | AQ | EG | N | C |
| DHA i - 3441FCZZ | 572 542 2307 | 37- 5 | AV | FG | N | C |
| DHA i - 3443FC12 | 572 542 2325 | 35- 8 | AY | FQ | N | C |
| DHA i - 3453FCZZ | | 38- 8 | AV | FG | N | C |
| DHA i - 3454FCZZ | | 38- 7 | AK | DX | N | C |
| DHA i - 3465FCZZ | 572 542 2309 | 34- 21 | AV | FG | N | C |
| DUNT - 7136FCA1 | 572 685 2220 | 37- 31 | AN | EQ | N | E |
| DUNT - 7187DS11 | 572 685 2242 | 13-901 | BW | RJ | N | E |
| " | 572 685 2242 | 14-901 | BW | RJ | N | E |
| " | 572 685 2242 | 15-901 | BW | RJ | N | E |
| DUNT - 7187DSZZ | 572 685 2181 | 13-901 | BV | RB | N | E |
| " | 572 685 2181 | 14-901 | BV | RB | N | E |
| " | 572 685 2181 | 15-901 | BV | RB | N | E |
| DUNT - 7188DS11 | | 19-901 | CE | UF | N | A |
| " | | 20-901 | CE | UF | N | A |
| DUNT - 7188DS12 | | 19-901 | CE | UF | N | A |
| " | | 20-901 | CE | UF | N | A |
| DUNT - 7193DSZZ | 572 685 2183 | 28-901 | BG | GX | N | E |
| DUNT - 7248DSZZ | 572 685 2184 | 6-901 | CM | UW | N | E |
| " | 572 685 2184 | 7-901 | CM | UW | N | E |
| DUNT - 7251DSZZ | 572 685 2185 | 23-901 | BZ | TF | N | E |
| DUNT - 7255DSZZ | 572 685 2186 | 36- 9 | AZ | FQ | N | E |
| DUNT - 7269FCZZ | 572 685 2227 | 38- 5 | CD | UD | | E |
| DUNT - 7272DSZZ | 572 685 2187 | 30- 28 | CU | VZ | N | E |
| DUNT - 7289DSZZ | 572 685 2222 | 31- 24 | AK | DX | N | E |
| DUNTW7189DS11 | 572 685 2223 | 24-901 | CG | UM | N | E |
| " | 572 685 2223 | 25-901 | CG | UM | N | E |
| DUNTW7189DS12 | 572 685 2234 | 24-901 | CG | UM | N | E |
| " | 572 685 2234 | 25-901 | CG | UM | N | E |
| DUNTW7189DSZZ | 572 685 2188 | 24-901 | CG | UM | N | E |
| " | 572 685 2188 | 25-901 | CG | UM | N | E |
| 【G】 | | | | | | |
| GCAB - 0946FCZ2 | 572 107 2065 | 37- 27 | AZ | FQ | | D |
| GCAB - 0947FCZZ | 572 107 2053 | 37- 2 | AT | EX | | D |
| GCAB - 0980FCZ5 | 572 107 2138 | 1- 18 | BA | FX | N | D |
| GCAB - 0981FCZ5 | 572 107 2139 | 27- 28 | AZ | FX | N | D |
| GCAB - 0981FCZZ | 572 107 2179 | 27- 28 | BB | GD | N | D |
| GCAB - 0982FCZ5 | 572 107 2140 | 2- 19 | AU | FG | N | D |
| GCAB - 0982FCZZ | 572 107 2168 | 2- 19 | AS | EQ | N | D |
| GCAB - 0983FCZ5 | 572 107 2141 | 16- 11 | AQ | EQ | N | C |
| GCAB - 0983FCZZ | 572 107 2169 | 16- 11 | AS | EQ | N | C |
| GCAB - 0984FCZ5 | 572 107 2142 | 1- 21 | BM | HR | N | D |
| GCAB - 0984FCZZ | 572 107 2170 | 1- 21 | BA | FX | N | D |
| GCAB - 0985FCZ5 | 572 107 2143 | 1- 19 | AP | EQ | N | D |
| GCAB - 0985FCZZ | 572 107 2171 | 1- 19 | AQ | EQ | N | D |
| GCAB - 0987FCZ5 | 572 107 2144 | 1- 6 | AV | FG | N | D |
| GCAB - 0987FCZZ | 572 107 2180 | 1- 6 | AU | EZ | N | D |
| GCAB - 0988FCZ5 | 572 107 2145 | 1- 3 | BC | GJ | N | D |
| GCAB - 0988FCZZ | 572 107 2172 | 1- 3 | BE | GN | N | D |
| GCAB - 0989FCZ5 | 572 107 2146 | 1- 16 | AT | EZ | N | D |
| GCAB - 0989FCZZ | 572 107 2181 | 1- 16 | AR | EQ | N | D |
| GCAB - 0990FCZ5 | 572 107 2147 | 1- 15 | AM | EQ | N | D |
| GCAB - 0990FCZZ | 572 107 2182 | 1- 15 | AP | EQ | N | D |
| GCAB - 0991FCZ5 | 572 107 2148 | 1- 13 | AS | EQ | N | D |
| GCAB - 0991FCZZ | 572 107 2183 | 1- 13 | AR | EQ | N | D |
| GCAB - 0992FCZ5 | 572 107 2149 | 1- 10 | AT | EZ | N | D |
| GCAB - 0992FCZZ | 572 107 2184 | 1- 10 | AV | FG | N | D |
| GCAB - 0993FCZ5 | 572 107 2150 | 1- 8 | BA | FX | N | D |
| GCAB - 0994FCZ5 | 572 107 2151 | 2- 5 | BA | FX | N | D |
| GCAB - 0994FCZZ | 572 107 2173 | 2- 5 | AR | EQ | N | D |
| GCAB - 0995FCZ5 | 572 107 2152 | 2- 1 | AQ | EQ | N | D |
| GCAB - 0995FCZZ | 572 107 2185 | 2- 1 | AR | EQ | N | D |
| GCAB - 0996FCZ5 | 572 107 2153 | 2- 6 | AW | FG | N | D |
| " | 572 107 2153 | 3- 12 | AW | FG | N | D |
| GCAB - 0996FCZZ | 572 107 2186 | 2- 6 | AW | FG | N | D |
| " | 572 107 2186 | 3- 12 | AW | FG | N | D |
| GCAB - 0997FCZ5 | 572 107 2154 | 2- 7 | AP | EQ | N | D |
| GCAB - 0997FCZZ | 572 107 2187 | 2- 7 | AQ | EQ | N | D |
| GCAB - 0998FCZ5 | 572 107 2155 | 2- 3 | AP | EQ | N | D |
| GCAB - 0998FCZZ | 572 107 2174 | 2- 3 | AG | DX | N | D |
| GCAB - 0999FCZ5 | 572 107 2156 | 2- 9 | AG | DX | N | D |
| GCAB - 0999FCZZ | 572 107 2175 | 2- 9 | AH | DX | N | D |
| GCAB - 1018FCZ5 | 572 107 2157 | 1- 1 | BF | FG | N | D |
| GCAB - 1018FCZZ | 572 107 2176 | 1- 1 | AY | FQ | N | D |
| GCAB - 1019FCZ5 | 572 107 2158 | 2- 15 | AV | FQ | N | D |
| GCAB - 1019FCZZ | 572 107 2188 | 2- 15 | AU | EZ | N | D |
| GCAB - 1020FCZ5 | 572 107 2159 | 2- 17 | AL | DX | N | D |
| GCAB - 1020FCZZ | 572 107 2189 | 2- 17 | AH | DX | N | D |
| GCAB - 1022FCZ5 | 572 107 2160 | 2- 16 | AQ | EZ | N | D |
| GCAB - 1022FCZZ | 572 107 2190 | 2- 16 | AU | EZ | N | D |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|-----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| GCAB - 1023FCZ5 | 572 107 2161 | 2- 11 | BC | EQ | N | D |
| GCAB - 1023FCZZ | 572 107 2177 | 2- 11 | AT | EZ | N | D |
| GCAB - 1024FCZ5 | 572 107 2162 | 2- 20 | AU | FQ | N | D |
| GCAB - 1024FCZZ | 572 107 2191 | 2- 20 | AX | FG | N | D |
| GCAB - 1025FCZ5 | 572 107 2163 | 2- 18 | AZ | EQ | N | D |
| GCAB - 1025FCZZ | 572 107 2178 | 2- 18 | AR | EQ | N | D |
| GCASP0173FCZ2 | 572 108 1303 | 10- 39 | BA | FX | | C |
| GCOVH0211FCZ2 | 572 110 1305 | 5- 11 | BB | GD | N | D |
| GCOVH0212FCZ2 | 572 110 1306 | 5- 5 | BB | GD | N | D |
| GCOVZ0237FCZZ | 572 110 1309 | 36-106 | AZ | FQ | N | D |
| GLEGG0075FCZZ | 572 123 0106 | 30- 14 | AE | DJ | | C |
| 【H】 | | | | | | |
| HPNLC0247FCZ5 | 572 158 0781 | 4- 13 | BD | GN | N | C |
| HPNLC0247FCZZ | 572 158 0783 | 4- 13 | AV | FG | N | C |
| HPNLH0249FCZZ | 572 158 0758 | 4- 10 | BF | GN | | C |
| 【J】 | | | | | | |
| JHNDM0163FCZ1 | 572 172 0223 | 29- 2 | AG | DX | N | C |
| JHNDP0164FCZ3 | 572 172 0220 | 10- 1 | BL | HL | N | D |
| JHNDP0167FCZ2 | 572 172 0224 | 22- 24 | AC | DJ | N | C |
| JKNBZ0143FCZZ | 572 174 0376 | 25- 6 | AD | DJ | N | C |
| JKNBZ0144FCZZ | 572 174 0377 | 27- 10 | AE | DS | N | C |
| 【L】 | | | | | | |
| LANGF1421FCZZ | 572 200 1463 | 29- 7 | AF | DS | N | C |
| LANGF1422FCZZ | 572 200 1464 | 29- 6 | AG | DS | N | C |
| LANGF1423FCZZ | 572 200 1465 | 6- 19 | AH | DX | N | C |
| LANGT1411FCZZ | 572 200 1466 | 23- 11 | AD | DJ | N | C |
| LBNDJ0002FCZZ | 572 201 0032 | 6- 33 | AA | DD | | C |
| LBNDJ0016FCZZ | 572 201 0010 | 38- 11 | AA | DD | | C |
| LBNDJ0043FCZ1 | 572 201 0125 | 12- 25 | AA | DJ | | C |
| " | 572 201 0125 | 35- 19 | AA | DJ | | C |
| " | 572 201 0125 | 7- 23 | AA | DJ | | C |
| LBNDZ0069FCZZ | 572 201 0158 | 1- 23 | AD | DJ | | C |
| LBOSZ2114FCZZ | 572 202 0455 | 30- 16 | AK | EB | N | C |
| LBSHC0355FCZZ | 572 204 0502 | 6- 9 | AF | DS | N | C |
| LBSHC0356FCZZ | 572 204 0503 | 7- 11 | AC | DJ | N | C |
| LBSHZ1001ACZZ | 596 204 0015 | 37- 12 | AB | DD | | C |
| LBSHZ1102CCZZ | 596 204 0010 | 3- 9 | AC | DD | | C |
| LBSHZ2050SCZZ | 595 204 0016 | 37- 16 | AB | DD | | C |
| LDAiU0576FCZZ | 572 210 1046 | 10- 25 | AG | DX | | C |
| LDAiU0610FCZZ | 572 210 1124 | 7- 9 | AE | DS | | C |
| LDAiU0619FCZ1 | 572 210 1199 | 8- 5 | AS | EQ | | C |
| LDAiU0639FCZZ | 572 210 1219 | 32- 8 | AE | DS | N | C |
| LDAiU0643FCZZ | 572 210 1220 | 31- 2 | AH | DX | N | C |
| LDAiU0646FCZ5 | 572 210 1221 | 4- 1 | BF | GN | N | C |
| LDAiU0646FCZZ | 572 210 1229 | 4- 1 | AX | FG | N | C |
| LDAiU0656FCZZ | 572 210 1222 | 20- 43 | AF | DS | N | C |
| LFiX-0524FCZZ | 572 211 0716 | 17- 27 | AC | DJ | | C |
| LFiX-0537FCZZ | 572 211 0713 | 7- 10 | AD | DJ | | C |
| LFiX-0545FCZZ | 572 211 0738 | 8- 16 | AC | DJ | | C |
| LFiX-0560FCZZ | 572 211 0739 | 37- 23 | AF | DS | | C |
| LFiX-0567FCZZ | 572 211 0740 | 37- 4 | AD | DJ | | C |
| LFiX-0572FCZ5 | 572 211 0756 | 2- 4 | AS | EQ | N | D |
| LFiX-0572FCZZ | 572 211 0759 | 2- 4 | AK | DX | N | D |
| LFRM-1062FCZZ | 572 213 2238 | 23- 5 | AP | EQ | N | C |
| LFRM-1064FCZ1 | 572 213 2269 | 19- 10 | AS | EZ | N | C |
| LFRM-1069FCZZ | 572 213 2240 | 24- 21 | AL | EB | N | C |
| LFRM-1073FCZ1 | 572 213 2257 | 27- 22 | AS | EG | N | C |
| LFRM-1074FCZZ | 572 213 2242 | 27- 23 | AS | EQ | N | C |
| LFRM-1076FCZZ | 572 213 2243 | 18- 16 | AN | EG | N | C |
| LFRM-1079FCZZ | 572 213 2244 | 27- 13 | AF | DS | N | C |
| LFRM-1080FCZZ | 572 213 2245 | 27- 14 | AH | DX | N | C |
| LHLDL1511FCZ1 | 572 214 2329 | 24- 8 | BA | FX | N | C |
| LHLDW0429FCZZ | 572 214 0398 | 34- 16 | AB | DD | | C |
| LHLDW0595FCZZ | 572 214 0467 | 9- 13 | AC | DD | | C |
| LHLDW1006FCZZ | 578 214 0007 | 34- 15 | AA | DD | | C |
| LHLDW1061FCZZ | 572 214 0597 | 23- 30 | AB | DD | | C |
| LHLDW1151FCZZ | 572 214 1300 | 31- 22 | AB | DJ | | C |
| LHLDW1152FCZZ | 572 214 1345 | 30- 4 | AC | DJ | | C |
| " | 572 214 1345 | 31- 23 | AC | DJ | | C |
| LHLDW1154FCZZ | 572 214 1321 | 31- 34 | AC | DJ | | C |
| LHLDW1155FCZZ | 572 214 1336 | 23- 8 | AC | DJ | | C |
| LHLDW1223FCZZ | 572 214 1441 | 35- 17 | AA | DJ | | C |
| LHLDW1226FCZZ | 572 214 1450 | 10- 40 | AB | DJ | | C |
| " | 572 214 1450 | 36- 25 | AB | DJ | | C |
| LHLDW1499FCZZ | 572 214 2204 | 37- 19 | AC | DJ | | C |
| LHLDW1545FCZZ | 572 214 2326 | 35- 18 | AB | DJ | N | C |
| LHLDW2087SCZZ | 595 214 0101 | 37- 41 | AA | DD | N | C |
| LHLDW5031BCZZ | 588 214 0029 | 6- 34 | AA | DD | | C |
| LHLDZ1085FCZ2 | 572 214 2205 | 3- 8 | AD | DJ | | C |
| LHLDZ1377FCZZ | 572 214 1795 | 10- 36 | AD | DJ | | C |
| LHLDZ1381FCZZ | 572 214 1799 | 7- 31 | AL | EB | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| LHLDZ1399FCZZ | 572 214 1949 | 25- 30 | AC | DJ | | C |
| LHLDZ1458FCZZ | 572 214 2206 | 4- 9 | AF | DS | | C |
| LHLDZ1459FCZZ | 572 214 2207 | 4- 6 | AE | DS | | C |
| LHLDZ1493FCZZ | 572 214 2211 | 37- 6 | AF | DS | | C |
| LHLDZ1494FCZZ | 572 214 2212 | 37- 3 | AF | DS | | C |
| LHLDZ1505FCZZ | 572 214 2213 | 7- 4 | AC | DJ | | C |
| LHLDZ1508FCZZ | 572 214 2330 | 33- 1 | AW | FG | N | C |
| LHLDZ1509FCZZ | 572 214 2331 | 19- 26 | AF | DS | N | C |
| LHLDZ1512FCZZ | 572 214 2332 | 24- 36 | AR | EQ | N | C |
| LHLDZ1513FCZZ | 572 214 2333 | 24- 22 | AD | DJ | N | C |
| LHLDZ1514FCZZ | 572 214 2334 | 16- 16 | AK | DX | N | C |
| LHLDZ1517FCZZ | 572 214 2335 | 11- 27 | AE | DS | N | C |
| LHLDZ1519FCZZ | 572 214 2336 | 20- 33 | AW | FG | N | C |
| LHLDZ1520FCZZ | 572 214 2337 | 15- 30 | AC | DJ | N | C |
| LHLDZ1521FCZZ | 572 214 2338 | 13- 20 | AE | DJ | N | C |
| LHLDZ1523FCZZ | 572 214 2339 | 13- 27 | AH | DX | N | C |
| LHLDZ1524FCZZ | 572 214 2340 | 13- 1 | AK | DX | N | C |
| LHLDZ1525FCZZ | 572 214 2341 | 31- 4 | AG | DJ | N | C |
| LHLDZ1539FCZZ | 572 214 2343 | 19- 29 | AD | DJ | N | C |
| LHLDZ1546FCZZ | 572 214 2327 | 29- 22 | AC | DJ | N | C |
| LHLDZ1547FCZZ | 572 214 2344 | 1- 30 | AD | DJ | N | C |
| " | 572 214 2344 | 38- 26 | AD | DJ | N | C |
| LPiN-0277FCZZ | 572 218 0350 | 1- 26 | AB | DJ | | C |
| LPiNS0014QSBZ | 572 218 0635 | 4- 18 | AF | DS | N | C |
| LPiNS0014QSCZ | 572 218 0636 | 4- 17 | AF | DS | N | C |
| LPiNS0096FCZZ | 572 218 0079 | 17- 12 | AB | DD | | C |
| " | 572 218 0079 | 18- 7 | AB | DD | | C |
| " | 572 218 0079 | 21- 5 | AB | DD | | C |
| " | 572 218 0079 | 23- 19 | AB | DD | | C |
| " | 572 218 0079 | 27- 32 | AB | DD | | C |
| LPiNS0133FCZZ | 572 218 0086 | 12- 4 | AA | DD | | C |
| " | 572 218 0086 | 15- 15 | AA | DD | | C |
| " | 572 218 0086 | 25- 4 | AA | DD | | C |
| LPiNS0155FCZZ | 572 218 0052 | 15- 6 | AA | DD | | C |
| " | 572 218 0052 | 16- 35 | AA | DD | | C |
| " | 572 218 0052 | 17- 13 | AA | DD | | C |
| LPiNS0165FCZZ | 572 218 0087 | 28- 28 | AB | DD | | C |
| LPiNS0258FCZZ | 572 218 0329 | 28- 21 | AA | DD | | C |
| LPiNS0280FCZZ | 572 218 0367 | 5- 9 | AD | DJ | | C |
| LPiNS0320FCZZ | 572 218 0546 | 27- 35 | AB | DJ | | C |
| LPiNS0327FCZZ | 572 218 0605 | 27- 34 | AC | DJ | | C |
| LPiNS7062SCZZ | 577 218 0001 | 10- 9 | AA | DD | | C |
| LPLTM2573FCZ1 | 572 221 2384 | 4- 14 | AD | DJ | | C |
| LPLTM5027FCZZ | 572 221 5629 | 1- 22 | AC | DJ | | C |
| LPLTM5414FCZ1 | 572 221 7959 | 10- 6 | AR | EQ | | C |
| LPLTM5416FCZZ | 572 221 6712 | 10- 34 | AH | DX | | C |
| LPLTM5714FCZZ | 572 221 7735 | 19- 38 | AB | DJ | | C |
| " | 572 221 7735 | 22- 7 | AB | DJ | | C |
| LPLTM5787FCZZ | 572 221 7890 | 37- 35 | AQ | EQ | | C |
| LPLTM5788FCZZ | 572 221 7891 | 37- 14 | AP | EQ | | C |
| LPLTM5789FCZZ | 572 221 7892 | 37- 30 | AF | DS | | C |
| LPLTM5892FCZZ | 572 221 7898 | 37- 22 | AD | DJ | | C |
| LPLTM5973FCZZ | 572 221 8141 | 33- 16 | AQ | EQ | N | C |
| LPLTM5976FCZZ | 572 221 8144 | 32- 14 | AL | EB | N | C |
| LPLTM5977FCZZ | 572 221 8206 | 38- 17 | AS | EQ | N | C |
| LPLTM5979FCZZ | 572 221 8145 | 31- 33 | AV | FG | N | C |
| LPLTM5980FCZZ | 572 221 8146 | 31- 21 | AK | EB | N | C |
| LPLTM5981FCZZ | 572 221 8147 | 31- 29 | AK | DX | N | C |
| LPLTM5986FCZZ | 572 221 8148 | 19- 14 | AD | DJ | N | C |
| LPLTM5987FCZZ | 572 221 8149 | 20- 9 | AG | DX | N | C |
| LPLTM5989FCZZ | 572 221 8150 | 6- 13 | AQ | EQ | N | C |
| LPLTM5991FCZZ | 572 221 8151 | 6- 23 | AW | FG | N | C |
| LPLTM5992FCZZ | 572 221 8152 | 7- 22 | AK | DX | N | C |
| LPLTM5996FCZ1 | 572 221 8153 | 24- 26 | AN | EG | N | C |
| LPLTM6003FCZZ | 572 221 8154 | 23- 24 | AD | DJ | N | C |
| LPLTM6016FCZZ | 572 221 8155 | 28- 12 | AC | DJ | N | C |
| LPLTM6025FCZZ | 572 221 8156 | 34- 3 | AE | DS | N | C |
| LPLTM6027FCZZ | 572 221 8157 | 31- 7 | AH | DX | N | C |
| LPLTM6028FCZZ | 572 221 8158 | 38- 6 | AL | EB | N | C |
| LPLTM6073FCZZ | 572 221 8159 | 28- 32 | AC | DJ | N | C |
| LPLTM6075FCZ1 | 572 221 8159 | 37- 28 | AS | EQ | N | C |
| LPLTM6079FCZZ | 572 221 8160 | 31- 20 | AD | DJ | N | C |
| LPLTM6082FCZZ | 572 221 8161 | 9- 10 | AT | EZ | N | C |
| LPLTM6083FCZZ | 572 221 8162 | 9- 7 | AV | FG | N | C |
| LPLTM6084FCZZ | 572 221 8163 | 9- 2 | AK | EB | N | C |
| LPLTM6085FCZZ | 572 221 8164 | 9- 9 | AN | EG | N | C |
| LPLTM6086FCZZ | 572 221 8165 | 9- 12 | AK | DX | N | C |
| LPLTM6087FCZZ | 572 221 8166 | 9- 3 | AN | EG | N | C |
| LPLTM6089FCZZ | 572 221 8167 | 30- 10 | AK | DX | N | C |
| LPLTM6090FCZZ | 572 221 8168 | 34- 13 | AE | DJ | N | C |
| LPLTM6092FCZ1 | 572 221 8169 | 1- 9 | AM | EG | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| LPLTM6093FCZZ | 572 221 8170 | 29- 5 | AM | EG | N | C |
| LPLTM6095FCZZ | 572 221 8171 | 9- 5 | AC | DJ | N | C |
| LPLTM6096FCZZ | 572 221 8172 | 6- 17 | AF | DS | N | C |
| LPLTM6097FCZZ | 572 221 8173 | 29- 8 | AD | DJ | N | C |
| LPLTM6100FCZZ | 572 221 8174 | 29- 4 | AM | EG | N | C |
| LPLTM6102FCZ1 | 572 221 8175 | 31- 45 | AN | EG | N | C |
| LPLTM6108FCZZ | 572 221 8176 | 37- 29 | AF | DS | N | C |
| LPLTM6109FCZZ | 572 221 8195 | 24- 43 | AD | DJ | N | C |
| LPLTM6112FCZZ | 572 221 8196 | 22- 27 | AH | DX | N | C |
| LPLTP5411FCZZ | 572 221 6755 | 10- 13 | AQ | EQ | | C |
| LPLTP5412FCZZ | 572 221 6756 | 10- 5 | AP | EQ | | C |
| LPLTP5413FCZZ | 572 221 6757 | 10- 18 | AF | DS | | C |
| LPLTP5998FCZZ | 572 221 8177 | 25- 10 | BB | GD | N | C |
| LPLTP6019FCZZ | 572 221 8178 | 16- 6 | AD | DJ | N | C |
| LPLTP6020FCZZ | 572 221 8179 | 13- 14 | AF | DS | N | C |
| LPLTP6098FCZZ | 572 221 8180 | 21- 3 | AD | DJ | N | C |
| LRALM0183FCZZ | 572 223 0285 | 7- 36 | AG | DX | | C |
| LRALM0184FCZZ | 572 223 0286 | 7- 35 | AG | DX | | C |
| LRALM0201FCZZ | 572 223 0299 | 6- 26 | AN | EG | N | C |
| LRALM0202FCZZ | 572 223 0300 | 29- 19 | AN | EG | N | C |
| LSOU-0026QSCZ | 572 226 0696 | 13- 4 | BA | FX | N | C |
| LSOU-0189FCZ5 | 572 226 0697 | 13- 21 | AT | EZ | N | C |
| LSOU-0189FCZZ | 572 226 0700 | 13- 21 | AU | EZ | N | C |
| LSOU-0190FCZ5 | 572 226 0698 | 13- 10 | AV | FG | N | C |
| LSOU-0190FCZZ | 572 226 0701 | 13- 10 | AT | EZ | N | C |
| LSOU-0193FCZ5 | 572 226 0699 | 13- 8 | AN | EQ | N | C |
| LSOU-0193FCZZ | 572 226 0710 | 13- 8 | AP | EQ | N | C |
| LSTPP0172FCZ1 | 572 230 0380 | 24- 40 | AA | DJ | | C |
| LSTPP0011QSZZ | 578 230 0043 | 22- 21 | AC | DJ | | C |
| LSTPP0274FCZZ | 572 230 0326 | 16- 26 | AA | DD | | C |
| " | 572 230 0326 | 17- 10 | AA | DD | | C |
| LSTPP0275FCZZ | 572 230 0327 | 16- 15 | AE | DS | | C |
| LSTPP0314FCZZ | 572 230 0395 | 10- 23 | AA | DJ | | C |
| LSTPP0366FCZZ | 572 230 0537 | 14- 19 | AD | DJ | N | C |
| LSTYM0261FCZZ | 572 231 0527 | 8- 11 | AB | DJ | | C |
| LSTYM0293FCZZ | 572 231 0595 | 21- 28 | AP | EQ | N | C |
| LSTYM0295FCZZ | 572 231 0596 | 15- 38 | AL | EB | N | C |
| LSTYM0298FCZZ | 572 231 0597 | 27- 15 | AH | DX | N | C |
| LSTYM0301FCZZ | 572 231 0598 | 27- 27 | AF | DS | N | C |
| LSUPP0076FCZZ | 572 233 0103 | 37- 20 | AA | DD | | C |
| LSUPP0118FCZZ | 572 233 0143 | 37- 18 | AB | DJ | | C |
| LSUPP0126FCZZ | 572 233 0156 | 31- 35 | AC | DJ | N | C |
| " | 572 233 0156 | 31- 5 | AC | DJ | N | C |
| LSUPP1001ACZZ | 596 233 0001 | 34- 12 | AB | DD | | C |
| LX-BZ0004QSZZ | 572 970 1917 | 7- 37 | AB | DD | | C |
| LX-BZ0036GCZZ | 578 970 0190 | 20- 37 | AC | DD | | C |
| LX-BZ0049FCZZ | 572 970 0353 | 7- 15 | AB | DD | | C |
| LX-BZ0071FCZZ | 572 970 0435 | 30- 6 | AA | DD | | C |
| LX-BZ0324FCZZ | 572 970 0197 | 7- 12 | AA | DD | | C |
| LX-BZ0531FCZZ | 572 970 0220 | 10- 37 | AA | DD | | C |
| LX-BZ0555FCZZ | 572 970 0234 | 36- 14 | AB | DD | | D |
| LX-BZ0736FCZZ | 572 970 1499 | 24- 20 | AB | DD | | C |
| LX-BZ0776FCZZ | 572 970 1677 | 2- 32 | AG | DS | | C |
| LX-BZ0833FCZZ | 572 970 1816 | 10- 22 | AC | DD | | C |
| " | 572 970 1816 | 31- 47 | AC | DD | | C |
| LX-BZ0840FCZZ | 572 970 1818 | 28- 37 | AC | DD | | C |
| LX-BZ0850FCZZ | 572 970 1977 | 11- 7 | AC | DD | | C |
| " | 572 970 1977 | 33- 10 | AC | DD | | C |
| LX-BZ0855FCZZ | 572 970 1980 | 30- 17 | AC | DD | | C |
| " | 572 970 1980 | 38- 19 | AC | DD | | C |
| LX-BZ0880FCZZ | 572 970 1990 | 9- 6 | AB | DD | | C |
| LX-BZ0884FCZZ | 572 970 1964 | 10- 8 | AB | DD | | C |
| LX-BZ0898FCZZ | 572 970 2035 | 30- 15 | AC | DD | | C |
| LX-BZ0901FCZZ | 572 970 2269 | 1- 32 | AC | DD | | C |
| " | 572 970 2269 | 38- 28 | AC | DD | | C |
| LX-BZ0916FCZZ | 572 970 2273 | 21- 12 | AA | DD | | C |
| LX-BZ0924FCZZ | 572 970 2061 | 25- 26 | AD | DJ | | C |
| LX-BZ0938FCZZ | 572 970 2326 | 37- 43 | AC | DD | | C |
| LX-BZ0944FCZ1 | 572 970 2578 | 27- 11 | AH | DS | N | C |
| LX-BZ0949FCZZ | 572 970 2559 | 19- 13 | AC | DD | N | C |
| LX-BZ0959FCZZ | 572 970 2560 | 30- 9 | AC | DD | N | C |
| LX-BZ0960FCZZ | 572 970 2520 | 17- 22 | AC | DD | | C |
| " | 572 970 2520 | 30- 25 | AC | DD | | C |
| LX-BZ0962FCZ1 | 572 970 2566 | 37- 40 | AF | DS | N | C |
| LX-BZ0963FCZZ | 572 970 2579 | 38- 14 | AF | DS | N | C |
| LX-BZ0965FCZZ | 572 970 2581 | 19- 39 | AE | DS | N | C |
| LX-BZ1022LCZZ | 594 970 0327 | 38- 3 | AB | DD | | C |
| LX-BZ3006SC0S | 541 970 5148 | 24- 51 | AA | DD | | C |
| " | 541 970 5148 | 25- 34 | AA | DD | | C |
| LX-LZ0022FCZZ | 572 973 0001 | 31- 50 | AB | DD | | C |
| LX-NZ0088FCZZ | 572 980 0102 | 1- 40 | AC | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| LX-WZ0042FCZ1 | 572 990 0422 | 27- 7 | AA | DD | | C |
| LX-WZ0326FCZZ | 572 990 0386 | 36- 16 | AA | DD | | D |
| LX-WZ0443FCZZ | 572 990 0540 | 24- 6 | AB | DD | | C |
| " | 572 990 0540 | 31- 51 | AB | DD | | C |
| " | 572 990 0540 | 31- 53 | AB | DD | | C |
| " | 572 990 0540 | 33- 11 | AB | DD | | C |
| " | 572 990 0540 | 37- 17 | AB | DD | | C |
| LX-WZ0445FCZ1 | 572 990 0549 | 20- 61 | AC | DD | N | C |
| " | 572 990 0549 | 21- 9 | AC | DD | N | C |
| LX-WZ0448FCZZ | 572 990 0547 | 25- 42 | AB | DD | N | C |
| LX-WZ2011SCZZ | 595 990 0031 | 15- 41 | AA | DD | | C |
| " | 595 990 0031 | 20- 45 | AA | DD | | C |
| 【M】 | | | | | | |
| MARMP0147FCZ2 | 572 240 0446 | 3- 10 | AK | DX | | C |
| MARMP0148FCZ2 | 572 240 0447 | 3- 5 | AK | DX | | C |
| MARMP0293FCZ1 | 572 240 0473 | 11- 4 | AL | EB | N | C |
| MARMP0294FCZ1 | 572 240 0474 | 14- 31 | AM | EG | N | C |
| MARMP0295FCZZ | 572 240 0475 | 15- 23 | AF | DS | N | C |
| MARMP0297FCZZ | 572 240 0488 | 16- 23 | AB | DJ | N | C |
| MARMP0298FCZZ | 572 240 0476 | 27- 26 | AC | DJ | N | C |
| MARMP0301FCZ1 | 572 240 0471 | 24- 7 | AE | DJ | N | C |
| MCAMP0106FCZZ | 572 241 0146 | 21- 4 | AC | DJ | N | C |
| MHNG-0170FCZ1 | 572 246 0256 | 5- 8 | AE | DS | | C |
| MHNG-0210FCZZ | 572 246 0426 | 5- 3 | AQ | EZ | | C |
| MHNG-0211FCZZ | 572 246 0427 | 5- 4 | AQ | EZ | | C |
| MLEVF0845FCZ1 | 572 248 1469 | 25- 32 | AE | DS | N | C |
| MLEVF0846FCZ1 | 572 248 1470 | 25- 28 | AE | DS | N | C |
| MLEVP0035QSE1 | 572 248 1225 | 13- 7 | AC | DJ | | C |
| MLEVP0695FCZZ | 572 248 0881 | 11- 26 | AC | DJ | | C |
| MLEVP0754FCZZ | 572 248 1063 | 10- 16 | AF | DS | | C |
| MLEVP0755FCZ1 | 572 248 1206 | 10- 14 | AE | DJ | | C |
| MLEVP0781FCZZ | 572 248 1309 | 27- 16 | AD | DJ | | C |
| MLEVP0786FCZZ | 572 248 1311 | 25- 33 | AC | DD | | C |
| MLEVP0787FCZZ | 572 248 1312 | 25- 36 | AC | DD | | C |
| MLEVP0840FCZZ | 572 248 1471 | 32- 13 | AD | DJ | N | C |
| MLEVP0841FCZZ | 572 248 1472 | 32- 7 | AG | DX | N | C |
| MLEVP0842FCZZ | 572 248 1473 | 23- 16 | AE | DS | N | C |
| MLEVP0843FCZ1 | 572 248 1474 | 20- 17 | AC | DJ | N | C |
| MLEVP0848FCZZ | 572 248 1475 | 25- 8 | AD | DJ | N | B |
| MLEVP0850FCZZ | 572 248 1476 | 28- 33 | AG | DX | N | C |
| MLEVP0851FCZZ | 572 248 1477 | 28- 14 | AE | DS | N | C |
| MLEVP0852FCZZ | 572 248 1478 | 15- 24 | AG | DS | N | C |
| MLEVP0853FCZ1 | 572 248 1479 | 16- 7 | AF | DS | N | C |
| MLEVP0854FCZZ | 572 248 1480 | 17- 1 | AC | DJ | N | C |
| MLEVP0857FCZZ | 572 248 1481 | 18- 14 | AF | DJ | N | C |
| MLEVP0863FCZZ | 572 248 1482 | 27- 1 | AE | EB | N | C |
| MLEVP0864FCZZ | 572 248 1483 | 36- 32 | AD | DJ | N | C |
| MLEVP0865FCZZ | 572 248 1484 | 20- 23 | AC | DS | N | C |
| MLEVP0871FCZZ | 572 248 1486 | 14- 20 | AD | DJ | N | C |
| MLEVP0875FCZZ | 572 248 1487 | 24- 5 | AF | DS | N | C |
| MLNKP0027FCZZ | 572 251 0075 | 14- 12 | AE | DJ | N | C |
| MLNKP0029FCZZ | 572 251 0076 | 15- 27 | AD | DJ | N | C |
| MSL i-0138FCZZ | 572 256 0169 | 8- 10 | AC | DJ | | C |
| MSL i-0140FCZZ | 572 256 0186 | 27- 12 | BA | FX | N | C |
| MSPRC2114FCZZ | 572 258 1969 | 13- 22 | AB | DJ | | C |
| MSPRC2616FCZZ | 572 258 2929 | 16- 25 | AC | DJ | | C |
| MSPRC2631FCZZ | 572 258 2943 | 10- 15 | AC | DJ | | C |
| MSPRC2640FCZZ | 572 258 2951 | 10- 17 | AC | DJ | | C |
| MSPRC2642FCZ1 | 572 258 3297 | 10- 26 | AB | DJ | | C |
| MSPRC2645FCZZ | 572 258 2956 | 33- 9 | AB | DJ | | C |
| MSPRC2654FCZ1 | 572 258 3067 | 27- 8 | AB | DJ | | C |
| MSPRC2669FCZZ | 572 258 2971 | 10- 33 | AB | DJ | | C |
| MSPRC2731FCZ1 | 572 258 3490 | 18- 8 | AC | DJ | | C |
| MSPRC3029FCZZ | 572 258 4120 | 32- 9 | AC | DJ | N | C |
| MSPRC3044FCZ1 | 572 258 4307 | 19- 19 | AD | DJ | N | C |
| MSPRC3047FCZZ | 572 258 4122 | 19- 9 | AB | DJ | N | C |
| MSPRC3054FCZZ | 572 258 4123 | 25- 27 | AE | DJ | N | C |
| MSPRC3059FCZZ | 572 258 4124 | 24- 24 | AC | DJ | N | C |
| MSPRC3066FCZZ | 572 258 4125 | 15- 29 | AC | DJ | N | C |
| MSPRC3073FCZZ | 572 258 4126 | 11- 28 | AC | DJ | N | C |
| MSPRC3074FCZZ | 572 258 4127 | 11- 6 | AC | DJ | N | C |
| MSPRC3077FCZ1 | 572 258 4189 | 21- 10 | AC | DJ | N | C |
| MSPRC3085FCZ1 | 572 258 4166 | 17- 37 | AC | DJ | N | C |
| MSPRC3104FCZZ | 572 258 4130 | 18- 20 | AD | DJ | N | C |
| MSPRC3106FCZZ | 572 258 4195 | 20- 60 | AC | DJ | N | C |
| MSPRC3109FCZZ | 572 258 4131 | 19- 27 | AC | DJ | N | C |
| MSPRC3122FCZZ | 572 258 4132 | 15- 9 | AD | DJ | N | C |
| MSPRC3160FCZZ | 572 258 4184 | 24- 49 | AC | DJ | N | C |
| MSPRC3169FCZZ | 572 258 4133 | 11- 14 | AC | DJ | N | C |
| MSPRD3035FCZZ | 572 258 4134 | 32- 6 | AC | DJ | N | C |
| MSPRD3040FCZZ | 572 258 4135 | 23- 25 | AC | DJ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| MSPRD3041FCZZ | 572 258 4136 | 23- 23 | AD | DJ | N | C |
| MSPRD3042FCZZ | 572 258 4137 | 23- 22 | AD | DJ | N | C |
| MSPRD3045FCZZ | 572 258 4138 | 19- 16 | AD | DJ | N | C |
| MSPRD3046FCZZ | 572 258 4139 | 19- 8 | AD | DJ | N | C |
| MSPRD3057FCZZ | 572 258 4140 | 25- 7 | AC | DJ | N | B |
| MSPRD3058FCZZ | 572 258 4141 | 25- 16 | AC | DJ | N | C |
| MSPRD3067FCZZ | 572 258 4142 | 17- 2 | AC | DJ | N | C |
| MSPRD3084FCZZ | 572 258 4143 | 11- 5 | AD | DJ | N | C |
| MSPRD3093FCZ1 | 572 258 4144 | 16- 9 | AC | DJ | N | C |
| MSPRD3097FCZZ | 572 258 4145 | 18- 15 | AC | DJ | N | C |
| MSPRD3099FCZ1 | 572 258 4185 | 15- 25 | AC | DJ | N | C |
| MSPRD3100FCZZ | 572 258 4147 | 14- 11 | AC | DJ | N | C |
| MSPRD3102FCZZ | 572 258 4148 | 27- 19 | AC | DJ | N | C |
| MSPRD3103FCZZ | 572 258 4149 | 27- 21 | AD | DJ | N | C |
| MSPRD3125FCZZ | 572 258 4150 | 31- 46 | AD | DJ | N | C |
| MSPRD3163FCZZ | 572 258 4151 | 27- 25 | AC | DJ | N | C |
| MSPRP2825FCZZ | 572 258 3919 | 8- 12 | AC | DJ | | C |
| MSPRP3009FCZZ | 572 258 3922 | 4- 26 | AD | DJ | | C |
| MSPRP3030FCZZ | 572 258 4167 | 32- 2 | AD | DJ | N | C |
| MSPRP3031FCZZ | 572 258 4168 | 32- 3 | AF | DS | N | C |
| MSPRP3033FCZZ | 572 258 4169 | 32- 4 | AG | DX | N | C |
| MSPRP3034FCZZ | 572 258 4170 | 32- 5 | AG | DX | N | C |
| MSPRP3036FCZZ | 572 258 4171 | 34- 18 | AE | DJ | N | C |
| MSPRP3037FCZZ | 572 258 4172 | 34- 11 | AD | DJ | N | C |
| MSPRP3038FCZZ | 572 258 4173 | 23- 9 | AC | DJ | N | C |
| MSPRP3052FCZZ | 572 258 4174 | 24- 12 | AG | DS | N | C |
| MSPRP3056FCZZ | 572 258 4175 | 24- 9 | AF | DS | N | C |
| " | 572 258 4175 | 27- 4 | AF | DS | N | C |
| MSPRP3081FCZZ | 572 258 4176 | 28- 11 | AF | DS | N | C |
| MSPRP3082FCZZ | 572 258 4177 | 28- 8 | AF | DS | N | C |
| MSPRP3105FCZZ | 572 258 4178 | 17- 33 | AC | DJ | N | C |
| MSPRP3164FCZZ | 572 258 4179 | 29- 21 | AD | DJ | N | C |
| " | 572 258 4179 | 34- 5 | AD | DJ | N | C |
| MSPRP3168FCZZ | | 38- 2 | AC | DJ | N | C |
| MSPRT1563FCZZ | 572 258 0701 | 3- 3 | AC | DD | | C |
| MSPRT2414FCZZ | 572 258 2452 | 20- 24 | AC | DJ | | C |
| " | 572 258 2452 | 24- 45 | AC | DJ | | B |
| " | 572 258 2452 | 25- 11 | AC | DJ | | B |
| MSPRT3032FCZZ | 572 258 4152 | 32- 15 | AC | DJ | N | C |
| MSPRT3049FCZZ | 572 258 4153 | 20- 18 | AC | DJ | N | C |
| MSPRT3050FCZZ | 572 258 4154 | 21- 20 | AC | DJ | N | C |
| MSPRT3063FCZZ | 572 258 4155 | 26- 5 | AC | DJ | N | C |
| MSPRT3064FCZZ | 572 258 4156 | 28- 18 | AD | DJ | N | C |
| MSPRT3092FCZZ | 572 258 4192 | 16- 34 | AC | DJ | N | C |
| MSPRT3094FCZ1 | 572 258 4157 | 16- 4 | AC | DJ | N | C |
| " | 572 258 4157 | 17- 23 | AC | DJ | N | C |
| MSPRT3098FCZZ | 572 258 4158 | 7- 21 | AC | DJ | N | C |
| MSPRT3110FCZ1 | 572 258 4180 | 28- 34 | AC | DJ | N | C |
| MSPRT3121FCZ1 | 572 258 4306 | 14- 2 | AC | DJ | N | C |
| MSPRT3165FCZZ | 572 258 4162 | 20- 48 | AC | DJ | N | C |
| MSPRT3190FCZZ | 572 258 4186 | 24- 50 | AF | DS | N | C |
| 【N】 | | | | | | |
| NBLTH0239FCZZ | 572 271 0408 | 11- 20 | AF | DX | | C |
| NBLTH0371FCZ1 | 572 271 0866 | 7- 20 | AF | DS | N | B |
| NBLTH0373FCZZ | 572 271 0854 | 18- 4 | AF | DS | N | C |
| NBLTH0374FCZZ | 572 271 0855 | 28- 25 | AE | DJ | N | C |
| NBLTH0376FCZZ | 572 271 0856 | 17- 29 | AF | DS | N | C |
| NBLTT7029XCZZ | 578 271 0045 | 14- 26 | AG | DS | | C |
| NBRGC0188FCZZ | 572 272 0243 | 16- 28 | AB | DD | | C |
| " | 572 272 0243 | 17- 15 | AB | DD | | C |
| " | 572 272 0243 | 28- 20 | AB | DD | | C |
| NBRGC0280FCZZ | 572 272 0272 | 14- 34 | AB | DD | | C |
| NBRGC0319FCZ1 | 572 272 0482 | 21- 13 | AC | DJ | | C |
| NBRGC0387FCZ1 | 572 272 0471 | 11- 11 | AC | DJ | | C |
| NBRGC0504FCZZ | 572 272 0467 | 15- 7 | AC | DJ | | C |
| NBRGC0651FCZZ | 572 272 0722 | 12- 10 | AD | DJ | | C |
| NBRGC0672FCZZ | 572 272 0809 | 23- 6 | AE | DJ | N | C |
| NBRGC0683FCZZ | 572 272 0815 | 28- 10 | AC | DJ | N | C |
| NBRGM0096FCZ1 | 572 272 0487 | 14- 9 | AC | DJ | | C |
| " | 572 272 0487 | 15- 18 | AC | DJ | | C |
| NBRGP0012QSZZ | 578 272 0139 | 25- 2 | AC | DJ | | C |
| NBRGP0604FCZZ | 572 272 0684 | 18- 2 | AD | DJ | | C |
| NBRGP0626FCZZ | 572 272 0678 | 10- 30 | AC | DJ | | C |
| " | 572 272 0678 | 16- 24 | AC | DJ | | C |
| " | 572 272 0678 | 17- 11 | AC | DJ | | C |
| " | 572 272 0678 | 18- 9 | AC | DJ | | C |
| NBRGP0664FCZZ | 572 272 0725 | 20- 25 | AD | DJ | | C |
| NBRGP0674FCZZ | 572 272 0816 | 19- 37 | AE | DJ | N | C |
| NBRGP0675FCZZ | 572 272 0817 | 19- 5 | AH | DX | N | B |
| NBRGP0676FCZ1 | 572 272 0891 | 19- 20 | AC | DJ | N | C |
| NBRGP0677FCZZ | 572 272 0819 | 19- 2 | AC | DJ | N | B |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| NBRGP0678FCZZ | 572 272 0820 | 19- 4 | AF | DS | N | B |
| NBRGP0682FCZZ | 572 272 0821 | 18- 6 | AC | DJ | N | C |
| NBRGP0687FCZZ | 572 272 0822 | 22- 28 | AG | DS | N | C |
| NBRGP0688FCZ1 | 572 272 0823 | 22- 20 | AD | DJ | N | C |
| NBRGY0466FCZZ | 572 272 0425 | 7- 26 | AK | EB | | C |
| NBRGY0646FCZZ | 572 272 0784 | 24- 38 | AS | EQ | | B |
| NBRGY0681FCZZ | 572 272 0824 | 25- 15 | AX | FG | N | B |
| NBRGY2122SCZZ | 595 272 0047 | 12- 2 | AB | DD | | C |
| NCPL-0049FCBZ | 572 274 0071 | 11- 16 | AT | EZ | | C |
| NCPL-0049FCZZ | 572 274 0068 | 14- 29 | AH | DX | | C |
| NCPL-0056FCZZ | 572 274 0077 | 23- 14 | AF | DS | N | B |
| NFANP0068FCZZ | 572 277 0120 | 33- 4 | BB | GD | N | B |
| NFANP0070FCZZ | 572 277 0121 | 1- 27 | AZ | FX | N | B |
| NFANP0071FCZZ | 572 277 0122 | 1- 29 | AZ | FX | N | B |
| " | 572 277 0122 | 38- 25 | AX | FX | N | B |
| NFANP0072FCZZ | 572 277 0123 | 31- 42 | BA | FX | N | B |
| NGERH0111FCWZ | 572 281 2095 | 12- 21 | AD | DJ | | C |
| " | 572 281 2095 | 16- 22 | AD | DJ | | C |
| " | 572 281 2095 | 17- 8 | AD | DJ | | C |
| NGERH0193FCZZ | 572 281 0318 | 10- 10 | AB | DD | | C |
| NGERH0317FCZZ | 572 281 0525 | 15- 5 | AC | DJ | | C |
| NGERH0484FCZZ | 572 281 0654 | 28- 24 | AB | DD | | C |
| NGERH0780FCZ1 | 572 281 1074 | 24- 34 | AE | DS | | B |
| NGERH0866FCZZ | 572 281 0955 | 12- 23 | AC | DD | | B |
| " | 572 281 0955 | 25- 5 | AC | DD | | C |
| " | 572 281 0955 | 28- 26 | AC | DD | | C |
| NGERH0867FCZZ | 572 281 0956 | 12- 22 | AC | DD | | C |
| NGERH1062FCZZ | 572 281 1253 | 24- 33 | AE | DS | | B |
| NGERH1245FCZZ | 572 281 1588 | 17- 7 | AF | DS | | C |
| NGERH1252FCZZ | 572 281 1595 | 12- 16 | AD | DJ | | C |
| NGERH1305FCZZ | 572 281 1867 | 26- 6 | AK | DX | | B |
| NGERH1383FCZZ | 572 281 2099 | 15- 17 | AD | DJ | | C |
| NGERH1496FCZZ | 572 281 2321 | 12- 20 | AE | DJ | N | C |
| NGERH1497FCZZ | 572 281 2322 | 12- 14 | AE | DS | N | B |
| NGERH1499FCZZ | 572 281 2315 | 20- 44 | AG | DX | N | B |
| NGERH1500FCZZ | 572 281 2323 | 20- 21 | AD | DJ | N | B |
| NGERH1501FCZZ | 572 281 2324 | 21- 24 | AK | EB | N | B |
| NGERH1502FCZZ | 572 281 2325 | 21- 23 | AD | DJ | N | C |
| NGERH1503FCZZ | 572 281 2326 | 21- 19 | AC | DJ | N | C |
| NGERH1504FCZZ | 572 281 2327 | 21- 17 | AD | DJ | N | C |
| NGERH1505FCZZ | 572 281 2328 | 21- 22 | AD | DJ | N | C |
| NGERH1507FCZZ | 572 281 2316 | 24- 39 | AT | EZ | N | B |
| NGERH1509FCZZ | 572 281 2329 | 26- 9 | AE | DJ | N | A |
| NGERH1510FCZZ | 572 281 2330 | 12- 24 | AD | DJ | N | B |
| NGERH1511FCZZ | 572 281 2331 | 15- 11 | AE | DJ | N | C |
| NGERH1525FCZZ | 572 281 2332 | 21- 8 | AD | DJ | N | C |
| NGERH1526FCZZ | 572 281 2333 | 15- 8 | AE | DJ | N | C |
| NGERH1529FCZZ | 572 281 2337 | 22- 9 | AC | DJ | N | C |
| NGERH1530FCZ1 | 572 281 2320 | 30- 5 | AK | EB | N | C |
| NGERH1531FCZZ | 572 281 2334 | 28- 5 | AD | DJ | N | C |
| NGERH1536FCZZ | 572 281 2335 | 15- 10 | AC | DJ | N | C |
| NGERK1272FCZ1 | 572 281 1834 | 10- 27 | AF | DS | | C |
| NGERP1385FCZZ | 578 281 0358 | 13- 16 | AF | DS | | C |
| NGERR1386FCZZ | 572 281 2187 | 13- 18 | AE | DJ | | C |
| NPLYZ0005QSZZ | 572 284 0700 | 7- 32 | AG | DX | | C |
| NPLYZ0006QSZZ | 572 284 0701 | 7- 33 | AD | DJ | | C |
| NPLYZ0013QSZZ | 578 284 0054 | 7- 13 | AL | EB | | C |
| NPLYZ0146FCZZ | 572 284 0097 | 28- 27 | AB | DD | | C |
| NPLYZ0352FCZZ | 572 284 0725 | 18- 5 | AE | DJ | | C |
| NPLYZ0365FCZZ | 572 284 0788 | 11- 19 | AC | DJ | | C |
| NPLYZ0398FCZZ | 572 284 0819 | 14- 25 | AC | DJ | | C |
| NPLYZ0401FCZZ | 572 284 0876 | 7- 38 | BB | GD | N | C |
| NPLYZ0402FCZZ | 572 284 0871 | 28- 9 | AD | DJ | N | C |
| NPLYZ0403FCZZ | 572 284 0872 | 17- 30 | AD | DJ | N | C |
| NPLYZ0404FCZZ | 572 284 0873 | 14- 30 | AE | DJ | N | C |
| NPLYZ0409FCZZ | 572 284 0874 | 11- 15 | AL | EB | N | C |
| NROLP0896FCZZ | 572 287 1092 | 16- 2 | AC | DD | | C |
| " | 572 287 1092 | 17- 21 | AC | DD | | C |
| NROLP1060FCZZ | 572 287 1396 | 14- 4 | AF | DS | | C |
| NROLP1403FCZZ | 572 287 2391 | 18- 1 | AR | FQ | N | C |
| NROLP1408FCZZ | 572 287 2392 | 32- 10 | AD | DJ | N | C |
| NROLP1432FCZZ | 572 287 2393 | 28- 17 | AE | DJ | N | C |
| NROLR1311FCZZ | 572 287 2165 | 14- 28 | AN | EG | | B |
| " | 572 287 2165 | 15- 35 | AN | EG | | B |
| NROLR1391FCZZ | 572 287 2368 | 19- 3 | AY | FQ | N | A |
| NROLR1392FCZZ | 572 287 2394 | 20- 19 | BA | FX | N | A |
| NROLR1394FCZ1 | 572 287 2395 | 25- 1 | AT | EZ | N | C |
| NROLR1395FCZZ | 572 287 2396 | 24- 37 | BN | HZ | N | A |
| NROLR1396FCZZ | 572 287 2397 | 25- 14 | BH | HV | N | A |
| NROLR1398FCZ1 | 572 287 2398 | 28- 22 | AR | EQ | N | C |
| NROLR1399FCZ1 | 572 287 2399 | 28- 29 | AR | EQ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| NRÖLR1400FCZZ | 572 287 2400 | 15- 1 | AS | EZ | N | C |
| NRÖLR1401FCZZ | 572 287 2401 | 17- 14 | AS | EQ | N | C |
| NRÖLR1402FCZZ | 572 287 2402 | 18- 10 | AU | EZ | N | C |
| NRÖLR1406FCZZ | 572 287 2408 | 16- 27 | AM | EG | N | C |
| NRÖLR1411FCZZ | 572 287 2403 | 11- 17 | AK | EB | N | B |
| " | 572 287 2403 | 17- 42 | AK | EB | N | B |
| NRÖLR1428FCZZ | 572 287 2369 | 11- 21 | AK | DX | N | B |
| " | 572 287 2369 | 14- 27 | AK | DX | N | B |
| NRÖLR1429FCZZ | 572 287 2404 | 17- 16 | AS | EQ | N | C |
| NSFTZ1805FCZZ | 572 290 1403 | 3- 1 | AE | DS | | C |
| NSFTZ2467FCZZ | 572 290 2317 | 10- 24 | AF | DS | | C |
| NSFTZ2591FCZZ | 572 290 2727 | 11- 18 | AF | DS | | C |
| NSFTZ2685FCZ1 | 572 290 2901 | 30- 20 | AL | EB | N | C |
| NSFTZ2687FCZZ | 572 290 2902 | 12- 17 | AK | EB | N | C |
| NSFTZ2688FCZZ | 572 290 2903 | 12- 3 | AL | EB | N | C |
| NSFTZ2689FCZZ | 572 290 2904 | 19- 24 | AR | EQ | N | C |
| NSFTZ2690FCZ1 | 572 290 2964 | 19- 18 | AL | EB | N | C |
| NSFTZ2691FCZZ | 572 290 2906 | 21- 1 | AU | EZ | N | C |
| NSFTZ2694FCZZ | 572 290 2907 | 7- 16 | AP | EQ | N | C |
| NSFTZ2697FCZZ | 572 290 2908 | 27- 20 | AN | EQ | N | C |
| NSFTZ2700FCZZ | 572 290 2909 | 11- 12 | AQ | EQ | N | C |
| NSFTZ2701FCZZ | 572 290 2910 | 14- 24 | AK | DX | N | C |
| NSFTZ2703FCZZ | | 16- 33 | AF | DS | N | C |
| NSFTZ2704FCZZ | 572 290 2911 | 16- 3 | AL | EB | N | C |
| " | 572 290 2911 | 17- 24 | AL | EB | N | C |
| NSFTZ2707FCZZ | 572 290 2912 | 14- 3 | AH | DX | N | C |
| NSFTZ2712FCZ1 | 572 290 2963 | 20- 31 | AN | EG | N | C |
| NSFTZ2713FCZZ | 572 290 2914 | 28- 30 | AK | DX | N | C |
| NSFTZ2730FCZZ | 572 290 2915 | 21- 7 | AK | EB | N | C |
| NSFTZ2736FCZZ | 572 290 2916 | 22- 25 | AP | EQ | N | C |
| NSFTZ2738FCZZ | 572 290 2917 | 37- 45 | AD | DJ | N | C |
| [P] | | | | | | |
| PBOX-0131FCZZ | 572 307 0477 | 34- 4 | AU | EZ | N | C |
| PBRSR0218FCZ1 | 572 310 0367 | 28- 16 | AH | DX | N | B |
| PBRSR0219FCZ1 | 572 310 0368 | 27- 30 | AG | DX | N | B |
| PBRSR0222FCZZ | 572 310 0369 | 19- 34 | AK | DX | N | B |
| PBRSR0223FCZ1 | 572 310 0380 | 19- 35 | AL | EB | N | B |
| PBRSR0224FCZZ | 572 310 0371 | 24- 48 | AH | DX | N | B |
| PCAPH0009YSZZ | 578 312 0026 | 20- 16 | AC | DJ | | C |
| PCAPH0010GCZZ | 578 312 0023 | 49-101 | AD | DJ | | C |
| " | 578 312 0023 | 53- 1 | AD | DJ | | C |
| " | 578 312 0023 | 58- 1 | AD | DJ | | C |
| PCAPH0082FCZZ | 572 312 0079 | 29- 1 | AD | DJ | N | B |
| PCASZ0298FCZZ | 572 315 0228 | 20- 27 | AQ | EQ | N | C |
| PCASZ0299FCZZ | 572 315 0229 | 11- 1 | AF | DS | N | C |
| PCLC-0297FCZZ | 572 316 0390 | 12- 5 | AU | FG | | B |
| PCLC-0298FCZZ | 572 316 0391 | 12- 13 | AT | EZ | | B |
| " | 572 316 0391 | 15- 19 | AT | EZ | | B |
| PCLC-0316FCZ1 | 572 316 0424 | 15- 34 | AR | EQ | N | B |
| " | 572 316 0424 | 17- 43 | AR | EQ | N | B |
| PCLC-0317FCZZ | 572 316 0425 | 14- 10 | AR | EQ | N | B |
| PCLC-0318FCZZ | 572 316 0426 | 20- 22 | AC | DJ | N | B |
| PCLC-0321FCZZ | 572 316 0428 | 11- 8 | AT | EZ | N | B |
| PCLR-0441FCZZ | 572 318 0490 | 30- 24 | AK | DX | | C |
| PCLR-0442FCZZ | 572 318 0491 | 16- 32 | AD | DJ | | C |
| PCLR-0450FCZZ | 572 318 0529 | 17- 28 | AD | DJ | | C |
| PCLR-0474FCZZ | 572 318 0593 | 21- 14 | AC | DJ | N | C |
| PCLR-0475FCZZ | 572 318 0594 | 24- 10 | AA | DJ | N | C |
| " | 572 318 0594 | 27- 5 | AA | DJ | N | C |
| PCLR-0477FCZZ | 572 318 0595 | 26- 10 | AE | DJ | N | C |
| PCLR-0479FCZZ | 572 318 0592 | 28- 36 | AC | DJ | N | C |
| PCOVP0911FCZZ | 572 323 2321 | 2- 30 | AD | DJ | N | D |
| PCOVP0941FCZZ | 572 323 2322 | 2- 31 | AD | DJ | N | D |
| PCOVP1468FCZZ | 572 323 1745 | 53- 2 | AD | DJ | | D |
| " | 572 323 1745 | 58- 2 | AD | DJ | | D |
| PCOVP1509FCZZ | 572 323 1968 | 17- 25 | AH | DX | | D |
| PCOVP1564FCZZ | 572 323 2178 | 37- 1 | AF | DS | | D |
| PCOVP1618FCZ1 | 572 323 2324 | 1- 34 | AH | DX | N | D |
| PCOVP1623FCZ1 | 572 323 2325 | 1- 36 | AH | DX | N | D |
| PCOVP1631FCZZ | 572 323 2326 | 6- 3 | AP | EQ | N | C |
| PCOVP1632FCZZ | 572 323 2327 | 6- 30 | AM | EG | N | C |
| PCOVP1634FCZZ | 572 323 2328 | 29- 14 | AF | DS | N | C |
| PCOVP1636FCZ1 | 572 323 2355 | 24- 11 | AW | EZ | N | C |
| PCOVP1637FCZZ | 572 323 2330 | 24- 18 | AN | EQ | N | C |
| PCOVP1638FCZZ | 572 323 2331 | 25- 35 | AZ | FX | N | C |
| PCOVP1639FCZ5 | 572 323 2332 | 14- 1 | AR | EQ | N | C |
| PCOVP1639FCZZ | 572 323 2454 | 14- 1 | AQ | EQ | N | C |
| PCOVP1640FCZ1 | 572 323 2455 | 15- 22 | AN | EQ | N | C |
| PCOVP1640FCZ5 | 572 323 2333 | 15- 22 | AL | EB | N | C |
| PCOVP1641FCZZ | 572 323 2334 | 15- 26 | AG | DS | N | C |
| PCOVP1642FCZ1 | 572 323 2335 | 14- 18 | AL | EB | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| PCOVP1643FCZ1 | 572 323 2336 | 10- 3 | AU | EZ | N | D |
| PCOVP1646FCZZ | 572 323 2337 | 2- 10 | AG | DX | N | D |
| PCOVP1648FCZ1 | 572 323 2338 | 20- 47 | AE | DX | N | C |
| PCOVP1649FCZZ | 572 323 2339 | 20- 15 | AN | EG | N | C |
| PCOVP1650FCZZ | 572 323 2340 | 24- 1 | AT | DX | N | C |
| PCOVP1652FCZZ | 572 323 2341 | 13- 26 | AN | EQ | N | C |
| PCOVP1653FCZZ | 572 323 2342 | 13- 3 | AN | EQ | N | C |
| PCOVP1654FCZZ | 572 323 2198 | 30- 8 | AM | EQ | | C |
| PCOVP1656FCZZ | 572 323 2343 | 27- 29 | AG | DX | N | D |
| PCOVP1658FCZ1 | 572 323 2344 | 14- 17 | AG | DX | N | C |
| PCOVP1659FCZZ | 572 323 2345 | 30- 26 | AK | DX | N | C |
| PCOVP1660FCZZ | 572 323 2346 | 30- 23 | AM | EG | N | C |
| PCOVP1697FCZZ | 572 323 2347 | 34- 7 | AG | DX | N | C |
| PCOVP1698FCZZ | 572 323 2348 | 34- 10 | AN | EQ | N | C |
| PCOVP1699FCZ1 | 572 323 2356 | 34- 2 | AN | EQ | N | C |
| PCOVP1700FCZZ | 572 323 2350 | 30- 30 | AG | DX | N | C |
| PCOVP1703FCZ5 | 572 323 2351 | 1- 12 | AP | EQ | N | C |
| PCOVP1703FCZZ | 578 323 0281 | 1- 12 | AP | EQ | N | C |
| PCOVP1706FCZ5 | 572 323 2352 | 1- 39 | AE | DJ | N | C |
| PCOVP1706FCZZ | 572 323 2358 | 1- 39 | AE | DS | N | C |
| PCOVP1707FCZZ | 572 323 2453 | 16- 13 | AG | DX | N | D |
| PCUSF0334FCZZ | 572 326 0296 | 8- 9 | AP | EQ | | C |
| PCUSS0374FCZZ | 572 326 0515 | 6- 24 | AE | DS | N | C |
| PCUSU0203FCZZ | 572 326 0021 | 8- 6 | AE | DS | | C |
| PDUC-0166FCZZ | 572 332 0235 | 33- 17 | AX | EZ | N | C |
| PDUC-0167FCZ2 | 572 332 0249 | 32- 16 | AK | EB | N | C |
| PDUC-0168FCZZ | 572 332 0237 | 33- 15 | AK | DX | N | C |
| PDUC-0169FCZ1 | 572 332 0234 | 31- 44 | AE | DS | N | C |
| PFI LW0294FCZZ | 572 337 0410 | 4- 22 | AE | DS | N | C |
| PFI LZ0290FCZ1 | 572 337 0411 | 33- 2 | BA | FX | N | A |
| PFI LZ0296FCZZ | 572 337 0412 | 1- 38 | AQ | EQ | N | A |
| PFTA-0134FCZ1 | 572 344 0114 | 2- 8 | AE | DS | N | C |
| PFTA-0141FCZ5 | 572 344 0115 | 1- 7 | AK | DX | N | D |
| PFTA-0141FCZZ | 572 344 0118 | 1- 7 | AH | DX | N | D |
| PFTA-0142FCZZ | 572 344 0116 | 1- 11 | AE | DS | N | D |
| PFTA-0144FCZZ | 572 344 0117 | 2- 21 | AE | DJ | N | D |
| PGIDH1833FCZ1 | 572 345 3731 | 10- 11 | AC | DJ | | C |
| PGIDH1968FCZZ | 572 345 3904 | 25- 39 | AK | EB | N | C |
| PGIDH2016FCZZ | 572 345 3905 | 34- 14 | AC | DJ | N | C |
| PGIDM1802FCZZ | 572 345 2967 | 17- 18 | AK | DX | | C |
| PGIDM1890FCZZ | 572 345 3688 | 7- 5 | AC | DJ | | C |
| PGIDM1966FCZ1 | 572 345 3906 | 32- 12 | AP | EQ | N | C |
| PGIDM1967FCZZ | 572 345 3907 | 32- 1 | AR | EG | N | C |
| PGIDM1969FCZZ | 572 345 3908 | 27- 24 | AN | FQ | N | B |
| PGIDM1970FCZZ | 572 345 3909 | 27- 2 | BB | EQ | N | C |
| PGIDM1971FCZZ | 572 345 3896 | 28- 7 | AY | FQ | N | C |
| PGIDM1972FCZZ | 572 345 3910 | 28- 15 | AY | FQ | N | C |
| PGIDM1973FCZ5 | 572 345 3911 | 15- 36 | AS | EQ | N | C |
| PGIDM1973FCZZ | 572 345 3950 | 15- 36 | AU | EZ | N | C |
| PGIDM1974FCZ1 | 572 345 3951 | 14- 6 | AV | FG | N | C |
| PGIDM1974FCZ5 | 572 345 3912 | 14- 6 | AV | FG | N | C |
| PGIDM1977FCZZ | 572 345 3913 | 16- 1 | AN | EG | N | C |
| PGIDM1978FCZZ | 572 345 3914 | 17- 35 | AW | FG | N | C |
| PGIDM1979FCZZ | 572 345 3915 | 18- 12 | AH | DX | N | C |
| PGIDM1981FCZZ | 572 345 3916 | 11- 13 | AH | DX | N | C |
| PGIDM1982FCZZ | 572 345 3917 | 17- 44 | AF | DS | N | C |
| PGIDM1983FCZZ | 572 345 3918 | 11- 25 | AS | EQ | N | C |
| PGIDM1984FCZZ | 572 345 3919 | 17- 36 | AF | DS | N | C |
| PGIDM1985FCZZ | 572 345 3920 | 14- 14 | AF | DS | N | C |
| PGIDM1986FCZZ | 572 345 3921 | 13- 25 | AF | DS | N | C |
| PGIDM1987FCZZ | 572 345 3922 | 13- 24 | AG | DS | N | C |
| PGIDM1988FCZZ | 572 345 3923 | 17- 20 | AS | EZ | N | C |
| PGIDM1989FCZZ | 572 345 3948 | 16- 31 | AH | DX | N | C |
| PGIDM1990FCZZ | 572 345 3949 | 16- 30 | AH | DX | N | C |
| PGIDM1991FCZZ | 572 345 3924 | 30- 13 | AE | DJ | N | C |
| PGIDM1992FCZZ | 572 345 3925 | 30- 12 | AD | DJ | N | C |
| PGIDM2007FCZZ | 572 345 3926 | 28- 31 | AP | EQ | N | C |
| PGLDW2015FCZZ | 572 345 3897 | 13- 11 | AG | DS | N | C |
| PGLSP0003QSZZ | 572 348 0134 | 2- 12 | BA | FX | | D |
| PGUMS0283FCZ1 | 572 352 0337 | 7- 25 | AA | DJ | | C |
| PHOG-0385FCZZ | 572 355 0251 | 34- 9 | AB | DD | | C |
| PLNS-0076FCZZ | 572 372 0099 | 22- 6 | AL | EB | N | B |
| PMAGT0015FCZZ | 572 373 0029 | 1- 17 | AD | DJ | | C |
| PMIR-0164FCZZ | 572 374 0221 | 8- 13 | AP | EQ | | C |
| PMLT-1287FCZZ | 572 375 1027 | 20- 30 | AB | DJ | N | C |
| PMLT-1288FCZ1 | 572 375 1028 | 20- 28 | AB | DJ | N | C |
| PMLT-1298FCZ1 | 572 375 1037 | 6- 29 | AE | DS | N | C |
| PMLT-1303FCZ1 | 572 375 1030 | 16- 19 | AD | DJ | N | C |
| PMLT-1304FCZZ | 572 375 1031 | 16- 10 | AC | DJ | N | C |
| PMLT-1305FCZZ | 572 375 1032 | 16- 8 | AC | DJ | N | C |
| PMLT-1312FCZZ | 572 375 1033 | 22- 26 | AB | DJ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| PMLT-1313FCZZ | 572 375 1034 | 16- 12 | AC | DJ | N | C |
| PMLT-1316FCZZ | 572 375 1035 | 1- 37 | AC | DJ | N | C |
| PMLT-1317FCZZ | 572 375 1036 | 16- 20 | AH | DX | N | C |
| PRDAF0089FCZZ | 572 397 0197 | 58- 4 | AU | EZ | | C |
| PRDAR0057FCZ1 | | 58- 3 | AF | DS | N | C |
| PREFL0172FCZZ | 572 432 0074 | 8- 3 | AK | DX | | C |
| PRNGP0077FCZZ | 572 399 0159 | 26- 11 | AA | DD | | C |
| PRNGP0081FCZZ | 572 399 0159 | 28- 23 | AA | DD | | C |
| PRNGP0081FCZZ | 572 399 0178 | 17- 31 | AA | DJ | | C |
| PRNGP0109FCZZ | 572 399 0254 | 25- 29 | AA | DJ | N | C |
| PRNGP0110FCZZ | 572 399 0255 | 23- 13 | AA | DJ | N | C |
| PSEL-0809FCZZ | 572 400 0808 | 20- 14 | AD | DJ | N | C |
| PSEL-0829FCZ1 | 572 400 0810 | 22- 29 | AC | DJ | N | C |
| PSEL-0830FCZZ | 572 400 0820 | 22- 33 | AA | DJ | N | C |
| PSEL-0831FCZZ | 572 400 0811 | 20- 52 | AC | DJ | N | C |
| PSEL-0832FCZZ | 572 400 0812 | 20- 53 | AC | DJ | N | C |
| PSEL-0835FCZ1 | 572 400 0814 | 22- 31 | AC | DJ | N | C |
| PSEL-0853FCZZ | 572 400 0815 | 20- 5 | AC | DJ | N | C |
| PSEL-0854FCZZ | 572 400 0816 | 20- 55 | AA | DJ | N | C |
| PSEL-0855FCZZ | 572 400 0817 | 20- 54 | AA | DJ | N | C |
| PSEL-0864FCZZ | 572 400 0818 | 22- 32 | AD | DJ | N | C |
| PSEL-0866FCZZ | 572 400 0821 | 22- 34 | AB | DJ | N | C |
| PSHEP4932FCZ1 | 572 403 5213 | 6- 28 | AC | DJ | | C |
| PSHEP4968FCZZ | 572 403 5231 | 20- 10 | AD | DJ | N | C |
| PSHEP4970FCZ2 | 572 403 5232 | 15- 39 | AE | DS | N | C |
| PSHEP4971FCZZ | 572 403 5233 | 15- 2 | AC | DJ | N | C |
| PSHEP4972FCZ1 | 572 403 5234 | 18- 11 | AE | DS | N | C |
| PSHEP4985FCZ1 | 572 403 5235 | 18- 19 | AE | DJ | N | C |
| PSHEP4986FCZZ | 572 403 5236 | 21- 27 | AC | DJ | N | C |
| PSHEP4993FCZ2 | 572 403 5237 | 15- 40 | AE | DS | N | C |
| PSHEP5006FCZZ | 572 403 5238 | 4- 28 | AE | DS | N | C |
| PSHEP5013FCZ1 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ2 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ3 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ4 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ5 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ6 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ7 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZ8 | | 36- 10 | * | * | N | D |
| PSHEP5013FCZZ | | 36- 10 | * | * | N | D |
| PSHEP5015FCZZ | 572 403 5239 | 25- 37 | AD | DJ | N | C |
| PSHEP5019FCZZ | 572 403 5240 | 8- 8 | AF | DS | N | C |
| PSHEP5022FCZZ | 572 403 5241 | 14- 23 | AC | DJ | N | C |
| PSHEP5037FCZZ | 572 403 5242 | 14- 7 | AC | DJ | N | C |
| PSHEP5061FCZ1 | 572 403 5272 | 22- 13 | AD | DJ | N | C |
| PSHEP5062FCZZ | 572 403 5273 | 22- 5 | AB | DJ | N | C |
| PSHEP5071FCZZ | 572 403 5243 | 14- 15 | AB | DJ | N | C |
| PSHEP5075FCZZ | 572 403 5244 | 6- 18 | AF | DS | N | C |
| PSHEP5076FCZZ | 572 403 5245 | 20- 56 | AC | DJ | N | C |
| PSHEP5086FCZZ | 572 403 5246 | 14- 33 | AB | DJ | N | C |
| PSHEP5087FCZZ | 572 403 5247 | 19- 36 | AC | DJ | N | C |
| PSHEP5089FCZZ | 572 403 5248 | 22- 15 | AA | DJ | N | C |
| PSHEP5111FCZZ | 572 403 5279 | 33- 20 | AA | DJ | N | C |
| PSHEP5115FCZZ | 572 403 5280 | 16- 36 | AC | DJ | N | C |
| PSHEP5119FCZZ | 578 403 0860 | 14- 35 | AB | DJ | N | C |
| PSHEP5121FCZZ | 572 403 5283 | 22- 35 | AA | DJ | N | C |
| PSHEP5127FCZZ | 572 403 5323 | 25- 43 | AC | DJ | N | C |
| PSHEP5130FCZZ | | 19- 40 | AA | DJ | N | C |
| PSHEZ3130FCZZ | 572 403 2466 | 10- 7 | AB | DD | | C |
| PSHEZ4684FCZZ | 572 403 4410 | 58- 5 | AC | DJ | | C |
| PSHEZ4788FCZ1 | 572 403 4682 | 15- 3 | AD | DJ | | C |
| PSHEZ4836FCZZ | 572 403 5061 | 6- 35 | AB | DJ | | C |
| PSHEZ4843FCZ1 | 572 403 5215 | 6- 27 | AC | DJ | | C |
| PSHEZ4879FCZZ | 572 403 5068 | 37- 33 | AH | DX | | C |
| PSHEZ4906FCZZ | 572 403 5069 | 4- 25 | AC | DJ | | C |
| PSHEZ4933FCZZ | 572 403 5099 | 37- 24 | AD | DJ | | C |
| PSHEZ4973FCZZ | 572 403 5250 | 19- 1 | AH | DX | N | B |
| PSHEZ4974FCZZ | 572 403 5251 | 20- 57 | AC | DJ | N | B |
| PSHEZ4997FCZ1 | 572 403 5253 | 22- 11 | AC | DJ | N | A |
| PSHEZ4998FCZ1 | 572 403 5254 | 22- 12 | AB | DJ | N | A |
| PSHEZ5007FCZZ | 572 403 5255 | 17- 32 | AF | DS | N | C |
| PSHEZ5027FCZZ | 572 403 5256 | 22- 8 | AB | DJ | N | B |
| PSHEZ5059FCZZ | 572 403 5210 | 5- 1 | AU | EZ | | D |
| PSHEZ5065FCZZ | 572 403 5257 | 4- 19 | AQ | EQ | N | C |
| PSHEZ5074FCZZ | 572 403 5259 | 27- 33 | AC | DJ | N | C |
| PSHEZ5088FCZZ | 572 403 5261 | 15- 37 | AF | DS | | C |
| PSHEZ5099FCZ1 | 572 403 5281 | 22- 30 | AC | DJ | N | C |
| PSHEZ5126FCZZ | 572 403 5324 | 20- 63 | AF | DS | N | C |
| PSHT-0094FCZZ | 572 407 0120 | 20- 46 | AD | DJ | N | C |
| PSLDH0178FCZZ | 572 408 0142 | 3- 6 | AD | DJ | | C |
| PSTK-0015FCZ2 | 572 441 0013 | 5- 6 | AU | EZ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| PTME-0271FCZZ | 572 420 0296 | 13- 23 | AD | DJ | | C |
| PTME-0276FCZ1 | 572 420 0320 | 24- 44 | AK | EB | | A |
| " | 572 420 0320 | 25- 12 | AK | EB | | A |
| PTME-0290FCZZ | 572 420 0346 | 27- 17 | AD | DJ | N | C |
| PTPE-0243FCZ1 | 572 423 0239 | 10- 12 | AC | DJ | | C |
| PWIR-0199FCZZ | 572 427 1665 | 7- 1 | AR | EQ | N | C |
| PWIR-0200FCZZ | 572 427 1666 | 7- 7 | AR | EQ | N | C |
| [Q] | | | | | | |
| QACCB7623QCZZ | 572 500 0067 | 36- 11 | AQ | EQ | N | B |
| QACCB7626QCPZ | | 36- 11 | * | * | N | B |
| QACCD7912QCPZ | 572 500 0094 | 36- 11 | AS | EQ | N | B |
| QACCE6922QCPZ | 572 500 0097 | 36- 11 | AQ | EQ | N | B |
| QACCJ6912QCPZ | 572 500 0095 | 36- 11 | AV | FG | N | B |
| QACCL7922QCPZ | 572 500 0096 | 36- 11 | AN | EQ | N | B |
| QCNCM0672FCZZ | 595 510 0041 | 55- 1 | AB | DD | | C |
| QCNCM0879FCZZ | 572 510 0823 | 51- 1 | AF | DS | | C |
| QCNCM0923FC10 | 572 510 0876 | 51- 2 | AE | DJ | | C |
| " | 572 510 0876 | 52- 1 | AE | DJ | | C |
| " | 572 510 0876 | 53- 96 | AE | DJ | | C |
| QCNCM0923FC12 | 572 510 0939 | 51- 3 | AE | DJ | | C |
| " | 572 510 0939 | 55- 2 | AE | DJ | | C |
| QCNCM0923FC14 | 572 510 0937 | 52- 2 | AE | DJ | | C |
| " | 572 510 0937 | 53- 3 | AE | DJ | | C |
| QCNCM0923FC16 | 572 510 0868 | 51- 4 | AF | DS | | C |
| " | 572 510 0868 | 52- 3 | AF | DS | | C |
| QCNCM0923FC22 | 572 510 0869 | 51- 5 | AF | DS | | C |
| " | 572 510 0869 | 53- 4 | AF | DS | | C |
| QCNCM0923FC24 | 572 510 0870 | 51- 6 | AF | DS | | C |
| " | 572 510 0870 | 52- 4 | AF | DS | | C |
| " | 572 510 0870 | 53- 5 | AF | DS | | C |
| QCNCM0923FC32 | 572 510 0871 | 51- 7 | AG | DS | | C |
| QCNCM0923FC3D | 594 510 0463 | 51- 8 | AF | DS | | C |
| " | 594 510 0463 | 55- 3 | AF | DS | | C |
| QCNCM0931FCZZ | 572 510 0872 | 55- 4 | AF | DS | | C |
| QCNCM0991FCZZ | 572 510 0996 | 52- 5 | AG | DX | | C |
| " | 572 510 0996 | 56- 1 | AG | DX | | C |
| QCNCM0999FCZZ | 572 510 1004 | 12- 18 | AC | DJ | | C |
| QCNCM1000FCZZ | 572 510 1044 | 12- 19 | AC | DJ | | C |
| QCNCM1069AC0H | 596 510 0032 | 55- 5 | AE | DJ | | C |
| QCNCM1069AC1J | 569 510 0003 | 52- 6 | AD | DJ | | C |
| " | 569 510 0003 | 53- 6 | AD | DJ | | C |
| " | 569 510 0003 | 55- 6 | AD | DJ | | C |
| QCNCM1069ACZZ | 541 510 5071 | 49- 1 | AD | DD | | C |
| QCNCM1156FCZZ | 572 510 1226 | 50- 81 | AD | DJ | | C |
| QCNCM1171FCZZ | 572 510 1229 | 54- 1 | AE | DS | | C |
| QCNCM1172FCZZ | | 56- 2 | AL | EB | N | C |
| QCNCM1182FCZZ | 572 510 1230 | 58- 6 | AM | EG | | C |
| QCNCM1183FCZZ | 572 510 1231 | 58- 7 | AM | EG | | C |
| QCNCM1187FCZZ | 572 510 1359 | 53- 7 | AM | EG | N | C |
| QCNCM7014SC0B | 595 510 0337 | 49- 2 | AD | DJ | | C |
| QCNCM7014SC0C | 595 510 0338 | 49- 3 | AA | DD | | C |
| " | 595 510 0338 | 51- 9 | AA | DD | | C |
| " | 595 510 0338 | 53- 8 | AA | DD | | C |
| QCNCM7014SC0F | 595 510 0346 | 51- 10 | AB | DD | | C |
| " | 595 510 0346 | 52- 7 | AB | DD | | C |
| " | 595 510 0346 | 55- 7 | AB | DD | | C |
| QCNCM7014SC0G | 595 510 0347 | 53- 9 | AB | DD | | C |
| QCNCP0340QCZZ | 572 510 0921 | 58- 8 | AC | DJ | | C |
| QCNCW0864FCZZ | 572 510 0770 | 55- 8 | AG | DX | | C |
| QCNCW0885FCZZ | 572 510 0834 | 51- 11 | AG | DX | | C |
| QCNCW0948FCZ6 | 572 510 1079 | 53- 10 | AC | DJ | | C |
| QCNCW1047FCZZ | 572 510 1126 | 53- 11 | AH | DX | | C |
| QCNCW1155FCZZ | 572 510 1220 | 49- 4 | AE | DJ | | C |
| " | 572 510 1220 | 50- 1 | AE | DJ | | C |
| QCNCW1157FCZZ | 572 510 1358 | 52- 8 | AB | DJ | | C |
| QCNCW1164FCZZ | | 56- 3 | AE | DJ | N | C |
| QCNCW1165FCZZ | | 56- 4 | AG | DX | N | C |
| QCNCW1169FCZZ | 572 510 1214 | 52- 9 | AG | DS | | C |
| QCNCW1170FCZZ | 572 510 1215 | 51- 13 | AG | DS | | C |
| " | 572 510 1215 | 53- 12 | AG | DS | | C |
| QCNCW1186FCZZ | 572 510 1352 | 53- 13 | AF | DS | | C |
| QCNCW1190FCZZ | 572 510 1360 | 58- 10 | AN | EG | | C |
| QCNCW5380NCZZ | 585 510 0432 | 52- 10 | AC | DJ | | C |
| QCNW-0190FCZZ | 572 512 0429 | 31- 38 | AD | DJ | N | C |
| QCNW-0197FCZZ | 572 512 0430 | 35- 3 | AL | EB | N | C |
| " | 572 512 0430 | 6- 36 | AL | EB | N | C |
| QCNW-0199FCZZ | 572 512 0431 | 8- 15 | AE | DJ | N | C |
| QCNW-0210FCZZ | 572 512 0423 | 37- 37 | AE | DJ | | C |
| QCNW-0211FCZZ | 572 512 0432 | 35- 15 | AF | DS | N | C |
| QCNW-0213FCZZ | 572 512 0434 | 35- 4 | AH | DX | N | C |
| " | 572 512 0434 | 6- 37 | AH | DX | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| QCNW-0214FCZZ | 572 512 0435 | 4- 8 | AD | DJ | N | C |
| QCNW-0215FCZZ | 572 512 0436 | 34- 17 | AZ | FQ | N | C |
| QCNW-7197XCZZ | 578 512 0283 | 36- 27 | AH | DX | | C |
| QEARP0138FCZZ | 572 514 0107 | 19- 25 | AE | DJ | N | C |
| QEARP0139FCZZ | 572 514 0108 | 19- 22 | AD | DJ | N | C |
| QEARP0140FCZZ | 572 514 0109 | 22- 19 | AD | DJ | N | C |
| QFS-D1327QCZZ | 572 515 0397 | 55- 9 | AE | DS | | A |
| QFS-E1111QCZZ | | 56- 5 | AF | DS | | A |
| QFSHB0028FCZZ | 578 516 0011 | 55- 10 | AC | DJ | | C |
| " | 578 516 0011 | 56- 6 | AC | DJ | | C |
| QJAKT0001FCZZ | 578 517 0010 | 50- 2 | AD | DJ | | C |
| QJAKT0002FCZZ | 578 517 0009 | 50- 3 | AE | DJ | | C |
| QPiN-0003GCZZ | 578 523 0004 | 49-102 | AC | DJ | | C |
| " | 578 523 0004 | 53- 14 | AC | DJ | | C |
| " | 578 523 0004 | 58- 11 | AC | DJ | | C |
| QSOC00081FCZZ | 572 527 0125 | 50- 82 | AL | EB | | C |
| QSOCN0002ESZZ | 578 527 0030 | 58- 9 | AH | DX | | C |
| QSOCN0005ESZZ | 578 527 0032 | 58- 12 | AE | DS | | C |
| QSOCN0082FCZZ | 572 527 0124 | 49- 5 | AP | EQ | | C |
| QSOCZ0001QSZZ | 578 527 0024 | 53- 15 | AL | EB | | C |
| " | 578 527 0024 | 58- 13 | AL | EB | | C |
| QSOCZ0002QSZZ | 578 527 0027 | 58- 14 | AD | DJ | | C |
| QSOCZ0071FCZZ | 572 527 0112 | 52- 11 | AP | EQ | | C |
| QSOCZ0073FCNA | 572 527 0126 | 58- 15 | AL | EB | | C |
| QSOCZ0073FCZZ | 572 527 0115 | 49- 6 | AL | EB | | C |
| " | 572 527 0115 | 51- 14 | AL | EB | | C |
| " | 572 527 0115 | 53- 16 | AL | EB | | C |
| QSOCZ6428ACZZ | 541 527 1013 | 51- 15 | AE | DS | | C |
| " | 541 527 1013 | 52- 12 | AE | DS | | C |
| " | 541 527 1013 | 53- 17 | AE | DS | | C |
| QSW-B0017QSZZ | 572 530 0719 | 13- 6 | AF | DS | N | B |
| " | 572 530 0719 | 20- 49 | AF | DS | N | B |
| QSW-C1390QCZZ | 572 530 0507 | 30- 1 | AN | EQ | | B |
| QSW-C9294QCZZ | 572 530 0681 | 31- 48 | AF | DS | | B |
| QSW-C9295QCZZ | 572 530 0682 | 37- 15 | AL | EB | | B |
| QSW-M0502FCZZ | 572 530 0603 | 17- 6 | AH | DX | | B |
| " | 572 530 0603 | 30- 3 | AH | DX | | B |
| " | 572 530 0603 | 31- 1 | AH | DX | | B |
| QSW-P0005QSZZ | 572 530 0672 | 54- 3 | AC | DJ | | B |
| QSW-P0469FCZZ | 572 530 0536 | 54- 4 | AD | DS | | B |
| [R] | | | | | | |
| RALMB1002LCZZ | 594 601 0010 | 54- 5 | AE | DS | | B |
| RCiLF0068FCZZ | 572 614 0193 | 56- 7 | AF | DS | | C |
| RCiLZ0089FCZZ | 572 614 0239 | 50- 6 | AG | DX | | C |
| RCiLZ0353AFZZ | 596 614 0565 | 58- 16 | AH | DX | | C |
| RC-KZ0008QCZZ | 572 591 0090 | 49- 7 | AB | DD | | C |
| " | 572 591 0090 | 50- 4 | AB | DD | | C |
| RC-KZ0009QCZZ | 572 591 0093 | 50- 83 | AB | DD | | C |
| RC-KZ1054CCN2 | 541 590 5042 | 55- 11 | AB | DD | | C |
| RCORF0046FCZZ | 572 615 0085 | 36- 28 | AH | DX | N | C |
| RCORF1057ACZZ | 596 615 0149 | 58- 17 | AB | DJ | | C |
| RCRSP0068FCZZ | 572 616 0152 | 49- 8 | AG | DS | | B |
| RCRSP0069FCZZ | 572 616 0153 | 49- 9 | AG | DS | | B |
| " | 572 616 0153 | 53- 18 | AG | DS | | B |
| RCRSP0071FCZZ | | 51- 16 | AH | DX | N | B |
| RCRSP0077FCZZ | 572 616 0175 | 53- 19 | AF | DS | | B |
| RCRSP0079FCZZ | 572 616 0176 | 53- 20 | AF | DS | | B |
| RCRSP0080FCZZ | 572 616 0180 | 58- 18 | AF | DS | | B |
| RCRSP6676RCZZ | 579 616 0064 | 53- 21 | AG | DX | | B |
| " | 579 616 0064 | 58- 20 | AG | DX | | B |
| RCRSQ0072FCZZ | 572 616 0177 | 52- 13 | AF | DS | | B |
| RCRSQ0073FCZZ | 572 616 0178 | 52- 14 | AF | DS | | B |
| " | 572 616 0178 | 53- 22 | AF | DS | | B |
| RCRSQ0074FCZZ | 572 616 0179 | 52- 15 | AF | DS | | B |
| RCRSZ0001QSZZ | 572 616 0100 | 51- 17 | AG | DS | | B |
| " | 572 616 0100 | 52- 16 | AG | DS | | B |
| RCRUA0010FCZZ | 572 616 0154 | 49- 10 | AQ | EQ | | B |
| RDENC0004FCZZ | 572 685 2080 | 37- 11 | BV | RB | | E |
| " | 572 685 2080 | 57-901 | BV | RB | | E |
| RDENC0012FCZZ | 572 685 2218 | 31- 39 | BR | LB | N | E |
| RDENC0013FCZZ | 572 685 2219 | 31- 37 | BK | HG | N | E |
| RDENC0020FCZ1 | 572 685 2216 | 31- 31 | BU | NE | N | E |
| RDENC0021FCZZ | 572 685 2177 | 31- 31 | BW | RJ | N | E |
| RDTC00155FCZZ | 572 618 0167 | 13- 19 | AU | EZ | N | B |
| RDTC0153FCZZ | 572 618 0168 | 24- 30 | AN | EQ | N | B |
| " | 572 618 0168 | 25- 19 | AN | EQ | N | B |
| RFiLN0046FCZZ | 572 621 0067 | 52- 17 | AH | DX | | C |
| RFiLN0047FCZZ | 572 621 0063 | 49- 12 | AC | DJ | | C |
| " | 572 621 0063 | 50- 7 | AC | DJ | | C |
| RFiLN0048FCZZ | 572 621 0064 | 58- 21 | AC | DJ | | C |
| RFiLN2011SCZZ | 595 621 0004 | 50- 8 | AC | DJ | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| RFILN5022NCZZ | 585 621 0015 | 53- 23 | AC | DJ | | C |
| RFILZ0004QSZZ | 578 621 0030 | 51- 18 | AM | EG | | C |
| RFILZ1042LCZZ | 594 621 0050 | 49- 13 | AC | DJ | | C |
| " | 594 621 0050 | 52- 18 | AC | DJ | | C |
| RFILZ1043LCZZ | 594 621 0051 | 51- 19 | AC | DJ | | C |
| " | 594 621 0051 | 52- 19 | AC | DJ | | C |
| " | 594 621 0051 | 53- 24 | AC | DJ | | C |
| RHETP0084FCZZ | 572 623 0099 | 30- 11 | AS | EQ | | C |
| RHETP0099FCZZ | 572 623 0103 | 6- 31 | AV | EQ | N | C |
| RH-IX0002FCZZ | 572 573 2550 | 49- 35 | AQ | EQ | | B |
| RH-IX0003QSZZ | 578 573 1149 | 51- 20 | AQ | EQ | | B |
| " | 578 573 1149 | 52- 20 | AQ | EQ | | B |
| RH-IX0004FCZZ | 572 573 2545 | 49- 53 | AS | EQ | | B |
| RH-IX1013ACZZ | 596 573 4270 | 58- 22 | BK | HC | | B |
| RH-IX1030YAZZ | 595 573 5963 | 52- 21 | AG | DS | | B |
| " | 595 573 5963 | 53- 25 | AG | DS | | B |
| RLMPD0674FCZ1 | 572 626 0648 | 8- 1 | BE | GN | N | B |
| RLMPU0668FCZZ | 572 626 0644 | 24- 41 | BA | FX | N | B |
| RLMPU0669FCZZ | 572 626 0645 | 24- 41 | BA | FX | N | B |
| RLMPU0670FCZZ | 572 626 0646 | 25- 13 | AZ | FQ | N | B |
| RLMPU0671FCZZ | 572 626 0647 | 25- 13 | AZ | FQ | N | B |
| RLMPU0672FCZZ | 572 626 0649 | 24- 41 | BA | FX | N | B |
| RLMPU0673FCZZ | 572 626 0650 | 25- 13 | AZ | FQ | N | B |
| RMEMM0001FCZZ | 572 629 0001 | 53- 26 | BZ | TF | | B |
| RMOTP0891FCZZ | 572 630 1123 | 12- 7 | BG | GT | N | B |
| RMOTS0879FCNA | 572 630 1131 | 23- 29 | BD | GN | N | B |
| RMOTS0879FCZZ | 572 630 1124 | 23- 10 | BD | GN | N | B |
| RMOTS0881FCZZ | 572 630 1125 | 20- 38 | BC | GD | N | B |
| RMOTS0882FCZZ | 572 630 1126 | 21- 29 | BA | FX | N | B |
| RMOTS0883FCZZ | 572 630 1127 | 31- 56 | BA | FX | N | B |
| RMOTS0884FCZZ | 572 630 1128 | 26- 3 | BA | FX | N | B |
| RMOTS0885FCZ1 | 572 630 1129 | 7- 19 | BE | GN | N | B |
| RMOTS0890FCZZ | 572 630 1130 | 28- 1 | BA | FX | N | B |
| RMPTC4103QCJJ | 594 631 0091 | 52- 22 | AC | DD | | B |
| RMPTC4330QCJJ | 594 631 0082 | 52- 23 | AC | DD | | B |
| RMPTC4473QCJJ | 593 631 0296 | 52- 24 | AC | DD | | B |
| RMPTR4100ACZZ | 567 631 0099 | 58- 23 | AB | DD | | B |
| RMPTR4103ACZZ | 567 631 0100 | 58- 24 | AB | DD | | B |
| RMPTR4330ACZZ | 567 631 0109 | 58- 25 | AB | DD | | B |
| RMPTW4100QCJJ | 572 631 0264 | 53- 27 | AA | DD | | B |
| RMPTW4101QCJJ | 521 631 0027 | 51- 21 | AB | DD | | B |
| " | 521 631 0027 | 53- 28 | AB | DD | | B |
| RMPTW4102QCJJ | 567 631 0055 | 51- 22 | AB | DD | | B |
| RMPTW4103QCJJ | 571 631 0147 | 51- 23 | AB | DD | | B |
| " | 571 631 0147 | 53- 29 | AB | DD | | B |
| " | 571 631 0147 | 55- 12 | AB | DD | | B |
| RMPTW4330QCJJ | 567 631 0058 | 51- 24 | AB | DD | | B |
| RMPTW4470QCJJ | 521 631 0024 | 53- 30 | AB | DD | | B |
| RMPTW4472QCJJ | 567 631 0059 | 51- 26 | AB | DD | | B |
| RMPTW4473QCJJ | 567 631 0060 | 51- 27 | AB | DD | | B |
| " | 567 631 0060 | 55- 13 | AB | DD | | B |
| RPLU-0013QSZZ | 572 647 0336 | 20- 35 | AN | EG | | B |
| RRLYD1211QCZZ | 572 637 0164 | 50- 10 | AH | DX | | B |
| RRLYD1411QCZZ | 572 637 0165 | 50- 11 | AM | EG | | B |
| RRLYD3211QCZZ | 595 637 0065 | 50- 84 | AM | EG | | B |
| RR-WZ0418FCZZ | 572 580 1088 | 50- 9 | AF | DS | | B |
| RTHM-0021FCZZ | 572 644 0029 | 25- 18 | AN | EG | | B |
| RTHM-0022FCZZ | 572 644 0030 | 24- 27 | AN | EG | | B |
| RTRNP0534FCZZ | 572 654 0285 | 50- 85 | AT | EZ | | B |
| RTRNP2105SCZZ | 595 654 0032 | 50- 86 | AP | EQ | | B |
| RTRNZ0511FCZZ | 572 660 0367 | 56- 8 | AQ | EQ | | B |
| [S] | | | | | | |
| SPAKA0581YSZZ | 572 902 1718 | 36- 7 | AE | DS | N | D |
| SPAKA4693FCZZ | 572 902 0929 | 36- 18 | AE | DS | | C |
| SPAKA6075FCZZ | 572 902 1602 | 36- 22 | AE | DJ | N | D |
| SPAKA6235DSZZ | 572 902 1719 | 36-104 | AH | DX | N | D |
| SPAKA6302FCZ1 | 572 902 1705 | 36- 17 | AD | DJ | N | D |
| SPAKA6336FCZZ | 572 902 1706 | 36- 2 | AK | EB | N | D |
| SPAKA6337FCZZ | 572 902 1707 | 36- 3 | AN | EG | N | D |
| SPAKA6338FCZZ | 572 902 1708 | 36- 2 | AL | EB | N | D |
| SPAKA6339FCZZ | 572 902 1709 | 36- 3 | AN | EQ | N | D |
| SPAKA6345FCZZ | 572 902 1713 | 36- 26 | AE | DJ | N | D |
| SPAKA6346FCZZ | 572 902 1714 | 36- 12 | AD | DJ | N | D |
| SPAKA6384FCZZ | 572 902 1721 | 36- 2 | AL | EB | N | D |
| SPAKA6385FCZZ | 572 902 1722 | 36- 3 | AP | EQ | N | D |
| SPAKA6386FCZZ | 572 902 1723 | 36-103 | AL | EB | N | D |
| SPAKA6440FCZZ | 572 902 1724 | 36-102 | AL | EB | N | D |
| SPAKA6450FCZZ | | 36- 22 | AD | DJ | N | D |
| SPAKC6334DS11 | | 36- 1 | BE | GN | N | D |
| SPAKC6334DS12 | 572 901 1931 | 36- 1 | BU | NN | N | D |
| SPAKC6334DS14 | | 36- 1 | BE | GN | N | D |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| SPAKC6334DS15 | 572 901 1932 | 36- 1 | BU | NN | N | D |
| SPAKC6335DS11 | | 36- 1 | BE | GN | N | D |
| SPAKC6335DSZZ | 572 901 1915 | 36- 1 | BB | GD | N | D |
| SPAKC6383DS11 | | 36- 1 | BF | GN | N | D |
| SPAKC6383DSZZ | 572 901 1922 | 36- 1 | AZ | FQ | N | D |
| SSAKA0006UCZZ | 541 906 1016 | 36- 30 | AA | DD | | C |
| SSAKA2440QCZZ | 595 906 0005 | 36- 13 | AB | DD | | D |
| SSAKA3640QCZZ | 595 906 0002 | 36- 8 | AB | DD | | C |
| SSAKA5003CCZZ | 500 906 0006 | 36- 21 | AA | DD | | C |
| SSAKH3013CCZZ | 500 906 0015 | 36- 29 | AA | DD | | C |
| SSAKZ0018FCZZ | 572 906 0119 | 36- 4 | AN | EG | | D |
| [T] | | | | | | |
| TCADS1511FCZZ | 572 913 0956 | 36- 10 | AC | DJ | | D |
| TCADS1512FCZZ | 572 913 0957 | 36- 10 | AB | DJ | | D |
| TCADZ1178FCZZ | 572 913 0651 | 36- 15 | AB | DJ | | D |
| TCADZ1275FCZZ | 572 913 0734 | 36- 24 | AB | DJ | | D |
| TCADZ1593FCZZ | 572 913 0991 | 36-105 | AC | DJ | N | D |
| TCADZ1595FCZZ | 572 913 0993 | 20- 62 | AC | DJ | N | C |
| TCADZ6015FCZZ | 572 913 0988 | 36-101 | AC | DJ | N | D |
| TCADZ6017FCZZ | 572 913 0990 | 36- 10 | AF | DS | N | D |
| TCADZ6017GHZZ | | 36- 10 | * | * | N | D |
| TCAUA0770FCZZ | 572 914 0035 | 1- 42 | AB | DD | | C |
| TCAUH1035FCZZ | 572 914 0672 | 30- 7 | AC | DJ | | C |
| TINSD2344GHZZ | | 36- 10 | * | * | N | D |
| TINSD2359GHZZ | | 36- 10 | * | * | N | D |
| TINSD2375GHZZ | | 36- 10 | * | * | N | D |
| TINSD2391GHZZ | | 36- 10 | * | * | N | D |
| TINSD2457GHZZ | | 36- 10 | * | * | N | D |
| TINSE2332FCZZ | 572 916 2065 | 36- 10 | BA | FX | N | D |
| TINSE2333GHZZ | | 36- 10 | * | * | N | D |
| TINSE2334FCZZ | 572 916 2055 | 36- 10 | BB | GD | N | D |
| TINSE2334GHZZ | | 36- 10 | * | * | N | D |
| TINSE2347FCZZ | 572 916 2066 | 36- 10 | AP | EQ | N | D |
| TINSE2348GHZZ | | 36- 10 | * | * | N | D |
| TINSE2349FCZZ | 572 916 2056 | 36- 10 | AQ | EQ | N | D |
| TINSE2349GHZZ | | 36- 10 | * | * | N | D |
| TINSE2363FCZZ | 572 916 2057 | 36- 10 | AM | EG | N | D |
| TINSE2364GHZZ | | 36- 10 | * | * | N | D |
| TINSE2365FCZZ | 572 916 2058 | 36- 10 | AM | EG | N | D |
| TINSE2365GHZZ | | 36- 10 | * | * | N | D |
| TINSE2379FCZZ | 572 916 2059 | 36- 10 | AN | EQ | N | D |
| TINSE2380GHZZ | | 36- 10 | * | * | N | D |
| TINSE2381FCZZ | 572 916 2060 | 36- 10 | AN | EQ | N | D |
| TINSE2381GHZZ | | 36- 10 | * | * | N | D |
| TINSE2445FCZZ | 572 916 2074 | 36- 10 | AM | EG | N | D |
| TINSE2446GHZZ | | 36- 10 | * | * | N | D |
| TINSE2447FCZZ | 572 916 2075 | 36- 10 | AM | EG | N | D |
| TINSE2447GHZZ | | 36- 10 | * | * | N | D |
| TINSF2336FCZZ | 572 916 2067 | 36- 10 | BA | FX | N | D |
| TINSF2336GHZZ | | 36- 10 | * | * | N | D |
| TINSF2351FCZZ | 572 916 2068 | 36- 10 | AP | EQ | N | D |
| TINSF2351GHZZ | | 36- 10 | * | * | N | D |
| TINSF2367FCZZ | 572 916 2061 | 36- 10 | AM | EG | N | D |
| TINSF2367GHZZ | | 36- 10 | * | * | N | D |
| TINSF2383FCZZ | 572 916 2062 | 36- 10 | AN | EQ | N | D |
| TINSF2383GHZZ | | 36- 10 | * | * | N | D |
| TINSF2449FCZZ | 572 916 2076 | 36- 10 | AM | EG | N | D |
| TINSF2449GHZZ | | 36- 10 | * | * | N | D |
| TINSG2341GHZZ | | 36- 10 | * | * | N | D |
| TINSG2356GHZZ | | 36- 10 | * | * | N | D |
| TINSG2372GHZZ | | 36- 10 | * | * | N | D |
| TINSG2388GHZZ | | 36- 10 | * | * | N | D |
| TINSG2454GHZZ | | 36- 10 | * | * | N | D |
| TINSH2339GHZZ | | 36- 10 | * | * | N | D |
| TINSH2354GHZZ | | 36- 10 | * | * | N | D |
| TINSH2370GHZZ | | 36- 10 | * | * | N | D |
| TINSH2386GHZZ | | 36- 10 | * | * | N | D |
| TINSH2452GHZZ | | 36- 10 | * | * | N | D |
| TINSI2338GHZZ | | 36- 10 | * | * | N | D |
| TINSI2353GHZZ | | 36- 10 | * | * | N | D |
| TINSI2369GHZZ | | 36- 10 | * | * | N | D |
| TINSI2385GHZZ | | 36- 10 | * | * | N | D |
| TINSI2451GHZZ | | 36- 10 | * | * | N | D |
| TINSJ2329FCZZ | 572 916 2045 | 36- 10 | BB | GD | N | D |
| TINSJ2330FCZZ | 572 916 2046 | 36- 10 | BA | FX | | D |
| TINSJ2331FCZZ | 572 916 2047 | 36- 10 | AV | FG | N | D |
| TINSJ2362FCZZ | 572 916 2063 | 36- 10 | AK | EB | N | D |
| TINSJ2378FCZZ | 572 916 2064 | 36- 10 | AS | EQ | N | D |
| TINSJ2444FCZZ | 572 916 2078 | 36- 10 | AM | EG | N | D |
| TINSS2337GHZZ | | 36- 10 | * | * | N | D |
| TINSS2352GHZZ | | 36- 10 | * | * | N | D |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| TINS2368GHZZ | | 36- 10 | * | * | N | D |
| TINS23684GHZZ | | 36- 10 | * | * | N | D |
| TINS22450GHZZ | | 36- 10 | * | * | N | D |
| TINSW2340GHZZ | | 36- 10 | * | * | N | D |
| TINSW2355GHZZ | | 36- 10 | * | * | N | D |
| TINSW2371GHZZ | | 36- 10 | * | * | N | D |
| TINSW2387GHZZ | | 36- 10 | * | * | N | D |
| TINSW2453GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2342GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2343GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2357GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2358GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2373GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2374GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2389GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2390GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2455GHZZ | | 36- 10 | * | * | N | D |
| TINSZ2456GHZZ | | 36- 10 | * | * | N | D |
| TLABF2705FCZZ | 577 917 0006 | 1- 43 | AB | DD | | C |
| TLABH4186FCZZ | 572 917 3188 | 1- 45 | AE | DS | | C |
| TLABH4746FCZZ | 572 917 3691 | 24- 2 | AH | DX | N | C |
| TLABH4747FCZ1 | 572 917 3692 | 20- 41 | AH | DX | N | C |
| TLABH4747FCZZ | 572 917 3749 | 20- 41 | AE | DJ | N | C |
| TLABH4748FCZZ | 572 917 3693 | 2- 26 | AF | DS | N | C |
| TLABH4749FCZZ | 572 917 3705 | 2- 26 | AE | DJ | N | C |
| TLABS4306FCZZ | 572 917 3307 | 1- 47 | AC | DJ | | C |
| TLABZ0059QSZZ | 572 917 3355 | 1- 50 | AE | DJ | | C |
| TLABZ4047FCZZ | 572 917 3041 | 10- 4 | AC | DJ | | C |
| " | 572 917 3041 | 1- 41 | AC | DJ | | C |
| TLABZ4238FCZZ | 572 917 3233 | 10- 32 | AD | DJ | | C |
| TLABZ4239FCZZ | 572 917 3308 | 10- 32 | AD | DJ | | C |
| TLABZ4240FCZZ | 572 917 3309 | 10- 32 | AD | DJ | | C |
| TLABZ4335FCZZ | 572 917 3385 | 7- 39 | AB | DJ | | C |
| TLABZ4694FCZZ | 572 917 3593 | 1- 48 | AF | DS | | C |
| TLABZ4720FCZZ | 572 917 3607 | 1- 49 | AC | DJ | | C |
| TLABZ4742FCZZ | 572 917 3702 | 1- 33 | AL | EB | N | C |
| TLABZ4753FCZZ | 572 917 3695 | 22- 23 | AA | DJ | N | C |
| TLABZ4754FCZZ | 572 917 3696 | 22- 23 | AA | DJ | N | C |
| TLABZ4755FCZZ | 572 917 3697 | 22- 23 | AA | DJ | N | C |
| TLABZ4756FCZZ | 572 917 3698 | 22- 23 | AB | DJ | N | C |
| TLABZ4759FCZZ | 572 917 3699 | 13- 30 | AH | DX | N | C |
| TLABZ4766FCZ1 | 572 917 3700 | 22- 3 | AC | DJ | N | C |
| TLABZ4772FCZ1 | 572 917 3715 | 20- 50 | AF | DJ | N | B |
| [U] | | | | | | |
| UBAT10014FCZZ | 572 932 0022 | 53- 31 | AN | EQ | | B |
| UBATL2033SCZZ | 595 932 0026 | 58- 26 | AK | EB | | B |
| UCLEZ0169FCZZ | 572 704 0125 | 20- 12 | AQ | EQ | N | A |
| UCLEZ0170FCZZ | 572 704 0126 | 20- 6 | AK | EB | N | A |
| UCLEZ0171FCZZ | 572 704 0127 | 22- 14 | AX | FG | N | A |
| UCLEZ0172FCZ1 | 572 704 0128 | 22- 18 | AQ | EQ | N | A |
| UKOG-0304FCZZ | 572 941 0300 | 36- 10 | AQ | EQ | N | D |
| [V] | | | | | | |
| VCAAPF0JJ107M | 572 590 0055 | 58- 27 | AF | DS | | C |
| VCCCCZ1EH221J | 595 593 1444 | 49- 14 | AB | DD | | C |
| " | 595 593 1444 | 50- 14 | AB | DD | | C |
| VCCCCZ1HH100D | 521 593 0027 | 49- 15 | AA | DD | | C |
| VCCCCZ1HH101J | 521 593 0028 | 50- 15 | AA | DD | | C |
| " | 521 593 0028 | 58- 28 | AA | DD | | C |
| VCCCCZ1HH150J | 521 593 0029 | 49- 16 | AA | DD | | C |
| " | 521 593 0029 | 52- 25 | AA | DD | | C |
| VCCCCZ1HH151J | 596 593 1667 | 53- 32 | AC | DD | | C |
| VCCCCZ1HH180J | 578 593 0186 | 51- 29 | AA | DD | | C |
| VCCCCZ1HH220J | 521 593 0023 | 51- 30 | AA | DD | | C |
| " | 521 593 0023 | 52- 26 | AA | DD | | C |
| " | 521 593 0023 | 53- 33 | AA | DD | | C |
| " | 521 593 0023 | 58- 29 | AA | DD | | C |
| VCCCCZ1HH270J | 567 593 0396 | 53- 34 | AA | DD | | C |
| VCCUCY1AJ105Z | 596 593 0899 | 51- 31 | AC | DD | | C |
| VCE9EA1CW106M | 572 594 0924 | 50- 21 | AC | DD | | C |
| VCE9GA1CW476M | 572 594 0925 | 50- 22 | AD | DD | | C |
| VCEAEA0JW107M | 541 591 5218 | 52- 27 | AA | DD | | C |
| VCEAGA0JW107M | 541 591 5321 | 51- 32 | AC | DD | | C |
| VCEAGA1AW107M | 585 594 0057 | 53- 35 | AB | DD | | C |
| VCEAGA1AW108M | 597 594 0001 | 51- 33 | AC | ZT | | C |
| VCEAGA1AW476M | 572 594 0061 | 52- 28 | AA | DD | | C |
| " | 572 594 0061 | 53- 36 | AA | DD | | C |
| " | 572 594 0061 | 55- 14 | AA | DD | | C |
| VCEAGA1AW477M | 541 591 5323 | 51- 34 | AB | DD | | C |
| " | 541 591 5323 | 52- 29 | AB | DD | | C |
| VCEAGA1CW106M | 541 591 5281 | 52- 30 | AA | DD | | C |
| " | 541 591 5281 | 55- 15 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VCEAGA1CW107M | 541 591 5089 | 52- 31 | AC | DD | | C |
| VCEAGA1HW224M | 501 591 5002 | 52- 32 | AA | DD | | C |
| VCEAGA1VW107M | 541 591 5325 | 52- 33 | AB | DD | | C |
| VCEAGA1VW227M | 572 594 0086 | 52- 34 | AB | DD | | C |
| VCEAGU1VW108M | 585 594 0059 | 55- 16 | AE | DX | | C |
| VCEAJU1CW476M | 596 594 0062 | 54- 6 | AB | DD | | C |
| VCEAPH1VC225M | 567 594 0130 | 58- 30 | AC | DD | | C |
| VCEAPS1AC227M | 572 594 0923 | 58- 31 | AD | DJ | | C |
| VCEAPS1CC106M | 588 594 0085 | 49- 17 | AC | DD | | C |
| " | 588 594 0085 | 58- 32 | AC | DD | | C |
| VCEAPS1CC226M | 593 594 0584 | 58- 33 | AC | DJ | | C |
| VCEAPS1CC476M | 567 594 0128 | 58- 34 | AC | DJ | | C |
| VCEAPS1HC475M | 567 594 0132 | 49- 18 | AC | DJ | | C |
| VCEAPZ1EW107M | 588 594 0089 | 49- 19 | AD | DJ | | C |
| " | 588 594 0089 | 58- 35 | AD | DJ | | C |
| VCEAPZ1EW476M | 594 594 0040 | 49- 20 | AE | DJ | | C |
| VCEAZA1AW477M | 572 594 0828 | 53- 37 | AC | DD | | C |
| VCEAZA1HW476M | 578 594 0148 | 50- 16 | AC | DD | | C |
| VCEAZA1HW105M | 594 594 0295 | 50- 17 | AB | DD | | C |
| VCEAZA1HW225M | 594 594 0291 | 50- 87 | AB | DD | | C |
| VCEAZA1HW226M | 578 594 0178 | 50- 18 | AC | DD | | C |
| VCEAZA1HW334M | 594 594 0294 | 50- 19 | AB | DD | | C |
| VCEAZA1HW475M | 572 594 0761 | 50- 20 | AB | DD | | C |
| VCEAZA1VW476M | 578 594 0149 | 55- 17 | AC | DD | | C |
| VCEAZU0JW338M | 572 594 0926 | 51- 36 | AE | DJ | | C |
| VCEAZU1VW106M | 578 594 0140 | 51- 35 | AB | DD | | C |
| VCEAZU1VW477M | 572 594 0655 | 51- 37 | AD | DJ | | C |
| VCFYDA1HA104J | 572 596 0404 | 49- 21 | AC | DD | | C |
| VCFYDA1HA105J | 572 596 0405 | 49- 22 | AE | DJ | | C |
| " | 572 596 0405 | 50- 88 | AE | DJ | | C |
| VCFYDA1HA333J | 572 596 0406 | 49- 23 | AC | DD | | C |
| VCFYDA1HA474J | 595 596 0218 | 49- 24 | AD | DJ | | C |
| VCFYJU2AA824K | 572 596 0377 | 50- 89 | AF | DS | | C |
| VCFYJU2EA105K | 595 596 0062 | 50- 23 | AE | DS | | C |
| VCFYJU2GA473K | 595 596 0091 | 50- 90 | AC | DD | | C |
| VCFYJU2JA103K | 595 596 0093 | 56- 9 | AC | DD | | C |
| VCKYCY1EB104K | 596 593 1153 | 53- 38 | AG | DX | | C |
| VCKYCY1HB223K | 595 593 1641 | 51- 38 | AC | DD | | C |
| VCKYCY1HB223Z | 594 593 0072 | 52- 35 | AA | DD | | C |
| VCKYCY1AB333K | 595 593 1674 | 50- 91 | AB | DD | | C |
| VCKYCY1AF224Z | 572 593 0355 | 49- 25 | AC | DD | | C |
| VCKYCY1CB103K | 595 593 1450 | 49-103 | AA | DD | | C |
| VCKYCY1CF104Z | 521 593 0017 | 49- 26 | AB | DD | | C |
| " | 521 593 0017 | 51- 39 | AB | DD | | C |
| " | 521 593 0017 | 52- 36 | AB | DD | | C |
| " | 521 593 0017 | 53- 39 | AB | DD | | C |
| " | 521 593 0017 | 58- 37 | AB | DD | | C |
| VCKYCY1EB103K | 567 593 0417 | 53- 40 | AB | DD | | C |
| VCKYCY1EB472K | 521 593 0054 | 49- 27 | AA | DD | | C |
| " | 521 593 0054 | 52- 37 | AA | DD | | C |
| VCKYCY1EF223Z | 567 593 0398 | 56- 10 | AA | DD | | C |
| VCKYCY1HB102K | 521 593 0030 | 49- 28 | AA | DD | | C |
| " | 521 593 0030 | 50- 25 | AA | DD | | C |
| " | 521 593 0030 | 51- 40 | AA | DD | | C |
| " | 521 593 0030 | 52- 38 | AA | DD | | C |
| " | 521 593 0030 | 53- 41 | AA | DD | | C |
| " | 521 593 0030 | 55- 18 | AA | DD | | C |
| " | 521 593 0030 | 58- 38 | AA | DD | | C |
| VCKYCY1HB222K | 521 593 0032 | 50- 92 | AA | DD | | C |
| " | 521 593 0032 | 55- 19 | AA | DD | | C |
| VCKYCY1HB471K | 521 593 0033 | 49- 29 | AA | DD | | C |
| " | 521 593 0033 | 50- 26 | AA | DD | | C |
| " | 521 593 0033 | 53- 42 | AA | DD | | C |
| " | 521 593 0033 | 55- 20 | AA | DD | | C |
| " | 521 593 0033 | 56- 11 | AA | DD | | C |
| VCKYCY1HF103Z | 567 593 0374 | 52- 39 | AA | DD | | C |
| " | 567 593 0374 | 58- 39 | AA | DD | | C |
| VCKYPU1EB223Z | 572 593 0312 | 54- 7 | AB | DD | | C |
| VCKYPU3SD150K | 572 593 0418 | 56- 12 | AC | DD | | C |
| VCKYTQ0JF106Z | 596 593 1290 | 52- 40 | AD | DJ | | C |
| VCCYNU1HM223K | 595 596 0107 | 50- 93 | AA | DD | | C |
| VHD0R5G4B42-1 | 595 570 0003 | 50- 27 | AF | DS | | B |
| VHD10DDA40+-1 | 572 570 0569 | 50- 29 | AD | DJ | | B |
| VHD1SS133//--1 | 541 570 5063 | 49- 32 | AA | DD | | B |
| " | 541 570 5063 | 50- 28 | AA | DD | | B |
| VHD1SS355//--1 | 595 570 0304 | 53- 43 | AB | DJ | | B |
| VHDDAN202U/-1 | 500 570 5015 | 51- 41 | AB | DD | | B |
| " | 500 570 5015 | 52- 41 | AB | DD | | B |
| " | 500 570 5015 | 53- 44 | AB | DD | | B |
| VHDDAP202U/-1 | 500 570 5023 | 51- 42 | AB | DD | | B |
| " | 500 570 5023 | 52- 42 | AB | DD | | B |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VHDDAP202U/-1 | 500 570 5023 | 53- 45 | AB | DD | | B |
| VHDDSM1D1//--1 | 572 570 0366 | 55- 21 | AB | DJ | | B |
| VHDDSS133//--1 | 500 570 5006 | 51- 43 | AA | DD | | B |
| " | 500 570 5006 | 52- 43 | AA | DD | | B |
| " | 500 570 5006 | 54- 8 | AA | DD | | B |
| " | 500 570 5006 | 55- 22 | AA | DD | | B |
| VHDM1FS4///--1 | 521 570 0024 | 52- 44 | AD | DJ | | B |
| VHDMA704A//--1 | 572 570 0328 | 51- 44 | AC | DJ | | B |
| " | 572 570 0328 | 52- 45 | AC | DJ | | B |
| VHDRA13++++-1 | 572 570 0560 | 51- 45 | AD | DJ | | B |
| " | 572 570 0560 | 52- 46 | AD | DJ | | B |
| " | 572 570 0560 | 55- 23 | AD | DJ | | B |
| VHDRB051L40-1 | 594 570 0251 | 58- 40 | AE | DS | | B |
| VHDRB451F//--1 | 594 570 0199 | 53- 46 | AD | DS | | B |
| " | 594 570 0199 | 58- 41 | AD | DS | | B |
| VHDRB751V40-1 | 521 570 0013 | 49- 31 | AD | DJ | | B |
| VHEH2S2C1//--1 | 595 571 0250 | 50- 30 | AB | DJ | | B |
| VHEH2S3B1//--1 | 595 571 0002 | 52- 47 | AC | DJ | | B |
| VHEMTZJ33B+-1 | 572 571 0264 | 50- 31 | AC | DJ | | B |
| VHEMTZJ4R7B-1 | 595 571 0272 | 50- 32 | AC | DJ | | B |
| VHEMTZJ8.2B-1 | 595 571 0265 | 50- 33 | AB | DJ | | B |
| VHERD22FB//--1 | 500 571 0074 | 51- 46 | AD | DJ | | B |
| VHERD5.1EB2-1 | 595 571 0006 | 49- 33 | AA | DD | | B |
| VHH103AT-2/-1 | 595 572 0003 | 51- 47 | AG | DS | | B |
| " | 595 572 0003 | 56- 13 | AG | DS | | B |
| VHHMSMDC014-1 | 596 572 0031 | 51- 48 | AF | DS | | B |
| VH1107AP66C-1 | 572 573 2908 | 58- 42 | BX | TF | | B |
| VH11085CZAD-1 | 572 573 2909 | 58- 43 | AH | DX | | B |
| VH1161622FH1C | 572 573 2848 | 52- 48 | BA | FX | | B |
| VH12309SC1H-1 | 572 573 2569 | 58- 44 | AT | EZ | | B |
| VH12309SC+-1 | 572 573 2849 | 53- 47 | AV | FG | | B |
| VH128F081L07F | 572 573 2902 | 31- 26 | AY | FQ | N | E |
| VH128F081L11F | 572 573 2973 | 38- 24 | AY | FQ | N | E |
| VH128F082L06S | 572 573 2912 | 37- 38 | BF | GN | N | E |
| VH128F161L01F | 572 573 2903 | 6- 8 | BA | FX | N | C |
| VH128F162L01F | 572 573 2904 | 6- 10 | BD | GN | N | C |
| VH128F322L22F | 572 573 2905 | 34- 22 | BH | HC | N | C |
| VH128F322L23F | 572 573 2906 | 34- 22 | BH | HC | N | C |
| VH128F322L32F | 572 573 2974 | 38- 23 | BG | GT | N | E |
| VH128F322L33F | | 38- 22 | BM | HR | N | E |
| VH129F04-01FC | 572 573 2494 | 49- 39 | AX | FG | | B |
| VH158C256AP-1 | 572 573 2235 | 53- 48 | BB | GD | | B |
| VH160852ATB-1 | 572 573 2910 | 58- 45 | AX | FG | | B |
| VH161LV6416-1 | 578 573 1169 | 52- 49 | AX | FG | | B |
| VH165946P110C | 572 573 2874 | 51- 49 | BB | GD | | B |
| VH165949P03-1 | 572 573 2875 | 53- 50 | BE | GN | | B |
| VH174HC132M-1 | 572 573 2497 | 49- 57 | AF | DS | | B |
| VH174HC74AM-1 | 572 573 2484 | 49- 58 | AE | DJ | | B |
| VH174LCX04M-1 | 578 573 1174 | 49- 59 | AE | DJ | | B |
| VH174LCX08MTC | 572 573 2090 | 52- 50 | AE | DJ | | B |
| " | 572 573 2090 | 58- 46 | AE | DJ | | B |
| VH174LCX14MTC | 572 573 2091 | 52- 51 | AE | DJ | | B |
| " | 572 573 2091 | 53- 51 | AE | DJ | | B |
| " | 572 573 2091 | 58- 47 | AE | DJ | | B |
| VH174LCX244MT | 572 573 2092 | 52- 52 | AM | DX | | B |
| " | 572 573 2092 | 53- 52 | AM | DX | | B |
| " | 572 573 2092 | 58- 48 | AM | DX | | B |
| VH174LCX245MT | 572 573 2093 | 52- 53 | AM | DX | | B |
| " | 572 573 2093 | 53- 53 | AM | DX | | B |
| " | 572 573 2093 | 58- 49 | AM | DX | | B |
| VH174LVX08M-1 | 578 573 1155 | 49- 60 | AE | DJ | | B |
| VH174LVX14M-1 | 572 573 2485 | 49- 61 | AE | DJ | | B |
| VH174LVX16128 | 578 573 1048 | 58- 50 | AP | EQ | | B |
| VH174VHC08/-1 | 572 573 1476 | 52- 54 | AE | DS | | B |
| VH174VHC32MTC | 572 573 2097 | 51- 50 | AD | DJ | | B |
| VH1755B300E-1 | 572 573 2911 | 58- 51 | BZ | TF | | B |
| VH17SZ125M5-1 | 572 573 2486 | 58- 52 | AE | DS | | B |
| VH185672011-1 | 572 573 2852 | 53- 54 | BV | RB | | B |
| VH190C363A+-1 | 572 573 2854 | 52- 56 | AU | FG | | B |
| VH190CF364A-1 | 572 573 2853 | 53- 55 | AU | FG | | B |
| VH1BU4066BCF1 | 595 573 3115 | 50- 34 | AD | DJ | | B |
| VH1CY25811S-1 | 572 573 2869 | 53- 56 | AN | EG | | B |
| VH1CY25814S-1 | 572 573 2870 | 53- 58 | AN | EG | | B |
| VH1D3032++++-1 | 572 573 2925 | 58- 55 | AX | FG | N | B |
| VH1D8501A+-1 | 572 573 2924 | 58- 56 | BS | MW | N | B |
| VH1EES02L400P | 572 573 2498 | 49- 34 | AG | DX | | B |
| VH1EES04L400P | 572 573 2414 | 58- 57 | AG | DX | | B |
| VH1H8D3063+-1 | 578 573 1163 | 50- 95 | AW | FG | | B |
| VH1H8S2320+-1 | 578 573 1145 | 51- 52 | AY | FQ | | B |
| " | 578 573 1145 | 52- 58 | AY | FQ | | B |
| VH1HC151MTC-1 | 572 573 2837 | 51- 53 | AE | DJ | | B |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VH1HG73C095-1 | 572 573 2459 | 52- 59 | AY | FQ | | B |
| VH1Hi207ECB-1 | 578 573 1292 | 53- 59 | AN | EQ | | B |
| VH1HN58V65A-1 | 572 573 2288 | 51- 54 | AW | FG | | B |
| " | 572 573 2288 | 52- 60 | AW | FG | | B |
| VH1LCX244SJ-1 | 572 573 2481 | 49- 36 | AG | DX | | B |
| VH1LCX574MT-1 | 572 573 2871 | 53- 60 | AF | DS | | B |
| VH1LCX74MTC-1 | 572 573 2444 | 53- 61 | AE | DJ | | B |
| VH1LHF80J01-1 | 595 573 6174 | 53- 62 | AX | FG | | B |
| VH1LM111718-1 | 578 573 1166 | 49- 37 | AH | DX | | B |
| VH1LM324D+-1 | 572 573 2445 | 51- 55 | AE | DJ | | B |
| VH1LM339D+-1 | 572 573 2446 | 51- 56 | AE | DJ | | B |
| VH1LM358DR+-1 | 578 573 1112 | 52- 61 | AF | DS | | B |
| VH1LM393D+-1 | 572 573 2447 | 53- 63 | AE | DJ | | B |
| VH1LM98513+-1 | 572 573 2872 | 52- 62 | AY | FQ | | B |
| VH1M3032ATC-1 | 572 573 2907 | 53- 64 | AT | EZ | N | B |
| VH1M51957BFP1 | 567 573 0126 | 51- 57 | AH | DX | | B |
| " | 567 573 0126 | 52- 63 | AH | DX | | B |
| " | 567 573 0126 | 53- 65 | AH | DX | | B |
| VH1M87J8310-1 | 572 573 2841 | 52- 64 | BQ | LP | | B |
| VH1M87L4240-1 | 572 573 2842 | 52- 65 | BG | GT | | B |
| VH1M87M1290-1 | 572 573 2843 | 52- 66 | BZ | TF | | B |
| VH1MAX3225E-1 | 572 573 2482 | 49- 38 | AT | EZ | | B |
| " | 572 573 2482 | 53- 66 | AT | EZ | | B |
| VH1MBLV064N-1 | 572 573 2873 | 52- 67 | BA | FX | | B |
| VH1MN195004-1 | 572 573 2468 | 49- 40 | BN | HZ | | B |
| VH1MTD2007F-1 | 567 573 1405 | 52- 68 | AU | EZ | | B |
| VH1NJM2113M-1 | 595 573 3547 | 49- 42 | AG | DS | | B |
| VH1NJM2903M/- | 572 573 0025 | 58- 60 | AD | DJ | | B |
| VH1NJM4558MF1 | 572 573 1736 | 49- 43 | AE | DJ | | B |
| " | 572 573 1736 | 50- 35 | AE | DJ | | B |
| VH1NJU4051M-1 | 595 573 3786 | 49- 44 | AG | DX | | B |
| VH1NJU4052BMF | 578 573 0533 | 49- 45 | AG | DS | | B |
| VH1NJU4053BMF | 578 573 0363 | 49- 46 | AG | DS | | B |
| VH1NJU6356E-1 | 572 573 1737 | 53- 67 | AK | DX | | B |
| " | 572 573 1737 | 58- 61 | AK | DX | | B |
| VH1PM2500+-1 | 572 573 2409 | 53- 68 | BP | LP | | B |
| VH1PST591CMT1 | 595 573 2858 | 49- 47 | AE | DS | | B |
| VH1PST5911M-1 | 585 573 1696 | 49- 48 | AG | DS | | B |
| VH1PST598DN-1 | 572 573 2472 | 58- 62 | AF | DS | | B |
| VH1PST5981N-1 | 523 573 0081 | 58- 63 | AF | DS | | B |
| VH1PST994C+-1 | 572 573 2496 | 49- 49 | AG | DS | | B |
| VH1R1117D25-1 | 572 573 2900 | 58- 64 | AG | DS | | B |
| VH1SD4M16L1-1 | 572 573 2410 | 49- 50 | AZ | FX | | B |
| VH1SD8M16L1-1 | 572 573 2460 | 52- 70 | BB | GD | | B |
| " | 572 573 2460 | 53- 69 | BB | GD | | B |
| VH1SH770910-1 | 578 573 1168 | 49- 51 | BH | GX | | B |
| " | 578 573 1168 | 53- 70 | BH | GX | | B |
| VH1SLA7024MT/- | 572 573 1217 | 55- 24 | AS | EQ | | B |
| VH1SLA7031M-1 | 572 573 2844 | 51- 59 | AQ | EQ | | B |
| " | 572 573 2844 | 55- 25 | AQ | EQ | | B |
| VH1SLA7032M-1 | 572 573 2897 | 51- 60 | AR | EQ | | B |
| VH1SR1024-7LL | 572 573 2461 | 53- 71 | AU | EZ | | B |
| VH1SR1024L15J | 572 573 2483 | 49- 52 | AU | FG | | B |
| VH1TA31076F-1 | 572 573 1739 | 50- 36 | AH | DX | | B |
| VH1TA7291AS-1 | 572 573 2570 | 51- 61 | AG | DX | | B |
| VH1TD62003AF/- | 572 573 2085 | 51- 62 | AE | DS | | B |
| " | 572 573 2085 | 52- 71 | AE | DS | | B |
| VH1TD62503F/- | 572 573 0907 | 49- 54 | AG | DX | | B |
| " | 572 573 0907 | 52- 72 | AG | DX | | B |
| VH1THS56F//--1 | 595 573 3362 | 50- 97 | AS | EZ | | B |
| VH1TR88017S-1 | 572 573 2469 | 49- 55 | BA | FX | | B |
| VH1UPD65946-1 | 572 573 2470 | 49- 56 | BB | GD | | B |
| VH1UPD85632-1 | 572 573 2845 | 52- 73 | BM | HV | | B |
| VH1UPD85658-1 | 572 573 2846 | 52- 74 | BV | RB | | B |
| VH1VC4051MT-1 | 572 573 2856 | 51- 63 | AF | DS | | B |
| VH1VHC14MTC-1 | 572 573 2847 | 51- 64 | AD | DJ | | B |
| VH1VHCT14AM-1 | 578 573 1092 | 51- 65 | AE | DJ | | B |
| VH1VHCT244T-1 | 595 573 5596 | 55- 26 | AK | DX | | B |
| VH1VT574MTC-1 | 572 573 2857 | 51- 67 | AF | DS | | B |
| VHP1LHEE-002A | 578 574 0042 | 49- 62 | AC | DJ | | B |
| VHP1LHLE-002A | 578 574 0043 | 54- 9 | AC | DJ | | B |
| VHPGP1A22LC-1 | 572 574 0100 | 6- 15 | AK | EB | | B |
| VHPGP1A71L3-1 | 572 568 0153 | 11- 22 | AG | DS | N | B |
| " | 572 568 0153 | 13- 5 | AG | DS | N | B |
| " | 572 568 0153 | 15- 28 | AG | DS | N | B |
| " | 572 568 0153 | 17- 3 | AG | DS | N | B |
| " | 572 568 0153 | 21- 25 | AG | DS | N | B |
| " | 572 568 0153 | 23- 15 | AG | DS | N | B |
| " | 572 568 0153 | 25- 9 | AG | DS | N | B |
| " | 572 568 0153 | 28- 4 | AG | DS | N | B |
| " | 572 568 0153 | 28- 40 | AG | DS | N | B |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VHPGP1A71L3-1 | 572 568 0153 | 31- 32 | AG | DS | N | B |
| VHPGP2C21//1 | 572 568 0107 | 20- 1 | BE | GN | | B |
| VHPGP3A38//1 | 572 574 0040 | 6- 11 | AH | DX | | B |
| VHPLT1F67AF-1 | 595 574 0220 | 52- 75 | AC | DJ | | B |
| " | 595 574 0220 | 53- 72 | AC | DJ | | B |
| VHPLT9400E/-1 | 572 574 0310 | 54- 10 | AK | EB | | B |
| VHPPC814X1+-1 | 572 568 0154 | 50- 37 | AD | DJ | | B |
| VHPPC817D//1 | 596 574 0016 | 50- 38 | AD | DJ | | B |
| VHPTLP624-1BV | 572 574 0308 | 50- 39 | AG | DX | | B |
| VHVDSS-401M// | 578 577 0027 | 50- 40 | AH | DX | | B |
| VHVTN07G101-1 | 595 577 0103 | 50- 42 | AB | DJ | | B |
| VHVTNR5V471K/ | 578 577 0026 | 50- 41 | AD | DJ | | B |
| VRD-HT2EY100J | 595 581 0453 | 50- 43 | AA | DD | | C |
| VRD-HT2EY102J | 507 581 5010 | 54- 11 | AA | DD | | C |
| VRD-HT2EY104J | 505 581 5003 | 50- 44 | AA | DD | | C |
| " | 505 581 5003 | 55- 28 | AA | DD | | C |
| VRD-HT2EY111J | 588 581 0061 | 54- 12 | AA | DD | | C |
| VRD-HT2EY124J | 595 581 0454 | 50- 45 | AA | DD | | C |
| VRD-HT2EY151J | 541 581 5470 | 54- 13 | AA | DD | | C |
| VRD-HT2EY164J | 588 581 0069 | 50- 46 | AA | DD | | C |
| VRD-HT2EY183J | 571 581 0415 | 50- 47 | AA | DD | | C |
| VRD-HT2EY204J | 507 581 5013 | 50- 48 | AA | DD | | C |
| VRD-HT2EY224J | 579 581 0158 | 50- 49 | AA | DD | | C |
| VRD-HT2EY242J | 571 581 0369 | 55- 27 | AA | DD | | C |
| VRD-HT2EY300J | 588 581 0088 | 50- 50 | AA | DD | | C |
| VRD-HT2EY302J | 581 581 0003 | 54- 14 | AA | DD | | C |
| VRD-HT2EY303J | 579 581 0123 | 50- 52 | AA | DD | | C |
| VRD-HT2EY471J | 507 581 5017 | 50- 53 | AA | DD | | C |
| VRD-HT2EY472J | 507 581 5018 | 50- 98 | AA | DD | | C |
| VRD-HT2EY473J | 507 581 5019 | 54- 15 | AA | DD | | C |
| " | 507 581 5019 | 55- 38 | AA | DD | | C |
| VRD-HT2EY562J | 595 581 0480 | 55- 29 | AA | DD | | C |
| VRD-HT2EY682J | 571 581 0452 | 50- 55 | AA | DD | | C |
| " | 571 581 0452 | 54- 16 | AA | DD | | C |
| VRD-HT2EY751J | 507 581 5045 | 49- 63 | AA | DD | | C |
| VRD-HT2EY910J | 577 581 0025 | 50- 56 | AA | DD | | C |
| VRD-HT2EY911J | 588 581 0035 | 54- 17 | AA | DD | | C |
| VRD-HT2HY471J | 579 581 0125 | 49- 64 | AA | DD | | C |
| VRD-RC2EY103J | 500 581 5014 | 56- 15 | AA | DD | | C |
| VRS-CY1JD270J | 521 581 0007 | 51- 69 | AA | DD | | C |
| VRS-CZ1JD000J | 521 581 0082 | 49- 65 | AA | DD | | C |
| " | 521 581 0082 | 50- 57 | AA | DD | | C |
| " | 521 581 0082 | 51- 70 | AA | DD | | C |
| " | 521 581 0082 | 52- 76 | AA | DD | | C |
| " | 521 581 0082 | 53- 73 | AA | DD | | C |
| " | 521 581 0082 | 58- 67 | AA | DD | | C |
| VRS-CZ1JD100J | 567 581 0524 | 53- 74 | AA | DD | | C |
| " | 567 581 0524 | 58- 68 | AA | DD | | C |
| VRS-CZ1JD101J | 521 581 0137 | 49- 67 | AA | DD | | C |
| " | 521 581 0137 | 51- 71 | AA | DD | | C |
| " | 521 581 0137 | 52- 77 | AA | DD | | C |
| " | 521 581 0137 | 53- 75 | AA | DD | | C |
| " | 521 581 0137 | 56- 16 | AA | DD | | C |
| VRS-CZ1JD102J | 521 581 0093 | 49- 68 | AA | DD | | C |
| " | 521 581 0093 | 50- 58 | AA | DD | | C |
| " | 521 581 0093 | 51- 72 | AA | DD | | C |
| " | 521 581 0093 | 52- 78 | AA | DD | | C |
| " | 521 581 0093 | 53- 76 | AA | DD | | C |
| " | 521 581 0093 | 55- 30 | AA | DD | | C |
| " | 521 581 0093 | 58- 69 | AA | DD | | C |
| VRS-CZ1JD103F | 521 581 0127 | 49- 69 | AA | DD | | C |
| " | 521 581 0127 | 51- 73 | AA | DD | | C |
| " | 521 581 0127 | 52- 79 | AA | DD | | C |
| VRS-CZ1JD103J | 521 581 0085 | 49- 70 | AA | DD | | C |
| " | 521 581 0085 | 50- 59 | AA | DD | | C |
| " | 521 581 0085 | 51- 74 | AA | DD | | C |
| " | 521 581 0085 | 52- 80 | AA | DD | | C |
| " | 521 581 0085 | 53- 77 | AA | DD | | C |
| " | 521 581 0085 | 58- 70 | AA | DD | | C |
| VRS-CZ1JD104F | 521 581 0253 | 51- 75 | AA | DD | | C |
| VRS-CZ1JD104J | 521 581 0083 | 49- 71 | AA | DD | | C |
| " | 521 581 0083 | 51- 76 | AA | DD | | C |
| VRS-CZ1JD105J | 521 581 0094 | 51- 77 | AA | DD | | C |
| " | 521 581 0094 | 52- 81 | AA | DD | | C |
| " | 521 581 0094 | 53- 78 | AA | DD | | C |
| " | 521 581 0094 | 58- 71 | AA | DD | | C |
| VRS-CZ1JD113F | 567 581 0525 | 51- 78 | AA | DD | | C |
| VRS-CZ1JD113J | 521 581 0095 | 50- 60 | AA | DD | | C |
| VRS-CZ1JD121J | 567 581 0526 | 53- 79 | AA | DD | | C |
| VRS-CZ1JD122J | 521 581 0096 | 52- 83 | AA | DD | | C |
| VRS-CZ1JD123J | 521 581 0097 | 49- 72 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|---------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VRS-CZ1JD123J | 521 581 0097 | 52- 84 | AA | DD | | C |
| VRS-CZ1JD133F | 572 581 2079 | 49- 73 | AA | DD | | C |
| VRS-CZ1JD133J | 572 581 2155 | 52- 85 | AA | DD | | C |
| VRS-CZ1JD151J | 567 581 0527 | 50- 99 | AA | DD | | C |
| " | 567 581 0527 | 53- 80 | AA | DD | | C |
| VRS-CZ1JD152J | 521 581 0175 | 49- 74 | AA | DD | | C |
| " | 521 581 0175 | 52- 86 | AA | DD | | C |
| " | 521 581 0175 | 53- 81 | AA | DD | | C |
| " | 521 581 0175 | 58- 73 | AA | DD | | C |
| VRS-CZ1JD153F | 521 581 0290 | 49- 75 | AB | DD | | C |
| VRS-CZ1JD153J | 567 581 0528 | 50- 61 | AA | DD | | C |
| VRS-CZ1JD162J | 578 581 0333 | 51- 79 | AA | DD | | C |
| VRS-CZ1JD182J | 521 581 0189 | 53- 82 | AA | DD | | C |
| VRS-CZ1JD183J | 521 581 0102 | 49- 76 | AA | DD | | C |
| " | 521 581 0102 | 50- 62 | AA | DD | | C |
| VRS-CZ1JD201J | 521 581 0254 | 51- 80 | AA | DD | | C |
| " | 521 581 0254 | 58- 74 | AA | DD | | C |
| VRS-CZ1JD202J | 567 581 0695 | 51- 81 | AA | DD | | C |
| " | 567 581 0695 | 53- 83 | AA | DD | | C |
| VRS-CZ1JD203F | 521 581 0131 | 52- 88 | AA | DD | | C |
| VRS-CZ1JD203J | 567 581 0530 | 49- 77 | AA | DD | | C |
| " | 567 581 0530 | 50- 63 | AA | DD | | C |
| " | 567 581 0530 | 52- 89 | AA | DD | | C |
| VRS-CZ1JD220J | 567 581 0532 | 52- 90 | AA | DD | | C |
| " | 567 581 0532 | 58- 75 | AA | DD | | C |
| VRS-CZ1JD221J | 567 581 0533 | 51- 82 | AA | DD | | C |
| " | 567 581 0533 | 52- 91 | AA | DD | | C |
| VRS-CZ1JD222J | 567 581 0534 | 49- 78 | AA | DD | | C |
| " | 567 581 0534 | 50- 100 | AA | DD | | C |
| VRS-CZ1JD223J | 521 581 0104 | 50- 64 | AA | DD | | C |
| VRS-CZ1JD242J | 521 581 0219 | 52- 92 | AA | DD | | C |
| " | 521 581 0219 | 55- 32 | AA | DD | | C |
| VRS-CZ1JD243J | 521 581 0190 | 50- 65 | AA | DD | | C |
| VRS-CZ1JD271J | 572 581 2153 | 53- 84 | AA | DD | | C |
| " | 572 581 2153 | 55- 33 | AA | DD | | C |
| VRS-CZ1JD272J | 567 581 0634 | 50- 66 | AA | DD | | C |
| " | 567 581 0634 | 51- 84 | AA | DD | | C |
| " | 567 581 0634 | 53- 85 | AA | DD | | C |
| VRS-CZ1JD273F | 572 581 2080 | 49- 79 | AA | DD | | C |
| " | 572 581 2080 | 51- 85 | AA | DD | | C |
| VRS-CZ1JD273J | 572 581 2081 | 49- 80 | AA | DD | | C |
| " | 572 581 2081 | 50- 67 | AA | DD | | C |
| VRS-CZ1JD302J | 572 581 2072 | 49- 81 | AA | DD | | C |
| VRS-CZ1JD303J | 572 581 2074 | 51- 86 | AA | DD | | C |
| " | 572 581 2074 | 52- 93 | AA | DD | | C |
| VRS-CZ1JD330J | 521 581 0202 | 49- 82 | AA | DD | | C |
| " | 521 581 0202 | 51- 87 | AA | DD | | C |
| " | 521 581 0202 | 52- 94 | AA | DD | | C |
| " | 521 581 0202 | 58- 76 | AA | DD | | C |
| VRS-CZ1JD331J | 567 581 0537 | 50- 101 | AA | DD | | C |
| " | 567 581 0537 | 52- 95 | AA | DD | | C |
| VRS-CZ1JD332F | 521 581 0193 | 52- 96 | AA | DD | | C |
| VRS-CZ1JD332J | 521 581 0107 | 50- 68 | AA | DD | | C |
| " | 521 581 0107 | 58- 77 | AA | DD | | C |
| VRS-CZ1JD333J | 521 581 0124 | 49- 83 | AA | DD | | C |
| " | 521 581 0124 | 53- 86 | AA | DD | | C |
| VRS-CZ1JD362J | 521 581 0284 | 52- 97 | AA | DD | | C |
| VRS-CZ1JD363J | 567 581 0616 | 49- 84 | AA | DD | | C |
| " | 567 581 0616 | 50- 102 | AA | DD | | C |
| VRS-CZ1JD391J | 521 581 0203 | 51- 88 | AA | DD | | C |
| VRS-CZ1JD393F | 572 581 2082 | 49- 85 | AA | DD | | C |
| VRS-CZ1JD393J | 521 581 0285 | 49- 86 | AA | DD | | C |
| " | 521 581 0285 | 50- 103 | AA | DD | | C |
| VRS-CZ1JD470J | 521 581 0170 | 52- 98 | AA | DD | | C |
| " | 521 581 0170 | 53- 87 | AA | DD | | C |
| " | 521 581 0170 | 58- 78 | AA | DD | | C |
| VRS-CZ1JD471J | 567 581 0617 | 49- 87 | AA | DD | | C |
| " | 567 581 0617 | 52- 99 | AA | DD | | C |
| " | 567 581 0617 | 53- 88 | AA | DD | | C |
| VRS-CZ1JD472F | 572 581 2062 | 52- 100 | AA | DD | | C |
| VRS-CZ1JD472J | 521 581 0088 | 49- 88 | AA | DD | | C |
| " | 521 581 0088 | 50- 104 | AA | DD | | C |
| " | 521 581 0088 | 51- 89 | AA | DD | | C |
| " | 521 581 0088 | 52- 101 | AA | DD | | C |
| " | 521 581 0088 | 53- 89 | AA | DD | | C |
| VRS-CZ1JD473J | 521 581 0109 | 49- 89 | AA | DD | | C |
| " | 521 581 0109 | 51- 90 | AA | DD | | C |
| " | 521 581 0109 | 52- 102 | AA | DD | | C |
| " | 521 581 0109 | 53- 90 | AA | DD | | C |
| " | 521 581 0109 | 55- 34 | AA | DD | | C |
| VRS-CZ1JD512J | 578 581 0332 | 50- 70 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| VRS-CZ1JD513J | 572 581 2083 | 49- 90 | AA | DD | | C |
| " | 572 581 2083 | 50- 71 | AA | DD | | C |
| VRS-CZ1JD560J | 572 581 2084 | 49- 91 | AA | DD | | C |
| VRS-CZ1JD621J | 572 581 2064 | 50- 72 | AA | DD | | C |
| VRS-CZ1JD622J | 578 581 0317 | 51- 91 | AA | DD | | C |
| VRS-CZ1JD680J | 572 581 2065 | 53- 91 | AA | DD | | C |
| VRS-CZ1JD682J | 521 581 0226 | 49- 92 | AA | DD | | C |
| VRS-CZ1JD683J | 567 581 0543 | 49- 93 | AA | DD | | C |
| " | 567 581 0543 | 50-105 | AA | DD | | C |
| VRS-CZ1JD753J | 521 581 0198 | 49- 94 | AA | DD | | C |
| VRS-CZ1JD821J | 572 581 2073 | 50-106 | AA | DD | | C |
| " | 572 581 2073 | 51- 93 | AA | DD | | C |
| VRS-CZ1JD822J | 572 581 2066 | 50-107 | AA | DD | | C |
| VRS-CZ1JD823J | 572 581 2067 | 58- 79 | AA | DD | | C |
| VRS-CZ1JD912J | 572 581 2086 | 49- 95 | AA | DD | | C |
| VRS-CZ1JD913J | 521 581 0199 | 49- 96 | AA | DD | | C |
| VRS-HT3DA1R0J | 567 581 0073 | 55- 35 | AB | DD | | C |
| VRS-HT3DAR51J | 572 581 2234 | 52-105 | AC | DD | | C |
| VRS-RA3AA202J | 572 581 1845 | 50- 74 | AB | DD | | C |
| VRS-RA3AA472J | 572 581 1846 | 50-108 | AB | DD | | C |
| VRS-TP2BD1R0J | 585 581 0486 | 51- 94 | AA | DD | | C |
| VS2SA1576A/-1 | 521 576 0072 | 51- 96 | AB | DJ | | B |
| VS2SA1807-P-1 | 595 576 0368 | 50- 76 | AE | DS | | B |
| VS2SB1197/-1 | 571 576 0349 | 52-106 | AC | DJ | | B |
| VS2SD1198K/-1 | 572 576 0510 | 53- 92 | AC | DJ | | B |
| VS2SC1740SR-1 | 595 576 0048 | 54- 18 | AB | DD | | B |
| VS2SC2412K/-1 | 500 576 5005 | 51- 97 | AB | DD | | B |
| " | 500 576 5005 | 53- 93 | AB | DD | | B |
| VS2SC2412KS-1 | 507 576 5010 | 50- 77 | AB | DD | | B |
| VS2SC3415-P-1 | 595 576 0378 | 50- 78 | AP | EQ | | B |
| VS2SD1266A0-1 | 572 576 0505 | 50- 79 | AF | DS | | B |
| VS2SD1857A+-1 | 572 576 0604 | 56- 17 | AB | DJ | | B |
| VS2SD592A/-1 | 572 576 0462 | 49-100 | AE | DJ | | B |
| VS2SD592A-S-1 | 595 576 0471 | 50- 80 | AK | DX | | B |
| VS2SJ243///-1 | 521 576 0057 | 53- 94 | AD | DJ | | B |
| VSDTA114EUA-1 | 594 576 0224 | 49- 97 | AC | DJ | | B |
| " | 594 576 0224 | 52-107 | AC | DJ | | B |
| VSDTA114YUA-1 | 596 576 0538 | 51- 98 | AC | DJ | | B |
| VSDTA144EUA-1 | 596 576 0539 | 51- 99 | AC | DJ | | B |
| VSDTC114EK/-1 | 595 576 0038 | 58- 80 | AB | DD | | B |
| VSDTC114EUA-1 | 594 576 0225 | 49- 98 | AC | DJ | | B |
| VSDTC114YK/-1 | 507 576 5005 | 58- 81 | AC | ZZ | | B |
| VSDTC114YUA-1 | 594 576 0248 | 51-100 | AB | DJ | | B |
| " | 594 576 0248 | 52-108 | AB | DJ | | B |
| " | 594 576 0248 | 53- 95 | AB | DJ | | B |
| VSDTC143ZKA-1 | 594 576 0231 | 50- 75 | AC | DJ | | B |
| VSDTC363EU+-1 | 572 576 0582 | 49- 99 | AC | DJ | | B |
| VVLLM065HB1-1 | 572 567 0010 | 4- 7 | CB | TX | | B |
| 【X】 | | | | | | |
| XBBS230P08000 | 572 970 2308 | 22- 1 | AA | DD | | C |
| XBBS230P04000 | 541 970 5027 | 20- 34 | AA | DD | | C |
| XBBS230P06000 | 541 970 5028 | 20- 2 | AA | DD | | C |
| " | 541 970 5028 | 58- 82 | AA | DD | | C |
| XBBS230P08000 | 571 970 0241 | 30- 27 | AA | DD | | C |
| XBBS240P06000 | 572 970 0626 | 7- 3 | AA | DD | | C |
| XBBS240P10000 | 577 970 0051 | 6- 16 | AA | DD | | C |
| XBBS240P14000 | 572 970 1400 | 6- 12 | AA | DD | | C |
| XBBSE40P06000 | 572 970 1465 | 36- 31 | AA | DD | | C |
| XBPSD30P06KS0 | 541 970 0016 | 24- 15 | AA | DD | | C |
| " | 541 970 0016 | 3- 4 | AA | DD | | C |
| XBPSD30P08K00 | 541 970 0014 | 31- 30 | AA | DD | | C |
| XBPSD30P08KS0 | 541 970 1097 | 37- 21 | AA | DD | | C |
| XBPSD30P12XS0 | 572 970 2567 | 8- 4 | AA | DD | N | C |
| XBPSD40P06K00 | 541 970 1038 | 33- 7 | AA | DD | | C |
| " | 541 970 1038 | 37- 9 | AA | DD | | C |
| XBPSD40P08K00 | 541 970 1106 | 31- 25 | AA | DD | | C |
| " | 541 970 1106 | 31- 54 | AA | DD | | C |
| XBPSD40P40XS0 | 572 970 1504 | 37- 10 | AA | DD | | C |
| XPBSE26P08000 | 572 970 2332 | 37- 42 | AA | DD | | C |
| XPBSE30P06000 | 541 970 0020 | 38- 4 | AA | DD | | C |
| XBTSE40P06000 | 572 970 0638 | 2- 24 | AA | DD | | C |
| XEBSD30P06000 | 578 970 0102 | 13- 28 | AA | DD | | C |
| " | 578 970 0102 | 19- 23 | AA | DD | | C |
| " | 578 970 0102 | 20- 7 | AA | DD | | C |
| " | 578 970 0102 | 24- 14 | AA | DD | | C |
| " | 578 970 0102 | 25- 38 | AA | DD | | C |
| XEBSD30P08000 | 578 970 0105 | 17- 26 | AA | DD | | C |
| " | 578 970 0105 | 18- 17 | AA | DD | | C |
| " | 578 970 0105 | 19- 30 | AA | DD | | C |
| " | 578 970 0105 | 20- 11 | AA | DD | | C |
| " | 578 970 0105 | 22- 17 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| XEBSD30P08000 | 578 970 0105 | 24- 4 | AA | DD | | C |
| " | 578 970 0105 | 25- 24 | AA | DD | | C |
| " | 578 970 0105 | 28- 39 | AA | DD | | C |
| " | 578 970 0105 | 29- 23 | AA | DD | | C |
| " | 578 970 0105 | 3- 13 | AA | DD | | C |
| " | 578 970 0105 | 31- 49 | AA | DD | | C |
| " | 578 970 0105 | 8- 2 | AA | DD | | C |
| XEBSD30P10000 | 578 970 0106 | 20- 36 | AA | DD | | C |
| " | 578 970 0106 | 32- 18 | AA | DD | | C |
| XEBSD30P12000 | 572 970 0571 | 24- 53 | AA | DD | | C |
| XEBSD30P16000 | 578 970 0107 | 17- 5 | AA | DD | | C |
| " | 578 970 0107 | 31- 3 | AA | DD | | C |
| XEBSD40P08000 | 572 970 0587 | 10- 21 | AA | DD | | C |
| " | 572 970 0587 | 11- 24 | AA | DD | | C |
| " | 572 970 0587 | 11- 31 | AA | DD | | C |
| " | 572 970 0587 | 20- 40 | AA | DD | | C |
| " | 572 970 0587 | 23- 7 | AA | DD | | C |
| " | 572 970 0587 | 27- 31 | AA | DD | | C |
| " | 572 970 0587 | 30- 31 | AA | DD | | C |
| " | 572 970 0587 | 32- 11 | AA | DD | | C |
| " | 572 970 0587 | 32- 19 | AA | DD | | C |
| " | 572 970 0587 | 33- 13 | AA | DD | | C |
| XEBSD40P10000 | 572 970 0588 | 22- 22 | AA | DD | | C |
| " | 572 970 0588 | 2- 27 | AA | DD | | C |
| XEBSD40P30000 | 572 970 1429 | 1- 28 | AA | DD | | C |
| XEBSD40P35000 | 572 970 2564 | 33- 5 | AC | DD | N | C |
| XEBSE30P06000 | 578 970 0082 | 28- 13 | AA | DD | | C |
| " | 578 970 0082 | 29- 3 | AA | DD | | C |
| XEBSE30P08000 | 595 970 0121 | 1- 25 | AA | DD | | C |
| " | 595 970 0121 | 13- 13 | AA | DD | | C |
| " | 595 970 0121 | 16- 29 | AA | DD | | C |
| " | 595 970 0121 | 16- 5 | AA | DD | | C |
| XEBSE30P10000 | 595 970 0122 | 37- 8 | AA | DD | | C |
| XEBSE30P12000 | 595 970 0345 | 37- 7 | AA | DD | | C |
| XEBSE40P08000 | 572 970 1505 | 10- 2 | AA | DD | | C |
| " | 572 970 1505 | 1- 4 | AA | DD | | C |
| " | 572 970 1505 | 16- 14 | AA | DD | | C |
| " | 572 970 1505 | 17- 19 | AA | DD | | C |
| " | 572 970 1505 | 2- 25 | AA | DD | | C |
| " | 572 970 1505 | 28- 35 | AA | DD | | C |
| " | 572 970 1505 | 4- 2 | AA | DD | | C |
| XEBSE40P10000 | 572 970 0575 | 13- 2 | AA | DD | | C |
| " | 572 970 0575 | 14- 22 | AA | DD | | C |
| " | 572 970 0575 | 15- 13 | AA | DD | | C |
| XEPSD30P05000 | 578 970 0091 | 3- 11 | AA | DD | | C |
| XEPSD30P06X00 | 595 970 0301 | 13- 17 | AA | DD | | C |
| XEPSD30P08000 | 595 970 0137 | 4- 4 | AA | DD | | C |
| XEPSD30P08X00 | 595 970 0136 | 20- 51 | AA | DD | | C |
| XEPSD40P06000 | 578 970 0083 | 7- 28 | AA | DD | | C |
| XEPSD40P40000 | 572 970 2572 | 31- 43 | AC | DD | N | C |
| XHBS230P06000 | 572 970 1971 | 24- 17 | AA | DD | | C |
| " | 572 970 1971 | 25- 40 | AA | DD | | C |
| XHBS230P08000 | 572 970 2002 | 24- 3 | AA | DD | | C |
| XHBS240P08000 | 572 970 2004 | 24- 47 | AB | DD | | C |
| XHBS230P04000 | 578 970 0072 | 24- 29 | AA | DD | | C |
| " | 578 970 0072 | 25- 21 | AA | DD | | C |
| " | 578 970 0072 | 6- 5 | AA | DD | | C |
| XHBS230P05000 | 595 970 0162 | 38- 10 | AA | DD | | C |
| XHBS230P06000 | 541 970 1017 | 20- 42 | AA | DD | | C |
| " | 541 970 1017 | 21- 15 | AA | DD | | C |
| " | 541 970 1017 | 23- 3 | AA | DD | | C |
| " | 541 970 1017 | 24- 19 | AA | DD | | C |
| " | 541 970 1017 | 24- 46 | AA | DD | | C |
| " | 541 970 1017 | 25- 31 | AA | DD | | C |
| " | 541 970 1017 | 26- 4 | AA | DD | | C |
| " | 541 970 1017 | 28- 2 | AA | DD | | C |
| " | 541 970 1017 | 30- 18 | AA | DD | | C |
| " | 541 970 1017 | 38- 1 | AA | DD | | C |
| " | 541 970 1017 | 6- 20 | AA | DD | | C |
| " | 541 970 1017 | 6- 7 | AA | DD | | C |
| " | 541 970 1017 | 7- 18 | AA | DD | | C |
| XHBS230P08000 | 578 970 0060 | 38- 15 | AA | DD | | C |
| XHBS230P08KS0 | 572 970 2565 | 31- 55 | AB | DD | N | C |
| " | 572 970 2565 | 6- 2 | AB | DD | N | C |
| " | 572 970 2565 | 9- 4 | AB | DD | N | C |
| XHBS230P10000 | 572 970 0530 | 19- 28 | AA | DD | | C |
| " | 572 970 0530 | 24- 31 | AA | DD | | C |
| " | 572 970 0530 | 25- 22 | AA | DD | | C |
| XHBS230P14000 | 572 970 1532 | 30- 2 | AA | DD | | C |
| XHBS240P06000 | 578 970 0073 | 29- 20 | AA | DD | | C |
| " | 578 970 0073 | 7- 30 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| XHBSE30P04000 | 595 970 0160 | 34- 20 | AA | DD | | C |
| XHBSE30P06000 | 578 970 0070 | 11- 3 | AA | DD | | C |
| " | 578 970 0070 | 1- 31 | AA | DD | | C |
| " | 578 970 0070 | 31- 18 | AA | DD | | C |
| " | 578 970 0070 | 34- 6 | AA | DD | | C |
| " | 578 970 0070 | 37- 13 | AA | DD | | C |
| " | 578 970 0070 | 38- 27 | AA | DD | | C |
| XHBSE30P08000 | 595 970 0163 | 11- 30 | AA | DD | | C |
| " | 595 970 0163 | 1- 35 | AA | DD | | C |
| " | 595 970 0163 | 20- 13 | AA | DD | | C |
| " | 595 970 0163 | 2- 22 | AA | DD | | C |
| " | 595 970 0163 | 29- 18 | AA | DD | | C |
| " | 595 970 0163 | 30- 19 | AA | DD | | C |
| " | 595 970 0163 | 31- 36 | AA | DD | | C |
| " | 595 970 0163 | 31- 9 | AA | DD | | C |
| " | 595 970 0163 | 34- 19 | AA | DD | | C |
| " | 595 970 0163 | 6- 6 | AA | DD | | C |
| XHBSE40P05000 | 572 970 2023 | 37- 32 | AB | DD | | C |
| XHBSE40P08000 | 572 970 0539 | 11- 29 | AA | DD | | C |
| " | 572 970 0539 | 11- 32 | AA | DD | | C |
| " | 572 970 0539 | 12- 26 | AA | DD | | C |
| " | 572 970 0539 | 1- 24 | AA | DD | | C |
| " | 572 970 0539 | 12- 8 | AA | DD | | C |
| " | 572 970 0539 | 13- 29 | AA | DD | | C |
| " | 572 970 0539 | 17- 45 | AA | DD | | C |
| " | 572 970 0539 | 2- 23 | AA | DD | | C |
| " | 572 970 0539 | 23- 28 | AA | DD | | C |
| " | 572 970 0539 | 26- 2 | AA | DD | | C |
| " | 572 970 0539 | 27- 3 | AA | DD | | C |
| " | 572 970 0539 | 28- 38 | AA | DD | | C |
| " | 572 970 0539 | 29- 15 | AA | DD | | C |
| " | 572 970 0539 | 30- 22 | AA | DD | | C |
| " | 572 970 0539 | 31- 19 | AA | DD | | C |
| " | 572 970 0539 | 33- 8 | AA | DD | | C |
| " | 572 970 0539 | 37- 46 | AA | DD | | C |
| " | 572 970 0539 | 6- 21 | AA | DD | | C |
| " | 572 970 0539 | 9- 1 | AA | DD | | C |
| XHBSE40P10000 | 595 970 0167 | 37- 47 | AA | DD | | C |
| XHBSE40P12000 | 572 970 1585 | 16- 17 | AA | DD | | C |
| XHSSE30P10000 | 594 970 0122 | 4- 15 | AA | DD | | C |
| XJBSD40P08000 | 572 970 1466 | 5- 10 | AA | DD | | C |
| XJBSD40P12000 | 572 970 0570 | 5- 2 | AA | DD | | C |
| XJBSE40P12000 | 572 970 2568 | 1- 2 | AA | DD | N | C |
| XRESP30-06000 | 541 399 5002 | 3- 2 | AA | DD | | C |
| XRESP40-05000 | 572 399 0053 | 7- 34 | AA | DD | | C |
| XRESP40-06000 | 509 399 5001 | 11- 9 | AA | DD | | C |
| " | 509 399 5001 | 12- 12 | AA | DD | | C |
| " | 509 399 5001 | 14- 21 | AA | DD | | C |
| " | 509 399 5001 | 15- 20 | AA | DD | | C |
| " | 509 399 5001 | 19- 6 | AA | DD | | C |
| " | 509 399 5001 | 20- 20 | AA | DD | | C |
| " | 509 399 5001 | 21- 16 | AA | DD | | C |
| " | 509 399 5001 | 28- 6 | AA | DD | | C |
| XRESP50-06000 | 572 399 0063 | 11- 10 | AA | DD | | C |
| " | 572 399 0063 | 12- 15 | AA | DD | | C |
| " | 572 399 0063 | 14- 8 | AA | DD | | C |
| " | 572 399 0063 | 15- 21 | AA | DD | | C |
| " | 572 399 0063 | 17- 40 | AA | DD | | C |
| " | 572 399 0063 | 19- 7 | AA | DD | | C |
| " | 572 399 0063 | 20- 32 | AA | DD | | C |
| " | 572 399 0063 | 25- 3 | AA | DD | | C |
| " | 572 399 0063 | 27- 18 | AA | DD | | C |
| " | 572 399 0063 | 28- 19 | AA | DD | | C |
| XRESP70-08000 | 571 399 0027 | 10- 31 | AA | DD | | C |
| " | 571 399 0027 | 12- 11 | AA | DD | | C |
| " | 571 399 0027 | 15- 4 | AA | DD | | C |
| " | 571 399 0027 | 16- 21 | AA | DD | | C |
| " | 571 399 0027 | 17- 9 | AA | DD | | C |
| " | 571 399 0027 | 18- 3 | AA | DD | | C |
| " | 571 399 0027 | 21- 2 | AA | DD | | C |
| " | 571 399 0027 | 24- 35 | AA | DD | | C |
| " | 571 399 0027 | 26- 7 | AA | DD | | C |
| " | 571 399 0027 | 27- 6 | AA | DD | | C |
| " | 571 399 0027 | 7- 14 | AA | DD | | C |
| XRESP80-08000 | 571 399 0029 | 23- 18 | AA | DD | | C |
| XWHSD30-05080 | 500 990 0026 | 24- 28 | AA | DD | | C |
| " | 500 990 0026 | 25- 20 | AA | DD | | C |
| XWHSD30-08100 | 505 990 5001 | 21- 11 | AA | DD | | C |
| XWHSD40-08100 | 541 990 0043 | 30- 21 | AA | DD | | C |
| XWHSE30-05080 | 572 990 0529 | 37- 44 | AA | DD | | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 【 0 】 | | | | | | |
| 0CW023100FZWS | 572 970 2545 | 42- 15 | AB | DJ | N | C |
| 〃 | 572 970 2545 | 47- 13 | AB | DJ | N | C |
| 0CW030040FZWS | 572 970 0889 | 43- 45 | AA | DD | | C |
| 〃 | 572 970 0889 | 47- 26 | AA | DD | | C |
| 0CW030060FZBP | 572 970 0946 | 45- 6 | AA | DD | | C |
| 0CW030060FZSW | 572 970 0951 | 41- 45 | AA | DD | | C |
| 〃 | 572 970 0951 | 47- 28 | AA | DD | | C |
| 0CW030060FZTP | 572 970 0952 | 41- 24 | AA | DD | | C |
| 〃 | 572 970 0952 | 43- 31 | AA | DD | | C |
| 〃 | 572 970 0952 | 44- 25 | AA | DD | | C |
| 〃 | 572 970 0952 | 47- 24 | AA | DD | | C |
| 0CW030060FZWS | 572 970 0953 | 39- 29 | AA | DD | | C |
| 〃 | 572 970 0953 | 41- 56 | AA | DD | | C |
| 〃 | 572 970 0953 | 45- 30 | AA | DD | | C |
| 〃 | 572 970 0953 | 47- 19 | AA | DD | | C |
| 0CW030080FNWS | 572 970 1975 | 41- 12 | AA | DJ | | C |
| 0CW030080FZBi | 572 970 1276 | 43- 14 | AA | DJ | | C |
| 0CW030080FZWS | 572 970 0960 | 41- 28 | AA | DD | | C |
| 〃 | 572 970 0960 | 42- 3 | AA | DD | | C |
| 〃 | 572 970 0960 | 45- 38 | AA | DD | | C |
| 0CW040060FNBB | 572 970 1625 | 41- 29 | AB | DJ | | C |
| 0CW040060FNBi | 572 970 0988 | 45- 22 | AA | DD | | C |
| 0CW040060FZBP | 572 970 1645 | 44- 35 | AB | DJ | | C |
| 0CW040060FZTP | 572 970 1002 | 46- 7 | AA | DD | | C |
| 〃 | 572 970 1002 | 47- 21 | AA | DD | | C |
| 0CW040060FZWS | 572 970 1003 | 44- 5 | AA | DD | | C |
| 0CW040080FNBi | 572 970 1209 | 39- 17 | AA | DD | | C |
| 〃 | 572 970 1209 | 45- 13 | AA | DD | | C |
| 0CW040080FZSW | 572 970 1211 | 46- 3 | AA | DD | | C |
| 0CW040080FZTP | 572 970 1023 | 39- 27 | AA | DD | | C |
| 〃 | 572 970 1023 | 42- 6 | AA | DD | | C |
| 0CW040080FZWS | 572 970 1024 | 42- 11 | AA | DD | | C |
| 〃 | 572 970 1024 | 46- 1 | AA | DD | | C |
| 0CW040100FNiT | 572 970 2547 | 39- 3 | AB | DJ | N | C |
| 0CW040120FZiT | 572 970 2548 | 47- 5 | AB | DJ | N | C |
| 0CW2078P023B/ | 572 970 1392 | 42- 31 | AC | DJ | | C |
| 〃 | 572 970 1392 | 45- 21 | AC | DJ | | C |
| 0CW2078P086B/ | 572 970 1216 | 43- 27 | AB | DD | | C |
| 〃 | 572 970 1216 | 45- 29 | AB | DD | | C |
| 0CW2078P652B/ | 572 203 1129 | 43- 37 | AE | DS | N | C |
| 0CW2129P188A/ | 572 208 0004 | 43- 32 | AD | DJ | N | C |
| 0CW2158P322A/ | 572 970 2549 | 39- 19 | AC | DJ | N | C |
| 0CW2164P142A/ | 572 214 1313 | 45- 2 | AE | DS | | C |
| 0CW2164P330A/ | 572 970 1544 | 41- 14 | AB | DJ | | C |
| 〃 | 572 970 1544 | 43- 12 | AB | DJ | | C |
| 0CW2164P340A/ | 572 970 1224 | 42- 5 | AA | DD | | C |
| 0CW2164P340A1 | 572 970 2569 | 47- 8 | AB | DJ | N | C |
| 0CW2166P034B/ | 572 317 0005 | 40- 37 | AC | DJ | | C |
| 0CW2185P357A/ | 572 970 2015 | 39- 14 | AA | DJ | | C |
| 〃 | 572 970 2015 | 41- 6 | AA | DJ | | C |
| 〃 | 572 970 2015 | 43- 49 | AA | DJ | | C |
| 〃 | 572 970 2015 | 44- 16 | AA | DJ | | C |
| 〃 | 572 970 2015 | 47- 9 | AA | DJ | | C |
| 0CW2198P305B/ | 572 273 0024 | 45- 35 | AH | DX | N | C |
| 0CW2198P374A/ | 572 990 0541 | 45- 14 | AC | DJ | N | C |
| 0CW2205P025A/ | 572 413 0782 | 45- 17 | AD | DJ | N | C |
| 0CW2205P147A/ | 572 258 4181 | 45- 16 | AG | DX | N | C |
| 0CW2205P351A/ | 572 287 2343 | 45- 19 | AU | EZ | N | C |
| 0CW2205P360A/ | 572 258 4077 | 45- 3 | AD | DJ | N | C |
| 0CW2214P044A/ | 572 345 3869 | 45- 15 | AF | DS | N | C |
| 0CW2214P116B/ | 572 200 1458 | 47- 1 | AE | DJ | N | C |
| 0CW2214P128B/ | 572 203 1130 | 39- 13 | AK | DX | N | C |
| 0CW2214P157B/ | 572 258 4078 | 45- 36 | AK | DX | N | C |
| 0CW2214P393A/ | 572 373 0143 | 47- 27 | AG | DX | N | C |
| 0CW2214P455C/ | 572 258 4079 | 41- 23 | AE | DS | N | C |
| 〃 | 572 258 4079 | 43- 13 | AE | DS | N | C |
| 0CW2214P520B/ | 572 214 2314 | 45- 28 | AU | EZ | N | C |
| 0CW2214P575A/ | 572 271 0835 | 45- 37 | BR | LP | N | A |
| 0CW2225P312A/ | 572 272 0807 | 40- 19 | AD | DJ | N | C |
| 0CW2240P835A/ | 572 568 0152 | 41- 27 | AT | EZ | N | B |
| 〃 | 572 568 0152 | 43- 25 | AT | EZ | N | B |
| 0CW2247P326A/ | 572 272 0808 | 41- 15 | AF | DS | N | C |
| 0CW2252P620C/ | 572 208 0005 | 40- 16 | AD | DJ | N | C |
| 〃 | 572 208 0005 | 41- 19 | AD | DJ | N | C |
| 〃 | 572 208 0005 | 43- 40 | AD | DJ | N | C |
| 0CW2254P058A/ | 572 248 1448 | 41- 43 | AE | DJ | N | C |
| 0CW2254P338A/ | 572 214 2315 | 41- 44 | AC | DJ | N | C |
| 0CW2254P494A/ | 572 970 2551 | 40- 2 | AB | DJ | N | C |
| 〃 | 572 970 2551 | 41- 22 | AB | DJ | N | C |
| 〃 | 572 970 2551 | 44- 19 | AB | DJ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 0CW2260P002A/ | 572 281 2303 | 40- 43 | AE | DJ | N | C |
| 0CW2260P457// | 572 403 5314 | 44- 40 | AP | EQ | N | C |
| 0CW2260P458// | 572 403 5315 | 44- 41 | AP | EQ | N | C |
| 0CW2261P023E// | 572 290 2877 | 40- 27 | AD | DJ | N | C |
| 0CW2261P055A/ | 572 284 0861 | 40- 25 | AC | DJ | N | C |
| 0CW2268K040B/ | 572 203 1131 | 41- 42 | AG | DX | N | C |
| 0CW2268K041A/ | 572 203 1132 | 41- 13 | AG | DX | N | C |
| 0CW2268K522A/ | 572 630 1110 | 44- 6 | BL | HL | N | B |
| 0CW2268P005A/ | 572 273 0025 | 44- 15 | AD | DJ | N | C |
| 0CW2268P056// | 572 240 0464 | 40- 11 | AE | DJ | N | C |
| 0CW2268P057// | 572 240 0465 | 40- 3 | AE | DJ | N | C |
| 0CW2268P059// | 572 284 0863 | 45- 18 | AE | DJ | N | C |
| 0CW2268P064// | 572 284 0864 | 42- 17 | AG | DX | N | C |
| 0CW2268P065// | 572 281 2304 | 42- 18 | AG | DX | N | C |
| 0CW2268P066// | 572 281 2305 | 42- 25 | AH | DX | N | C |
| 0CW2268P069// | 572 273 0026 | 46- 11 | AD | DJ | N | C |
| 0CW2268P071// | 572 273 0027 | 41- 8 | AE | DJ | N | C |
| 0CW2268P073// | 572 281 2306 | 41- 21 | AD | DJ | N | C |
| 0CW2268P076// | 572 217 0129 | 46- 12 | AD | DJ | N | C |
| 0CW2268P076B/ | 572 217 0129 | 47- 37 | AD | DJ | N | C |
| 0CW2268P076B/ | 572 217 0130 | 40- 51 | AD | DJ | N | C |
| 0CW2268P078// | 572 284 0865 | 43- 17 | AE | DS | N | C |
| 0CW2268P083// | 572 284 0866 | 42- 4 | AF | DS | N | C |
| 0CW2268P084// | 572 203 1133 | 39- 5 | AF | DS | N | C |
| 0CW2268P085// | 572 281 2307 | 39- 10 | AE | DJ | N | C |
| 0CW2268P110// | 572 505 0013 | 45- 25 | AH | DX | N | C |
| 0CW2268P145// | 572 258 4080 | 47- 23 | AG | DS | N | C |
| 0CW2268P146// | 572 231 0584 | 45- 31 | AP | EQ | N | C |
| 0CW2268P170// | 572 258 4081 | 39- 11 | AE | DS | N | C |
| 0CW2268P217// | 572 290 2878 | 42- 21 | AK | EB | N | C |
| 0CW2268P303// | 572 287 2344 | 41- 48 | BA | FX | N | C |
| 0CW2268P335// | 572 258 4082 | 42- 33 | AD | DJ | N | C |
| 0CW2268P336// | 572 403 5196 | 41- 47 | AD | DJ | N | C |
| 0CW2268P344// | 572 316 0417 | 42- 24 | AP | EQ | N | C |
| 0CW2268P352// | 572 258 4083 | 43- 16 | AD | DJ | N | C |
| 0CW2268P354// | 572 258 4084 | 41- 16 | AG | DX | N | C |
| 0CW2268P360// | 572 258 4085 | 44- 3 | AD | DJ | N | C |
| 0CW2268P401// | 572 345 3870 | 41- 50 | AG | DS | N | C |
| 0CW2268P402// | 572 345 3871 | 46- 2 | AK | DX | N | C |
| 0CW2269K001// | 572 505 0015 | 47- 22 | AH | DX | N | C |
| 0CW2269K008// | 572 505 0016 | 47- 31 | AK | EB | N | C |
| 0CW2269K011// | 572 505 0017 | 42- 32 | AH | DX | N | C |
| 0CW2269K012// | 572 505 0018 | 46- 10 | AG | DX | N | C |
| 0CW2269K013// | 572 505 0019 | 42- 8 | AU | EZ | N | C |
| 0CW2269K016// | 572 505 0020 | 44- 33 | AF | DS | N | C |
| 0CW2269K025F/ | 572 246 0439 | 47- 29 | BD | GJ | N | C |
| 0CW2269K026G/ | 572 246 0440 | 47- 17 | BD | GN | N | C |
| 0CW2269K032// | 572 685 2170 | 39- 12 | CB | TZ | N | E |
| 0CW2269K042B/ | 572 400 0819 | 41- 37 | AF | EQ | N | C |
| 0CW2269K047// | 572 110 1283 | 41- 9 | AR | EQ | N | B |
| 0CW2269K061// | 572 290 2879 | 40- 31 | AL | EB | N | C |
| 0CW2269K062B/ | 572 345 3982 | 40- 45 | AU | EZ | N | E |
| 0CW2269K064// | 572 226 0685 | 39-501 | BG | GT | N | D |
| 0CW2269K066// | 572 685 2171 | 39- 28 | BY | TF | N | D |
| 0CW2269K094C/ | 572 214 2348 | 41- 3 | AZ | FX | N | B |
| 0CW2269K202// | 572 684 3985 | 47- 3 | BZ | TF | N | E |
| 0CW2269K207// | 572 521 0236 | 39- 25 | AH | DX | N | E |
| 0CW2269K221// | 572 542 2223 | 48- 3 | AM | EG | N | C |
| 0CW2269K222B/ | 572 542 2315 | 48- 9 | AG | DX | N | C |
| 0CW2269K223B/ | 572 542 2316 | 48- 2 | AL | EB | N | C |
| 0CW2269K224// | 572 542 2226 | 48- 11 | AL | EB | N | C |
| 0CW2269K225B/ | 572 542 2317 | 48- 1 | AP | EQ | N | C |
| 0CW2269K230// | 572 542 2228 | 48- 6 | AK | EB | N | C |
| 0CW2269K231// | 572 542 2229 | 48- 10 | AK | DX | N | C |
| 0CW2269K232// | 572 542 2230 | 39- 15 | AY | FQ | N | B |
| 0CW2269K234B/ | 572 542 2318 | 48- 7 | AY | FQ | N | C |
| 0CW2269K240// | 572 573 2818 | 47- 4 | AX | FG | N | B |
| 0CW2269K241B/ | 572 630 1132 | 42- 12 | BL | HL | N | B |
| 0CW2269K242B/ | 572 630 1133 | 46- 4 | BM | HV | N | B |
| 0CW2269K243// | | 48- 8 | BL | HL | N | C |
| 0CW2269P001// | 572 210 1216 | 47- 2 | BP | LP | N | D |
| 0CW2269P002// | 572 110 1284 | 39- 23 | AX | FQ | N | C |
| 0CW2269P003// | 572 110 1285 | 39- 16 | BA | FX | N | C |
| 0CW2269P004// | 572 226 0686 | 39- 4 | BB | GD | N | C |
| 0CW2269P005// | 572 345 3873 | 44- 12 | AP | EQ | N | C |
| 0CW2269P006// | 572 110 1286 | 44- 8 | AW | FG | N | C |
| 0CW2269P007// | 572 110 1287 | 40- 13 | AZ | FQ | N | D |
| 0CW2269P009// | 572 110 1288 | 39- 18 | AP | EQ | N | C |
| 0CW2269P010// | 572 345 3874 | 41- 1 | AS | EQ | N | C |
| 0CW2269P011// | 572 345 3875 | 41- 2 | AQ | EQ | N | C |
| 0CW2269P012A/ | 572 345 3930 | 41- 55 | AM | EG | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 0CW2269P013// | 572 345 3931 | 43- 52 | AQ | EQ | N | C |
| 0CW2269P014C/ | 572 345 3983 | 43- 26 | AW | FG | N | C |
| 0CW2269P015// | 572 110 1289 | 43- 23 | AG | DS | N | C |
| 0CW2269P016// | 572 248 1449 | 43- 34 | AD | DJ | N | C |
| 0CW2269P017// | 572 248 1450 | 43- 10 | AE | DJ | N | C |
| 0CW2269P018// | 572 110 1290 | 44- 26 | AQ | EQ | N | C |
| 0CW2269P020// | 572 284 0867 | 47- 36 | AD | DJ | N | C |
| 0CW2269P022// | 572 214 2316 | 45- 24 | AF | DS | N | C |
| 0CW2269P025// | 572 214 2317 | 45- 5 | AG | DS | N | C |
| 0CW2269P026// | 572 214 2318 | 45- 23 | AF | DS | N | C |
| 0CW2269P029// | 572 214 2319 | 45- 4 | AG | DS | N | C |
| 0CW2269P038// | 572 214 2320 | 41- 46 | AE | DS | N | C |
| 0CW2269P052// | 572 230 0534 | 40- 18 | AD | DJ | N | C |
| 0CW2269P053// | 572 248 1451 | 40- 49 | AE | DS | N | C |
| 0CW2269P054D/ | 572 221 8356 | 40- 6 | AE | DS | N | C |
| 0CW2269P055// | 572 248 1452 | 42- 1 | AE | DS | N | C |
| 0CW2269P056// | 572 273 0028 | 42- 30 | AD | DJ | N | C |
| 0CW2269P057// | 572 284 0868 | 42- 23 | AE | DS | N | C |
| 0CW2269P059// | 572 248 1453 | 43- 39 | AE | DJ | N | C |
| 0CW2269P060// | 572 248 1454 | 44- 21 | AE | DJ | N | C |
| 0CW2269P061E/ | 572 240 0489 | 40- 30 | AG | DX | N | C |
| 0CW2269P062// | 572 240 0467 | 40- 36 | AN | EG | N | C |
| 0CW2269P065// | 572 110 1291 | 41- 4 | AE | DS | N | C |
| 0CW2269P066// | 572 214 2321 | 41- 7 | AF | DS | N | C |
| 0CW2269P068// | 572 345 3877 | 39- 1 | AK | DX | N | C |
| 0CW2269P069// | 572 345 3878 | 39- 6 | AK | DX | N | C |
| 0CW2269P071D/ | 572 110 1308 | 40- 50 | AH | DX | N | C |
| 0CW2269P077// | 572 248 1455 | 39- 7 | AL | EB | N | C |
| 0CW2269P099A/ | 572 284 0875 | 45- 9 | AD | DJ | N | C |
| 0CW2269P104// | 572 203 1134 | 44- 18 | AF | DS | N | C |
| 0CW2269P105// | 572 427 1661 | 43- 21 | AH | DX | N | C |
| 0CW2269P106// | 572 427 1662 | 43- 22 | AF | DS | N | C |
| 0CW2269P107// | 572 203 1135 | 43- 33 | AK | DX | N | C |
| 0CW2269P108// | 572 203 1136 | 47- 15 | AH | DX | N | C |
| 0CW2269P109// | 572 345 3879 | 41- 33 | AT | EZ | N | C |
| 0CW2269P110// | 572 203 1137 | 44- 24 | AP | EQ | N | C |
| 0CW2269P111// | 572 203 1138 | 44- 2 | AN | EG | N | C |
| 0CW2269P112// | 572 203 1139 | 44- 20 | AF | DS | N | C |
| 0CW2269P114// | 572 203 1140 | 46- 8 | AQ | EQ | N | C |
| 0CW2269P115// | 572 203 1141 | 41- 30 | AL | EB | N | C |
| 0CW2269P116// | 572 203 1142 | 47- 25 | AH | DX | N | C |
| 0CW2269P119// | 572 221 8106 | 45- 12 | AQ | EQ | N | C |
| 0CW2269P120// | 572 221 8107 | 45- 11 | AP | EQ | N | C |
| 0CW2269P123// | 572 203 1143 | 45- 20 | AH | DX | N | C |
| 0CW2269P128// | 572 258 4086 | 44- 14 | AE | DS | N | C |
| 0CW2269P132// | 572 203 1144 | 40- 12 | AE | DS | N | C |
| 0CW2269P133// | 572 203 1145 | 40- 1 | AG | DX | N | C |
| 0CW2269P139// | 572 203 1146 | 40- 8 | AE | DS | N | C |
| 0CW2269P142// | 572 203 1147 | 43- 44 | AF | DS | N | C |
| 0CW2269P145// | 572 231 0585 | 47- 40 | AW | FG | N | C |
| 0CW2269P146// | 572 231 0586 | 47- 14 | AN | EG | N | C |
| 0CW2269P147// | 572 248 1456 | 47- 18 | AF | DS | N | C |
| 0CW2269P149// | 572 203 1148 | 41- 31 | AE | DJ | N | C |
| 0CW2269P159// | 572 203 1149 | 47- 10 | AF | DS | N | C |
| 0CW2269P160A/ | 572 505 0021 | 44- 4 | AG | DX | N | C |
| 0CW2269P171// | 572 258 4087 | 42- 13 | AL | EB | N | C |
| 0CW2269P172// | 572 258 4088 | 47- 11 | AK | DX | N | C |
| 0CW2269P176// | 572 258 4090 | 45- 33 | AE | DS | N | C |
| 0CW2269P206// | 572 290 2880 | 40- 29 | AQ | EQ | N | C |
| 0CW2269P207// | 572 290 2881 | 43- 35 | AF | DS | N | C |
| 0CW2269P211// | 572 290 2882 | 44- 28 | AG | DX | N | C |
| 0CW2269P221// | 572 290 2883 | 47- 34 | AH | DX | N | C |
| 0CW2269P300// | 572 287 2345 | 40- 23 | AN | EQ | N | B |
| 0CW2269P301// | 572 287 2346 | 40- 14 | AV | FG | N | B |
| 0CW2269P303// | 572 277 0119 | 44- 17 | AY | FQ | N | C |
| 0CW2269P304// | 572 403 5197 | 43- 24 | AD | DJ | N | C |
| 0CW2269P305// | 572 310 0360 | 44- 7 | AQ | EQ | N | C |
| 0CW2269P306// | 572 310 0361 | 43- 2 | AQ | EQ | N | C |
| 0CW2269P307// | 572 403 5198 | 44- 32 | AN | EQ | N | C |
| 0CW2269P308// | 572 258 4092 | 43- 41 | AD | DJ | N | C |
| 0CW2269P309// | 572 258 4093 | 44- 27 | AC | DJ | N | C |
| 0CW2269P311// | 572 326 0498 | 41- 11 | AG | DX | N | B |
| 0CW2269P315// | 572 258 4094 | 41- 41 | AD | DJ | N | C |
| 0CW2269P316// | 572 316 0418 | 40- 28 | AH | DX | N | C |
| 0CW2269P318// | 572 316 0419 | 40- 42 | AH | DX | N | C |
| 0CW2269P320// | 572 326 0499 | 41- 10 | AE | DS | N | B |
| 0CW2269P324// | 572 400 0806 | 41- 25 | AE | DS | N | C |
| 0CW2269P326// | 572 287 2347 | 45- 27 | AZ | FQ | N | C |
| 0CW2269P327// | 572 287 2348 | 45- 1 | BA | FX | N | C |
| 0CW2269P331// | 572 310 0362 | 41- 39 | AT | EZ | N | C |
| 0CW2269P332// | 572 310 0363 | 41- 35 | AR | EQ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|---------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 0CW2269P333// | 572 287 2349 | 43- 19 | BB | GD | N | B |
| 0CW2269P334// | 572 287 2350 | 41- 26 | AY | FQ | N | B |
| 0CW2269P335// | 572 403 5199 | 44- 13 | AD | DJ | N | C |
| 0CW2269P336// | 572 403 5200 | 43- 4 | AG | DX | N | C |
| 0CW2269P337// | 572 403 5201 | 44- 31 | AE | DJ | N | C |
| 0CW2269P338// | 572 403 5202 | 44- 11 | AD | DJ | N | C |
| 0CW2269P339// | 572 326 0500 | 43- 47 | AD | DJ | N | C |
| 0CW2269P340// | 572 403 5203 | 43- 28 | AF | DS | N | C |
| 0CW2269P341B/ | 572 403 5277 | 40- 21 | AF | DS | N | C |
| 0CW2269P343// | 572 287 2351 | 45- 7 | AZ | FQ | N | C |
| 0CW2269P344D/ | 572 403 5316 | 40- 48 | AG | DS | N | C |
| 0CW2269P349B/ | 572 258 4191 | 41- 5 | AD | DJ | N | C |
| 0CW2269P350// | 572 326 0501 | 40- 7 | AD | DJ | N | C |
| 0CW2269P351// | 572 326 0502 | 44- 30 | AC | DJ | N | C |
| 0CW2269P354// | 572 326 0503 | 43- 1 | AL | EB | N | C |
| 0CW2269P355A/ | 572 326 0516 | 40- 52 | AH | DX | N | C |
| 0CW2269P356A/ | 572 326 0517 | 40- 53 | AF | DS | N | C |
| 0CW2269P357// | 572 287 2352 | 44- 29 | AG | DX | N | C |
| 0CW2269P358// | 572 403 5206 | 43- 30 | AD | DJ | N | C |
| 0CW2269P359// | 572 403 5207 | 43- 29 | AN | EG | N | C |
| 0CW2269P361// | 572 399 0253 | 40- 15 | AD | DJ | N | C |
| 0CW2269P362// | 572 326 0504 | 40- 5 | AD | DJ | N | C |
| 0CW2269P363// | 572 258 4096 | 46- 5 | AD | DJ | N | C |
| 0CW2269P364// | 572 326 0505 | 40- 10 | AF | DS | N | C |
| 0CW2269P365// | 572 326 0506 | 39- 20 | AV | FG | N | C |
| 0CW2269P366// | 572 326 0507 | 39- 21 | AS | EQ | N | C |
| 0CW2269P368// | 572 326 0508 | 40- 4 | AF | DS | N | C |
| " | 572 326 0508 | 44- 10 | AF | DS | N | C |
| 0CW2269P369// | 572 326 0509 | 44- 9 | AE | DS | N | C |
| 0CW2269P381// | 572 917 3675 | 39- 24 | AL | EB | N | C |
| 0CW2269P382// | 572 326 0510 | 45- 26 | AD | DJ | N | C |
| 0CW2269P389// | 572 326 0511 | 43- 50 | AD | DJ | N | C |
| 0CW2269P393A1 | 572 373 0146 | 47- 38 | AG | DX | N | C |
| 0CW2269P399A/ | 572 403 5266 | 44- 37 | AE | DS | N | C |
| 0CW2269P440// | 572 647 0402 | 43- 51 | AT | EZ | N | C |
| 0CW2269P451A/ | 572 403 5267 | 41- 52 | AF | DS | N | C |
| 0CW2269P453A/ | 572 403 5268 | 41- 53 | AE | DJ | N | C |
| 0CW2269P455A/ | 572 403 5269 | 41- 54 | AQ | EQ | N | C |
| 0CW2269P459// | 572 403 5317 | 40- 60 | AG | DS | N | C |
| 0CW2269P460// | 572 403 5318 | 40- 61 | AE | DS | N | C |
| 0CW3085P334A/ | 572 970 2552 | 43- 20 | AC | DJ | N | C |
| " | 572 970 2552 | 44- 34 | AC | DJ | N | C |
| 0CW4048P300A/ | 572 970 2553 | 44- 1 | AC | DJ | N | C |
| 0CW4054P143B1 | 572 970 2577 | 47- 16 | AB | DJ | N | C |
| 0CW4054P220D/ | 572 970 1731 | 39- 26 | AB | DJ | | C |
| " | 572 970 1731 | 46- 9 | AB | DJ | | C |
| 0CW4062Q304B/ | 572 970 2555 | 43- 11 | AC | DJ | N | C |
| 0CW660580//// | 572 980 0091 | 39- 9 | AA | DD | | C |
| 0CWE120001648 | 572 530 0715 | 42- 14 | AP | EQ | N | B |
| " | 572 530 0715 | 47- 12 | AP | EQ | N | B |
| 0CWE314000619 | 572 568 0058 | 39- 8 | AH | DX | | B |
| " | 572 568 0058 | 41- 32 | AH | DX | | B |
| " | 572 568 0058 | 42- 2 | AH | DX | | B |
| " | 572 568 0058 | 43- 9 | AH | DX | | B |
| 0CWE450000070 | 572 201 0104 | 47- 6 | AB | DJ | | C |
| 0CWE450001128 | 572 201 0169 | 43- 8 | AC | DJ | | C |
| 0CWE450001139 | 572 399 0252 | 43- 6 | AC | DJ | N | C |
| " | 572 399 0252 | 47- 7 | AC | DJ | N | C |
| 0CWER040SKP// | 572 399 0086 | 40- 33 | AB | DD | | C |
| " | 572 399 0086 | 44- 22 | AB | DD | | C |
| 0CWER050SKP// | 572 399 0089 | 40- 20 | AA | DD | | C |
| " | 572 399 0089 | 41- 17 | AA | DD | | C |
| " | 572 399 0089 | 42- 20 | AA | DD | | C |
| " | 572 399 0089 | 43- 18 | AA | DD | | C |
| " | 572 399 0089 | 46- 13 | AA | DD | | C |
| " | 572 399 0089 | 47- 32 | AA | DD | | C |
| 0CWER070SKP// | 572 399 0101 | 41- 20 | AA | DD | | C |
| " | 572 399 0101 | 42- 19 | AA | DD | | C |
| " | 572 399 0101 | 43- 38 | AA | DD | | C |
| " | 572 399 0101 | 45- 10 | AA | DD | | C |
| 0CWHPO2010SCH | 572 218 0634 | 40- 26 | AC | DJ | N | C |
| " | 572 218 0634 | 42- 26 | AC | DJ | N | C |
| 0CWNSBLT00056 | 572 271 0623 | 40- 24 | AN | EG | | C |
| 0CWNSBLT00277 | 572 271 0834 | 42- 22 | AP | EQ | N | C |
| 0CWNSBLT00278 | 572 271 0862 | 44- 36 | AL | EB | N | C |
| 0CWNSBLT00281 | 572 271 0863 | 47- 41 | AQ | EQ | N | C |
| 0CWNSBLT00282 | 572 271 0864 | 47- 35 | AR | EQ | N | C |
| 0CWNSBRG00016 | 572 272 0626 | 42- 9 | AT | EZ | | C |
| " | 572 272 0626 | 47- 33 | AT | EZ | | C |
| 0CWNSBRG00019 | 572 272 0806 | 41- 18 | AQ | EQ | N | C |
| " | 572 272 0806 | 43- 15 | AQ | EQ | N | C |

| PARTS CODE | JAPAN ONLY ORDER CODE | NO. | PRICE R. | | NEW | P/R |
|----------------|--------------------------|--------|----------|-----|-----|-----|
| | | | Ex. | Ja. | | |
| 0CWNSBRG00019 | 572 272 0806 | 45- 8 | AQ | EQ | N | C |
| 0CWNPW080025// | 572 256 0185 | 41- 40 | AB | DJ | N | C |
| 0FT23040224// | 572 200 1334 | 57- 1 | AD | DJ | | C |
| 0FT23042251// | 572 397 0182 | 57- 2 | AP | EQ | | C |
| 0FT23075095// | 572 512 0394 | 57- 3 | AP | EQ | | C |
| 0FT23095657// | 572 576 0569 | 57- 96 | AF | DS | | B |
| " | 572 576 0569 | 57- 97 | AF | DS | | B |
| " | 572 576 0569 | 57- 98 | AF | DS | | B |
| " | 572 576 0569 | 57- 99 | AF | DS | | B |
| 0FT23124819// | 572 594 0890 | 57-100 | AK | DX | | C |
| 0FT23124827// | 572 594 0891 | 57-101 | AF | DS | | C |
| 0FT23194310// | 572 575 0159 | 57- 4 | AU | EZ | | B |
| 0FT23204782// | 572 594 0893 | 57-102 | AP | EQ | | C |
| 0FT23204790// | 572 594 0894 | 57-103 | AP | EQ | | C |
| " | 572 594 0894 | 57-104 | AP | EQ | | C |
| 0FT23241823// | 572 590 0053 | 57-105 | AP | EQ | | B |
| 0FT23259382// | 572 594 0895 | 57-106 | AP | EQ | | C |
| 0FT23259420// | 572 594 0896 | 57-107 | AP | EQ | | C |
| 0FT23259447// | 572 594 0897 | 57-108 | AK | DX | | C |
| 0FT23259498// | 572 594 0898 | 57-109 | AK | DX | | C |
| " | 572 594 0898 | 57-110 | AK | DX | | C |
| " | 572 594 0898 | 57-111 | AK | DX | | C |
| 0FT23287629// | 572 576 0570 | 57-112 | AK | DX | | B |
| 0FT23287637// | 572 576 0571 | 57-113 | AP | EQ | | B |
| 0FT23287696// | 572 576 0580 | 57-114 | AP | EQ | | B |
| 0FT23287823// | 572 594 0900 | 57-115 | AK | DX | | C |
| 0FT23314081// | 572 573 2389 | 57- 5 | AU | EZ | | B |
| 0FT23319431// | 572 570 0525 | 57-116 | AF | DS | | B |
| " | 572 570 0525 | 57-117 | AF | DS | | B |
| 0FT23326101// | 572 594 0901 | 57-118 | AU | EZ | | C |
| 0FT23329089// | 572 594 0902 | 57-119 | AK | DX | | C |
| " | 572 594 0902 | 57-120 | AK | DX | | C |
| 0FT23379450// | 572 573 2390 | 57-121 | AU | EZ | | B |
| " | 572 573 2390 | 57-122 | AU | EZ | | B |
| 0FT23394395// | 572 594 0903 | 57-123 | AU | EZ | | C |
| 0FT23414892// | 572 581 1976 | 57-124 | AF | DS | | C |
| 0FT23415341// | 572 581 1979 | 57-125 | AF | DS | | C |
| 0FT23415430// | 572 581 1982 | 57-126 | AF | DS | | C |
| 0FT23415570// | 572 581 1984 | 57-127 | AF | DS | | C |
| " | 572 581 1984 | 57-128 | AF | DS | | C |
| " | 572 581 1984 | 57-129 | AF | DS | | C |
| 0FT23415600// | 572 581 1985 | 57-130 | AF | DS | | C |
| 0FT23415643// | 572 581 1988 | 57-131 | AF | DS | | C |
| 0FT23415651// | 572 581 1989 | 57-132 | AF | DS | | C |
| 0FT23415716// | 572 581 1992 | 57-133 | AF | DS | | C |
| 0FT23415740// | 572 581 1994 | 57-134 | AF | DS | | C |
| 0FT23415899// | 572 581 1996 | 57-135 | AF | DS | | C |
| 0FT23423816// | 572 990 0439 | 57- 7 | AC | DJ | | C |
| 0FT23429199// | 572 570 0526 | 57-136 | AK | DX | | B |
| 0FT23432963// | 572 990 0440 | 57- 8 | AC | DJ | | C |
| 0FT23462226// | 572 581 1999 | 57- 33 | AD | DJ | | C |
| " | 572 581 1999 | 57- 34 | AD | DJ | | C |
| 0FT23462234// | 572 581 2001 | 57- 35 | AD | DJ | | C |
| " | 572 581 2001 | 57- 36 | AD | DJ | | C |
| " | 572 581 2001 | 57- 37 | AD | DJ | | C |
| " | 572 581 2001 | 57- 38 | AD | DJ | | C |
| 0FT23462250// | 572 581 2002 | 57- 39 | AD | DJ | | C |
| " | 572 581 2002 | 57- 40 | AD | DJ | | C |
| " | 572 581 2002 | 57- 41 | AD | DJ | | C |
| " | 572 581 2002 | 57- 42 | AD | DJ | | C |
| " | 572 581 2002 | 57- 43 | AD | DJ | | C |
| 0FT23462269// | 572 581 2003 | 57- 44 | AD | DJ | | C |
| " | 572 581 2003 | 57- 45 | AD | DJ | | C |
| " | 572 581 2003 | 57- 46 | AD | DJ | | C |
| 0FT23462293// | 572 581 2004 | 57- 47 | AD | DJ | | C |
| 0FT23463362// | 572 581 2005 | 57- 48 | AD | DJ | | C |
| 0FT23484661// | 572 581 2060 | 57-137 | AD | DJ | | C |
| 0FT23485706// | 572 512 0396 | 57- 9 | AK | DX | | C |
| 0FT23486796// | 572 594 0904 | 57-138 | AK | DX | | C |
| 0FT23486850// | 572 594 0905 | 57-139 | AK | DX | | C |
| " | 572 594 0905 | 57-140 | AK | DX | | C |
| 0FT23536106// | 572 581 2006 | 57- 49 | AD | DJ | | C |
| " | 572 581 2006 | 57- 50 | AD | DJ | | C |
| " | 572 581 2006 | 57- 51 | AD | DJ | | C |
| 0FT23538850// | 572 581 2009 | 57- 52 | AD | DJ | | C |
| " | 572 581 2009 | 57- 53 | AD | DJ | | C |
| 0FT23538885// | 572 581 2010 | 57- 54 | AD | DJ | | C |
| 0FT23538915// | 572 581 2011 | 57- 55 | AD | DJ | | C |
| 0FT23538923// | 572 581 2012 | 57- 56 | AD | DJ | | C |
| 0FT23538974// | 572 581 2013 | 57- 57 | AD | DJ | | C |
| 0FT23538982// | 572 581 2014 | 57- 58 | AD | DJ | | C |

注意

- 電池を正しく交換しないと爆発を起こす危険がある。
- 機器製造者が指定したものと同一型名のもの、又は、その同等の電池とのみ交換すること。
- 使用済みの電池は、製造者の指示に従って処分すること。

CAUTION FOR BATTERY REPLACEMENT

- (Danish) ADVARSEL !
Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Levér det brugte batteri tilbage til leverandoren.
- (English) Caution !
Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the manufacturer.
Dispose of used batteries according to manufacturer's instructions.
- (Finnish) VAROITUS
Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan
tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden
mukaisesti.
- (French) ATTENTION
Il y a danger d'explosion s'il y a remplacement incorrect
de la batterie. Remplacer uniquement avec une batterie du
même type ou d'un type équivalent recommandé par
le constructeur.
Mettre au rebut les batteries usagées conformément aux
instructions du fabricant.
- (Swedish) VARNING
Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparatillverkaren.
Kassera använt batteri enligt fabrikantens
Instruktion.
- (German) Achtung
Explosionsgefahr bei Verwendung inkorrektter Batterien.
Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder
vom Hersteller empfohlene Batterien verwendet werden.
Entsorgung der gebrauchten Batterien nur nach den vom
Hersteller angegebenen Anweisungen.

CAUTION FOR BATTERY DISPOSAL

- (For USA,CANADA)
Contains lithium-ion battery. Must be disposed of properly.
Remove the battery from the product and contact
federal or state environmental
agencies for information on recycling and disposal options.

SHARP

COPYRIGHT © 2003 BY SHARP CORPORATION

All rights reserved.

Printed in Japan.

No part of this publication may be reproduced,
stored in a retrieval system, or transmitted.

In any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

SHARP CORPORATION
Digital Document Systems Group
Products Quality Assurance Department
Yamatokoriyama, Nara 639-1186, Japan

2003 March Printed in Japan ⓘ